

how to get start:

install

1>run USB2SPI_R2_Setup.exe to install applications

2>run M3F20xm_drv_R2_for_(x86/amd64).exe to install m3f20xm device driver

3>run DfuSe_Demo_V3.0.3_(x86/amd64).exe to install DFU device driver

use

1>click start menu->ONYIB->USB2SPI->USB2SPI to start usb2spi applications

3>click start menu->ONYIB->USB2SPI->update to replace firmware

refer

1>click start menu->ONYIB->USB2SPI->USER manual

2>click start menu->ONYIB->USB2SPI->library manual