

**MEDIATEK**

*everyday genius*

## Thermal bring up SOP

Version: 1.0  
Release date: 2019-03-21

© 2015 - 2019 MediaTek Inc.

This document contains information that is proprietary to MediaTek Inc. ("MediaTek") and/or its licensor(s). MediaTek cannot grant you permission for any material that is owned by third parties. You may only use or reproduce this document if you have agreed to and been bound by the applicable license agreement with MediaTek ("License Agreement") and been granted explicit permission within the License Agreement ("Permitted User"). If you are not a Permitted User, please cease any access or use of this document immediately. Any unauthorized use, reproduction or disclosure of this document in whole or in part is strictly prohibited. THIS DOCUMENT IS PROVIDED ON AN "AS-IS" BASIS ONLY. MEDIATEK EXPRESSLY DISCLAIMS ANY AND ALL WARRANTIES OF ANY KIND AND SHALL IN NO EVENT BE LIABLE FOR ANY CLAIMS RELATING TO OR ARISING OUT OF THIS DOCUMENT OR ANY USE OR INABILITY TO USE THEREOF. Specifications contained herein are subject to change without notice.

Specifications are subject to change without notice.

## Document Revision History

---

Revision	Date	Description
1.0	2019-03-13	Initial Draft

## Table of Contents

<b>Document Revision History</b>	<b>3</b>
<b>Table of Contents</b>	<b>4</b>
<b>1. Introduction</b>	<b>5</b>
1.1 Purpose	5
1.2 Definitions, Acronyms and Abbreviations	5
1.3 References	5
1.4 Overview	5
<b>2. Specific Contents</b>	<b>6</b>
2.1 Thermal architecture overflow	6
<b>3 Notification</b>	<b>7</b>
3.1 What case would trigger reboot/shutdown	7
3.2 How to avoid	7

## 1. Introduction

---

This document is about MT8183 thermal software configuration.

### 1.1 Purpose

This document is for customer to configure and use thermal in MT8183 Project.

### 1.2 Definitions, Acronyms and Abbreviations

- bts: board thermal sensor
  - It is thermal sensor mount on PCB board.

### 1.3 References

No

### 1.4 Overview

Sections overview. Such as:

Section 1 is the introduction and includes a description of the project.


Section 2 provides a system overview.

Section 3 describes what case would trigger reboot/shutdown.

## 2. Specific Contents

Thermal zone bind cooler by Linux thermal framework. Once temperature over trip point, corresponding cooler mechanism will be activated.

### 2.1 Thermal architecture overflow



### 3 Notification

Thermal projecting function might trigger reboot/shutdown

#### 3.1 What case would trigger reboot/shutdown

- NTC register table does not match with source code.
- AUXADC channel is not right one with source code.

#### 3.2 How to avoid

- Return 0 degree of board sensor as workaround

```
diff --git a/drivers/misc/mediatek/thermal/common/thermal_zones/mtk_ts_bts.c b/d
rivers/misc/mediatek/thermal/common/thermal_zones/mtk_ts_bts.c
index ed58012..c8fb9df 100644
--- a/drivers/misc/mediatek/thermal/common/thermal_zones/mtk_ts_bts.c
+++ b/drivers/misc/mediatek/thermal/common/thermal_zones/mtk_ts_bts.c
@@ -618,6 +618,8 @@ int mtkts_bts_get_hw_temp(void)
     t_ret = get_hw_bts_temp();
     t_ret = t_ret * 1000;

+    t_ret = 0;
+
     mutex_unlock(&BTS_lock);
```