

MEDIATEK

INTERNAL USE

MT8183 O1 Bring up SOP Audio



Glossary (名词解释/名詞解釋)

- Receiver (Earpiece)
 - 听筒
 - 聽筒
- \$(proj)
 - Your company's project
 - Such as MTK's turnkey solution, tb8183m1_64_bsp is \$(proj)
 - 贵司的project
 - 如MTK的turnkey, tb8183m1_64_bsp即为\$(proj)
 - 貴司的project
 - 如MTK的turnkey, tb8183m1_64_bsp即為\$(proj)



Receiver

- 是否有Receiver (听筒)元件？
- 目前tablet部份, 默认没有earpiece这项硬件元件，因此造成一些CTS, factory mode使用上的误解及不便，客户可以在device/mediatek/ic -name/下进行客制化，方便开关此feature
- 具体的路径： device/mediatek/**folder**/audio_policy_config/audio_policy_configuration.xml

if there is no Earpiece in the project, remove the sections of earpiece port and route from audio policy config

```
<devicePort tagName="Earpiece" type="AUDIO_DEVICE_OUT_EARPIECE" role="sink"> ...  
</devicePort>  
<route type="mix" sink="Earpiece" ... />
```

Digital Microphone

- 若贵司的Main_MIC (PMIC) 是接到DMIC的话, 请开启 Digital MIC configuration



@/alps/device/mediatek/ \$(proj)/ ProjectConfig.mk

MTK_DIGITAL_MIC_SUPPORT = yes

注意：


Digital Mic. support $F_s \leq 32k$

Analog Mic. support $F_s \leq 48k$



Dual Microphone

- 当平台使用到2个麦克风时, 要打开Dual Mic configuration
[@/alps/device/mediatek/ \\$\(proj\)/ ProjectConfig.mk](#)
`MTK_DUAL_MIC_SUPPORT = yes`
- Main Mic.接AIN0, Ref Mic.接AIN2



- 如需要使用 MTK的Dual Mic Noise Reduction (DMNR), 必须 follow MTK design guide
 - Visit DCC: 2-mic NR ME design note_tablet_rev1.pptx

When SPK use External AMP from HP

- 当使用外接功放来推喇叭时，需注意以下几件事
 - 请定义 `#define USING_EXTAMP_HP` (下列的Header)
`alps/vendor/mediatek/proprietary/custom/$(proj)/hal/audioflinger/audio/audio_custom_exp.h`
 - 若没有使用到 External AMP, 请务必把这个 define 关掉

当平台有2个Speaker

- 在以下path加入以下的宏

alps/vendor/mediatek/proprietary/custom/ \$(proj)/ hal/audioflinger/audio audio_custom_exp.h

- **#define ENABLE_STEREO_SPEAKER**

MEDIATEK

everyday genius