


- Meter should indicate zero (continuity).
- Turn operating lever in direction of arrow **7** [4].
- Ohmmeter should indicate infinity just before lever contacts stop **7** [5].
- Ensure a gap of 0,5-0,7 mm **7** [3] exists between operating lever and stop.
- If necessary, adjust position of plate **7** [1] until specified gap obtained.

**NOTE:** In idle position, operating lever must touch idle switch plate **7** [1].

## Adjusting full throttle switch - **6** & **8**

- Disconnect multi-plug from throttle body.
- Connect ohmmeter between switch terminals 2 & 3 **6**.
- Meter should indicate infinity.
- Position 4,5 mm drill between throttle lever and full throttle stop **8** [1].
- Meter should still indicate infinity.
- Repeat with 3,5 mm drill.
- Meter should indicate zero ohms (continuity).
- If adjustment necessary, remove throttle body cover plate **8** [3].
- Clamp 3,5 mm drill between throttle lever and full throttle stop **8** [1].
- Slacken full throttle switch screws and adjust switch **8** [2] until correct position obtained.
- Tighten switch screws and replace throttle body cover plate.




## 2.3 Coolant temperature sensor

Self-diagnosis code: 2312

Technical Data	
Temperature - °C	Resistance - ohms
0	3750
20	2500
40	1250
60	600
80	325
100	200

### Checking - **9**

- Disconnect temperature sensor multi-plug.
- Check coolant temperature.
- Connect ohmmeter across sensor terminals.
- Compare resistance indicated with that specified.




## 2.4 Intake air temperature sensor

Self-diagnosis code: 2322

Technical Data	
Temperature - °C	Resistance - ohms
0	3750
20	2500
40	1250
60	600
80	325

### Checking - **10**

- Disconnect CO potentiometer multi-plug.
- Connect ohmmeter between terminals 2 & 3 of potentiometer.
- Check ambient temperature with thermometer.
- Compare resistance indicated with that specified.



## 2.5 Auxiliary air valve

### Preparatory conditions


- Engine coolant temperature less than 30°C.
- Idle speed as specified.
- No air leaks in air intake system.

### Checking operation

- Start engine and allow to idle.
- Disconnect throttle switch multi-plug from throttle body.
- Pinch hose between air valve and air intake elbow.
- Engine speed should decrease.
- Run engine until it reaches normal operating temperature (at least 80°C).
- Pinch hose between air valve and air intake elbow.
- Engine speed should not change.

### Checking voltage supply - **11**

- Disconnect coil HT lead (at distributor), and earth it.
- Disconnect air valve multi-plug.
- Connect voltmeter across terminals 3 and 4 of harness multi-plug **11**.
- Crank engine with starter.
- Minimum 9 volts should be indicated.
- Connect ohmmeter across contacts 3 and 4 of air valve.
- Meter should indicate zero (continuity).
- Reconnect HT lead.



## 2.6 Injector valves

Technical Data	
Resistance between connector terminals 1 & 2	3,7-5,0 ohms
Resistance between injector valve terminals	15-20 ohms

### Checking resistance - **12** & **13**

- Disconnect multi-plug connector from injector rail.
- Connect LED tester across multi-plug harness side terminals 1 and 2 **12** [A].
- Crank engine with starter.
- LED tester should flicker.
- Connect ohmmeter across injector

