



wire_8: Power supply positive
 wire_7: Power supply negative
 wire_6: Start/Stop with emergency stop
 wire_5: PWM speed control signal (Connect to negative for high-speed operation)
 wire_4: Rotation direction control (forward/reverse) (Connect to negative terminal to switch direction)
 wire_3: Encoder power supply (5V)
 wire_2: Encoder signal A
 wire_1: Encoder signal B
 wire_0