

Data Reading

Data Reading

1. Quick Start
2. Hardware Wiring
3. Usage Method
4. Phenomenon and Results
5. Code Explanation


1. Quick Start

This tutorial explains how to use the ESP32-S3 motherboard to read the digital information from an eight-channel grayscale line-following module and print the results via a serial port assistant.

The hardware used in this tutorial is the ESP32-S3 WIFI image transmission module lite and the eight-channel grayscale line-following module sold by Yabo. After connecting the wires according to the wiring diagram below, you can obtain the data by programming the ESP32-S3. Modules other than Yabo's are for reference only.

2. Hardware Wiring

The ESP32-S3's USB port needs to be connected to the computer's USB port using a data cable.



The eight-channel grayscale module sold by Yabo uses XH2.54 to 6-pin DuPont cable for connection:




Eight-channel grayscale line-following module	ESP32-S3
5V	5V
GND	GND
AD0	RX1(35)
AD1	TX1(36)
AD2	SCL(37)
OUT	SDA(38)


The serial port and IIC identifiers here are merely labels used on the ESP32 module board; the serial port and IIC functions are not actually used.

3. Usage Method

1. Open the programming tool `flash_download_tool`, select the ESP32-S3 chip, and then click OK.



2. Connect the ESP32-S3 to the computer via a data cable, and then select the COM port and baud rate in the software.



- In the **SPIDownload** window, select three ESP32S3 firmware files to be burned. The path is usually in the **build** folder under the root directory of the code project. The format is a .bin file. Remember to enter the firmware address. Make sure the box to the left of ".bin file" is checked, and both the file name and address are green.

Check "DoNotChgBin". Leave other configurations as default.


The screenshot shows two windows from a firmware flashing tool. The top window, titled "SPIDownload", contains a list of files to be burned. Three files are selected with checkboxes: "e_Read\build\bootloader\bootloader.bin" at address "0x0", "d\build\partition_table\partition-table.bin" at address "0x8000", and "irayscale_Read\build\Grayscale_Read.bin" at address "0x10000". The bottom window, titled "SPIFlashConfig", contains configuration options. Under "SPI SPEED", "80MHz" is selected. Under "SPI MODE", "DIO" is selected. The "DoNotChgBin" checkbox is checked. The "DetectedInfo" section displays: "flash vendor: 5Eh : ZB", "flash devID: 4016h", "QUAD;4MB", and "crystal: 40 Mhz".

The file and address mapping is shown in the table below:


Firmware Name	Firmware Address	Remarks
bootloader.bin	0x0000	Boot file
partition-table.bin	0x8000	Partition table file
Grayscale_Read.bin	0x10000	Function file

- Click the **START** button, and the tool will automatically begin flashing the firmware.

Note: If flashing the firmware does not start automatically, please press and hold the IO0 key, then press the EN key, and release them simultaneously to manually enter flashing mode, and then click the **START** button.



5. After downloading, a blue FINISH indicator will appear. At this point, power off and restart the microcontroller or press the EN key to restart the program and close the programming tool. Finally, use a serial port assistant to open this port to see the printed information.



4. Phenomenon and Results

After programming, open the serial port assistant. You can see the continuously printed digital values of the eight-channel grayscale tracking module. X1 corresponds to X1 on the module; when the X1 LED is lit, the corresponding value is 1.

```
[2025-11-08 17:18:48.215]# RECV ASCII>
[ X1:1 ][ X2:1 ][ X3:1 ][ X4:1 ][ X5:1 ][ X6:1 ][ X7:1 ][ X8:1 ]

[2025-11-08 17:18:48.312]# RECV ASCII>
[ X1:1 ][ X2:1 ][ X3:1 ][ X4:1 ][ X5:1 ][ X6:1 ][ X7:1 ][ X8:1 ]

[2025-11-08 17:18:48.407]# RECV ASCII>
[ X1:1 ][ X2:1 ][ X3:1 ][ X4:1 ][ X5:1 ][ X6:1 ][ X7:1 ][ X8:1 ]

[2025-11-08 17:18:48.502]# RECV ASCII>
[ X1:1 ][ X2:1 ][ X3:1 ][ X4:1 ][ X5:1 ][ X6:1 ][ X7:1 ][ X8:1 ]

[2025-11-08 17:18:48.613]# RECV ASCII>
[ X1:1 ][ X2:1 ][ X3:1 ][ X4:1 ][ X5:1 ][ X6:1 ][ X7:1 ][ X8:1 ]

[2025-11-08 17:18:48.709]# RECV ASCII>
[ X1:1 ][ X2:1 ][ X3:1 ][ X4:1 ][ X5:1 ][ X6:1 ][ X7:1 ][ X8:1 ]
```

5. Code Explanation

```
// Grayscale_Read.c
void app_main(void)
{
    Grayscale_Sensor_Init();

    xTaskCreate(
        Grayscale_ReadData_Task, // Task function
        "GrayscaleReadData", // Task name
        4096, // Stack size (bytes)
        NULL,
        2, // Priority
        NULL
    );
}

void Grayscale_ReadData_Task(void *arg) {
    while (1) {
        Grayscale_Sensor_Read_All(g_sensor_data);

        for (i = 0; i < GRAYSCALE_SENSOR_CHANNELS; i++)
        {
            printf("[ %s:%d ]", sensor_labels[i], g_sensor_data[i]);
        }
        printf("\n");
        delay_ms(100);
    }
}
```

- `app_main`: The main entry point function for the ESP-IDF project. It first calls `Grayscale_Sensor_Init()` to initialize the sensor, and then uses `xTaskCreate()` to create a FreeRTOS task specifically for reading and printing sensor data.
- `Grayscale_ReadData_Task`: An infinite loop task. In each loop, it calls `Grayscale_Sensor_Read_All()` to retrieve the latest sensor data, and then formats and outputs the data to the serial port using `printf`.

```
// grayscale_sensor.c
void Grayscale_Sensor_Init(void)
{
    gpio_config_t io_conf_output = {
        .pin_bit_mask = (1ULL << 35) | (1ULL << 36) | (1ULL << 37),
        .mode = GPIO_MODE_OUTPUT,
        //...
    };
    gpio_config(&io_conf_output);

    gpio_config_t io_conf_input = {
        .pin_bit_mask = (1ULL << 38),
        .mode = GPIO_MODE_INPUT,
        //...
    };
    gpio_config(&io_conf_input);
}

void Grayscale_Sensor_Read_All(uint16_t* sensor_values)
{
    uint8_t i;
```

```

    for (i = 0; i < GRAYSCALE_SENSOR_CHANNELS; i++)
    {
        _select_channel(i);
        _delay_us(50);
        sensor_values[i] = Read_OUT_value();
    }
}

```

- `Grayscale_Sensor_Init`: Initializes GPIOs using the `gpio_config` structure and functions provided by ESP-IDF. Configures control pins (GPIO35-37) as outputs and data pins (GPIO38) as inputs.
- `Grayscale_Sensor_Read_All`: Iterates through all 8 sensor channels, selects a channel using `_select_channel`, reads its value, and stores it in an array.