

15.Set root user password

Input following command:


```
sudo passwd root
```

After executing this command, the system will prompt you to enter the root password twice. Just enter the password you want to set, and then execute

```
sudo passwd --unlock root
```

After executing this command, the system will prompt you to enter the root password twice. Just enter the password you want to set, and then execute

```
su
```



```
pi@raspberrypi: ~  
pi@raspberrypi:~ $ sudo passwd root  
Enter new UNIX password:  
Retype new UNIX password:  
passwd: password updated successfully  
pi@raspberrypi:~ $ sudo passwd --unlock root  
passwd: password expiry information changed.  
pi@raspberrypi:~ $ su  
Password:  
root@raspberrypi:/home/pi#
```

The root user is successfully unlocked.