

# Discrete fourier transform algorithm

The Fourier transform can decompose an image into its sine and cosine components. In other words, it can convert an image from its spatial domain to its frequency domain. The idea of this transformation is that any function can accurately approach the sum of infinite  $\sin()$  functions and  $\cos()$  functions. The Fourier transform provides this method to achieve this effect.

For discrete signals such as digital images, the frequency indicates the intensity of the signal change, or the speed of the signal change. The higher the frequency, the more drastic the change. The smaller the frequency, the gentler the signal. Corresponding to the image, high-frequency signals are often edge signals and noise signals in the image, while low-frequency signals include signals such as image contours and background that change frequently.

## 1.Use

Source code launch file path: `~/opt/ros/noetic/share/opencv_apps/launch`

Step 1: Start the camera

```
roslaunch dofbot_visual opencv_apps.launch img_flip:=false
```

- `img_flip` parameter: whether the image needs to be flipped horizontally, the default is false.

[`usb_cam-test.launch`] file opens the [`web_video_server`] node by default, and you can directly use the [`IP:8080`] web page to view images in real time.

Step 2: Start the corner detection function of Opencv\_apps

```
roslaunch opencv_apps discrete_fourier_transform.launch # Discrete Fourier  
Transform Algorithm
```

Each functional case will have a parameter [`debug_view`], Boolean type, whether to use Opencv to display images, which is displayed by default.

If no display is required, set it to [`False`], for example

```
roslaunch opencv_apps contour_moments.launch debug_view:=False
```

However, after starting in this way, some cases cannot be displayed in other ways, because in the source code, some [`debug_view`] is set to [`False`], which will turn off image processing.

## 2. Display method

- `rqt_image_view`

Enter the following command to select the corresponding topic

```
rqt_image_view
```

- `opencv`

The system displays it by default, no need to do anything.

- Web viewing

(Same as under LAN) Enter IP+port in the browser, for example:

```
192.168.2.116:8080
```

For specific IP, use your current virtual machine IP.

### 3. Effect display

On the right is the picture after the Fourier transform algorithm

