

Manage OLED service

In the factory image, the OLED service will be automatically started when the computer is powered on. Under normal circumstances, it does not need to be managed and can be left to start automatically.

Shut down the service

Shut down the program service

```
sudo systemctl stop yahboom_oled.service
```

Permanently shut down the service

```
sudo systemctl disable yahboom_oled.service
```

Query the service status

```
sudo systemctl status yahboom_oled.service
```

Start the service

Start the service

```
sudo systemctl start yahboom_oled.service
```

Restart the service

```
sudo systemctl restart yahboom_oled.service
```

Set the service to start automatically when the computer is powered on

```
sudo systemctl enable yahboom_oled.service
```