

Manage JupyterLab service

In the factory image, Jupyter Lab service will be automatically started when booting. Under normal circumstances, it does not need to be managed and can be kept automatically started at boot.

Shut down the service

Shut down the program service

```
sudo systemctl stop jupyterlab.service
```

Permanently shut down the service

```
sudo systemctl disable jupyterlab.service
```

Query the service status

```
sudo systemctl status jupyterlab.service
```

Start the service

Start the service

```
sudo systemctl start jupyterlab.service
```

Restart the service

```
sudo systemctl restart jupyterlab.service
```

Set the service to start automatically at boot

```
sudo systemctl enable jupyterlab.service
```