

Manage OLED Services

In the factory image, OLED service will automatically start at boot. Under normal circumstances, no management is needed; just keep it set to auto-start at boot.

Close Services

Stop program service

```
sudo systemctl stop yahboom_oled.service
```

Permanently close service

```
sudo systemctl disable yahboom_oled.service
```

Query service status

```
sudo systemctl status yahboom_oled.service
```

Start Services

Start service

```
sudo systemctl start yahboom_oled.service
```

Restart service

```
sudo systemctl restart yahboom_oled.service
```

Set service to auto-start at boot

```
sudo systemctl enable yahboom_oled.service
```