



How to use the handle and mbit(joystick)

1. You need to download the [Handle joystick control code.hex](#) program from the [Handle code](#) folder to the micro:bit board on the micro:bit handle and download the [microbit-mbit.hex](#) program from the [mbit car code](#) folder to the micro:bit board on the car.
2. After the program is downloaded, power on the handle and the car, they can be paired automatically, and you can remotely control them.

Push the joystick to forward: The car forward

Push the joystick to backward: The car back

Push the joystick to the left: The car turn left

Push the joystick to the right: The car turn right

Press the button B1: The car lights up the red LED

Press the button B2: The car lights up the green LED

Press the button B3: The car lights up the blue LED

Press the button B4: The car lights up the yellow LED

Reset button is the restart button:

