



How to use the handle and mbit(gravity)

1. You need to download the [Handle gravity control code.hex](#) program from the [Handle code](#) folder to the micro:bit board on the micro:bit handle and download the [microbit-mbit.hex](#) program from the [mbit car code](#) folder to the micro:bit board on the car.
2. After the program is downloaded, power on the handle and the car, they can be paired automatically, and you can remotely control them.

The handle is tilted forward: the car forward

The handle is tilted backward: the car back

The handle is tilted left: the car turn left

(Note: the left tilt should be placed horizontally and then left tilt)

The handle is tilted right: the car turn right

(Note: the right tilt should be placed horizontally and then right tilt)

Press the button B1: The car lights up the red LED

Press the button B2: The car lights up the green LED

Press the button B3: The car lights up the blue LED

Press the button B4: The car lights up the yellow LED

Reset button is the restart button:

