

## Documents to read before operation

---

The factory image of Jupyter Lab development environment has already installed the development environment. If you use the factory image, ignore the development environment section.

The default login URL of Jupyter Lab for Jetson Nano is the robot IP address: 8888, and the password is yahboom

Since Jetson Orin NX and Orin Nano use Docker images, the default login URL of Jupyter Lab is the robot IP address: 8889, and the password is yahboom