

Documents to read before operation

The Jupyter Lab development environment factory image has already installed the development environment. If you use the factory image, ignore the development environment section.

The default login URL of Jupyter Lab is the robot IP address: **8888**, and the password is **yahboom**