

# Solution to the camera disconnection in docker

---

Method 1:

Restart the robot.

Method 2:

Unplug the USB interface of the camera, then close all programs that call the camera, and then reinsert the USB interface of the camera. Enter the following command to check the device number of the camera. It must be `/dev/video0`. If it is `/dev/video1`, replug the USB cable of the camera.

```
11 /dev/video*
```