

Voice interaction hardware connection (ReadMe)

To run the voice interaction function, you must use the AI large-model voice module included in the AI large-model package that comes with the Jetson Orin series motherboards.

Wiring Diagram:

