

Must read before running

Must read before running

[Enter Docker](#)

The ROS1 environment is located in Docker. Users need to have a certain understanding of Docker to use it smoothly!

Note: Only USB cameras can be used to run visual cases in Docker!

Enter Docker

```
sh ~/ros_melodic.sh
```

