

After the program is downloaded, move the red dot through the joystick to catch the fruit falling from the top of the LCD screen. After the game is over, the score will be displayed on the LCD screen. If you need to play again, you need to press the reset button.

B1 is the deceleration button

B3 is the acceleration button

Reset button is the restart button

