

Pin level output control

Using simple in routines_ out.py

The program will output high and low levels (updated alternately every 2 seconds) to the physical pin PIN12

run a program:

```
sudo python3 simple_out.py
```

desired result

You can use a voltmeter to test whether the voltage of pin 12 increases or decreases

```
nano@nano-desktop:/opt/nvidia/jetson-gpio/samples$ sudo python3 simple_out.py
[sudo] password for nano:
Starting demo now! Press CTRL+C to exit
Outputting 1 to pin 18
Outputting 0 to pin 18
Outputting 1 to pin 18
Outputting 0 to pin 18
Outputting 1 to pin 18
Outputting 0 to pin 18
```