

## 9. Face Detection Algorithm

### 9.1.1、Use

Source code launch file path: /opt/ros/noetic/share/opencv\_apps/launch

Step 1: Start the camera

```
roslaunch ascam_visual opencv_apps.launch img_flip:=false
```

- img\_flip parameter: whether the image needs to be flipped horizontally, the default is false.

The [usb\_cam-test.launch] file opens the [web\_video\_server] node by default, and you can directly use the [IP:8080] web page to view the image in real time.

Step 2: Start the face detection function of Opencv\_apps

```
roslaunch opencv_apps face_detection.launch # Face detection algorithm
```

Each function case will have a parameter [debug\_view], Boolean type, whether to use Opencv to display the image, the default is displayed.

If you don't need to display, set it to [False], for example

```
roslaunch opencv_apps face_detection.launch debug_view:=False
```

However, after starting in this way, some cases may not be displayed in other ways, because in the source code, some [debug\_view] is set to [False], which will turn off image processing.

### 9.1.2, Display method

- rqt\_image\_view

Enter the following command and select the corresponding topic

```
rqt_image_view
```

- opencv

The system displays by default, and no processing is required.

- Web viewing

(Under the same LAN) Enter IP+port in the browser, for example:

```
192.168.2.116:8080
```

For specific IP, use your current virtual machine IP.

### 9.1.3, Effect display

If the code is successfully run, you can see the following effect diagram.

