

# Frequently Questions

---

## 1. Why do robots need to be configured with parameters?

Answer: Since each user's WiFi environment and IP address are different, parameters need to be configured according to the actual situation.

## 2. What should I do if I cannot read and write the robot configuration parameters when running the python3 config\_robot.py command?

Answer: Please press the reset button of the robot. It will be in the configuration state within 5 seconds after powering on (the MCU indicator light flashes every 300 milliseconds). At this time, you can run the configuration file to read and write the configuration normally.

## 3. What is the function of the type-C port on the control board?

Answer: The type-C interface marked with Serial is mainly used for communication, configuration, and firmware burning.

## 5. What is the reason for the robot buzzer to keep "beeping"?

Answer: When the battery is low, the robot will make a "beeping" sound (every 100 milliseconds). At this time, the robot cannot be controlled. Please save the code, shut down, and then charge the robot.

## 6. What does the robot MCU status indicator represent?

A: The baseboard MCU enters the **configuration state** after booting up. After about 5 seconds, it automatically enters the **connection agent state**. After successfully connecting to the agent, it starts to initialize ROS related topics. If the **agent error** occurs, the agent task is automatically terminated. If the agent initialization is completed, it enters the **normal state**.

LED light indication function	LED light phenomenon
Configuration state	LED light flashes (flashes once every 300 milliseconds)
Connection agent state	LED light flashes slowly (flashes once every 1 second)
Normal state	LED light double flashes (flashes twice every 3 seconds)
Low voltage state	LED light flashes quickly (flashes once every 100 milliseconds)

## 7. How to avoid interference when there are multiple robots in the same LAN?

A: Interference can be avoided by setting different ROS\_DOMAIN\_IDs. The setting range of ROS\_DOMAIN\_ID is: 0~101. Please modify the set\_ros\_domain\_id(20) parameter in the config\_robot.py file and write the configuration to the microROS control board. Then add a line "export ROS\_DOMAIN\_ID=20 " to the .bashrc file in the virtual machine/computer user directory, save and restart the terminal.

## 8. The map will float when cartographer is building a map

Answer: You need to turn slowly when turning, or build a map in a place with many feature points.

