

My computer can't automatically recognize the drive letter (RPI-RP2).

- ① You need to make sure that the BOOTSEL button is pressed before connecting to the computer, and you can release the BOOTSEL button after Pico is connected to the computer.
- ② The Micro USB cable used must be a data cable, and a USB cable that can only supply power cannot be used.