

1. Realize the control of playing your favorite music by pressing the button to switch songs.
2. When four buttons are pressed, seven tones are emitted, such as red button (do), green button (ru/ sol), blue button (mi / la), yellow button (fa / si).

Tip: According to the tone do(262), ri(294) mi(330), fa(350), sol(393), la(441), si(495), the tone can be switched by pressing the red button and other button at the same time.

Reference answer:

For the code of this course, please refer to **Button_Expand_1.sb3** , **Button_Expand_2.sb3**.