

Drive motor

Drive motor

1. Experimental Purpose
2. Hardware Connection
3. Core code analysis
4. Compile, download and burn firmware
5. Experimental Results

1. Experimental Purpose


Learn how to control motors using the PWM output of the STM32 control board.

Note: Since the motor starts moving after the program is downloaded, please suspend the car or motor in the air first to avoid the car running around.


2. Hardware Connection

As shown in the figure below, the STM32 control board integrates four encoder motor control interfaces. This requires additional connection to the encoder motor. The motor control interface supports 520 encoder motors. Because the encoder voltage requires high voltage and high current, a battery must be plugged in for power.

The corresponding names of the four motor interfaces are: left front wheel -> M1, left rear wheel -> M2, right front wheel -> M3, right rear wheel -> M4.




There is a detailed line sequence silk screen near the motor interface. Here we take motor M1 as an example. M1+ and M1- are the interfaces for controlling the rotation of the motor, GND and +3.3V are the power supply circuits for the encoder, and H1A and H1B are the encoder pulse detection pins.



The corresponding relationship between the motor PWM drive GPIO is shown in the following table:

Motor interface PWM signal	STM32 GPIO numbering	STM32 timer channels
M1+(M1A)	PE13	TIM1_CH3
M1-(M1B)	PE14	TIM1_CH4
M2+(M2A)	PE9	TIM1_CH1
M2-(M2B)	PE11	TIM1_CH2
M3+(M3A)	PA5	TIM8_CH1N
M3-(M3B)	PB0	TIM8_CH2N
M4+(M4A)	PC8	TIM8_CH3
M4-(M4B)	PC9	TIM8_CH4

Motor interface wiring diagram:



3. Core code analysis

The path corresponding to the program source code is:

```
Board_Samples/STM32_Samples/Motor
```

First, initialize the configuration parameters of timer TIM1, set the division coefficient to 4, and the counting range to 0~1999. Since the clock frequency of timer TIM1 is 240Mhz, the PWM frequency is calculated to be $240000000/(4+1)/(1999+1)=24\text{kHz}$.

Categories

A->Z

System Core >

Analog >

Timers >

HRTIM

LPTIM1

LPTIM2

LPTIM3

LPTIM4

LPTIM5

RTC

TIM1

TIM2

TIM3

TIM4

TIM5

TIM6

TIM7

TIM8

TIM12

TIM13

TIM14

TIM15

TIM16

TIM17

Connectivity >

Multimedia >

Mode

Slave Mode

Disable

Trigger Source

Disable

Clock Source

Disable

Channel1

PWM Generation CH1

Channel2

PWM Generation CH2

Channel3

PWM Generation CH3

Channel4

PWM Generation CH4

Channel5

Disable

Channel6

Disable

Combined Channels

Disable

Configuration

Reset Configuration

✓ NVIC Settings

✓ DMA Settings

✓ GPIO Settings

✓ Parameter Settings

✓ User Constants

Configure the below parameters :

Search (Ctrl+F)

⏪

⏩

ⓘ

Counter Settings

Prescaler (PSC - 16 bits... 4

Counter Mode Up

Counter Period (AutoRel... 1999

Internal Clock Division (... No Division

Repetition Counter (RCR... 0

auto-reload preload Enable

Trigger Output (TRGO) Paramet...

Master/Slave Mode (MS... Disable (Trigger input effect not del...

Trigger Event Selection ... Reset (UG bit from TIMx_EGR)

Trigger Event Selection ... Reset (UG bit from TIMx_EGR)

```

void MX_TIM1_Init(void)
{
    TIM_MasterConfigTypeDef sMasterConfig = {0};
    TIM_OC_InitTypeDef sConfigOC = {0};
    TIM_BreakDeadTimeConfigTypeDef sBreakDeadTimeConfig = {0};

    /* USER CODE BEGIN TIM1_Init 1 */

    /* USER CODE END TIM1_Init 1 */
    htim1.Instance = TIM1;
    htim1.Init.Prescaler = 4;
    htim1.Init.CounterMode = TIM_COUNTERMODE_UP;
    htim1.Init.Period = 1999;
    htim1.Init.ClockDivision = TIM_CLOCKDIVISION_DIV1;
    htim1.Init.RepetitionCounter = 0;
    htim1.Init.AutoReloadPreload = TIM_AUTORELOAD_PRELOAD_ENABLE;
    if (HAL_TIM_PWM_Init(&htim1) != HAL_OK)
    {
        Error_Handler();
    }
    sMasterConfig.MasterOutputTrigger = TIM_TRGO_RESET;

```

```

sMasterConfig.MasterOutputTrigger2 = TIM_TRG02_RESET;
sMasterConfig.MastersSlaveMode = TIM_MASTERSLAVEMODE_DISABLE;
if (HAL_TIMEx_MasterConfigSynchronization(&htim1, &sMasterConfig) != HAL_OK)
{
    Error_Handler();
}
sConfigOC.OCMode = TIM_OCMode_PWM1;
sConfigOC.Pulse = 0;
sConfigOC.OCpolarity = TIM_OCPOLARITY_HIGH;
sConfigOC.OCNPolarity = TIM_OCNPOLARITY_HIGH;
sConfigOC.OCFastMode = TIM_OCFAST_DISABLE;
sConfigOC.OCIdleState = TIM_OCIDLESTATE_RESET;
sConfigOC.OCNIdleState = TIM_OCNIDLESTATE_RESET;
if (HAL_TIM_PWM_ConfigChannel(&htim1, &sConfigOC, TIM_CHANNEL_1) != HAL_OK)
{
    Error_Handler();
}
if (HAL_TIM_PWM_ConfigChannel(&htim1, &sConfigOC, TIM_CHANNEL_2) != HAL_OK)
{
    Error_Handler();
}
if (HAL_TIM_PWM_ConfigChannel(&htim1, &sConfigOC, TIM_CHANNEL_3) != HAL_OK)
{
    Error_Handler();
}
if (HAL_TIM_PWM_ConfigChannel(&htim1, &sConfigOC, TIM_CHANNEL_4) != HAL_OK)
{
    Error_Handler();
}
sBreakDeadTimeConfig.OffStateRunMode = TIM_OSSR_DISABLE;
sBreakDeadTimeConfig.OffStateIDLEMode = TIM_OSSI_DISABLE;
sBreakDeadTimeConfig.LockLevel = TIM_LOCKLEVEL_OFF;
sBreakDeadTimeConfig.DeadTime = 0;
sBreakDeadTimeConfig.BreakState = TIM_BREAK_DISABLE;
sBreakDeadTimeConfig.BreakPolarity = TIM_BREAKPOLARITY_HIGH;
sBreakDeadTimeConfig.BreakFilter = 0;
sBreakDeadTimeConfig.Break2State = TIM_BREAK2_DISABLE;
sBreakDeadTimeConfig.Break2Polarity = TIM_BREAK2POLARITY_HIGH;
sBreakDeadTimeConfig.Break2Filter = 0;
sBreakDeadTimeConfigAutomaticOutput = TIM_AUTOMATICOUTPUT_DISABLE;
if (HAL_TIMEx_ConfigBreakDeadTime(&htim1, &sBreakDeadTimeConfig) != HAL_OK)
{
    Error_Handler();
}
HAL_TIM_MspPostInit(&htim1);
}

```

定时器TIM8的初始化参数与定时器TIM1的参数一致。

Categories

A-Z

System Core >

Analog >

Timers >

HRTIM

LPTIM1

LPTIM2

LPTIM3

LPTIM4

LPTIM5

RTC

TIM1

TIM2

TIM3

TIM4

TIM5

TIM6

TIM7

TIM8

TIM12

TIM13

TIM14

TIM15

TIM16

TIM17

Connectivity >

Multimedia >

Mode

Slave Mode

Disable

Trigger Source

Disable

Clock Source

Disable

Channel1

PWM Generation CH1N

Channel2

PWM Generation CH2N

Channel3

PWM Generation CH3

Channel4

PWM Generation CH4

Channel5

Disable

Channel6

Disable

Combined Channels

Disable

Configuration

Reset Configuration

NVIC Settings

DMA Settings

GPIO Settings

Parameter Settings

User Constants

Configure the below parameters :

Search (Ctrl+F)

Counter Settings

Prescaler (PSC - 16 bits... 4

Counter Mode Up

Counter Period (AutoRel... 1999

Internal Clock Division (... No Division

Repetition Counter (RCR... 0

auto-reload preload Enable

Trigger Output (TRGO) Paramet...

Master/Slave Mode (MS... Disable (Trigger input effect not del...

Trigger Event Selection ... Reset (UG bit from TIMx_EGR)

Trigger Event Selection ... Reset (UG bit from TIMx_EGR)

```

void MX_TIM8_Init(void)
{
    TIM_MasterConfigTypeDef sMasterConfig = {0};
    TIM_OC_InitTypeDef sConfigOC = {0};
    TIM_BreakDeadTimeConfigTypeDef sBreakDeadTimeConfig = {0};

    /* USER CODE BEGIN TIM8_Init 1 */

    /* USER CODE END TIM8_Init 1 */
    htim8.Instance = TIM8;
    htim8.Init.Prescaler = 4;
    htim8.Init.CounterMode = TIM_COUNTERMODE_UP;
    htim8.Init.Period = 1999;
    htim8.Init.ClockDivision = TIM_CLOCKDIVISION_DIV1;
    htim8.Init.RepetitionCounter = 0;
    htim8.Init.AutoReloadPreload = TIM_AUTORELOAD_PRELOAD_ENABLE;
    if (HAL_TIM_PWM_Init(&htim8) != HAL_OK)
    {
        Error_Handler();
    }
    sMasterConfig.MasterOutputTrigger = TIM_TRGO_RESET;
    sMasterConfig.MasterOutputTrigger2 = TIM_TRGO2_RESET;

```

```

sMasterConfig.MasterSlaveMode = TIM_MASTERSLAVEMODE_DISABLE;
if (HAL_TIMEx_MasterConfigSynchronization(&htim8, &sMasterConfig) != HAL_OK)
{
    Error_Handler();
}
sConfigOC.OCMode = TIM_OCMode_PWM1;
sConfigOC.Pulse = 0;
sConfigOC.OCpolarity = TIM_OCPOLARITY_HIGH;
sConfigOC.OCNPolarity = TIM_OCNPOLARITY_HIGH;
sConfigOC.OCFastMode = TIM_OCFAST_DISABLE;
sConfigOC.OCIdleState = TIM_OCIDLESTATE_RESET;
sConfigOC.OCNIdleState = TIM_OCNIDLESTATE_RESET;
if (HAL_TIM_PWM_ConfigChannel(&htim8, &sConfigOC, TIM_CHANNEL_1) != HAL_OK)
{
    Error_Handler();
}
if (HAL_TIM_PWM_ConfigChannel(&htim8, &sConfigOC, TIM_CHANNEL_2) != HAL_OK)
{
    Error_Handler();
}
if (HAL_TIM_PWM_ConfigChannel(&htim8, &sConfigOC, TIM_CHANNEL_3) != HAL_OK)
{
    Error_Handler();
}
if (HAL_TIM_PWM_ConfigChannel(&htim8, &sConfigOC, TIM_CHANNEL_4) != HAL_OK)
{
    Error_Handler();
}
sBreakDeadTimeConfig.OffStateRunMode = TIM_OSSR_DISABLE;
sBreakDeadTimeConfig.OffStateIDLEMode = TIM_OSSI_DISABLE;
sBreakDeadTimeConfig.LockLevel = TIM_LOCKLEVEL_OFF;
sBreakDeadTimeConfig.DeadTime = 0;
sBreakDeadTimeConfig.BreakState = TIM_BREAK_DISABLE;
sBreakDeadTimeConfig.BreakPolarity = TIM_BREAKPOLARITY_HIGH;
sBreakDeadTimeConfig.BreakFilter = 0;
sBreakDeadTimeConfig.Break2State = TIM_BREAK2_DISABLE;
sBreakDeadTimeConfig.Break2Polarity = TIM_BREAK2POLARITY_HIGH;
sBreakDeadTimeConfig.Break2Filter = 0;
sBreakDeadTimeConfigAutomaticOutput = TIM_AUTOMATICOUTPUT_DISABLE;
if (HAL_TIMEx_ConfigBreakDeadTime(&htim8, &sBreakDeadTimeConfig) != HAL_OK)
{
    Error_Handler();
}
/* USER CODE BEGIN TIM8_Init 2 */

/* USER CODE END TIM8_Init 2 */
HAL_TIM_MspPostInit(&htim8);
}

```

电机初始化启动PWM输出。


```

void Motor_Init(void)
{
    HAL_TIM_PWM_Start(&htim1, TIM_CHANNEL_1);
    HAL_TIM_PWM_Start(&htim1, TIM_CHANNEL_2);
    HAL_TIM_PWM_Start(&htim1, TIM_CHANNEL_3);
    HAL_TIM_PWM_Start(&htim1, TIM_CHANNEL_4);

    HAL_TIMEx_PWMN_Start(&htim8, TIM_CHANNEL_1);
    HAL_TIMEx_PWMN_Start(&htim8, TIM_CHANNEL_2);
    HAL_TIM_PWM_Start(&htim8, TIM_CHANNEL_3);
    HAL_TIM_PWM_Start(&htim8, TIM_CHANNEL_4);
}

```

将电机PWM通道与定时器的对应关系使用宏定义关联。

```

#define PWM_M1_A    TIM1->CCR3
#define PWM_M1_B    TIM1->CCR4

#define PWM_M2_A    TIM1->CCR1
#define PWM_M2_B    TIM1->CCR2

#define PWM_M3_A    TIM8->CCR1
#define PWM_M3_B    TIM8->CCR2

#define PWM_M4_A    TIM8->CCR3
#define PWM_M4_B    TIM8->CCR4

```

由于电机的启动电压过低时无法转动，所以需要增加死区过滤，控制电机才更加敏捷。

```

#define MOTOR_IGNORE_PULSE    (999)

static int16_t Motor_Ignore_Dead_Zone(int16_t pulse)
{
    if (pulse > 0) return pulse + MOTOR_IGNORE_PULSE;
    if (pulse < 0) return pulse - MOTOR_IGNORE_PULSE;
    return 0;
}

```

需要限制输入的PWM值。

```

#define MOTOR_MAX_PULSE    (1999)

static int16_t Motor_Limit_Pulse(int16_t pulse)
{
    if (pulse >= MOTOR_MAX_PULSE) return MOTOR_MAX_PULSE;
    if (pulse <= -MOTOR_MAX_PULSE) return -MOTOR_MAX_PULSE;
    return pulse;
}

```

设置电机速度，传入电机ID值来区分电机，speed用来控制电机的速度，取值范围是 \pm MOTOR_MAX_SPEED。

```

#define MOTOR_MAX_SPEED    (1000)

```

```

typedef enum {
    MOTOR_ID_M1 = 0,
    MOTOR_ID_M2,
    MOTOR_ID_M3,
    MOTOR_ID_M4,
    MOTOR_ID_MAX
} Motor_ID;

void Motor_Set_Pwm(uint8_t id, int16_t speed)
{
    int16_t pulse = Motor_Ignore_Dead_Zone(speed);
    // Limit input 限制输入
    pulse = Motor_Limit_Pulse(pulse);

    switch (id)
    {
    case MOTOR_ID_M1:
    {
        pulse = -pulse;
        if (pulse >= 0)
        {
            PWM_M1_A = pulse;
            PWM_M1_B = 0;
        }
        else
        {
            PWM_M1_A = 0;
            PWM_M1_B = -pulse;
        }
        break;
    }
    case MOTOR_ID_M2:
    {
        pulse = -pulse;
        if (pulse >= 0)
        {
            PWM_M2_A = pulse;
            PWM_M2_B = 0;
        }
        else
        {
            PWM_M2_A = 0;
            PWM_M2_B = -pulse;
        }
        break;
    }
    case MOTOR_ID_M3:
    {
        if (pulse >= 0)
        {
            PWM_M3_A = pulse;
            PWM_M3_B = 0;
        }
        else
        {
            PWM_M3_A = 0;
            PWM_M3_B = -pulse;
        }
    }
    }
}

```

```

        break;
    }
    case MOTOR_ID_M4:
    {
        if (pulse >= 0)
        {
            PWM_M4_A = pulse;
            PWM_M4_B = 0;
        }
        else
        {
            PWM_M4_A = 0;
            PWM_M4_B = -pulse;
        }
        break;
    }
    case MOTOR_ID_MAX:
    {
        if (pulse >= 0)
        {
            PWM_M1_A = 0;
            PWM_M1_B = Motor_ABS(pulse);
            PWM_M2_A = 0;
            PWM_M2_B = Motor_ABS(pulse);
            PWM_M3_A = Motor_ABS(pulse);
            PWM_M3_B = 0;
            PWM_M4_A = Motor_ABS(pulse);
            PWM_M4_B = 0;
        }
        else
        {
            PWM_M1_A = Motor_ABS(pulse);
            PWM_M1_B = 0;
            PWM_M2_A = Motor_ABS(pulse);
            PWM_M2_B = 0;
            PWM_M3_A = 0;
            PWM_M3_B = Motor_ABS(pulse);
            PWM_M4_A = 0;
            PWM_M4_B = Motor_ABS(pulse);
        }
        break;
    }

    default:
        break;
}
}

```

电机停止函数，brake函数为停止状态，brake=MOTOR_STOP表示自由停止，brake=MOTOR_BRAKE表示刹车停止。

```

typedef enum {
    MOTOR_STOP = 0,
    MOTOR_BRAKE=1,
} Motor_Stop_Mode;

```

```

void Motor_Stop(uint8_t brake)
{
    if (brake != 0) brake = 1;
    PWM_M1_A = brake * MOTOR_MAX_PULSE;
    PWM_M1_B = brake * MOTOR_MAX_PULSE;
    PWM_M2_A = brake * MOTOR_MAX_PULSE;
    PWM_M2_B = brake * MOTOR_MAX_PULSE;
    PWM_M3_A = brake * MOTOR_MAX_PULSE;
    PWM_M3_B = brake * MOTOR_MAX_PULSE;
    PWM_M4_A = brake * MOTOR_MAX_PULSE;
    PWM_M4_B = brake * MOTOR_MAX_PULSE;
}

```

在App_Handle函数里控制电机循环执行：前进1秒，停止1秒，后退1秒，停止1秒。

```

void App_Handle(void)
{
    Motor_Init();
    HAL_Delay(1000);


    while (1)
    {
        Motor_Set_Pwm(MOTOR_ID_M1, MOTOR_MAX_PULSE/3);
        Motor_Set_Pwm(MOTOR_ID_M2, MOTOR_MAX_PULSE/3);
        Motor_Set_Pwm(MOTOR_ID_M3, MOTOR_MAX_PULSE/3);
        Motor_Set_Pwm(MOTOR_ID_M4, MOTOR_MAX_PULSE/3);
        HAL_Delay(1000);
        Motor_Stop(MOTOR_STOP);
        HAL_Delay(1000);

        Motor_Set_Pwm(MOTOR_ID_M1, -MOTOR_MAX_PULSE/3);
        Motor_Set_Pwm(MOTOR_ID_M2, -MOTOR_MAX_PULSE/3);
        Motor_Set_Pwm(MOTOR_ID_M3, -MOTOR_MAX_PULSE/3);
        Motor_Set_Pwm(MOTOR_ID_M4, -MOTOR_MAX_PULSE/3);
        HAL_Delay(1000);
        Motor_Stop(MOTOR_BRAKE);
        HAL_Delay(1000);
    }
}

```

4. Compile, download and burn firmware


Select the project to be compiled in the file management interface of STM32CUBEIDE and click the compile button on the toolbar to start compiling.



If there are no errors or warnings, the compilation is complete.

```
make -j16 all
arm-none-eabi-size Led.elf
  text    data    bss     dec      hex filename
  8132     16   1576   9724   25fc Led.elf
Finished building: default.size.stdout

17:44:48 Build Finished. 0 errors, 0 warnings. (took 345ms)
```



Press and hold the BOOT0 button, then press the RESET button to reset, release the BOOT0 button to enter the serial port burning mode. Then use the serial port burning tool to burn the firmware to the board.

If you have STlink or JLink, you can also use STM32CUBEIDE to burn the firmware with one click, which is more convenient and quick.

5. Experimental Results

Note: Since the motor starts moving after the program is downloaded, please suspend the car or motor in the air first to avoid the car running around.

The MCU_LED light flashes every 200 milliseconds.

The car motor moves forward for 1 second, stops for 1 second, moves backward for 1 second, and stops for 1 second.