


# Accessories introduction


## 1. Jetson Nano SUB 4G version



\* The voice interaction module can only be used normally after binding the port according to the tutorial [Voice control courses --->Voice control module port binding].  
If only the voice module is connected but the port is not bound, the APP control program will not be able to start normally.

## 2. Jetson ORIN NX/Orin NANO version


## Wiring diagram for Jetson Orin Nano/Orin NX version



\* The voice interaction module can only be used normally after binding the port according to the tutorial [Voice control courses ---->Voice control module port binding].  
If only the voice module is connected but the port is not bound, the APP control program will not be able to start normally.

### 3. Raspberry Pi 5 version

## Wiring diagram for Raspberry Pi version



\* The voice interaction module can only be used normally after binding the port according to the tutorial [Voice control courses --->Voice control module port binding].  
If only the voice module is connected but the port is not bound, the APP control program will not be able to start normally.