

3. Remote control

3. Remote control

3.1. PuTTY login

3.2. SSH

3.3. jupyter lab

3.4. VNC

3.5. WinSCP


putty: <https://www.chiark.greenend.org.uk/~sgtatham/putty/latest.html>

VNC: <https://www.realvnc.com/en/connect/download/viewer/>

WinSCP: <https://winscp.net/eng/download.php>


Note: Before logging in remotely, you must know the IP of the robot, which can be displayed on an external monitor or OLED.

For example, the following figure: Username [jetson], hostname [yahboom].




3.1. PuTTY login

Enter the relevant link at the top, download the installation file, and double-click the [.exe] file to install.




After entering the IP address of the robot, click [open];



```
jetson@jetson-yahboom: ~  
login as: jetson  
jetson@192.168.2.103's password:  
Welcome to Ubuntu 18.04.5 LTS (GNU/Linux 4.9.201-tegra aarch64)  
  
* Documentation:  https://help.ubuntu.com  
* Management:    https://landscape.canonical.com  
* Support:        https://ubuntu.com/advantage  
This system has been minimized by removing packages and content that are  
not required on a system that users do not log into.  
  
To restore this content, you can run the 'unminimize' command.  
  
0 updates can be applied immediately.  
  
*** System restart required ***  
Last login: Tue Aug 31 15:17:45 2021 from 192.168.2.90
```

Enter the username [jetson] and password [yahboom], and press Enter to confirm.

The sign of successful login appears as shown below




```
jetson@yahboom:~$
```

3.2. SSH

Note: The interface cannot be displayed.

- Log in

operate under ubuntu system



```
jetson@jetson-yahboom: ~  
jetson@jetson-yahboom: ~ 80x24  
yahboom@Yahboom:~$ ssh jetson@192.168.2.103  
The authenticity of host '192.168.2.103 (192.168.2.103)' can't be established.  
ECDSA key fingerprint is SHA256:9UYkw1sqeLwqDgJTC+dzH//Ey8AtRTa4jgzBsMBXChE.  
Are you sure you want to continue connecting (yes/no)? yes  
Warning: Permanently added '192.168.2.103' (ECDSA) to the list of known hosts.  
jetson@192.168.2.103's password:  
Welcome to Ubuntu 18.04.5 LTS (GNU/Linux 4.9.201-tegra aarch64)  
  
* Documentation:  https://help.ubuntu.com  
* Management:    https://landscape.canonical.com  
* Support:        https://ubuntu.com/advantage  
This system has been minimized by removing packages and content that are  
not required on a system that users do not log into.  
  
To restore this content, you can run the 'unminimize' command.  
  
0 updates can be applied immediately.  
  
*** System restart required ***  
Last login: Tue Aug 31 15:33:40 2021 from 192.168.2.106
```

1. Enter the following command in the terminal

```
ssh jetson@192.168.2.103
```

2. Then enter [yes], 3) Enter the password [yahboom]

- copy file

If jetson's IP is 192.168.2.103, username: jetson; virtual machine username: yahboom


```

scp jetson@192.168.2.103:/home/jetson/xxx.tar.gz /home/yahboom/ # Copy files
from remote to local (file)
scp /home/yahboom/xxx.png jetson@192.168.2.103:/home/jetson/ # from local to
remote (file)
scp -r jetson@192.168.2.103:/home/jetson/test /home/yahboom/ # from remote to
local -r (folder)
scp -r /home/yahboom/test jetson@192.168.2.103:/home/jetson/ # from local to
remote (folder)

```

3.3. jupyter lab


Note: The interface cannot be displayed.



English input method, enter the following command, press Enter, enter the password [yahboom], and click [Log in].

```
http://192.168.2.103:8888
```

after login




You can enter the folder, modify the contents of the file directly, click [Terminal] under [Other], enter the terminal, and execute the required command.

3.4. VNC


Note: The interface can be displayed.

Enter the relevant link at the top, download the installation file, and double-click the [.exe] file to install.

The login steps are as shown in the picture. To use the vnc viewer software for VNC connection, you first need to query the IP address. What I found here is [192.168.2.103]. After entering the IP address, click [Enter] on the keyboard.




Enter the corresponding VNC user and enter the password [yahboom], select Remember password, and click [OK] to enter the VNC interface. The next time the IP remains unchanged, you do not need to enter the password again.




Adjust resolution

- **Jetson orin motherboard**

You need to set it to HIGH quality to log in remotely.





- Jetson nano

Use the command line to adjust according to your needs. It is only valid in this startup. Open the terminal and enter the following command

```
xrandr --fb 1920x1080
```

- Raspberry Pi

Modify the [config.txt] file and it will be valid forever. Open the terminal and enter the following command

```
sudo vim /boot/firmware/config.txt
```

For example, add at the bottom (set the resolution to 1920x1080)

```
hdmi_force_hotplug = 1
config_hdmi_boost = 4
hdmi_group = 2
hdmi_mode = 82
hdmi_drive = 2
hdmi_ignore_edid = 0xa5000080
disable_overscan = 1
```

```

device_tree_address=0x03000000

# The following settings are "defaults" expected to be overridden by the
# included configuration. The only reason they are included is, again,
# to
# support old firmwares which don't understand the "include" command.

enable_uart=1
cmdline=nobtcmd.txt

include syscfg.txt
include usercfg.txt

hdmi_force_hotplug=1
config_hdmi_boost=4
hdmi_group=2
hdmi_mode=82
hdmi_drive=2
hdmi_ignore_edid=0xa5000080
disable_overscan=1

```

For the introduction of configuration parameters, please refer to the blog:

<https://blog.csdn.net/coolwriter/article/details/77719003>

3.5. WinSCP

Go to the top related link, download the installation file, and double-click the [.exe] file to install.

Double-click the icon below to open the WinSCP software



This time the robot IP [192.168.2.93], username [jetson], password [yahboom].

If the login dialog box does not pop up, click [New Session] in the upper left part, enter the host name (H), user name, and password in turn, and click Login.

An example of a successful login is as follows

C:\Users\Administrator\Desktop\				/home/jetson/			
名字	大小	类型	已改变	名字	大小	已改变	权限
..		上级目录	2022/2/11 14:51:46	..		2021/12/11 10:38:34	rw-r--r--
3研发部 (yahboomr...	2 KB	快捷方式	2021/2/27 6:25:09	Desktop		2021/12/11 10:40:17	rw-r--r--
360安全卫士.lnk	2 KB	快捷方式	2021/2/25 14:20:40	Documents		2021/12/11 10:40:16	rw-r--r--
360软件管家.lnk	3 KB	快捷方式	2022/2/11 19:08:50	Downloads		2021/12/11 10:40:16	rw-r--r--
advanced_ip_scann...	2 KB	快捷方式	2021/2/26 14:15:58	Music		2021/12/11 10:40:16	rw-r--r--
balenaEtcher.lnk	3 KB	快捷方式	2021/12/3 15:24:27	Pictures		2021/12/11 10:40:16	rw-r--r--
Beyond Compare 2...	1 KB	快捷方式	2021/9/6 17:02:16	Public		2021/12/11 10:40:16	rw-r--r--
Delta-3A.exe.lnk	1 KB	快捷方式	2021/12/17 9:28:29	Rosmaster		2021/12/24 19:01:58	rw-rw-r--
DiskGenius.exe.lnk	2 KB	快捷方式	2021/3/1 15:43:36	software		2022/2/14 18:33:26	rw-rw-r--
FlyMcu.exe.lnk	1 KB	快捷方式	2021/2/26 4:09:11	Templates		2021/12/11 10:40:16	rw-r--r--
frame_grabber.exe...	1 KB	快捷方式	2021/12/17 9:28:11	Videos		2021/12/11 10:40:16	rw-r--r--
FSCapture.exe.lnk	1 KB	快捷方式	2021/8/31 15:42:23	yahboomcar_ws		2022/2/10 17:54:35	rw-rw-r--
Google Chrome.lnk	3 KB	快捷方式	2022/2/10 9:29:26	examples.desktop	9 KB	2021/12/11 10:38:34	rw-r--r--
Keil uVision5.LNK	1 KB	快捷方式	2021/3/30 10:03:28				
putty.exe.lnk	2 KB	快捷方式	2021/6/2 18:51:28				
QQ浏览器.lnk	2 KB	快捷方式	2021/2/26 2:43:04				
rpi-imager.exe.lnk	2 KB	快捷方式	2021/11/16 18:11:35				
SDFormatter.exe.lnk	2 KB	快捷方式	2021/7/14 9:02:17				

- Transfer files from computer to robot [jetson nano]

Just select the file (folder) that needs to be transferred and drag it to the right, then the column of [/home/jetson],

- Robot 【jetson nano】 transfer files to computer

Just select the file (folder) that needs to be transferred and drag it to the left, the column of [C:], or drag it directly to the desktop.