


Control principle

By reading the X1, X2, X3, and X4 interface levels of the four-way tracking module, it is determined whether the black line is detected and where the black line is located.



Black line detected

Light on → The corresponding interface of the four-way patrol module outputs a low level;

White line detected

Light off → The corresponding interface of the four-way patrol module outputs a high level.

Note: The correspondence between the interface, LED, and adjustment knob shall be based on the silk-screen numbers, for example: X1 corresponds to L1, SW1

Software Configuration

Pin Definition

Main Control Chip	Pin	Main Function (After Reset)	Default Multiplexing Function	Redefine Function
STM32F103RCT6	PC4	PC4	ADC12_IN14	
STM32F103RCT6	PC5	PC5	ADC12_IN15	
STM32F103RCT6	PB0	PB0	ADC12_IN8/TIM3_CH3/TIM8_CH2N	TIM1_CH2N
STM32F103RCT6	PB1	PB1	ADC12_IN9/TIM3_CH4/TIM8_CH3N	TIM1_CH3N

Software code

Since the default function of the pin is the normal IO pin function, we need to use the default multiplexing function.

Product supporting materials source code path: Attachment → Source code summary → 2.Extended_Course → 8.IRtracking

Control function

The tutorial only briefly introduces the code, you can open the project source code to read it in detail.

irtracking_init

```
void irtracking_init(void)
{
    GPIO_InitTypeDef GPIO_InitStructure;
    RCC_APB2PeriphClockCmd(IR_X1_Clk|IR_X2_Clk|IR_X3_Clk|IR_X4_Clk, ENABLE);

    GPIO_InitStructure.GPIO_Mode=GPIO_Mode_IN_FLOATING;
    GPIO_InitStructure.GPIO_Pin=IR_X1_Pin;
    GPIO_Init(IR_X1_Port,&GPIO_InitStructure);

    GPIO_InitStructure.GPIO_Mode=GPIO_Mode_IN_FLOATING;
    GPIO_InitStructure.GPIO_Pin=IR_X2_Pin;
    GPIO_Init(IR_X2_Port,&GPIO_InitStructure);

    GPIO_InitStructure.GPIO_Mode=GPIO_Mode_IN_FLOATING;
    GPIO_InitStructure.GPIO_Pin=IR_X3_Pin;
    GPIO_Init(IR_X3_Port,&GPIO_InitStructure);

    GPIO_InitStructure.GPIO_Mode=GPIO_Mode_IN_FLOATING;
    GPIO_InitStructure.GPIO_Pin=IR_X4_Pin;
    GPIO_Init(IR_X4_Port,&GPIO_InitStructure);
}
```

Experimental phenomenon

The IRtracking.hex file generated by the project compilation is located in the OBJ folder of the IRtracking project. Find the IRtracking.hex file corresponding to the project and use the FlyMcu software to download the program to the development board.

After the program is successfully downloaded: the serial port prints and the OLED displays the X1, X2, X3, and X4 interface levels of the four-way tracking module.

