

1 Service and Topic

We provide some services and topics to interact with mycobot.

1.1 Service

Enter in the command line:

```
source <ros-workspace>/devel/setup.bash # Add environment variables
roslaunch mycobot_communication communication_service.launch
```

Support parameters:

- port: concatenate serial string
- baud: baud rate

Open a new command line:

```
# Display active service information
rosservice list

#/get_joint_angles
#/get_joint_coords
#/set_joint_angles
#/set_joint_coords
#/switch_gripper_status
#/switch_pump_status
```

Related commands and instructions:

command	Detailed description
rosservice list	Display active service information
rosservice info [service name]	Display information about the specified service
rosservice type [service name]	Show service type
rosservice find [service name]	Find a service for a specified service type
rosservice uri [service name]	show ROSRPC URI service
rosservice args [service name]	show service parameters
rosservice call [service name] [parameters]	Request service with input parameters

1.2 Topic

Enter in the command line:

```
source <ros-workspace>/devel/setup.bash
roslaunch mycobot_communication communication_topic.launch
```

Support parameters:

- port: concatenate serial string
- baud: baud rate

Open a new command line:

```
# Display active service information
rostopic list

#/mycobot/angles_goal
#/mycobot/coords_goal
#/mycobot/angles_real
#/mycobot/coords_real
#/mycobot/pump_status
#/mycobot/gripper_status
```

Related commands and instructions:

Command	Detailed description
rostopic list	Display active topic list
rostopic echo [topic name]	Display the message content of the specified topic in real time
rostopic find [type name]	Display threads with messages of the specified type
rostopic type [topic name]	Displays the message type of the specified topic
rostopic bw [topic name]	Display the message bandwidth of the specified topic (bandwidth)
rostopic hz [topic name]	Display the message data publishing cycle of the specified topic
rostopic info [topic name]	Display information about the specified topic
rostopic pub [topic name] [message type] [parameters]	Post a message with the specified topic name

The difference between service and topic:

	service	topic
Synchronization	Asynchronous	Synchronous
communication model	pub/sub	server/client
underlying protocol	ROSTCP/ROSUDP	ROSTCP/ROSUDP
Feedback Mechanism	No	Yes

	service Yes	topic No
buffer		
Real-time	Weak	Strong
Node Relationship	Many-to-Many	One-to-Many
Applicable Scenarios	Data Transmission	Logical Processing

you can go to [service](#) and [topic](#) learn more about the use of these two features

2 Introduction to msg and srv

- msg: The msg file is a simple text file describing the fields of a ROS message. They are used to generate source code for messages in different languages (c++ or python, etc.).
- srv: srv files are used to describe services. It consists of two parts: the request (request) and the response (response). msg files are stored in the msg directory of the package, and srv files are stored in the srv directory.

2.1 rosmmsg

rosmmsg is a command line tool for displaying information about ROS message types.

rosmmsg demo:

```
rosmmsg show      # Show message description
rosmmsg info      # Display message information
rosmmsg list      # list all messages
rosmmsg md5       # Display md5 encrypted message
rosmmsg package   # Display all messages under a feature pack
rosmmsg packages  # List feature packs that contain messages
```

- rosmmsg list will list all msgs in the current ROS
- rosmmsg packages List all packages containing messages
- rosmmsg package List all msgs under a package

```
//rosmmsg package # Package names
rosmmsg package turtlesim
```

- rosmmsg show Show message description

```
//rosmmsg show # message name
rosmmsg show turtlesim/Pose
# result:
float32 x
float32 y
float32 theta
float32 linear_velocity
float32 angular_velocity
```

- rosmmsg info Works the same as rosmmsg show
- rosmmsg [md5](#) A check algorithm to ensure the consistency of data transmission

2.2 rossrv

rossrv is a command-line tool for displaying information about ROS service types, and uses a syntax that is highly similar to rosmmsg.

```
rossrv show      # Display service message details
rossrv info      # Display information about service messages
rossrv list      # List all service information
rossrv md5       # Display md5 encrypted service messages
rossrv package   # Display all service messages under a package
rossrv packages  # Show all packages that contain service messages
```

- rossrv list Will list all srv messages in the current ROS
- rossrv packages List all packages that contain service messages
- rossrv package List all msgs under a package

```
//rossrv package # Package names
rossrv package turtlesim
```

- rossrv show Show message description

```
//rossrv show # message name
rossrv show turtlesim/Spawn
# result:
float32 x
float32 y
float32 theta
string name
---
string name
```

- rossrv info The effect is the same as rossrv show
- rossrv md5 Use md5 checksum (encryption) for service data

3 Introduction to URDF

- Unified Robot Description Format, Unified Robot Description Format, abbreviated as URDF. The urdf package in ROS contains a C++ parser for URDF, and URDF files describe robot models in XML format. *URDF cannot be used alone, it needs to be combined with Rviz or Gazebo. URDF is just a file that needs to be rendered into a graphical robot model in Rviz or Gazebo.

3.1 urdf file description

Code example:

Only part of the code is intercepted here for display:

```
<?xml version="1.0"?>
<robot xmlns:xacro="http://www.ros.org/wiki/xacro" name="mycobot_ai_with" >

  <xacro:property name="width" value=".2" />
```

```

<link name="env">
<inertial>
  <origin xyz="0 0 0" rpy="0 0 0"/>
  <mass value="10"/>
  <inertia
    ixx="1.0" ixy="0.0" ixz="0.0"
    iyy="1.0" iyz="0.0"
    izz="1.0"/>
</inertial>
<visual>
  <geometry>
    <!-- 0.0 0 -0.04 1.5708 3.14159-->
    <mesh
filename="package://mycobot_description/urdf/mycobot/suit_env.dae"/>
    </geometry>
    <origin xyz = "0 0 0.0" rpy = "1.5708 0 -1.5708"/>
  </visual>
</link>

<link name="joint1">
<inertial>
  <origin xyz="0 0 0.1" rpy="0 0 0"/>
  <mass value="0.2"/>
  <inertia
    ixx="1.0" ixy="0.0" ixz="0.0"
    iyy="1.0" iyz="0.0"
    izz="1.0"/>
</inertial>
<visual>
  <geometry>
    <!-- 0.0 0 -0.04 1.5708 3.14159-->
    <mesh filename="package://mycobot_description/urdf/mycobot/joint1.dae"/>
  </geometry>
  <origin xyz = "0.0 0 0.02 " rpy = " 0 0 -1.5708"/>
</visual>
<collision>
  <geometry>
    <!-- 0.0 0 -0.04 1.5708 3.14159-->
    <mesh filename="package://mycobot_description/urdf/mycobot/joint1.dae"/>
  </geometry>
  <origin xyz = "0.0 0 0.02 " rpy = " 0 0 -1.5708"/>
</collision>
</link>

<joint name="vision_joint" type="fixed">
  <axis xyz="0 0 0"/>
  <limit effort = "1000.0" lower = "-3.14" upper = "3.14159" velocity = "0"/>
  <parent link="env"/>
  <child link="joint1"/>
  <origin xyz= "0 0 0" rpy = "0 0 0"/>
</joint>

<link name="world"/>
<joint name="fixed" type="fixed">

```

```

    <parent link="world"/>
    <child link="env"/>
  </joint>

</robot>

```

It can be seen that the urdf file is not complicated, it is mainly composed of two parts, `link` and `joint`, which are repeated continuously.

3.2 link section

The link element describes a rigid body with inertial, visual features, and collision properties

3.2.1 Attributes

name: The name used to describe the link itself

3.2.2 element

- `<inertial>`

(optional)

- Inertia properties of connecting rods

- `<origin>`

(optional, defaults to identity if not specified)

- Defines the reference coordinate of the inertial reference system relative to the connecting rod coordinate system. The coordinate must be defined at the center of gravity of the connecting rod, and its coordinate axis may not be parallel to the main axis of inertia.
- xyz (optional, defaults to zero vector) Represents the offset in the x , y , z x,y,zx,y,z directions, in meters.
- rpy(optional: defaults to identity if not specified) Indicates the rotation of the coordinate axis in the RPY direction, in radians.
- `<mass>` Mass properties of connecting rods
- `<inertia>` 3×3 rotational inertia matrix, consisting of six independent quantities: ixx , ixy , ixz , iyx , iyz , izz .

- `<visual>`

(optional)

- Visual properties of the connecting rod. It is used to specify the shape of the link display (rectangle, cylinder, etc.). There can be multiple visual elements in the same link, and the shape of the link is formed by two elements. In general, the model is more complex and can be drawn through solidworks to generate stl calls, and simple shapes such as adding end effectors can be directly written. At the same time, the position of the

geometry can be adjusted according to the gap between the theoretical model and the actual model.

- `<name1>` (optional) The name of the connecting rod geometry.
- `<origin>`

(optional, defaults to identity if not specified)

- The geometry coordinate system relative to the coordinate system of the connecting rod.
- xyz (optional: defaults to zero vector) Represents the offset in the x , y , z x,y,zx,y,z directions, in meters.
- rpy (optional: defaults to identity if not specified) Indicates the rotation of the coordinate axis in the RPY direction, in radians.

- `<geometry>`

(required)

- The shape of the visualization, which can be one of the following:
- `<box>` A rectangle with elements including length, width, and height. The origin is in the center.
- `<cylinder>` Cylinder, elements include radius and length. center of origin.
- `<sphere>` Sphere, element containing the radius. The origin is in the center.
- `<mesh>` The grid, as determined by the file, also provides a scale to define its boundaries. Collada .dae files are recommended, .stl files are also supported, but must be a local file.

- `<material>`

(optional)

- Visualize the component's material. It can be defined outside the link tag, but it must be inside the robot tag. When defining outside the link tag, the name of the link must be quoted.
- `<color>` (optional) Color, consisting of red/green/blue/alpha, in the range [0,1].
- `<texture>` (optional) Material properties, defined by the file.

- `<collision>`

(optional)

- Collision properties of the link. Collision properties differ from visual properties of connecting rods, and simple collision models are often used to simplify calculations. The same link can have multiple collision attribute labels, and the collision attribute representation of the link is composed of the set of geometric shapes defined by it.
- `<name>` (optional) Specifies the name of the connecting rod geometry

- `<origin>`

(optional, defaults to identity if not specified)

- The reference coordinate system of the collision component is relative to the reference coordinate system of the link coordinate system.
- xyz (optional, default zero vector) Represents the offset in the x , y , z x,y,zx,y,z directions, in meters.
- rpy (optional, defaults to identity if not specified) Indicates the rotation of the coordinate axis in the RPY direction, in radians.
- `<geometry>` Same as the geometry element description above

Detailed elements and the role of each element can go to [official documentation](#) to view

3.3 joint part

The joint section describes the kinematics and dynamics of the joint and specifies safety limits for the joint.

3.3.1 properties of joint:

name:

Specifies a unique name for the joint

type:

Specifies the type of joint, where type can be one of the following:

- revolute - A hinged joint that rotates along an axis, the range of which is specified by the upper and lower bounds.
- Continuous - A continuous hinged joint that rotates around an axis with no upper and lower bounds.
- Prismatic - A sliding joint that slides along an axis, the range of which is specified by upper and lower limits. +Fixed - this is not really a joint because it cannot move. All degrees of freedom are locked. This type of joint does not require axes, calibration, dynamics, limits or safety_controller.
- Floating - This joint allows motion in all 6 degrees of freedom.
- Plane - This joint allows movement in a plane perpendicular to the axis.

3.3.2 elements of joint

- `<origin>` (optional, defaults to identity if not specified) In the transformation from parent link to child link, the joint is located at the origin of the child link. Modifying this parameter can adjust the position of the connecting rod. It can be used to adjust the error between the actual model and the theoretical model, but it is not recommended to modify it greatly, because this parameter affects the connecting rod stl The position of , easily affects the collision detection effect.
 - xyz (optional: default to zero vector) Represents the offset in the x , y , z x,y,zx,y,z axis directions, in meters.
 - rpy (optional: default to zero vector) Represents the angle of rotation around a fixed axis: roll is around the x-axis, pitch is around the y-axis, and yaw is around the z-axis, expressed in radians.

- `<parent>` (required)
 - The name of the parent link is a mandatory attribute.
 - link The name of the parent link is the name of the link in the robot structure tree.
- `<child>` (required)
 - The name of the child link is a mandatory attribute.
 - link The name of the child link is the name of the link in the robot structure tree.
- `<axis>` (optional: defaults to (1,0,0))
 - The joint's axis is in the joint's coordinate system. This is the axis of rotation (revolute joint), the axis of movement of the prismatic joint, and the standard plane of the planar joint. This axis is specified in the joint coordinate system. Modifying this parameter can adjust the axis around which the joint rotates. It is often used to adjust the rotation direction. If the model rotation is opposite to the actual one, just multiply by -1. Fixed and floating joints do not need this element.
 - xyz(required) x , y , z x, y, zx, y, z components representing axis vectors, as normalized vectors.
- `<calibration>` (optional)
 - The reference point of the joint, used to correct the absolute position of the joint.
 - rising (optional) When the joint is moving forward, the reference point triggers a rising edge.
 - falling (optional) When the joint is moving forward, the reference point triggers a falling edge.
- `<dynamics>` (optional)
 - This element is used to specify the physical properties of the joint. Its value is used to describe the modeling performance of the joint, especially during simulation.

`<limit>` (Required when the joint is a rotation or translation joint)

- This element is a joint kinematics constraint.
- lower (optional, default to 0) Specify the attribute of the lower bound of the joint's motion range (the unit of the revolute joint is radians, and the unit of the prismatic joint is meters). This attribute is ignored for continuous joints.
- upper (optional, defaults to 0) Specify the attribute of the upper bound of the joint's motion range (the unit of the revolute joint is radians, and the unit of the prismatic joint is the meter). This attribute is ignored for continuous joints.
- effort (required) This property specifies the maximum force at which the joint will run.
- velocity (required) This property specifies the maximum speed of the joint runtime.

`<mimic>` (optional)

- This tag is used to specify a defined joint to mimic an existing joint. The value of this joint can be calculated using the following formula: $\text{value} = \text{multiplier} * \text{other_joint_value} + \text{offset}$
- joint(required) The name of the joint to mimic.
- multiplier(optional) Specify the multiplier factor in the above formula.
- offset(optional) Specify the offset term in the above formula. Default value is 0

`<safety_controller>` (optional)

- This element is a security control limit. The data under this element will be read into move_group, but it is invalid in practice. Move_group will skip this limit and directly read the

parameter content under limit. At the same time, setting this element may cause planning failure.

- `soft_lower_limit` (optional, defaults to 0) This attribute specifies the lower bound of the joint security control boundary, which is the starting limit point of the joint security control. This value needs to be greater than the lower value in the above limit.
- `soft_upper_limit` (optional, defaults to 0) This attribute specifies the upper bound of the joint security control boundary, which is the starting limit point of the joint security control. This value needs to be less than the upper value in the above limit.
- `k_position` (optional, defaults to 0) This attribute is used to describe the relationship between position and velocity.
- `k_velocity` (required) This property is used to describe the relationship between force and velocity.

Detailed elements and the role of each element can go to <http://wiki.ros.org/urdf/XML/joint> to view.