

# Swinging Arms Left and Right

---

## *Preparation*

M5Stack series: Make sure robot is connected with PC.

Other series: Make sure the robot is in normal status.

## Purpose for this section

---

This section introduces instructions for swinging arms left and right.

## Introduction to API

- `power_on()`




- Applicable to myCobot 280 series, mechArm series, myCobot 320 series and myPalletizer series
- Function: initiate system
- `release_all_servos()`



- Applicable to myCobot 280 series, mechArm series, myCobot 320 series and myPalletizer series
- Function: set robot arm into free moving mode

## Simple Demo

- Program for display:



- Motion:

Initiating system, arms move to starting point, after 2 seconds,

Joint 1 move to 50 degree at the speed of 20, after 2 seconds,

Joint 2 move to -50 degree at the speed of 20, after 2 seconds,

the above process loops again,

Joint 1, Joint 2, Joint 3 and Joint 4 move to 130 degree, 80 degree, -60 degree and 100 degree respectively.

Motion stops, and then all servos release.