

Joint control

1 Single joint control

`send_angle`

description: set the angle of a specified joint

parameters:

1.id, the number corresponding to a joint; for six axes, it is within 1-6; for four axes, it is within 1-4

2.degree: joint angle value to be set

3.speed: 0-100, the speed at which the joint moves to a specified angle to complete instructions

returned value: none

2 Multi joint control

`send_angles`

description: set the angles of six axes

parameters:

1.degrees: including the angles of all joints, and having a length of 6

2.speed: 0~100, the speed at which the joint moves to a specified angle to complete instructions

returned value: none