
 Choose Language (Translated by google)



Bed Auto Leveling Feature Use and Debug Guide for PL-08N bed leveling sensor

Wiring

1. Connect the PL-08N to the Z+(ZRIBV6) or Z1+(ZM3E4) connector on the control board.
2. Power on the 3d printer (or control board).
3. The LED of PL-08N should light up When it is closed to the hot bed, the LED should turn off when it is far away from the hotbed.




ZRIB V6.0



Near, light on



Far, light off




ZM3E4

Install

1. Move HOTEND to the middle of hot bed and adjust height of HOTEND or print platform, let the nozzle almost touched hot bed.

2. Install the Proximity sensor on the HOTEND. The bottom of the sensor should be approximately 2-4



mm above the nozzle.

⚠ The sensing distance of PL-08N to aluminum plate is about 3 ~ 5mm, and to stainless steel is 5 ~ 8mm. If you use a PEI stainless steel hot bed film, please raise the installation position to 4 ~ 6mm from the bottom of the nozzle.

Video Tutorial

Level Corners



📢 The automatic bed leveling function is used to correct the relative offset of different positions on the hot bed at the Z-axis height, not the absolute value. Before executing Bed Auto Leveling, you must perform **Level Corners** to make the machine obtain a correct absolute value of the starting point of Z axis (it is so called **Z axis absolute zero point** of the machine). Steps as below:

1. Make sure the hotbed and nozzle are cool, clean the filament on the nozzle.
2. Turn on the 3d printer.
3. Do **Control>>Config>>Auto Leveling: OFF**, if it is **OFF**, set to **ONF**.



4. Do **Prepare>>Bed Leveling>>Auto Home** on LCD screen.
5. Do **Prepare>>Bed Leveling>>Point1** on LCD screen.
6. Adjust the screws under the hotend, let the nozzle almost to touch the hotbed(Fig4).
7. Do **Prepare>>Bed Leveling>>Point 2/3/4** on LCD screen and Adjust the screws under the hotend, let the nozzle almost touched the hotbed.

8. Perform at least 2 cycles to confirm that the screws at the bottom of the hot bed have been adjusted.



After level coners, print "level_test_310.gcode" from SD card, and check if the hotbed is enough level.



Press the knob twice within one second to open the babysteps menu, and then rotate the knob to fine tune the distance from nozzle to hotbed.



Catch Probe Z offset

"**Probe Z Offset**" indicates that when the sensor sensed the hot bed, the distance between the nozzle and the Z axis absolute zero point.

If the sensor is installed correctly, the nozzle is always above the hot bed when the sensor sensed the hot bed, so **Probe Z Offset** is always a negative value. Since the sensing distance of each PL-08N sensor is different, and the actual installation height of PL-08N is also different, the **Probe Z Offset** of each machine is different too.

You need to do **Catch Z offset** to get the **Probe Z Offset** before doing bed auto leveling. Steps as below:

1. Do **Prepare>> Bed Leveling>>Catch Z-Offset**

2. Wait the catching done, and then check the Z Probe offset on menu **Montion>> Bed Leveling>> Probe Z Offset(Fig3).**



PS: if the HOME Z OFFSET is over(\geq) 2mm, it will remind to remove the glass first. If you doesn't use a glass bed, please check the settings of HOME Z OFFSET.

- ⚠ If "Catch Probe Z offset" fail, check if the probe installed too high.
- ⚠ The Probe Z offset value of your machine may be different from the above picture.

Level Bed

After completing the above steps, we have a reliable sensor to measure the hotbed surface and already set all its parameters. Now we need the machine to make a comprehensive measurement of the surface of the hot bed, so as to get a data sheet of the hot bed height on the surface.

- Do **Prepare>> Bed Leveling>>Auto Leveling**. After measure done, the state of Auto leveling on Leveling menu will change from Unactivated to Activated.



⚠ Note:

1. The measurement result should be between -1.0 to 1.0 mm. If it exceeds, it is recommended that you try to fine tune the printer or improve the flatness of the hotbed, because it may affect the printing quality.
2. If it is found that there is a large deviation in data arrangement between the Left/Right sides or the Front/Back sides, please adjust the bottom screw of the hotbed (when the data is + turn down the

hotbed, when the data is - turn up the hotbed)

Verification

Now you can try to print a test file to verify the bed auto leveling result. Steps as below:

1. Copy level_test_310.gcode to SD card and print it from SD card.
2. When printing started, double click (click twice in one second) the knob to open baby Z offset menu.
3. Rotate the knob and watch the nozzle, let the nozzle is higher than the hotbed about 0.3mm.



Apply bed auto leveling

1 Auto leveling feature will be disable automatically when the printer reset, you can turn it on manually:


1. Do **Prepare>>Auto Home>>Home All**
2. Do **Prepare>>Bed Leveling>>Active Autolevel: OFF Change to ON**



ATTENTION: After do these 2 steps, the printer will apply the hotbed auto leveling correction by using the stored parameters in the last time.

2 You can also add command to the "Start Gcode" of slicer, let the printer do bed auto leveling when printing from SD card.

You can also add a G29 command following the G28 command to the "start gcode" of slicing software, it will execute "bed auto leveling" in the star of printing.



⚠ ATTENTION PLEASE

If the following conditions occur, the parameters of the hot bed leveling table may change, you need to repeat all steps starting from **level Corners** to get the bed auto leveling data again.

1. Adjust the screws at the bottom of the hot bed.
2. The print head was reinstalled causing the nozzle height to change.
3. The installation position of the sensor has changed.
4. Replace a hotend sticker.
5. Reset the NVRAM of the control board.
6. Other.