




DWIN LCD MENU Description

DWIN LCD Menu Description

•Main Menu



Title	
LOGO	
Print from SD card	Contrll for Prepare to print
Printer Setting	Printer Information
Nozzle Temperature	Hotbed Temperature
Printing Speed	Current Z position


DWIN LCD Menu Description

•Printing status Menu




Title		
Printng file name and Progress bar		
Extruder Mix Rate and Auto Mixing mode		
Printed timer and Remain timer		
Printting controller		
Setting	Pasue&Resume Printing	Stop Printing
Nozzle Temperature		Hotbed Temperature
Printing Speed		Current Z position
Status Message Bar		

DWIN LCD Menu Description



DWIN LCD Menu Description



DWIN LCD Menu Description

Tune

Tuen menu only disply when print from SD card

Speed

Tune the ratio of printing speed

Hotend Temp

Tune Nozzle temperature

Bed Temp

Tune bed temperature

Fan Speed

Tune Extruder FAN Speed

Z Offset

Tune nozzle (or Bed) height

Double click the knob twice with in one second will open
BabySteps menu

BabySteps

Mixer

Tune mixer settings, refer to "Control>> Mixer" Menu

configure

Tune ON/OFF some features, refer to "Control>> Configure"
Menu