




Lenovo Legion Y530-15ICH Wireless LAN Card Replacement

How to replace the Wireless LAN Card in a Lenovo Y530-15ICH.

Written By: Christopher Nguyen



INTRODUCTION

A wireless LAN card is the part of a laptop that allows wireless access to a network. With one, you do not need a direct connection using an Ethernet cable. The wireless LAN card is responsible for the connection, speed, and stability in staying connected with a network. If your wireless connection is unstable or disconnecting randomly, then it might be time to replace your card.


This guide is to help replace a faulty wireless LAN card in the Lenovo Legion Y530-15ICH.




TOOLS:

- [Phillips #0 Screwdriver](#) (1)
 - [1 x Opening Picks](#) (1)
-

Step 1 — Wireless LAN Card




 Make sure your computer is turned off.


- Remove the five 7 mm screws using a Phillips #0 screwdriver.
- Remove the six 4 mm screws using a Phillips #0 screwdriver.

Step 2



- Slowly and carefully pry off the backside of the computer using an opening pick.
-  You can start from the corner or sides of computer. Slowly work around the computer until it completely detaches.

Step 3



- Detach the two antenna wires attached to the wireless LAN card.

Step 4




- Remove the single 4 mm screw using a Phillips #0 screwdriver.
- Remove the wireless LAN card.

Step 5




- Insert the new wireless LAN card.
- Re-insert the 4 mm screw using Phillips #0 screwdriver.
- ① It's normal for the wireless LAN card to pop up slightly. It will fit into place when you screw it back in.

Step 6



- Re-attach the black antenna cable to the top pin on the wireless LAN card.
- Re-attach the white antenna cable to the bottom pin on the wireless LAN card.

Step 7



- Snap the back cover onto the laptop.
- Using a Phillips #0 screwdriver, re-insert the five 7mm screws.
- Using a Phillips #0 screwdriver, re-insert the six 4mm screws.

After replacing the faulty wireless LAN card, you should be able to connect to a wireless network connection. The connection should be stable and not randomly disconnecting. If this doesn't fix your problem, then you may have to check the router or wireless connection point.