

GNSS SDK

Commands Manual

GNSS Module Series

Rev. GNSS_SDK_Commands_Manual_V1.3

Date: 2016-08-15



Our aim is to provide customers with timely and comprehensive service. For any assistance, please contact our company headquarters:

Quectel Wireless Solutions Co., Ltd.

Office 501, Building 13, No.99, Tianzhou Road, Shanghai, China, 200233

Tel: +86 21 5108 6236

Email: info@quectel.com

Or our local office. For more information, please visit:

<http://www.quectel.com/support/salesupport.aspx>

For technical support, or to report documentation errors, please visit:

<http://www.quectel.com/support/techsupport.aspx>

Or email to: Support@quectel.com

GENERAL NOTES

QUECTEL OFFERS THE INFORMATION AS A SERVICE TO ITS CUSTOMERS. THE INFORMATION PROVIDED IS BASED UPON CUSTOMERS' REQUIREMENTS. QUECTEL MAKES EVERY EFFORT TO ENSURE THE QUALITY OF THE INFORMATION IT MAKES AVAILABLE. QUECTEL DOES NOT MAKE ANY WARRANTY AS TO THE INFORMATION CONTAINED HEREIN, AND DOES NOT ACCEPT ANY LIABILITY FOR ANY INJURY, LOSS OR DAMAGE OF ANY KIND INCURRED BY USE OF OR RELIANCE UPON THE INFORMATION. THE INFORMATION SUPPLIED HEREIN IS SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.

COPYRIGHT

THE INFORMATION CONTAINED HERE IS PROPRIETARY TECHNICAL INFORMATION OF QUECTEL CO., LTD. TRANSMITTING, REPRODUCTION, DISSEMINATION AND EDITING OF THIS DOCUMENT AS WELL AS UTILIZATION OF THE CONTENT ARE FORBIDDEN WITHOUT PERMISSION. OFFENDERS WILL BE HELD LIABLE FOR PAYMENT OF DAMAGES. ALL RIGHTS ARE RESERVED IN THE EVENT OF A PATENT GRANT OR REGISTRATION OF A UTILITY MODEL OR DESIGN.

Copyright © Quectel Wireless Solutions Co., Ltd. 2016. All rights reserved.

About the Document

History

Revision	Date	Author	Description
1.0	2015-09-11	Hyman DING	Initial
1.1	2016-01-18	Connie ZHOU	Added the current supported SDK commands in Table 1.
1.2	2016-05-20	Simon HU	<ol style="list-style-type: none">1. Added the following new commands: PQECEP, PQODO, PQPZ90, PQGLP, PQVEL.2. Added L76 and L76-L in Table 1.3. Added the Chapter 3: Appendix References.
1.3	2016-08-15	Simon HU	<ol style="list-style-type: none">1. Added L26 in Table 1.2. Improved the function of PQODO to enable initial distance setting.

Contents

About the Document.....	2
Contents.....	3
Table Index.....	4
1 Introduction	5
2 Quectel NMEA Packet Protocol.....	6
2.1. Quectel NMEA Packet Format	6
2.2. PQBAUD Change NMEA Port Default Baudrate	7
2.3. PQEPE Enable/Disable PQEPE Sentence Output	7
2.4. PQ1PPS Set the Type and Pulse Width of 1PPS's Output	8
2.5. PQFLP Set the Module into FLP Mode	9
2.6. PQTXT Enable/Disable GPTXT Sentence Output	10
2.7. PQECEF Enable/Disable ECEFPOSVEL Sentence Output	11
2.8. PQODO Start/Stop Odometer Reading	12
2.9. PQPZ90 Enable/Disable Switching from WGS84 to PZ-90.11	13
2.10. PQGLP Set the Module into GLP Mode	14
2.11. PQVEL Enable/Disable 3 Ways Velocity Sentence Output	15
3 Appendix References	17
3.1. Related Documents	17
3.2. Terms and Abbreviations	17
3.3. Datum Sentence Definition.....	18

Table Index

TABLE 1: CURRENT SUPPORTED SDK COMMANDS.....	5
TABLE 2: RELATED DOCUMENTS	17
TABLE 3: TERMS AND ABBREVIATIONS	17
TABLE 4: DATUM SENTENCE DEFINITION	18

Quectel
Confidential

1 Introduction

Quectel GNSS modules support SDK commands which are defined and developed by Quectel. This document describes these SDK commands. The configuration parameters saved by SDK commands will still exist in flash even after upgrading the modules' firmware.

This document is applicable to Quectel L70, L76, L76-L, L80, L86, and L26 modules. Their supported SDK commands are shown in the table below:

Table 1: Current Supported SDK Commands

SDK Commands	Description	L70	L80	L76	L76-L	L86	L26
PQBAUD	Change NMEA Port Default Baudrate	Y	Y	Y	Y	Y	Y
PQEPE	Enable/Disable PQEPE Sentence Output	Y	Y	Y	Y	Y	Y
PQ1PPS	Set the Type and Pulse Width of 1PPS's Output	Y	Y	Y	Y	Y	Y
PQFLP	Set the Module into FLP(Fitness Low Power) Mode	Y	Y	N	N	N	N
PQTXT	Enable/Disable GPTXT Sentence Output	N	Y	N	N	Y	Y
PQECEF	Enable/Disable ECEFPOSVEL Sentence Output	N	N	Y	Y	N	Y
PQODO	Start/Stop Odometer Reading	N	N	Y	Y	N	Y
PQPZ90	Enable/Disable Switching from WGS84 to PZ-90.11	N	N	Y	Y	N	Y
PQGLP	Set the Module into GLP (GNSS Low Power) Mode	N	N	Y	Y	N	Y
PQVEL	Enable/Disable 3 Ways Velocity Sentence Output	N	N	Y	Y	N	Y

NOTES

1. Y means supported; N means not supported.
2. For more details about the usage of **\$PQFLP** and **\$PQGLP** commands, please refer to **document [1]**.

2 Quectel NMEA Packet Protocol

This chapter introduces the Quectel NMEA packet protocol which is a set of extension messages of the standard NMEA packet protocol. These messages are used to control and configure Quectel L70, L76, L76-L, L80, L86, and L26 modules.

The structure of Quectel NMEA packet is shown as below:

2.1. Quectel NMEA Packet Format

Preamble	TalkerID	PktType	DataField	*	CHK1	CHK2	CR	LF
----------	----------	---------	-----------	---	------	------	----	----

*The maximum length of each packet is restricted to 255 bytes.

Packet Contents:

Preamble: One byte character.

‘\$’

TalkerID: Two bytes character string.

“PQ”

PktType: 1-10 bytes character string.

An identifier used to tell the decoder how to decode the packet.

DataField: The DataField has variable lengths depending on the packet type.

A command symbol ‘,’ must be inserted ahead of each data field to help the decoder process the DataField.

*: 1 byte character.

The star symbol is used to mark the end of DataField.

CHK1,CHK2: Two bytes character string.

CHK1 and CHK2 are the check sum of the data between Preamble and ‘*’.

CR,LF: Two bytes binary data.

The two bytes are used to identify the end of a packet.

2.2. PQBAUD Change NMEA Port Default Baudrate

PQBAUD Change NMEA Port Default Baudrate

Write Command \$PQBAUD,W,<baudrate>*Checksum<CR><LF>	Response \$PQBAUD,W,OK*Checksum<CR><LF> If error \$PQBAUD,W,ERROR*Checksum<CR><LF>
Reference	

Parameter

<baudrate>	NMEA port baudrate. 9600 by default; could be set to 4800, 14400, 19200, 38400, 57600 and 115200
-------------------------	---

Example

```
$PQBAUD,W,115200*43 //Change NMEA port default baudrate to 115200
$PQBAUD,W,OK*40 //Set OK
```

NOTES

1. The command will be effective immediately after setting.
2. Parameter is automatically saved.
3. If you change the baudrate, then there is no response returned in the current baudrate.

2.3. PQEPE Enable/Disable PQEPE Sentence Output

The packet enables/disables output of the URC including EPE data, that is, estimated horizontal and vertical position errors.

PQEPE Enable/Disable PQEPE Sentence Output

Write Command \$PQEPE,W,<mode>,<save>*Checksum<CR><LF>	Response \$PQEPE,W,OK*Checksum<CR><LF> If error \$PQEPE,W,ERROR*Checksum<CR><LF>
URC Message	\$PQEPE,<EPE_hori>,<EPE_vert>*Checksum<CR><LF>

	<p>Parameter</p> <p><EPE_hori> Estimated horizontal position error</p> <p><EPE_vert> Estimated vertical position error</p> <p>Example</p> <p>\$PQEPE,5.3050,3.2000*53</p>
Reference	

Parameter

<mode>	<p>Operation</p> <p>0 Disable the URC including EPE data</p> <p>1 Enable the URC including EPE data</p>
<save>	<p>Save operation</p> <p>0 Parameter is not saved, ineffective after restart</p> <p>1 Parameter is saved in flash, effective after restart</p>

Example

```
$PQEPE,W,1,1*2A //Enable the URC including EPE data, and save parameter in flash
$PQEPE,W,OK*02 //Set OK
```

NOTE

The command will be effective immediately after setting.

2.4. PQ1PPS Set the Type and Pulse Width of 1PPS's Output

PQ1PPS Set the Type and Pulse Width of 1PPS's Output

<p>Write Command</p> <p>\$PQ1PPS,W,<type>,<width>*Checksum<CR><LF></p>	<p>Response</p> <p>\$PQ1PPS,W,OK*Checksum<CR><LF></p> <p>If error</p> <p>\$PQ1PPS,W,ERROR*Checksum<CR><LF></p>
Reference	

Parameter

<type>	The type of 1PPS's output 0 Disable 1PPS output 1 Send 1PPS after the first fix 2 Send 1PPS after 3D fix 3 Send 1PPS after 2D fix 4 Send 1PPS always
<width>	PPS pulse width in millisecond Range: 2-998

Example

```
$PQ1PPS,W,4,100*1D //Set the type of 1PPS's output and PPS pulse width
$PQ1PPS,W,OK*30 //Set OK
$PQ1PPS,W,0,0*18 //Disable 1PPS output
$PQ1PPS,W,OK*30 //Set OK
```

NOTES

1. The command will be effective immediately after setting.
2. Parameter is automatically saved.
3. If **<type>** is set as 0, **<width>** could be set as 0, 1, 2-998.

2.5. PQFLP Set the Module into FLP Mode

PQFLP Set the Module into FLP Mode

Write Command \$PQFLP,W,<mode>,<save>*Checksum m<CR><LF>	Response \$PQFLP,W,OK*Checksum<CR><LF> If error \$PQFLP,W,ERROR*Checksum<CR><LF>
Read Command \$PQFLP,R*Checksum<CR><LF>	Response \$PQFLP,R,<mode>*Checksum<CR><LF>
Reference	

Parameter

<mode>	Module operation mode 0 Normal mode
---------------------	--

	1	FLP mode
<save>		Save operation
	0	Parameter is not saved, ineffective after restart
	1	Parameter is saved in flash, effective after restart

Example

```
$PQFLP,W,1,1*20 //Change to FLP mode
$PQFLP,W,OK*08 //Set OK

$PQFLP,R*25 //Read mode
$PQFLP,R,1*38 //Read OK, FLP mode enabled
```

NOTE

The command will be effective immediately after setting.

2.6. PQTXT Enable/Disable GPTXT Sentence Output

PQTXT Enable/Disable GPTXT Sentence Output

Write Command	Response
\$PQTXT,W,<mode>,<save>*Checksum m <CR><LF>	\$PQTXT,W,OK*Checksum<CR><LF>
	If error
	\$PQTXT,W,ERROR*Checksum<CR><LF>
URC Message	\$GPTXT,01,01,02,<status>*Checksum<CR><LF>
	Parameter
	<status> Status of antenna
	ANTSTATUS=OK: antenna is well connected
	ANTSTATUS=OPEN: antenna has been disconnected
	ANTSTATUS=SHORT: antenna is short-circuited
	Example
	\$GPTXT,01,01,02,ANTSTATUS=OK*3B
Reference	

Parameter

<mode>	Operation
	0 Disable GPTXT sentence output 1 Enable GPTXT sentence output
<save>	Save operation
	0 Parameter is not saved, ineffective after restart 1 Parameter is saved in flash, effective after restart

Example

```
$PQTXT,W,1,1*22      //Enable GPTXT sentence output and save parameter in flash
$PQTXT,W,OK*0A        //Set OK
```

NOTE

The command will be effective immediately after setting.

2.7. PQECEF Enable/Disable ECEFPOSVEL Sentence Output

PQECEF Enable/Disable ECEFPOSVEL Sentence Output	
Write Command \$PQECEF,W,<mode>,<save>*ChkSum<CR><LF>	Response \$PQECEF,W,OK*ChkSum<CR><LF> If error \$PQECEF,W,ERROR*ChkSum<CR><LF>
Read Command \$PQECEF,R*ChkSum<CR><LF>	Response \$PQECEF,R,<mode>*ChkSum<CR><LF>
URC Message	\$ECEFPOSVEL,<time>,<x>,<y>,<z>,<v_x>,<v_y>,<v_z>*ChkSum<CR><LF> Parameter <div> <div><time></div> <div>UTC from the internal real-time clock</div> <div><x></div> <div>the value of X axis in ECEF</div> <div><y></div> <div>the value of Y axis in ECEF</div> <div><z></div> <div>the value of Z axis in ECEF</div> <div><v_x></div> <div>velocity component of X axis in ECEF</div> <div><v_y></div> <div>velocity component of Y axis in ECEF</div> <div><v_z></div> <div>velocity component of Z axis in ECEF</div> </div>

	Example \$ECEFPOSVEL,052743.000,-1526672.867459,6191083.982 801,143008.780911,0,0,0*14
Reference	

Parameter

<mode>	Operation 0 Disable ECEFPOSVEL sentence output 1 Enable ECEFPOSVEL sentence output
<save>	Save operation 0 Parameter is not saved, ineffective after restart 1 Parameter is saved in flash, effective after restart

Example

```
$PQCECF,W,1,1*7F // Enable ECEFPOSVEL sentence output, and save parameter in flash
$PQCECF,W,OK*57 // Set OK
$PQCECF,R*7A // Read mode
$PQCECF,R,1*67 // Read OK, ECEFPOSVEL sentence output enabled
```

NOTE

The command will be effective immediately after setting.

2.8. PQODO Start/Stop Odometer Reading

PQODO Start/Stop Odometer Reading	
Write Command \$PQODO,W,<mode>[,<initial distance>]*ChkSum<CR><LF>	Response \$PQODO,W,OK*ChkSum<CR><LF> If error \$PQODO,W,ERROR*ChkSum<CR><LF>
Read Command \$PQODO,R*ChkSum<CR><LF>	Response \$PQODO,R,<mode>*ChkSum<CR><LF> If error \$PQODO,R,ERROR*ChkSum<CR><LF>
Query Command \$PQODO,Q*ChkSum<CR><LF>	Response \$PQODO,Q,<distance>*ChkSum<CR><LF>

	If error \$PQODO,Q,ERROR*ChkSum<CR><LF>
Reference	

Parameter

<mode>	Start or stop odometer reading 0 Stop odometer reading and remember the distance value. 1 Start odometer reading and initialize the distance according to the <initial distance>.
<initial distance>	Set the initial distance, range [0,1e09], unit: meter. When <mode> is 1, this parameter can be omitted, and its default value is 0. When <mode> is 0, this parameter must be omitted.
<distance>	Current distance. Unit: meter.

Example

```
$PQODO,W,1*23 // Start odometer reading, and initial distance is 0m.
$PQODO,W,OK*16 // Set OK
$PQODO,W,1,1000000*3E // Start odometer reading, and initial distance is 1,000,000m.
$PQODO,W,OK*16 // Set OK
$PQODO,R*3B // Read mode
$PQODO,R,1*26 // Read OK, odometer reading has already been started
$PQODO,Q*38 // Query the distance value
$PQODO,Q,123.45*0B // Current distance value returned
```

NOTES

1. The command will be effective immediately after setting.
2. After module is restarted, the **\$PQODO** write command must be executed again to re-start odometer reading.

2.9. PQPZ90 Enable/Disable Switching from WGS84 to PZ-90.11

PQPZ90 Enable/Disable Switching from WGS84 to PZ-90.11

Write Command \$PQPZ90,W,<mode>,<save>*ChkSum <CR><LF>	Response \$PQPZ90,W,OK*ChkSum<CR><LF> If error
--	--

	\$PQPZ90,W,ERROR*ChkSum<CR><LF>
Read Command \$PQPZ90,R*ChkSum<CR><LF>	Response \$PQPZ90,R,<mode>*ChkSum<CR><LF>
URC Message	\$GNDTM,P90,x,xx.xxxx,x,xx.xxxx,x,xxx,W84*hh<CR><LF> > Parameter definition is available in Table 4.
Reference	Appendix 3.3

Parameter

<mode>	Operation 0 Disable switching from WGS84 to PZ-90.11 1 Enable switching from WGS84 to PZ-90.11
<save>	Save operation 0 Parameter is not saved, ineffective after restart 1 Parameter is saved in flash, effective after restart

Example

```
$PQPZ90,W,1,1*79 // Enable switching from WGS84 to PZ-90.11, and save parameter into flash
$PQPZ90,W,OK*51 // Set OK
$PQPZ90,R*7C // Read mode
$PQPZ90,R,0*60 // Read OK, switching from WGS84 to PZ-90.11 enabled
```

NOTES

1. The command will be effective immediately after setting <save> to 0. However, when <save> is set to 1, it will be effective only after restart.
2. If switching from WGS84 to PZ-90.11 is enabled and effective, the coordinate values in RMC and GGA sentences will be switched to PZ-90.11 after fixing. Also, a DTM sentence will be displayed to identify the datum used.

2.10. PQGLP Set the Module into GLP Mode

PQGLP Set the Module into GLP Mode

Write Command \$PQGLP,W,<mode>,<save>*ChkSum <CR><LF>	Response \$PQGLP,W,OK*ChkSum<CR><LF>
---	---

	If error \$PQGLP,W,ERROR*ChkSum<CR><LF>
Read Command \$PQGLP,R*ChkSum<CR><LF>	Response \$PQGLP,R,<mode>*ChkSum<CR><LF>
Reference	

Parameter

<mode>	Module operation mode 0 Normal mode 1 GLP mode
<save>	Save operation 0 Parameter is not saved, ineffective after restart 1 Parameter is saved in flash, effective after restart

Example

```
$PQGLP,W,1,1*21 // Change to GLP mode
$PQGLP,W,OK*09 // Set OK

$PQGLP,R*24 // Read mode
$PQGLP,R,1*39 // Read OK, GLP mode enabled
```

NOTE

The command will be effective immediately after setting.

2.11. PQVEL Enable/Disable 3 Ways Velocity Sentence Output

PQVEL Enable/Disable 3 Ways Velocity Sentence Output	
Write Command \$PQVEL,W,<mode>,<save>*ChkSum <CR><LF>	Response \$PQVEL,W,OK*ChkSum<CR><LF> If error \$PQVEL,W,ERROR*ChkSum<CR><LF>
Read Command \$PQVEL,R*ChkSum<CR><LF>	Response \$PQVEL,R,<mode>*ChkSum<CR><LF>
URC Message	\$PQVEL,<north_vel>,<east_vel>,<down_vel>*ChkSum<CR><LF>

	Parameter
	<north_vel> North velocity
	<east_vel> East velocity
	<down_vel> Down velocity
	Example
	\$PQVEL,1.000000,2.000000,-0.000000*42
Reference	

Parameter

<mode>	Enable/disable 3 ways velocity sentence output
0	Disable
1	Enable
<save>	Save operation
0	Parameter is not saved, ineffective after restart
1	Parameter is saved in flash, effective after restart

Example

```
$PQVEL,W,1,1*25 // Enable 3 ways velocity sentence output
$PQVEL,W,OK*0D // Set OK

$PQVEL,R*20 // Read mode
$PQVEL,R,1*3D // Read OK, 3 ways velocity sentence output enabled
```

NOTE

The command will be effective immediately after setting.

3 Appendix References

3.1. Related Documents

Table 2: Related Documents

SN	Document Name	Remark
[1]	Quectel_GNSS_Low_Power_Mode_Application_Note	GNSS Low Power Mode Application Note

3.2. Terms and Abbreviations

Table 3: Terms and Abbreviations

Abbreviation	Description
1PPS	1 Pulse Per Second
ECEF	Earth-Centered, Earth-Fixed
EPE	Estimated Position Error
FLP	Fitness Low Power
GGA	Global Positioning System Fixed Data
GLP	GNSS Low Power
GNSS	Global Navigation Satellite System
NMEA	National Marine Electronics Association
ODO	Odometer
PZ90	Parametry Zemli 1990

RMC	Recommended Minimum Specific GNSS Data
URC	Unsolicited Result Code
VEL	Velocity

3.3. Datum Sentence Definition

The datum sentence definition for \$GNDTM,xxx,x,xx.xxxx,x,xx.xxxx,x,xxx,xxx*hh<CR><LF> is illustrated below:

Table 4: Datum Sentence Definition

Field	Meaning
1	Local datum code (xxx): W84 – WGS84 W72 – WGS72 S85 – SGS85 P90 – PZ-90
2	Local datum sub code (x)
3	Latitude offset in minutes (xx.xxxx)
4	Latitude offset mark (N: +, S: -) (x)
5	Longitude offset in minutes (xx.xxxx)
6	Longitude offset mark (E: +, W: -) (x)
7	Altitude offset in meters.
8	Datum (xxx): W84 – WGS84 W72 – WGS72 S85 – SGS85 P90 – PZ-90
9	Checksum