

Advanced Card Systems Ltd.



ACR120S Contactless Reader/Writer



APPLICATION PROGRAMMING INTERFACE

Version 1.13 06-2007


Contents

1. Introduction.....	3
2. ACR120.....	4
2.1 Overview	4
2.2 Communication Speed	4
2.3 ACR120 API	4
Interface Function Prototypes	4
2.3.1.1 ACR120_Open	4
2.3.1.2 ACR120_Close.....	5
2.3.1.3 ACR120_Reset	5
2.3.1.4 ACR120_Select.....	6
2.3.1.5 ACR120_Login	7
2.3.1.6 ACR120_Read	9
2.3.1.7 ACR120_ReadValue.....	12
2.3.1.8 ACR120_ReadEEPROM	14
2.3.1.9 ACR120_ReadLowLevelRegister	15
2.3.1.10 ACR120_Write	15
2.3.1.11 ACR120_WriteValue	17
2.3.1.12 ACR120_WriteEEPROM.....	19
2.3.1.13 ACR120_WriteLowLevelRegister.....	20
2.3.1.14 ACR120_WriteMasterKey	20
2.3.1.15 ACR120_Inc.....	21
2.3.1.16 ACR120_Dec	23
2.3.1.17 ACR120_Copy	25
2.3.1.18 ACR120_Power.....	26
2.3.1.19 ACR120_ReadUserPort	27
2.3.1.20 ACR120_WriteUserPort	28
2.3.1.21 ACR120_GetID	29
2.3.1.22 ACR120_ListTag	30
2.3.1.23 ACR120_MultiTagSelect.....	31
2.3.1.24 ACR120_TxDataTelegram.....	32
2.3.1.25 ACR120_RequestVersionInfo	33
2.3.1.26 PICC_InitBlockNumber	34
2.3.1.27 PICC_Xch_APDU.....	36
2.3.1.28 PICC_RATS	37
2.3.1.29 PICC_Deselect.....	38
2.3.1.30 ACR120_ReadATQB	39
2.3.1.31 ACR120_SetFWI.....	40
2.3.1.32 ACR120_FlipUserPort.....	41
Appendix A: Table of Error Codes	42
Appendix B: Sector Number Adaptation on Mifare 4K Card	43
Appendix C: Physical and Logical Block/Sector Calculation.....	44
Mifare 1K.....	44
Mifare 4K.....	44

1. Introduction

This manual describes the use of ACR120 interface software to program the ACR120 readers. It is a set of library functions implemented for the application programmers to operate the ACR120 readers and the presented cards. Currently, it is supplied in the form of 32-bit DLL (for Windows 98/2K/XP). It can be programmed using the popular development tools like Visual C/C++, Visual Basic, Delphi, etc... ACR120 readers can be connected to the PC via the RS/232 interface.

The architecture of the ACR120 library can be visualized as the following diagram:



2. ACR120

2.1 Overview

ACR120 is a set of high-level functions provided for the application software to use. It provides a consistent application-programming interface (ACR120 API) for the application to operate on the ACR120 reader and the corresponding presented card. ACR120 communicates with the ACR120 reader via the communication port facilities provided by the operating system.

2.2 Communication Speed

The ACR120 library controls the communication speed between the reader and the PC. The default communication baud rate (factory setting) is 9600bps, no parity, eight bits and one stop bits. A higher speed of 115200bps can be achieved by using software command issuing from the host. If you are not sure about the factory setting of your readers, you can use the Analyze Reader Function of ACR120 Tools to detect the current ACR120 reader settings.

2.3 ACR120 API

The ACR120 Application Programming Interface (API) defines a common way of accessing the ACR120 reader. Application programs invoke ACR120 reader through the interface functions and perform operations on the presented card.

The header file ACR120.h is available for the program developer, which contains all the function prototypes and macros described below.

Interface Function Prototypes

Generally, a program is required to call ACR120_Open first to obtain a handle. The handle is required for all ACR120 function call except for ACR120_Open.

NOTE: All Card API's involving **SECTOR** and **BLOCK** parameters please refer to appendix C for further explanations.

2.3.1.1 ACR120_OPEN

Format:

```
DLLAPI INT16 AC_DECL ACR120_Open (INT16 ReaderPort,  
                                   INT16 BaudRate);
```

Function Description:

This function opens the port (connection) to ACR120 reader.

Parameters	Description
ReaderPort	The port number where the ACR120 reader is connected. Available choices are "ACR120_COM1" to "ACR120_COM8".
BaudRate	The port baud rate. Available choices are "ACR120_COM_BAUDRATE_9600" to "ACR120_COM_BAUDRATE_115200".
Return Value	INT16 Result code: 0 means success.

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A.

Example:

// open a port to an ACR120 reader connected at COM1 with a baud rate of 9600 bps.

```
INT16 rHandle;

rHandle = ACR120_Open(ACR120_COM1,
                     ACR120_COM_BAUDRATE_9600);
```

2.3.1.2 ACR120_CLOSE**Format:**

```
DLLAPI INT16 AC_DECL ACR120_Close (INT16 rHandle);
```

Function Description:

This function closes the port (connection) to ACR120 reader.

Parameters	Description	
rHandle	The handle to ACR120 reader returned by ACR120_Open	
Return Value	INT16	Result code: 0 means success.

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A.

Example:

// close the port (connection) to ACR120 reader.

```
INT16 RetCode;

RetCode = ACR120_Close (rHandle);
```

2.3.1.3 ACR120_RESET**Format:**

```
DLLAPI INT16 AC_DECL ACR120_Reset (INT16 rHandle, UINT8 stationID);
```

Function Description:

This function resets the reader.

Parameters	Description	
rHandle	The handle to ACR120 reader returned by ACR120_Open.	
stationID	The StationID of ACR120 Reader.	
Return Value	INT16	Result code: 0 means success.

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A.

Example:

```
// reset the reader (reader stationID:1)

INT16 RetCode;

RetCode = ACR120_Reset (rHandle, 1);
```

2.3.1.4 ACR120_SELECT**Format:**

```
DLLAPI INT16 AC_DECL ACR120_Select ( INT16  rHandle,
                                     UINT8   stationID,
                                     BOOL*    pHaveTag,
                                     UINT8*   pTAG,
                                     UINT8   pSN[ACR120_SN_LEN] );
```

Function Description:

This function Selects a single card in range and returns the card ID (Serial Number).

Parameters	Description	
rHandle	The handle to ACR120 reader returned by ACR120_Open.	
stationID	The StationID of ACR120 Reader.	
pHaveTag	Output Variable that will indicate whether the TAG Type Identification is returned: (TRUE) or (FALSE).	
pTAG	Output Variable that will contain the TAG Type Identification if returned (*pHaveTag = TRUE).	
pSN	Output Variable that will contain the card ID (Serial Number), AC_MIFARE_SN_LEN_4 (4 bytes long), AC_MIFARE_SN_LEN_7 (7 bytes long), AC_MIFARE_SN_LEN (10 bytes long).	
Return Value	INT16	Result code. 0 means success.

TAG Type Identification:

Tag Type Value	Tag Type Description	Serial Number Length
0x01	Mifare Light	4
0x02	Mifare 1K	4
0x03	Mifare 4K	4
0x04	Mifare DESFire	7
0x05	Mifare UltrLight	7
0x06	JCOP30	4
0x07	Shanghai Transport	4
0x08	MPCOS Combi	4
0x80	ISO type B, Calypso	4

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A.

Notes:

You have to select the card first before you can Login and manipulate the card.

When there's more than one card in antenna range, you can use ACR120_MultiTagSelect.

Example:

```
// Select a single card in range (reader stationID: 1)
```

```
INT16 RetCode;
```

```
UINT8 SID;
BOOL pHaveTag;
UINT8 pTAG;
UINT8 pSN[3];
CString StrMsg;
```

```
SID = 1;
```

```
RetCode = ACR120_Select (rHandle, SID, &pHaveTag, &pTAG, pSN);
```

```
// Get Serial Number Returned
```

```
StrMsg.Format("Card Serial: %X %X %X %X",pSN[0],pSN[1],pSN[2],pSN[3]);
```

2.3.1.5 ACR120_LOGIN**Format:**

```
DLLAPI INT16 AC_DECL ACR120_Login ( INT16    rHandle,
                                     UINT8     stationID,
                                     UINT8     sector,
                                     UINT8     keyType,
                                     INT        storedNo,
                                     UINT8     pKey[ACR120_KEY_LEN]);
```

Function Description:

This function performs authentication to access one sector of the card. Only one sector can be accessed at a time.

Parameters	Description
rHandle	The handle to ACR120 reader returned by ACR120_Open
stationID	The StationID of ACR120 Reader.
Sector *	The sector number to login in.
keyType	The type of key. It can be: ACR120_LOGIN_KEYTYPE_AA, ACR120_LOGIN_KEYTYPE_BB, ACR120_LOGIN_KEYTYPE_FF, ACR120_LOGIN_KEYTYPE_STORED_A and ACR120_LOGIN_KEYTYPE_STORED_B

storedNo	The stored no. of key to use, IF keyType = ACR120_LOGIN_KEYTYPE_STORED_A or ACR120_LOGIN_KEYTYPE_STORED_B.	
pKey	The login key, IF keyType = ACR120_LOGIN_KEYTYPE_AA or ACR120_LOGIN_KEYTYPE_BB. ACR120_KEY_LEN is 6 bytes long.	
Return Value	INT16	Result code. 0 means success.

* Please refer to Appendix B for logging in Mifare 4K cards.

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A.

Notes:

If keyType = ACR120_LOGIN_KEYTYPE_AA, or
If keyType = ACR120_LOGIN_KEYTYPE_BB,

Then storedNo. will not be used and can be just zero. While pKey must contain the 6 bytes key.

If keyType = ACR120_LOGIN_KEYTYPE_FF

Then the transport code: 0xFF 0xFF 0xFF 0xFF 0xFF 0xFF will be use.

If keyType = ACR120_LOGIN_KEYTYPE_STORED_A, or
If keyType = ACR120_LOGIN_KEYTYPE_STORED_B,

Then pKey will not be use and can be just zero's while storedNo is the keyNo of the MasterKey you want to use. (Refer to ACR120_WriteMasterKey)

Before you can manipulate the card e.g. read, write, copy, readvalue, writevalue, etc. You have to successfully Login first to the card sector you want to manipulate.

Example:

```
// Login to sector 1 using keyType ACR120_LOGIN_KEYTYPE_AA
// (reader stationID: 1)
```

```
INT16 RetCode;
```

```
UINT8 SID;
UINT8 sector;
UINT8 keyType;
Int storedNo;
UINT8 pKey[5];
SID = 1;
sector = 1;
keyType = ACR120_LOGIN_KEYTYPE_AA
storedNo = 0;
```

```
pKey[0] = 255;
pKey[1] = 255;
pKey[2] = 255;
pKey[3] = 255;
```



```
pKey[4] = 255;
pKey[5] = 255;
```

```
RetCode = ACR120_Login(rHandle, SID, sector, keyType, storedNo, pKey);
```

```
// Login to sector 1 using keyType ACR120_LOGIN_KEYTYPE_FF
// (reader stationID: 1)
```

```
INT16 RetCode;
```

```
UINT8 SID;
UINT8 sector;
UINT8 keyType;
Int storedNo;
UINT8 pKey[5];
```

```
SID = 1;
sector = 1;
keyType = ACR120_LOGIN_KEYTYPE_AA
storedNo = 0;
```

```
RetCode = ACR120_Login(rHandle, SID, sector, keyType, storedNo, pKey);
```

```
// Login to sector 1 using keyType ACR120_LOGIN_KEYTYPE_STORED_A
// masterkey is stored to ( keyNo: 3 ) using the ACR120_WriteMasterKey
// (reader stationID: 1)
```

```
INT16 RetCode;
```

```
UINT8 SID;
UINT8 sector;
UINT8 keyType;
Int storedNo;
UINT8 pKey[5];
```

```
SID = 1;
sector = 1;
keyType = ACR120_LOGIN_KEYTYPE_STORED_A
storedNo = 3;
```

```
RetCode = ACR120_Login(rHandle, SID, sector, keyType, storedNo, pKey);
```

2.3.1.6 ACR120_READ

Format:

```
DLLAPI INT16 AC_DECL ACR120_Read ( INT16  rHandle,
                                   UINT8   stationID,
                                   UINT8   block,
                                   UINT8   pBlockData[ACR120_DATA_LEN]);
```

Function Description:

This function reads a block within the sector where you Login.

Parameters	Description	
rHandle	The handle to ACR120 reader returned by ACR120_Open	
stationID	The StationID of ACR120 Reader.	
block	The block number you want to read.	
pBlockData	Output Variable that will Contain the data read. ACR120_DATA_LEN is 16 bytes long.	
Return Value	INT16	Result code. 0 means success.

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A.

Notes:

Memory Organization is based from Standard Card IC MF1 IC S50, which is 16 sectors with 4 blocks of 16 bytes each.

		Byte Number within a Block															
Sector	Block	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
15	3	Key A				Access Bits				Key B							
	2																
	1																
	0																
14	3	Key A				Access Bits				Key B							
	2																
	1																
	0																
:	:																
:	:																
:	:																
1	3	Key A				Access Bits				Key B							
	2																
	1																
	0																
0	3	Key A				Access Bits				Key B							
	2																
	1																
	0																

For you to access the exact block, you have to multiply the sector number by 4 plus the block number:
 $\text{Block} = (\text{Sector} * 4) + \text{BlockNumber}$

Example:

```
// Read block 1 of sector 1 (reader stationID: 1)
// let's assume we've successfully Login to sector 1
```

```
INT16 RetCode;

UINT8 SID;
UINT8 block;
UINT8 pBlockData[16];
CString StrMsg;

SID = 1;
block = (1 * 4) + 1
RetCode = ACR120_Read(rHandle, SID, block, pBlockData);

// Data Read
StrMsg.Format("Data Read: %X %X %X %X %X %X %X %X %X %X %X %X %X %X %X",
              pBlockData[0],pBlockData[1],
              pBlockData[2],pBlockData[3],
              pBlockData[4], pBlockData[5],
              pBlockData[6], pBlockData[7],
              pBlockData[8], pBlockData[9],
              pBlockData[10],pBlockData[11],
              pBlockData[12],pBlockData[13],
              pBlockData[14],pBlockData[15]);
```

```
// Read block 2 of sector 4 (reader stationID: 1)
// let's assume we've successfully Login to sector 4
```

```
INT16 RetCode;

UINT8 SID;
UINT8 block;
UINT8 pBlockData[16];
CString StrMsg;
SID = 1;
block = (4 * 4) + 2

RetCode = ACR120_Read(rHandle, SID, block, pBlockData);

// Data Read
StrMsg.Format("Data Read: %X %X %X %X %X %X %X %X %X %X %X %X %X %X %X",
              pBlockData[0],pBlockData[1],
              pBlockData[2],pBlockData[3],
              pBlockData[4], pBlockData[5],
              pBlockData[6], pBlockData[7],
              pBlockData[8], pBlockData[9],
              pBlockData[10],pBlockData[11],
              pBlockData[12],pBlockData[13],
              pBlockData[14],pBlockData[15]);
```

2.3.1.7 ACR120_READVALUE

Format:

```

DLLAPI INT16 AC_DECL ACR120_ReadValue( INT16    rHandle,
                                         UINT8    stationID,
                                         UINT8    block,
                                         INT32*    pValueData);

```

Function Description:

This function reads value block within the sector where you Login.

Parameters	Description	
rHandle	The handle to ACR120 reader returned by ACR120_Open	
stationID	The StationID of ACR120 Reader.	
block	The value block number you want to read.	
pValueData	Output Variable that will Contain the value read.	
Return Value	INT16	Result code. 0 means success.


Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A.

Notes:

Memory Organization is based on Standard Card IC MF1 IC S50, which are 16 sectors with 4 blocks of 16 bytes each.

Sector	Block	Byte Number within a Block															
		0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
15	3	Key A				Access Bits				Key B							
	2																
	1																
	0																
14	3	Key A				Access Bits				Key B							
	2																
	1																
	0																
:	:																
:	:																
:	:																
1	3	Key A				Access Bits				Key B							
	2																



For you to access the exact block, you have to multiply the sector number by 4 plus the block number:
 $\text{Block} = (\text{Sector} * 4) + \text{BlockNumber}$.

The difference between the ACR120_Read and ACR120_ReadValue is that the ACR120_Read reads the 16 Bytes data within the block while ACR120_ReadValue reads the INT32 value in the value block (block that was formatted by ACR120_WriteValue). "The block must be a value before reading; refer to ACR120_WriteValue"

Example:

```
// Read value of block 1 of sector 1 (reader stationID: 1)
// Let's assume logging into sector 1 was successful and a value is written to
// block 1 using ACR120_WriteValue
```

```
INT16 RetCode;

UINT8 SID;
UINT8 block;
UINT32 pValueData;
CString StrMsg;

SID = 1;
block = (1 * 4) + 1

RetCode = ACR120_ReadValue(rHandle, SID, block, &pValueData);

// Value Read
StrMsg.Format("Value Read: %d",pValueData);
```

```
// Read value of block 2 of sector 4 (reader stationID: 1)
// Let's assume logging into sector 4 was successful and a value is written to
// block 2 using ACR120_WriteValue
```

```
INT16 RetCode;

UINT8 SID;
UINT8 block;
UINT32 pValueData;
CString StrMsg;

SID = 1;
block = (4 * 4) + 2;

RetCode = ACR120_ReadValue(rHandle, SID, block, &pValueData);

// Value Read
StrMsg.Format("Value Read: %d", pValueData);
```

2.3.1.8 ACR120_READEEPROM

Format:

```

DLLAPI INT16 AC_DECL ACR120_ReadEEPROM ( INT16   rHandle,
                                           UINT8   stationID,
                                           UINT8   reg,
                                           UINT8*   pEEPROMData);

```

Function Description:

This function reads the internal EEPROM of the ACR120 reader

Parameters	Description
rHandle	The handle to ACR120 reader returned by ACR120_Open
stationID	The StationID of ACR120 Reader.
reg	The register number.
pEEPROMData	Output Variable that will Contain the EEPROM register's value.
Return Value	INT16 Result code. 0 means success.

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A.

Notes:

The details for the register map is shown below:

ACR120 Reader Module EEPROM Memory Organization		
Register Number	Name	Description
00h...03h	Unique device ID (32bit)	This number is unique for each device and therefore read only.
04h	Station ID	Indicates the address ID for every station. The ID is used for addressing within a party line.
05h	Protocol Configuration	Set Protocol type, power on behavior. 00h -> ACR120 reader in ASCII mode 01h -> ACR120 reader in Binary mode
06h	Baud Rate Selection	Defines Communication speed. 00h -> 9600 baud 01h -> 19200 baud 02h -> 38400 baud 03h -> 57600 baud
07h...0Fh	Reserved	
10h...13h	User Date	Free Usage

Example:

```
// Read Baud rate (register 06h) of EEPROM (reader stationID: 1)
```

```
INT16 RetCode;
```

```

UINT8 SID;
UINT8 reg;
UINT8 pEEPROMData;
CString StrMsg;

SID = 1;
reg = 6;

RetCode = ACR120_ReadEEPROM (rHandle, SID, reg, &pEEPROMData);

// Value Read
StrMsg.Format("EEPROM Data Read:: %d",pEEPROMData);

```

2.3.1.9 ACR120_READLOWLEVELREGISTER

Format:

```

ACR120_DLLAPI INT16 ACR120_DECLACR120_ReadLowLevelRegister(
    INT16      hReader,
    UINT8      stationID,
    UINT8      reg,
    UINT8*     pRegData);

```

* This command should be used under manufacturer's recommendation.

Function Description:

This function reads the internal register value.

Parameters	Description	
hReader	The handle to our reader returned by ACR120_Open.	
stationID	The station ID of our reader.	
reg	The register number.	
pRegData	Contains the register's value.	
Return Value	INT16	Result code. 0 means success.

2.3.1.10 ACR120_WRITE

Format:

```

DLLAPI INT16 AC_DECL ACR120_Write ( INT16    rHandle,
                                     UINT8     stationID,
                                     UINT8     block,
                                     UINT8     pBlockData[ACR120_DATA_LEN]);

```

Function Description:

This function reads a block within the sector where you Login.

Parameters	Description
rHandle	The handle to ACR120 reader returned by ACR120_Open
stationID	The StationID of ACR120 Reader.

block	The block number where you want to write.	
pBlockData	The 16 bytes Data to Write. ACR120_DATA_LEN is 16 bytes long.	
Return Value	INT16	Result code. 0 means success.

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A.

Notes:

Memory Organization is based on Standard Card IC MF1 IC S50, which are 16 sectors with 4 blocks of 16 bytes each.

Sector	Block	Byte Number within a Block															
		0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
15	3	Key A				Access Bits				Key B							
	2																
	1																
	0																
14	3	Key A				Access Bits				Key B							
	2																
	1																
	0																
:	:																
:	:																
:	:																
1	3	Key A				Access Bits				Key B							
	2																
	1																
	0																
0	3	Key A				Access Bits				Key B							
	2																
	1																
	0																

For you to access the exact block, you have to multiply the sector number by 4 plus the block number:

Block = (Sector * 4) + BlockNumber

Example:

```
// Write to block 1 of sector 1 (reader stationID: 1)
// Let's assume logging into sector 1 was successful
```

```
INT16 RetCode;
```



```

UINT8 SID;
UINT8 block;
UINT8 pBlockData[16];
CString StrMsg;

SID = 1;
block = (1 * 4) + 1

pBlockData[0] = 255;
pBlockData[1] = 255;
pBlockData[2] = 255;
pBlockData[3] = 255;
pBlockData[4] = 255;
pBlockData[5] = 255;
pBlockData[6] = 255;
pBlockData[7] = 255;
pBlockData[8] = 255;
pBlockData[9] = 255;
pBlockData[10] = 255;
pBlockData[11] = 255;
pBlockData[12] = 255;
pBlockData[13] = 255;
pBlockData[14] = 255;
pBlockData[15] = 255;

RetCode = ACR120_Write(rHandle, SID, block, pBlockData);

```

2.3.1.11 ACR120_WRITEVALUE

Format:

```

DLLAPI INT16 AC_DECL ACR120_WriteValue( INT16    rHandle,
                                         UINT8    stationID,
                                         UINT8    block,
                                         INT32    ValueData);

```

Function Description:

This function writes INT32 value to a block within the sector where you Login.

Parameters	Description	
rHandle	The handle to ACR120 reader returned by ACR120_Open	
stationID	The StationID of ACR120 Reader.	
block	The block number where you want to write.	
ValueData	The value you want to write.	
Return Value	INT16	Result code. 0 means success.

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A.

Notes:

Memory Organization is based on Standard Card IC MF1 IC S50, which are 16 sectors with 4 blocks of 16 bytes each.

Sector	Block	Byte Number within a Block															
		0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
15	3	Key A					Access Bits					Key B					
	2																
	1																
	0																
14	3	Key A					Access Bits					Key B					
	2																
	1																
	0																
:	:																
:	:																
:	:																
1	3	Key A					Access Bits					Key B					
	2																
	1																
	0																
0	3	Key A					Access Bits					Key B					
	2																
	1																
	0																

For you to access the exact block, you have to multiply the sector number by 4 plus the block number:
 Block = (Sector * 4) + BlockNumber.

Example:

// write value to block 1 of sector 1 (reader stationID: 1)

// Let's assume logging into sector 1 was successful

INT16 RetCode;

UINT8 SID;

UINT8 block;

UINT32 ValueData;

CString StrMsg;

SID = 1;

block = (1 * 4) + 1;

ValueData = 5000;

RetCode = ACR120_WriteValue(rHandle, SID, block, ValueData);

2.3.1.12 ACR120_WRITEEEPROM

Format:

```
DLLAPI INT16 AC_DECL ACR120_WriteEEPROM ( INT16  rHandle,
                                           UINT8  stationID,
                                           UINT8  reg,
                                           UINT8  EEPROMData);
```

Function Description:

This function writes to internal EEPROM of the ACR120 reader.

Parameters	Description	
rHandle	The handle to ACR120 reader returned by ACR120_Open	
stationID	The StationID of ACR120 Reader.	
reg	The register number.	
EEPROMData	The value to write at the ACR120 reader EEPROM reg.	
Return Value	INT16	Result code. 0 means success.

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A.

Notes:

The details for the register map is shown below:

ACR120 Reader Module EEPROM Memory Organization		
Register Number	Name	Description
00h...03h	Unique device ID (32bit)	This number is unique for each device and therefore read only.
04h	Station ID	Indicates the address ID for every station. The ID is used for addressing within a party line.
05h	Protocol Configuration	Set Protocol type, power on behavior. 00h -> ACR120 reader in ASCII mode 01h -> ACR120 reader in Binary mode
06h	Baud Rate Selection	Defines Communication speed. 00h -> 9600 baud 01h -> 19200 baud 02h -> 38400 baud 03h -> 57600 baud
07h...0Fh	Reserved	
10h...13h	User Date	Free Usage

Example:

```
// Write/Set Baud rate to 57600, (register 06h) of EEPROM (reader stationID: 1)
```

```

INT16 RetCode;

UINT8 SID;
UINT8 reg;
UINT8 EEPROMData;
CString StrMsg;

SID = 1;
reg = 6;
EEPROMData = 3;

RetCode = ACR120_WriteEEPROM (rHandle, SID, reg, EEPROMData);

```

2.3.1.13 ACR120_WRITELOWLEVELREGISTER

Format:

```

ACR120_DLLAPI INT16 ACR120_DECLACR120_WriteLowLevelRegister(
    INT16      hReader,
    UINT8      stationID,
    UINT8      reg,
    UINT8      registerData);

```

Function Description:

This function writes the internal register.

Parameters	Description	
hReader	The handle to our reader returned by ACR120_Open.	
stationID	The station ID of our reader.	
reg	The register number.	
registerData	Contains the register's value to write.	
Return Value	INT16	Result code. 0 means success.

* This command should be used under manufacturer's recommendation.

2.3.1.14 ACR120_WRITEMASTERKEY

Format:

```

DLLAPI INT16 AC_DECL ACR120_WriteMasterKey ( INT16    rHandle,
    UINT8    stationID,
    UINT8    keyNo,
    UINT8    pKey[ACR120_KEY_LEN]);

```

Function Description:

This function writes Master key to internal EEPROM of the ACR120 reader.

Parameters	Description
rHandle	The handle to ACR120 reader returned by ACR120_Open
stationID	The StationID of ACR120 Reader.

keyNo	The master key number.	
pKey	6 bytes key to write.	
Return Value	INT16	Result code. 0 means success.

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A.

Notes:

ACR120 reader currently can store up to 32 keys (0 - 31). Keys stored in the reader can be used to Login to a card sector by using the KeyType ACR120_LOGIN_KEYTYPE_STORED_A or ACR120_LOGIN_KEYTYPE_STORED_B.

Example:

```
// Write master key: AAh AAh AAh AAh AAh AAh ; keyNO:2 (reader stationID: 1)
```

```
INT16 RetCode;
```

```
UINT8 SID;
UINT8 keyNo;
UINT8 pKey(5);
CString StrMsg;
SID = 1;
keyNo = 2;
```

```
pKey[0]=170;
pKey[1]=170;
pKey[2]=170;
pKey[3]=170;
pKey[4]=170;
pKey[5]=170;
```

```
RetCode = ACR120_WriteMasterKey (rHandle, SID, keyNo, pKey);
```

2.3.1.15 ACR120_INC**Format:**

```
DLLAPI INT16 AC_DECL ACR120_Inc (INT16 rHandle,
                                UINT8 stationID,
                                UINT8 block,
                                INT32 value,
                                INT32* pNewValue);
```

Function Description:

This function Increments a value block by adding a value to previously stored value.

Parameters	Description
rHandle	The handle to ACR120 reader returned by ACR120_Open

stationID	The StationID of ACR120 Reader.	
block	Value Block Number.	
value	Value to be added to previously stored value in the block.	
pNewValue	The updated value after increment.	
Return Value	INT16	Result code. 0 means success.

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A.

Notes:

Memory Organization is based on Standard Card IC MF1 IC S50, which are 16 sectors with 4 blocks of 16 bytes each.

Sector	Block	Byte Number within a Block															
		0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
15	3	Key A				Access Bits				Key B							
	2																
	1																
	0																
14	3	Key A				Access Bits				Key B							
	2																
	1																
	0																
:	:																
:	:																
:	:																
1	3	Key A				Access Bits				Key B							
	2																
	1																
	0																
0	3	Key A				Access Bits				Key B							
	2																
	1																
	0																

Block must contain a Value before Incrementing.

"Refer to ACR120_WriteValue".

Example:

```
// Increment value block 1 of sector 1 by 500. (reader stationID: 1)

INT16 RetCode;

UINT8 SID;
UINT8 block;
UINT8 value;
UINT8 pNewValue;
CString StrMsg;

SID = 1;
Block = ( 1 * 4 ) + 1;
value = 500;

RetCode = ACR120_Inc (rHandle, SID, block, value, &pNewValue);

// Updated Value after increment
StrMsg.Format("Incremented Value: %d",pNewValue);
```

2.3.1.16 ACR120_DEC**Format:**

```
DLLAPI INT16 AC_DECL ACR120_Dec (INT16  rHandle,
                                UINT8   stationID,
                                UINT8   block,
                                INT32    value,
                                INT32*   pNewValue);
```

Function Description:

This function decrements a value block by subtracting a value to previously stored value.

Parameters	Description	
rHandle	The handle to ACR120 reader returned by ACR120_Open	
stationID	The StationID of ACR120 Reader.	
block	Value Block Number.	
value	Value to be subtracted to previously stored value in the block.	
pNewValue	The updated value after decrement.	
Return Value	INT16	Result code. 0 means success.

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A.

Notes:

Memory Organization is based on Standard Card IC MF1 IC S50, which are 16 sectors with 4 blocks of 16 bytes each.

		Byte Number within a Block															
Sector	Block	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
15	3	Key A					Access Bits					Key B					
	2																
	1																
	0																
14	3	Key A					Access Bits					Key B					
	2																
	1																
	0																
:	:																
:	:																
:	:																
1	3	Key A					Access Bits					Key B					
	2																
	1																
	0																
0	3	Key A					Access Bits					Key B					
	2																
	1																
	0																

Block must contain a Value before decrementing.
"Refer to ACR120_WriteValue".

Example:

// decrement value block 1 of sector 1 by 500. (reader stationID: 1)

```
INT16 RetCode;
```

```
UINT8 SID;
UINT8 block;
UINT8 value;
UINT8 pNewValue;
CString StrMsg;
```

```
SID = 1;
Block = ( 1 * 4 ) + 1;
value = 500;
```

```
RetCode = ACR120_dec (rHandle, SID, block, value, &pNewValue);
```

// Updated Value after decrement

```
StrMsg.Format("Decrement Value: %d",pNewValue);
```


2.3.1.17 ACR120_COPY

Format:

```

DLLAPI INT16 AC_DECL ACR120_Copy (INT16 rHandle,
                                   UINT8  stationID,
                                   UINT8  srcBlock,
                                   UINT8  desBlock,
                                   INT32* pNewValue);

```

Function Description:

This function copies a value block to another block of the same sector.

Parameters	Description	
rHandle	The handle to ACR120 reader returned by ACR120_Open	
stationID	The StationID of ACR120 Reader.	
srcBlock	The source block number.	
desBlock	The target block number.	
pNewValue	The updated value after copy.	
Return Value	INT16	Result code. 0 means success.


Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A.

Notes:

Memory Organization is based on Standard Card IC MF1 IC S50, which are 16 sectors with 4 blocks of 16 bytes each.

		Byte Number within a Block															
Sector	Block	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
15	3	Key A				Access Bits				Key B							
	2																
	1																
	0																
14	3	Key A				Access Bits				Key B							
	2																
	1																
	0																
:	:																
:	:																



Source block must contain a Value before copying to another block in the same sector. *“Refer to ACR120_WriteValue”.*

The destination or target block need not to be a value block.

Example:

```
// copy value block 1 of sector 1 to block 2 of sector 1. (reader stationID: 1)
// Lets assume that logging into sector 1 was successful and block one is a value
// block. “Refer to ACR120_WriteValue”.
```

```
INT16 RetCode;

UINT8 SID;
UINT8 srcBlock;
UINT8 desBlock;
UINT8 pNewValue;
CString StrMsg;

SID = 1;
srcBlock = ( 1 * 4 ) + 1;
desBlock= ( 1 * 4 ) + 2;

RetCode = ACR120_Copy(rHandle, SID, srcBlock, desBlock, &pNewValue);

// Updated Value of target block after copy.
StrMsg.Format("Block 2 Value: %d",pNewValue);
```

2.3.1.18 ACR120_POWER

Format:

```
DLLAPI INT16 AC_DECL ACR120_Power (INT16 rHandle,
                                   UINT8 stationID,
                                   BOOL bOn);
```

Function Description:

This function is used to turn the antenna power on/off for reducing power consumption.

Parameters	Description	
RHandle	The handle to ACR120 reader returned by ACR120_Open	
stationID	The StationID of ACR120 Reader.	
bOn	Turn on (TRUE) or off (FALSE)..	
Return Value	INT16	Result code. 0 means success.

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A.

Notes:

The antenna power will be turned on automatically before TAG access commands like "ACR120_Select" and "ACR120_MultiTagSelect".

Example:

// Turns antenna power off (reader stationID: 1)

```
INT16 RetCode;

UINT8 SID;
BOOL bOn;

SID = 1;
bOn = false;
RetCode = ACR120_Power (rHandle, SID,bOn);
```

// Turns antenna power on (reader stationID: 1)

```
INT16 RetCode;

UINT8 SID;
BOOL bOn;

SID = 1;
bOn = true;

RetCode = ACR120_Power (rHandle, SID,bOn);
```

2.3.1.19 ACR120_READUSERPORT**Format:**

```
DLLAPI INT16 AC_DECL ACR120_ReadUserPort (INT16 rHandle,
                                           UINT8 stationID,
                                           UINT8* pUserPortState);
```

Function Description:

This function is used to read in the state of user port (PIN 14 of the OEM module).

Parameters	Description	
RHandle	The handle to ACR120 reader returned by ACR120_Open	
stationID	The StationID of ACR120 Reader.	
pUserPortState	Contains the port state (only LSB is used).	
Return Value	INT16	Result code. 0 means success.

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A.

Example:

```
// Read User port (reader stationID: 1)
```

```
INT16 RetCode;
```

```
UINT8 SID;
```

```
UINT8 pUserPortState;
```

```
SID = 1;
```

```
RetCode = ACR120_ReadUserPort (rHandle, SID, &pUserPortState);
```

2.3.1.20 ACR120_WRITEUSERPORT**Format:**

```
DLLAPI INT16 AC_DECL ACR120_WriteUserPort (INT16  rHandle,
                                             UINT8   stationID,
                                             UINT8   userPortState);
```

Function Description:

For ACR120S, this function sets the state of the LED.

For ACR120S-SM, a relay is tied to the LED control. An additional control is made available for controlling the on board buzzer. This function sets the states of Relay (together with LED) and Buzzer.

* Please note that the LED state of some readers may have been tied to indicate operation status by software option in factory default. In this case, the user may not be able to change the Relay/LED independently. To release this tie, please use the ACR120_WRITEEEPROM function to write a value of 0x00 to a special EEPROM address of 0xFE then do a power reset to the reader. Doing this operation only once is enough to change the option permanently.

Parameters	Description	
RHandle	The handle to ACR120 reader returned by ACR120_Open	
stationID	The StationID of ACR120 Reader.	
	Value	Action

Parameters	Description	
userPortState	0x00	Relay/LED and Buzzer OFF
	0x01	Relay/LED ON, Buzzer OFF
	0x02	Relay/LED OFF Buzzer ON
	0x03	Relay/LED and Buzzer ON
Return Value	INT16	Result code. 0 means success.

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A.

Example:

// Clear User port (reader stationID: 1)

```
INT16 RetCode;

UINT8 SID;
UINT8 userPortState;

SID = 1;
userPortState = 0;

RetCode = ACR120_WriteUserPort (rHandle, SID, userPortState);
```

2.3.1.21 ACR120_GETID**Format:**

```
DLLAPI INT16 AC_DECL ACR120_GetID (INT16 rHandle,
                                   UINT8* pNumID,
                                   UINT8* pStationID);
```

Function Description:

This function gets the station ID's for all reader modules on the bus.

Parameters	Description	
rHandle	The handle to ACR120 reader returned by ACR120_Open	
pNumID	The number of station ID returned.	
pStationID	Contains the list of station ID returned.	
Return Value	INT16	Result code. 0 means success.

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A.

Example:

// Get station ID's

```

INT16 RetCode;

UINT8 pNumID;
UINT8 pStationID[255];

RetCode = ACR120_GetID(rHandle, &pNumID, pStationID);

```

2.3.1.22 ACR120_LISTTAG**Format:**

```

DLLAPI INT16 AC_DECL ACR120_ListTag( INT16    rHandle,
                                     UINT8     stationID,
                                     UINT8*    pNumTagFound,
                                     BOOL*     pHaveTag,
                                     UINT8*    pTAG,
                                     UINT8*    pSN) ;

```

Function Description:

This function lists the serial numbers of all tags, which are in readable antenna range.

Parameters	Description	
rHandle	The handle to ACR120 reader returned by ACR120_Open	
stationID	The StationID of ACR120 Reader.	
pNumTagFound	Contains of number of TAG listed.	
pHaveTag	Whether the TAG Type Identification is listed.	
pTAG	The list of TAG Type Identification. If pHaveTag is false, this is an array of serial number length of the cards detected. If pHaveTag is true, this is an array of Tag type. The corresponding serial number length could then be determined from the Tag type.	
pSN	The flat array of serial numbers. All serial numbers are concatenated with length of 4, 7 or 10 numbers. The lengths are indicated in pTag field.	
Return Value	INT16	Result code. 0 means success.

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A.

Example:**// List all Tag's in antenna range (stationID: 1)**

```

INT16 RetCode;

UINT8 SID;

```

```

UINT8* pNumTagFound;
BOOL* pHaveTag;
UINT8* pTAG;
UINT8* pSN[199];
UINT8 ctr;
UINT8 ctrl;

SID=1;

RetCode = ACR120_ListTag(rHandle, SID, &pNumTagFound, &pHaveTag, &pTAG, pSN);

StrMsg.Format("Number of Tag Found: %d", pNumTagFound);

```

```

//Display Serial Numbers Found
// Loop to Number of TagFound (pNumTagFound)

```

```

ctrl = 0;
for( ctr = 0 ; ctr < pNumTagFound; ctr++)
{

StrMsg.Format("SN[%d]: %X %X %X %X", ctr,
SN[ctrl+0],SN[ctrl+1],SN[ctrl+2],SN[ctrl+3]);
ctrl += 4;

}

```

2.3.1.23 ACR120_MULTITAGSELECT

Format:

```

DLLAPI INT16 AC_DECL ACR120_MultiTagSelect( INT16      rHandle,
                                           UINT8 stationID,
                                           UINT8 pSN[ACR120_SN_LEN],
                                           BOOL* pHaveTag,
                                           UINT8* pTAG,
                                           UINT8 pResultSN[ACR120_SN_LEN]);

```

Function Description:

This function selects a single card in range and returns the card ID (Serial Number).

Parameters	Description
rHandle	The handle to ACR120 reader returned by ACR120_Open
stationID	The StationID of ACR120 Reader.
pSN	Contains the serial number of the TAG to be selected. It's ACR120_SN_LEN is 4 bytes long. AC_MIFARE_SN_LEN_4 (4 bytes long), AC_MIFARE_SN_LEN_7 (7 bytes long), AC_MIFARE_SN_LEN (10 bytes long).
pHaveTag	Whether the TAG Type Identification of selected tag is returned.
pTAG	The TAG Type Identification of selected tag.

Parameters	Description	
pResultSN	The serial number of selected TAG. It's ACR120_SN_LEN is 4 bytes long. AC_MIFARE_SN_LEN_4 (4 bytes long), AC_MIFARE_SN_LEN_7 (7 bytes long), AC_MIFARE_SN_LEN (10 bytes long).	
Return Value	INT16	Result code. 0 means success.

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A.

Example:

```
// Select a card in range (reader stationID: 1)
// Let's assume that there were 2 cards in range and you wanted to select the one
// with serial number ( FFh FFh FFh FFh )

INT16 RetCode;

UINT8 SID;
UINT8 pSN[3];
BOOL* pHaveTag;
UINT8* pTAG;
UINT8 pResultSN[3];

SID = 1;

pSN[0]=FF;
pSN[1]=FF;
pSN[2]=FF;
pSN[3]=FF;

RetCode = ACR120_MultiTagSelect(rHandle, SID, pSN, &pHaveTag, &pTAG, pResultSN);

// Get Serial Number Returned
StrMsg.Format("Card Serial Selected: %X %X %X %X",
              pResultSN[0], pResultSN[1],
              pResultSN [2], pResultSN [3] );
```

2.3.1.24 ACR120_TXDATATELEGRAM**Format:**

```
ACR120_DLLAPI INT16 ACR120_DECL
ACR120_TxDataTelegram(
    INT16      hReader,
    UINT8      stationID,
    UINT8      length,
    BOOL       bParity,
    BOOL       bOddParity,
    BOOL       bCRCGen,
    BOOL       bCRCCheck,
    BOOL       bCryptoInactive,
    UINT8      bitFrame,
```



```

UINT8*      data,
UINT8*      pRecvLen,
UINT8*      recvData);

```

Function Description:

This function transfers user specific data frames.

Parameters	Description	
hReader	The handle to our reader returned by ACR120_Open.	
stationID	The station ID of our reader.	
length	The length of user specific data frame.	
bParity	TRUE if parity generation is enabled.	
bOddParity	TRUE if parity is odd. Otherwise it's even.	
bCRCGen	TRUE if CRC generation for transmission is enabled.	
bCRCCheck	TRUE if CRC checking for receiving is enabled.	
bCryptoInactive	TRUE if Crypto unit is deactivated before transmission start.	
bitFrame	Bit Framing (number of bits from last byte transmitted).	
data	Contains the user specific data frame.	
pRecvLen	It returns the length of response data received.	
recvData	Contains the response data received.	
Return Value	INT16	Result code. 0 means success.

2.3.1.25 ACR120_REQUESTVERSIONINFO**Format:**

```

ACR120_DLLAPI INT16 ACR120_DECL
ACR120_RequestVersionInfo(
    INT16      hReader,
    UINT8      stationID,
    UINT8*     pVersionInfoLen,
    UINT8*     pVersionInfo);

```

Function Description:

This function gets the reader's firmware version information.

Parameters	Description	
hReader	The handle to our reader returned by ACR120_Open.	
pNumID	The number of station ID returned.	
pVersionInfoLen	It returns the length of the Firmware Version string.	
PVersionInfo	It returns the Firmware Version string.	
Return Value	INT16	Result code. 0 means success.

2.3.1.26 **PICC_INITBLOCKNUMBER**

Format:

```
DLLAPI INT16 AC_DECL PICC_InitBlockNumber (INT16 FrameSizeIndex);
```

Function Description:

This function resets the block number to be used during the ISO14443 part 4 (T=CL) communication. This function also sets the frame length of the Card (PICC). By default the frame length is 16 bytes. The frame length of the card is reported by the ATS in type A and the ATQB in type B cards.

Parameters	Description	
Frame Size Index	An index to a maximum frame size which the card can accept	
Return Value	INT16	The actual frame length selected.

The argument only accepts the followings:

Frame Size Index	Frame Length (in bytes)
0	16
1	24
2	32
3	40
4	48
5	64
6	96
7	128
8	256
otherwise	16

Returns:

The actual frame length selected will be returned as a confirmation. e.g. if 4 is used as calling parameter, the value 48 is returned.

Notes:

This function should be called after each time with the ACR120_Select() or ACR120_MultiTagSelect() function.

It is suggested to execute this function for type A card or the function ACR120_READATQB for type B card, just after *the ACR120_Select* operation, then call the PICC_InitBlockNumber according to the result of the respective functions.

Example:

```
//=====
//Selects a single card and returns the card ID (Serial Number)
//=====

//Variable Declarations
BYTE ResultSN[11];
BYTE TagType;
BYTE ResultTag;
char SN[100];
UINT8 SID=1;
BYTE  DataLength, pData[10], ResponseDataLength, pResponseData[100];
INT16 TimeOut=50, i, CardFrameSize;
char  pdata[500];
char  *ATS_ATQB;

retcode = ACR120_Select(rHandle, SID, &TagType, &ResultTag, ResultSN);

//Check if Retcode is Error
if (retcode >=0 )
{
    if ((TagType == 4) || (TagType == 5)) {
        // Type A cards
        memcpy(SN,ResultSN, 7);
    } else {
        memcpy(SN,ResultSN, ResultTag);
    }

    // Get the Info Bytes, if it is a type B card

    CardFrameSize=0;
    pdata[0]='\0';
    ResponseDataLength=0;

    if (TagType==0x80) {
        // Type B Cards
        if (ACR120_ReadATQB(rHandle, SID, pResponseData)==0) {
            ResponseDataLength=7;
            CardFrameSize=pResponseData[10]>>4;
        }
    } else if (TagType < 0x80 || TagType == 0xff) {
        // Type A Cards
        if (PICC_RATS(rHandle, SID, 4, &ResponseDataLength, pResponseData)>=0) {
            CardFrameSize=pResponseData[1]&0x0f;
        }
    }

    PICC_InitBlockNumber(CardFrameSize);          // Set communication frame size
} else {
    // Card Selection Error handling here
}
```

2.3.1.27 PICC_XCH_APDU

Format:

```
DLLAPI INT16 AC_DECL_PICC_Xch_APDU (
    INT16 rHandle,
    UINT8 station_ID,
    BOOL typeA,
    INT16 *pTransmitLength,
    UINT8 *pxData,
    INT16 *pReceiveLength,
    UINT8 *prData);
```

Function Description:

This function handles the APDU exchange in T=CL protocol. This routine will handle the Frame Waiting Time Extension (WTX) and chaining for long messages.

Parameters	Description
rHandle	The handle to our reader returned by ACR120_Open
station_ID	the station ID of our reader.
typeA	A Boolean value indicates the card type, TRUE for type A cards, FALSE for type B cards
pTransmitLength	A pointer to the location storing the length of the data to transmit, in bytes
pxData	A pointer to the transmit data storage
pReceiveLength	A pointer to the location storing the length of the data received, in bytes
prData	A pointer to the receive data storage
Return Value	INT16 Result code. 0 means success.

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A.

Notes:

- 1) The function PICC_InitBlockNumber() should be called each time between the ACR120_Select() or ACR120_MultiTagSelect() function and this function.
- 2) In many cases, the status code SW1 and SW2 are the last 2 bytes of the received data.

Example:

```
INT16 rHandle;
UINT8 SID;
BOOL typeA;
INT16 xLen, rLen;
UINT rData[100];
UINT8 Cmd[5]={0x94, 0xb2, 0x01, 0x3c, 0x1D};
INT16 RetCode;

xLen=5;
SID=1;
typeA = FALSE;           // Type B card
```

```
//Selects a single card and returns the card ID (Serial Number)
retcode = ACR120_Select(rHandle, SID, &HaveTag, &tmpbyte, tmpArray);

if (retcode == 0)
{
    // If a card is selected, proceed to issue an APDU of 94B2013C1D
    PICC_InitBlockNumber(0);

    retcode = PICC_Xch_APDU(rHandle, SID, typeA, &xLen, Cmd, &rLen, rData);
    //check if retcode is error

    if(retcode < 0){
        // Exchange APDU failed
    } else{
        // Exchange APDU successful
    }
}
}
```

2.3.1.28 PICC_RATS

Format:

```
DLLAPI INT16 AC_DECL PICC_RATS (
    INT16 rHandle,
    UINT8 station_ID,
    UINT8 FSDI,
    BOOL typeA,
    UINT8 *pATSlen,
    UINT8 *pATS);
```

Function Description:

This function is only valid for ISO14443 type A cards. It requests an Answer-to-Select (ATS) message from the card after doing the ACR120_Select() operation. It tells the card how many bytes the reader can handle in a frame and also gets the operation parameters of the card when communicating in ISO14443 mode.

Parameters	Description	
rHandle	The handle to our reader returned by ACR120_Open	
station_ID	the station ID of our reader.	
FSDI	An index to a maximum frame size which the reader can accept. The value should not exceed 4, i.e. 48 bytes.	
typeA	A Boolean value indicates the card type. This value should always be TRUE.	
pATSlen	A pointer to the location storing the length of the ATS received	
pATS	A pointer to the ATS received	
Return Value	INT16	Result code. 0 means success.

The FSDI to (Frame Size for proximity coupling Device) FSD conversion:

FSDI	FSD (in bytes)
0	16
1	24
2	32
3	40

4	48
5	64
6	96
7	128
8	256
otherwise	RFU

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A. For detailed meaning of the ATS, please refer to corresponding documents.

Note:

There is no need for calling this function in type B cards.

2.3.1.29 *PICC_DESELECT***Format:**

```

DLLAPI INT16 AC_DECL PICC_Deselect(
    INT16 rHandle,
    UINT8 station_ID,
    BOOL typeA);

```

Function Description:

This function sends DESELECT (card close) signal to the cards running ISO14443 part 4 (T=CL) protocol.

Parameters	Description	
rHandle	The handle to our reader returned by ACR120_Open	
station_ID	the station ID of our reader.	
typeA	A Boolean value indicates the card type, TRUE for type A cards, FALSE for type B cards	
Return Value	INT16	Result code. 0 means success.

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A.

2.3.1.30 ACR120_READATQB

Format:

```
DLLAPI INT16 AC_DECL ACR120_ReadATQB(INT16      rHandle,
                                     UINT8 stationID,
                                     UINT8 *pATQB);
```

Function Description:

This function reads the ATQB data from the card. This function only works after a successful Select command on an ISO14443 type B card.

Parameters	Description
rHandle	The handle to ACR120 reader returned by ACR120_Open
stationID	The StationID of ACR120 Reader
pATQB	A pointer to a 7 byte data array containing the ATQB. The first 4 bytes and last 3 bytes being the Application Data and Protocol Info respectively.

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. An error will return if the ACR120_Select command is not previously executed with success on a type B card.

Notes:

This function only works after a successful Select command on an ISO14443 type B card.

Example:

```
INT16 RetCode;
UINT8 SID;
UINT8 pSN[4]
UINT8 pATQB[7];
BOOL pHaveTag;
UINT8 pTAG;

SID=1;
// Select a type B card
RetCode = ACR120_Select (rHandle, SID, &pHaveTag, &pTAG, pSN);

RetCode = ACR120_ReadATQB (rHandle, SID, pATQB);

if (RetCode==0) {
    StrMsg.Format("Card ATQB = %02X%02X%02X%02X%02X%02X%02X",
        pATQB[0], pATQB[1], pATQB[2], pATQB[3], pATQB[4],
        pATQB[5], pATQB[6]);
}
```

2.3.1.31 ACR120_SETFWI

```
ACR120_SetFWI (    INT16 hReader,
                  UINT8 stationID,
                  UINT8 *pFWI)
```

Function Description:

This function alters the default Frame Waiting Index (FWI) which the ISO14443 cards reported during the initial card operation. The value of the reader is adopted through the ACR120_RATS() operation in type A cards and the ACR120_Select() operation in type B cards. In some instances, the frame waiting time may need to extend to wait for certain computation intensive operations on the card, which the card will request for a Waiting Time Extension (WTX) inside the ISO14443 part 4 communication.

This function is called by the ACR120_Xch_APDU() API and is usually not needed to be called by high level application explicitly.

Parameters	Description	
RHandle	The handle to ACR120 reader returned by ACR120_Open	
stationID	The StationID of ACR120 Reader.	
pFWI	Contains the new FWI to be set (value <= 0x0e)	
Return Value	INT16	Result code. 0 means success.

Returns:

The return value is zero if the function is successful. Otherwise, it returns a negative value containing the error code. For the detailed meaning of the error code, please refer to appendix A. The new FWI value is updated by the function.

Please note that according to the ISO14443 part 4 specification, the maximum value of FWI is 0x0E. The FWI value will be updated by the maximum value the card reader that can support.

The actual waiting time FWT is calculated by the following formula:

$$\text{FWT} = (256 * 16 / 13560000) * (2 ^ \text{FWI})$$

which gives 4.94s if FWI = 14

ACR120_FLIPUSERPORT**Format:**

```
DLLAPI INT16 AC_DECL ACR120_FlipUserPort(INT16 rHandle,
                                         UINT8 stationID,
                                         UINT8 PortFlipAction);
```

Function Description:

This function is added to ease the LED/Relay flipping and Buzzer sounding operation. The ACR120_WriteUserPort only turns *ON* or *OFF* of the corresponding devices according to the argument userPortState (c.f. ACR120_WRITEUSERPORT function), it could be difficult for the controlling PC program to time the activation duration precisely. This function call activates the LED/Relay and Buzzer for a precise duration defined in EEPROM values in address 0x07 and 0x08 respectively. This function will not take any action when called if the value is zero (0x00) in the respective EEPROM locations.

Parameters	Description	
RHandle	The handle to ACR120 reader returned by ACR120_Open	
stationID	The StationID of ACR120 Reader.	
userPortState	Value	Action
	0x00	No action
	0x01	Turns on LED/Relay on for m milliseconds
	0x02	Turns on Buzzer on for m milliseconds
	0x03	Turns on LED/Relay and Buzzer on for the respective durations.
Return Value	INT16	Result code. 0 means success.

m = 200ms x (the value in EEPROM location 0x07)

n = 200ms x (the value in EEPROM location 0x08)

Returns:

The return value is always zero indicates a successful execution.

Appendix A: Table of Error Codes

Code	Meaning
ERR_ACR120_INTERNAL_UNEXPECTED(1000)	Library internal unexpected error
ERR_ACR120_PORT_INVALID(2000)	The port is invalid
ERR_ACR120_PORT_OCCUPIED(2010)	The port is occupied by another application
ERR_ACR120_HANDLE_INVALID(2020)	The handle is invalid
ERR_ACR120_INCORRECT_PARAM(2030)	Incorrect Parameter
ERR_ACR120_READER_NO_TAG(3000)	No TAG in reachable range / selected
ERR_ACR120_READER_READ_FAIL_AFTER_OP(3010)	Read fail after operation
ERR_ACR120_READER_NO_VALUE_BLOCK(3020)	Block doesn't contain value
ERR_ACR120_READER_OP_FAILURE(3030)	Operation failed
ERR_ACR120_READER_UNKNOWN(3040)	Reader unknown error
ERR_ACR120_READER_LOGIN_INVALID_STORED_KEY_FORMAT(4010)	Invalid stored key format in login process
ERR_ACR120_READER_WRITE_READ_AFTER_WRITE_ERROR(4020)	Reader can't read after write operation
ERR_ACR120_READER_DEC_FAILURE_EMPTY(4030)	Decrement failure (empty)

Appendix B: Sector Number Adaptation on Mifare 4K Card

Sector Number on Card	Sector Number for Log-in	Block Number	Card Type	
0x00	0x00	0x00-0x03	Mifare 1K	Mifare 4K
0x01	0x01	0x04-0x07	Standard sectors	Standard sectors
0x02	0x02	0x08-0x0B		
0x03	0x03	0x0C-0x0F		
0x04	0x04	0x10-0x13		
0x05	0x05	0x14-0x17		
0x06	0x06	0x18-0x1B		
0x07	0x07	0x1C-0x1F		
0x08	0x08	0x20-0x23		
0x09	0x09	0x24-0x27		
0x0A	0x0A	0x28-0x2B		
0x0B	0x0B	0x2C-0x2F		
0x0C	0x0C	0x30-0x33		
0x0D	0x0D	0x34-0x37		
0x0E	0x0E	0x38-0x3B		
0x0F	0x0F	0x3C-0x3F		
0x10	0x10	0x40-0x43		Big sectors
0x11	0x11	0x44-0x47		
0x12	0x12	0x48-0x4B		
0x13	0x13	0x4C-0x4F		
0x14	0x14	0x50-0x53		
0x15	0x15	0x54-0x57		
0x16	0x16	0x58-0x5B		
0x17	0x17	0x5C-0x5F		
0x18	0x18	0x60-0x63		
0x19	0x19	0x64-0x67		
0x1A	0x1A	0x68-0x6B		
0x1B	0x1B	0x6C-0x6F		
0x1C	0x1C	0x70-0x73		
0x1D	0x1D	0x74-0x77		
0x1E	0x1E	0x78-0x7B		
0x1F	0x1F	0x7C-0x7F		
0x20	0x20	0x80-0x8F		Big sectors
0x21	0x24	0x90-0x9F		
0x22	0x28	0xA0-0xAF		
0x23	0x2C	0xB0-0xBF		
0x24	0x30	0xC0-0xCF		
0x25	0x34	0xD0-0xDF		
0x26	0x38	0xE0-0xEF		
0x27	0x3C	0xF0-0xFF		

Appendix C: Physical and Logical Block/Sector Calculation

Mifare 1K

- Logical Sector is equal to Physical sector, which are 0 to 15.
- Logical block of each sector is from 0 to 3.
- Physical blocks = ((Sector * 4) + Logical block)

Mifare 4K

- **Case 1: If { 0 <= Logical Sector <= 31}**
 - Physical sector is equal to Logical.
 - Logical block of each sector is from 0 to 3.
 - Physical blocks = ((Sector * 4) + Logical block)
- **Case 2: If { 32 <= Logical Sector <= 39}**
 - Physical Sector = Logical Sector + ((Logical Sector - 32) * 3)
 - Logical block of each sector is from 0 to 15.
 - Physical blocks = ((Logical Sector - 32) * 16) + 128 + Logical block