

4.3 Error / Message



Error code and message are shown on the screen when errors are occurs.

<Recovery from an error / message>

- (1) Press [RESET] key.
- (2) It has recovered from the error if [START] key blinks. Press [START] key to start auto operation.
- (3) If [START] key is not blinked, recover the error according to the error list.