

Laptop Technical Service Manual

This document describes internal service procedures.

Step 1: Power off and disconnect battery.

Step 2: Remove bottom cover using standard tools.

Step 3: Replace thermal compound following manufacturer guidelines.

Step 4: Reassemble and run diagnostics.