



Control valve



Solenoid valve



Manual valve



Centrifugal pump



Flow Indicator  
Transmitter



Pressure Indicator  
Transmitter



Level Transmitter



Motor




Pressure Relief Valve  
(Optional)



High level Switch



Low level Switch



Agitator



Rotameter



Temperature Indicator  
Transmitter

CV1, CV2: Normally Open

SV1,SV2,SV3, SV4: Normally Open