

HP Array Configuration Utility Command Cheat Sheet

Utility Keyword abbreviations	
Abbreviations	chassisname = ch controller = ctrl logicaldrive = ld physicaldrive = pd drivewritecache = dwc
hpacucli utility	
hpacucli	<pre># hpacucli</pre> <pre># hpacucli help</pre> <p>Note: you can use the hpacucli command in a script</p>
Controller Commands	
Display (detailed)	<pre>hpacucli> ctrl all show config</pre> <pre>hpacucli> ctrl all show config detail</pre>
Status	<pre>hpacucli> ctrl all show status</pre>
Cache	<pre>hpacucli> ctrl slot=0 modify dwc=disable</pre> <pre>hpacucli> ctrl slot=0 modify dwc=enable</pre>
Rescan	<pre>hpacucli> rescan</pre> <p>Note: detects newly added devices since the last rescan</p>
Physical Drive Commands	
Display (detailed)	<pre>hpacucli> ctrl slot=0 pd all show</pre> <pre>hpacucli> ctrl slot=0 pd 2:3 show detail</pre> <p>Note: you can obtain the slot number by displaying the controller configuration (see above)</p>
Status	<pre>hpacucli> ctrl slot=0 pd all show status</pre> <pre>hpacucli> ctrl slot=0 pd 2:3 show status</pre>
Erase	<pre>hpacucli> ctrl slot=0 pd 2:3 modify erase</pre>
Blink disk LED	<pre>hpacucli> ctrl slot=0 pd 2:3 modify led=on</pre> <pre>hpacucli> ctrl slot=0 pd 2:3 modify led=off</pre>
Logical Drive Commands	
Display (detailed)	<pre>hpacucli> ctrl slot=0 ld all show [detail]</pre> <pre>hpacucli> ctrl slot=0 ld 4 show [detail]</pre>
Status	<pre>hpacucli> ctrl slot=0 ld all show status</pre> <pre>hpacucli> ctrl slot=0 ld 4 show status</pre>
Blink disk LED	<pre>hpacucli> ctrl slot=0 ld 4 modify led=on</pre> <pre>hpacucli> ctrl slot=0 ld 4 modify led=off</pre>
re-enabling failed drive	<pre>hpacucli> ctrl slot=0 ld 4 modify reenable forced</pre>

Create	<pre># logical drive - one disk hpacuccli> ctrl slot=0 create type=ld drives=1:12 raid=0 # logical drive - mirrored hpacuccli> ctrl slot=0 create type=ld drives=1:13,1:14 size=300 raid=1 # logical drive - raid 5 hpacuccli> ctrl slot=0 create type=ld drives=1:13,1:14,1:15,1:16,1:17 raid=5</pre> <p>Note: drives - specific drives, all drives or unassigned drives size - size of the logical drive in MB raid - type of raid 0, 1 , 1+0 and 5</p>
Remove	hpacuccli> ctrl slot=0 ld 4 delete
Expanding	hpacuccli> ctrl slot=0 ld 4 add drives=2:3
Extending	hpacuccli> ctrl slot=0 ld 4 modify size=500 forced
Spare	hpacuccli> ctrl slot=0 array all add spares=1:5,1:7
Display (detailed)	<pre>hpacuccli> ctrl all show config hpacuccli> ctrl all show config detail</pre>
Status	hpacuccli> ctrl all show status
Cache	<pre>hpacuccli> ctrl slot=0 modify dwc=disable hpacuccli> ctrl slot=0 modify dwc=enable</pre>
Rescan	<pre>hpacuccli> rescan</pre> <p>Note: detects newly added devices since the last rescan</p>