



**SEW**  
**EURODRIVE**



# **MOVIDRIVE® MDX61B**

## **Extended Positioning via Bus**

### **Application**

FA362820

Edition 04/2005

11335114 / EN

# Manual





|  |           |
|--|-----------|
| <b>1 Important Notes.....</b>                                  | <b>4</b>  |
| 1.1 Explanation of the icons .....                             | 4         |
| 1.2 Safety notes and general information .....                 | 5         |
| <b>2 System Description.....</b>                               | <b>6</b>  |
| 2.1 Application areas .....                                    | 6         |
| 2.2 Application example .....                                  | 7         |
| 2.3 Program identification .....                               | 8         |
| <b>3 Project Planning .....</b>                                | <b>9</b>  |
| 3.1 Prerequisites .....  | 9         |
| 3.2 Description of functions.....                              | 10        |
| 3.3 Scaling the drive .....                                    | 10        |
| 3.4 Limit switches, reference cams and machine zero .....      | 13        |
| 3.5 Process data assignment.....                               | 14        |
| 3.6 Software limit switches.....                               | 16        |
| 3.7 IPOS <sup>plus</sup> ® processing speed.....               | 18        |
| 3.8 Safe stop.....   | 19        |
| 3.9 SBus send object.....                                      | 19        |
| <b>4 Installation .....</b>                                    | <b>20</b> |
| 4.1 MOVITOOLS® software .....                                  | 20        |
| 4.2 Wiring diagram for MOVIDRIVE® MDX61B .....                 | 21        |
| 4.3 Bus installation for MOVIDRIVE® MDX61B .....               | 22        |
| 4.4 System bus connection (SBus 1).....                        | 29        |
| 4.5 Connecting hardware limit switches.....                    | 30        |
| <b>5 Startup.....</b>  | <b>31</b> |
| 5.1 General information .....                                  | 31        |
| 5.2 Preliminary work.....                                      | 31        |
| 5.3 Starting the "Extended positioning via bus" program .....  | 32        |
| 5.4 Parameters and IPOS <sup>plus</sup> ® variables .....      | 43        |
| 5.5 Recording IPOS <sup>plus</sup> ® variables .....           | 45        |
| <b>6 Operation and Service .....</b>                           | <b>46</b> |
| 6.1 Starting the drive .....                                   | 46        |
| 6.2 Monitor mode .....   | 48        |
| 6.3 Jog mode .....   | 49        |
| 6.4 Referencing mode.....                                      | 50        |
| 6.5 Automatic mode .....                                       | 52        |
| 6.6 Cycle diagrams .....                                       | 54        |
| 6.7 Fault information .....                                    | 58        |
| 6.8 Error messages.....  | 59        |
| <b>7 Compatibility between MOVIDRIVE® A / B / compact.....</b> | <b>61</b> |
| 7.1 Important notes .....                                      | 61        |
| <b>8 Index.....</b>  | <b>65</b> |



## Important notes

### Explanation of the icons

---

## 1 Important notes

Always follow the safety and warning instructions contained in this section!

### 1.1 Explanation of the icons



#### Hazard

Indicates an imminently hazardous situation which, if not avoided, WILL result in death or serious injury.



#### Warning

Indicates an imminently hazardous situation caused by the product which, if not avoided, WILL result in death or serious injury. You will also find this signal to indicate the potential for damage to property.



#### Caution

Indicates a potentially hazardous situation which, if not avoided, MAY result in minor injury or damage to products.



#### Note

Indicates a reference to additional information, for example on startup, or other useful data.



#### Documentation reference

Indicates a reference to a document, such as operating instructions, catalog, data sheet.



## 1.2 Safety notes and general information



### **Risk of an electrical shock**

Possible consequences: Death or serious injury.

Only electrical specialists are allowed to install and start up MOVIDRIVE<sup>®</sup> drive inverters observing the applicable accident prevention regulations and the MOVIDRIVE<sup>®</sup> operating instructions.



### **Potentially hazardous situation which, if not avoided, may result in damage to products or the surrounding area.**

Possible consequences: Damage to the product

Read through this manual carefully before you commence installation and startup of MOVIDRIVE<sup>®</sup> drive inverters with this application module. This manual does not replace the detailed operating instructions!

A requirement of fault-free operation and the possibility of any rights to claim under guarantee is that you observe the information in the documentation.



### **Documentation reference**

This manual was written assuming that the user is familiar with the MOVIDRIVE<sup>®</sup> documentation, in particular the MOVIDRIVE<sup>®</sup> system manual.

In this manual, cross references are marked with "→". For example, (→ Sec. X.X) means: Further information can be found in section X.X of this manual.



## **2 System Description**

### **2.1 Application areas**

The "Extended positioning via bus" application module is particularly suited to applications in which it is necessary to move to any number of positions at different speeds and with different acceleration ramps. Positioning to an external encoder is necessary when there is a non-positive connection between the motor shaft and the load. In this case, either an incremental encoder or an absolute encoder can be used.

The "Extended positioning via bus" application module is especially suitable for the following branches of industry and applications:

- **Materials handling technology**
  - Trolleys
  - Hoists
  - Rail vehicles
- **Logistics**
  - Storage and retrieval systems
  - Transverse carriages

**The "Extended positioning via bus" module offers the following advantages in these applications:**

- User-friendly user interface.
- You only have to enter the parameters required for "Extended bus positioning" (ratios, speeds, diameters).
- Guided parameter setting process instead of complicated programming.
- Monitor mode for optimum diagnostics.
- Users do not require any programming experience.
- Long travel distances possible ( $2^{18} \times \text{travel unit}$ )
- Either an incremental encoder or an absolute encoder can be used as the external encoder.
- It does not take long to get to know the system.



## 2.2 Application example

### **Transverse carriage**

A transverse carriage represents a typical application example of the "Extended positioning via bus" application module. The following figure shows a transverse carriage in a high-bay warehouse. Goods to be moved in and out of storage are transported between the shelf aisles and the distribution table. The transverse carriage has to cover long distances in this process. It also has to accelerate with different ramps and move at different speeds depending on the load.




Figure 1: Application example of a transverse carriage

04823AXX





### 2.3 Program identification

You can use the MOVITOOLS® software package to identify which application program was last loaded into the MOVIDRIVE® MDX61B unit. Proceed as follows:

- Connect MOVIDRIVE® to the PC via the serial port.
- Start MOVITOOLS®.
- In MOVITOOLS® start the program "Shell".
- In the Shell program, choose [Display] / [IPOS Information...].




Figure 2: IPOS information in Shell

06710AEN

- The "IPOS-Status" window appears. The entries in this window tell you which application software is stored in MOVIDRIVE® MDX61B.



Figure 3: Display of the current IPOS program version

11022AEN





## 3 Project Planning

### 3.1 Prerequisites

**PC and software** The "Extended positioning via bus" application module is implemented as an IPOS<sup>plus</sup>® program and forms part of the SEW MOVITOOLS<sup>®</sup> software package from version 4.20. In order to use MOVITOOLS<sup>®</sup>, you must have a PC with one of the following operating systems: Windows<sup>®</sup> 95, Windows<sup>®</sup> 98, Windows NT<sup>®</sup> 4.0 or Windows<sup>®</sup> 2000.

**SIMATIC S7 sample projects** There is a SIMATIC S7 sample project for you to try out the functionality of the "Extended positioning via bus" module. To access this sample project, go to the SEW homepage ([www.sew-eurodrive.de](http://www.sew-eurodrive.de)) and select the heading "Software."

#### Inverters, motors and encoders

##### • Inverters

**Application version** "Extended positioning via bus" can only be implemented on MOVIDRIVE<sup>®</sup> MDX61B units in application version (...-0T).

**Encoder feedback** It is essential for the "Extended positioning via bus" module to have encoder feedback, which means it **cannot** be implemented with MOVIDRIVE<sup>®</sup> MDX60B.

**MOVIDRIVE<sup>®</sup> MDX61B** "Extended positioning via bus" uses 4 or 6 process data words. A MOVIDRIVE<sup>®</sup> option will be required (→ table extract "Possible combinations" below), depending on the bus type used.

An external encoder is required for positioning in applications with a non-positive connection between the motor shaft and the load. If an absolute encoder is used as the external encoder, the MOVIDRIVE<sup>®</sup> option "Absolute encoder interface type DIP11B" is also required.

##### • Motors

- For operation on MOVIDRIVE<sup>®</sup> MDX61B with option DEH11B: CT/CV asynchronous servomotors (encoder installed as standard) or DR/DT/DV AC motors with encoder option (Hiperface<sup>®</sup>, sin/cos or TTL).
- For operation on MOVIDRIVE<sup>®</sup> MDX61B with option DER11B: CM/DS synchronous servomotors, resolver installed as standard.

##### • External encoders

- Interlocking connection between the motor shaft and the load:  
An external encoder is not required. If you also want to use an external encoder for positioning when there is an interlocking connection, you have to proceed in the same way as with a non-positive connection.
- Non-positive connection between the motor shaft and the load:  
An external encoder is required in addition to the motor encoder/resolver.  
Incremental encoder as external encoder: Connection to basic unit at X14.  
Absolute encoder as external encoder: Connection to option DIP11 at X62.

##### • Possible combinations

|   | Motor shaft/load connection   |  |
|---|---|--|
|   | Interlocking:<br>External encoder is not required   | Non-positive:<br>External encoder required |
| Encoder type (external encoder)                   | -   | Incremental encoder<br>Absolute encoder    |
| Bus type (required option)                        | PROFIBUS → DFP / InterBus → DFI / CAN-Bus → DFC / DeviceNet → DFD / Ethernet → DFE / System bus (SBus) → no option required |  |
| Additional MOVIDRIVE <sup>®</sup> option required | DEH11B or DER11B  | DIP11 / DEH11B / DER11B                    |



### 3.2 Description of functions

#### Functional characteristics

The "Extended positioning via bus" application offers the following functional characteristics:

- Any number of target positions can be specified via the fieldbus.
- Speed selection via fieldbus (for the LINEAR and JERK LIMITED ramp functions, the changes can be made during movement).
- Activation of software limit switches.
- Cyclical checkback of actual speed, actual position in the user unit, active current and unit utilization via process output data.
- Confirmation of the target position to which movement has taken place via bit PI1:3 "Target position reached" in the status word.
- Source actual position (motor encoder, external encoder or absolute encoder) can be selected.
- Simple connection to the machine control (PLC).
- Four (4) process data items instead of six (6) can be used for operation ( ... in this case, the ramp function does not have to be specified).

#### Three operating modes

- **Jog mode (PO2:11 = "1" and PO2:12 = "0")**
  - The drive is moved clockwise or counterclockwise using bits 9 or 10 in control word 2 (PO1).
  - The speed and ramps are variable and are specified by the PLC via the fieldbus.
- **Referencing mode (PO1:11 = "0" and PO1:12 = "1")**
  - Reference travel is started with bit 8 in control word 2 (PO1). Reference travel establishes the reference point (**machine zero**) for absolute positioning operations.
- **Automatic mode (PO1:11 = "1" and PO1:12 = "1")**
  - Positioning is started in automatic mode with bit 8 in control word 2 (PO1).
  - The target position is specified using process output data words PO2 and PO3.
  - The actual position is signaled back cyclically in user travel units using process input data words PI2 and PI3.
  - The set speed is specified using process output data word PO4.
  - The actual speed is signaled back cyclically using process input data word PI4.
  - Acceleration and deceleration ramps are specified using process output data words PO5 and PO6.
  - The active current and unit utilization are signaled back cyclically using process input data words PI5 and PI6.
  - Confirmation that the selected position has been reached is sent via bit 3 of the status word (PI1) "Target position reached."



The maximum possible travel distance depends on the travel unit set. Examples:

- Travel unit [1/ 10 mm] → max. possible travel distance = 26.2 m
- Travel unit [mm] → max. possible travel distance = 262 m

### 3.3 Scaling the drive

The controller must be able to detect the number of encoder pulses (increments) per travel unit to position the drive. The scaling function is used to set a user unit suitable to



the application.

**Drive without  
external encoder  
(interlocking  
connection)**

In drives without an external encoder, the system can calculate the scaling automatically **during startup** of the extended positioning via bus function. Enter the following data:

- Diameter of the drive wheel ( $d_{\text{drive wheel}}$ ) or slope of the spindle ( $s_{\text{spindle}}$ )
- Gear ratio of the gear unit ( $i_{\text{gear unit}}$ , speed-reduction)
- Gear ratio of the additional gear ( $i_{\text{gear unit}}$ , speed-reduction)

The following scaling factors are calculated:

- Pulses / distance scaling factor [inc/mm] using the formula:

$$\text{Pulses} = 4096 \times i_{\text{gear unit}} \times i_{\text{additional gear}}$$

$$\text{Distance} = \Pi \times d_{\text{drive wheel}} \text{ or } \Pi \times s_{\text{spindle}}$$

- Speed scaling factor

Numerator factor in [1/min] and denominator value in "speed unit".

You can also enter the distance and speed scaling factors directly. If you enter a unit other than [mm] or [1/10 mm] as the travel unit, this user unit will also be used for the position of the software limit switches, the reference offset and the maximum travel distances.



#### **Drive with external encoder (non-positive connection)**

In this case, you must have activated and scaled the external encoder **before starting** the "Extended positioning via bus" module. To do so, make the following settings in the Shell program **before starting** the extended positioning via bus module (→ following figure).

| 94. IPOS Encoder                 |                  |
|----------------------------------|------------------|
| 941 Source actual position       | EXTERN.ENC (X14) |
| 942 Encoder factor numerator     | 1                |
| 943 Encoder factor denominator   | 1                |
| 944 Encoder scaling ext. encoder | x 1              |
| 945 Encoder type (X14)           | HIPERFACE        |
| 946 Counting direction (X14)     | NORMAL           |
| 947 Hiperface offset (X14) [inc] | 0                |

10091AEN

- P941 Source actual position  
If an incremental encoder or an absolute encoder (DIP11) is connected, set P941 to "EXT. ENCODER (X14)". You can also make this setting during the startup procedure of the extended positioning via bus module.
- P942 Encoder factor numerator / P943 Encoder factor denominator / P944 Encoder scaling ext. encoder

The scaling calculation function is now blocked during startup of the extended positioning via bus module.



- For more information about scaling an external encoder, refer to the "IPOS<sup>plus</sup>® Positioning and Sequence Control System" manual.
- When using an absolute encoder, note the startup instructions in the "MOVIDRIVE<sup>®</sup> MDX61B0 Absolute Encoder Card DIP11B" manual.



### 3.4 Limit switches, reference cams and machine zero

Note the following points during project planning:

- The software limit switches must be located within the travel range of the hardware limit switches.
- When defining the reference position (position of the reference cam) and the software limit switches, make sure they **do not** overlap. Fault message F78 "IPOS SW limit switch" is generated in the event of an overlap during referencing.
- You can enter a reference offset during startup if you do not want the machine zero to be located on the reference cam. The following formula applies: Machine zero = Reference position + Reference offset This way, you can alter the machine zero without having to move the reference cam.



Please also refer to the information in the section "Software limit switches".



### 3.5 Process data assignment

The machine control (PLC) sends 6 process output data words (PO1 ... PO6) to the inverter and receives 6 process input data words (PI1 ... PI6) from the inverter.





Figure 4: Data exchange via process data

|     |                                    |     |                                       |
|-----|------------------------------------|-----|---------------------------------------|
| PA  | = Process output data              | PE  | = Process input data                  |
| PA1 | = Control word 2                   | PE1 | = Status word (IPOS PI data)          |
| PA2 | = Target position high             | PE2 | = Actual position high (IPOS PI data) |
| PA3 | = Target position low              | PE3 | = Actual position low (IPOS PI data)  |
| PA4 | = Set speed (IPOS PO data)         | PE4 | = Actual speed (IPOS PI data)         |
| PA5 | = Accelerating ramp (IPOS PO data) | PE5 | = Active current (IPOS PI data)       |
| PA6 | = Deceleration ramp (IPOS PO data) | PE6 | = Unit utilization (IPOS PI data)     |


#### Process output data

The assignment of the process output data words is as follows:


- PO1: Control word 2



- PA2 + PA3: Target position




- PA4: Setpoint speed



- PA5 + PA6: Acceleration ramp and deceleration ramp

PA5 Acceleration ramp


PA6 Deceleration ramp




**Process input data**

The assignment of the process input data words is as follows:


- PE1: Status word




- PE2 + PE3: Actual position




- PE4: Actual speed



- PE5: Active current



- PE6: Unit utilization







### 3.6 Software limit switches

#### General information

The "software limit switch" monitoring function is used to check that the target position is set to appropriate values. During this process, it is not important where the drive is positioned. In contrast to the monitoring of the hardware limit switches, the monitoring function for the software limit switches makes it possible to detect whether there is an error in the target specifications before the axis starts to move. The software limit switches are active when the axis is referenced; that is, when Bit 1 "IPOS reference" is set in PI1.

#### Moving clear of the software limit switch


When using an absolute encoder or Multiturn Hiperface® encoder it may be necessary for the drive to be moved within the range of the software limit switches (for example, after an encoder has been replaced). For this purpose, Bit 15 in the process output data word 1 (PO1) is set to "/SWLS" (= Moving clear of the software limit switch).

Bit 15 "/SWLS" is only available in jog mode and referencing mode. If Bit 15 is set, the drive can be moved out of the valid positioning range into the area of the software limit switches (→ Example 3).

It is necessary to differentiate between the following three examples:

#### Example 1

- Prerequisites:
  - Bit 15 "/SWLS" in the process output data word 1 (PO1) is not set.
  - Drive is within valid positioning area
  - Software limit switch monitoring function is active.



10981AEN

In jog mode, the drive runs until it is three position windows (P922) before the software limit switch and then stays there.


In automatic mode, the drive can be positioned up to the software limit switches but not beyond.

In referencing mode, the software limit switches are not active, which means the drive can move past the software limit switches during reference travel.




Example 2

- Prerequisites:
  - Bit 15 "/SWLS" in the process output data word 1 (PO1) is not set.
  - The drive is outside the software limit switches.



10982AEN

The following error message appears once the drive is enabled:



10983AEN

You can confirm the error message by pressing the reset button. The monitoring function is deactivated. In the area of the software limit switches, the drive can be moved at two different speeds as follows:

- Closer toward the travel range of the software limit switch at reference speed 2 (P902).
- Away from the travel range of the software limit switches at maximum speed.


The monitoring function is reactivated when:

- The actual position of the drive set using P941 enters the permitted positioning range again.
- A positioning job is issued via the opposite software limit switch.
- The unit is switched off and on again.



#### Example 3

- Prerequisite:
  - Bit 15 "/SWLS" in the process output data word 1 (PO1) is set.



10984AEN

The monitoring function is deactivated in the "Jog mode" and "Referencing mode" operating modes. The drive can be moved within the travel area of the software limit switches and from the valid positioning range into the area of the software limit switches without an error message being generated. The speed can be varied.



#### Changing the monitoring function of the software limit switches during operation!

Possible consequences: Risk of injury.

You must not change the monitoring function of the software limit switches (PO1, Bit 15 "/SWLS") during operation (i.e. when the axis is in motion).

### 3.7 IPOS<sup>plus</sup>® processing speed

The speed of the IPOS<sup>plus</sup>® program in MOVIDRIVE® MDX61B can be changed using the following parameters:

- P938 IPOS speed TASK1, setting range 0 - 9
- P939 IPOS speed TASK2, setting range 0 - 9

Setting value "0" for both parameters results in the same IPOS<sup>plus</sup>® processing speed as for MOVIDRIVE® MD\_60A.

- $P938 = 0 \triangle TASK1 = 1 \text{ command/ms}$
- $P938 = 0 \triangle TASK2 = 2 \text{ commands/ms}$

Values greater than zero are added to the IPOS<sup>plus</sup>® processing speed of MOVIDRIVE® MD\_60A. Note that the total of the commands per millisecond (commands/ms) for TASK1 and TASK2 must not be greater than 9.

If you start up the application module on a MOVIDRIVE® MDX61B unit, the parameters will be set as follows to ensure a sequence with optimized timing:

- $P938 = 5 \triangle TASK1 = 1 \text{ command / ms} + 5 \text{ commands / ms} = 6 \text{ commands / ms}$
- $P939 = 4 \triangle TASK2 = 2 \text{ commands / ms} + 4 \text{ commands / ms} = 6 \text{ commands / ms}$



### 3.8 Safe stop

A "Safe stop" can only be achieved by safe disconnection of the jumpers at terminal X17 (through safety switch or safety PLC).

The "Safe stop active" state is indicated by a "U" in the 7-segment display. In the application module, this state is treated in the same way as the "CONTROLLER INHIBIT" state.



For more information on the "Safe stop" function, refer to the following publications:


- MOVIDRIVE® MDX60B / 61B Safe Disconnection - Conditions
- MOVIDRIVE® MDX60B/61B Safe Disconnection - Applications

### 3.9 SBus send object

You have the option of setting up an SBus send object for transferring the cyclical actual position of the drive. In this way, the "Extended positioning via bus" module can be used as a master for the "DriveSync" application module or any IPOS<sup>plus</sup>® program.

#### Activating the SBus send object

To set up the SBus send object, set the IPOS<sup>plus</sup>® variable *H115 SwitchSBUS* to "1" and restart the IPOS<sup>plus</sup>® program (→following screenshot).



11010AXX

#### Settings for the SBus objects

The send and synchronization objects are initialized automatically once the IPOS<sup>plus</sup>® program has been restarted. The content of the send object is set to IPOS<sup>plus</sup>® encoder.

|           | Send object  | Synchronization object |
|-----------|--------------|------------------------|
| ObjectNo  | 2            | 1                      |
| CycleTime | 1            | 5                      |
| Offset    | 0            | 0                      |
| Format    | 4            | 0                      |
| DPointer  | IPOS Encoder | -                      |



## 4 Installation

### 4.1 MOVITOOLS® software

#### MOVITOOLS®

The "Extended positioning via bus" application module is part of the MOVITOOLS® software (version 4.20 and higher). Proceed as follows to install MOVITOOLS® on your computer:

- Insert the MOVITOOLS® CD into the CD-ROM drive of your PC.
- The MOVITOOLS® setup menu is started. Follow the instructions of the installation wizard.

You can now use the Program Manager to start MOVITOOLS®. Proceed as follows to perform startup for the inverter using the MOVITOOLS® Manager:

- Select the language you want in the "Language" selection field.
- In the "PC Interface" selection field, select the PC port (e.g. COM 1) to which the inverter is connected.
- In the "Device Type" field, select "Movidrive B".
- In the "Baudrate" field, select the baud rate set on the basic unit with the DIP switch S13 (standard setting → "57.6 kBaud").
- Click the <Update> button to display the connected inverter.




Figure 5: MOVITOOLS® window

10985AEN

#### Application version

The "Extended positioning via bus" application module can only be used on MOVIDRIVE® units in application version (...-0T). The application modules cannot be used with units in the standard version (-00).



## 4.2 Wiring diagram for MOVIDRIVE® MDX61B




Figure 6: Wiring diagram for MOVIDRIVE® MDX61B with option DEH11B or DER11B

55257AEN



## Installation

### Bus installation for MOVIDRIVE® MDX61B

#### 4.3 Bus installation for MOVIDRIVE® MDX61B

##### Overview

For the bus installation, please note the information in the relevant fieldbus manuals supplied with the fieldbus interfaces. Please refer to the MOVIDRIVE® MDX60B/61B operating instructions for information on installing the system bus (SBus).





Figure 7: Bus types

56363AXX






### PROFIBUS (DFP21B)

For more detailed information, refer to the "MOVIDRIVE® MDX61B Fieldbus interface DFP21B PROFIBUS DP" manual. This manual can be ordered from SEW-EURODRIVE. You can download the unit master data files (GSD) and type files for MOVIDRIVE® MDX61B from the SEW homepage (under the heading "Software") to facilitate startup.

### Technical data

| Option                            | PROFIBUS fieldbus interface type DFP21B                        |           |
|-----------------------------------|--|-----------|
|                                   | Part number  | 824 240 2 |
| Resources for startup/diagnostics | MOVITOOLS® software and DBG60B keypad                          |           |
| Protocol option                   | PROFIBUS DP and DP-V1 to IEC 61158                             |           |
| Supported baud rates              | Automatic baud rate detection from 9.6 kbaud ... 12 Mbaud      |           |
| Connection                        | 9-pin Sub-D socket<br>Assignment to IEC 61158                  |           |
| Bus termination                   | Not integrated, must be implemented in the PROFIBUS connector. |           |
| Station address                   | 0 ... 125, can be set using DIP switch                         |           |
| GSD file                          | SEWA6003.GSD   |           |
| DP ident number                   | 6003 hex = 24579 dec   |           |
| Max. number of process data       | 10 process data  |           |
| Mass                              | 0.2 kg (0.44 lb)   |           |



1. Green LED: RUN
2. Red LED: BUS FAULT
3. DIP switch for setting the station address.
4. 9-pin sub D socket: bus connection

### Pin assignment




Figure 8: Assignment of 9-pin sub D plug to IEC 61158

55276AXX

- (1) 9-pin sub D connector
- (2) Twist the signal wires together!
- (3) Conductive connection is necessary between the plug housing and the shield!



## Installation

### Bus installation for MOVIDRIVE® MDX61B

#### INTERBUS with fiber optic cable (DFI21B)

For more detailed information, refer to the "MOVIDRIVE® MDX61B Fieldbus Interface DFI21B INTERBUS with Fiber Optic Cable" manual. This manual can be ordered from SEW-EURODRIVE.

#### Technical data

|  | Option   | INTERBUS fieldbus interface type DFI21B (FO)   |
|--|--|--|
|  | Part number  | 824 311 5  |
|  | Resources for startup/diagnostics  | MOVITOOLS® software, DBG60B keypad and CMD tool  |
|  | Supported baud rates   | 500 kbaud and 2 Mbaud, can be selected via DIP switch  |
|  | Connection   | Remote bus input: 2 F-SMA connectors<br>Remote bus output: 2 F-SMA connectors<br>Optically controlled FO interface |
|  | Mass   | 0.2 kg (0.44 lb)   |
|  | 1. DIP switches for setting the process data length, PCP length and baud rate<br>2. Diagnostic LEDs<br>3. FO: Remote IN<br>4. FO: Incoming remote bus<br>5. FO: Remote OUT<br>6. FO: Outgoing remote bus |  |

#### Connection assignment

| Position | Signal              | Direction    | Wire color of FO cable |
|----------|---------------------|--------------|------------------------|
| 3        | FO remote IN        | Receive data | Orange (OG)            |
| 4        | Incoming remote bus | Send data    | Black (BK)             |
| 5        | FO remote OUT       | Receive data | Black (BK)             |
| 6        | Outgoing remote bus | Send data    | Orange (OG)            |



**INTERBUS  
(DFI11B)**

For more detailed information, refer to the "MOVIDRIVE® MDX61B Fieldbus Interface DFI11B INTERBUS" manual. This manual can be ordered from SEW-EURODRIVE.

*Technical data*


| Option                            |  | INTERBUS fieldbus interface type DFI11B  |
|-----------------------------------|--|--|
| Part number                       |  | 824 309 3  |
| Resources for startup/diagnostics |  | MOVITOOLS® software and DBG60B keypad  |
| Supported baud rates              |  | 500 kbaud and 2 Mbaud, can be selected via DIP switch  |
| Connection                        |  | Remote bus input: 9-pin sub D connector<br>Remote bus output: 9-pin Sub-D socket<br>RS-485 transmission technology, 6-core shielded and twisted-pair cable |
| Module ID                         |  | E3 <sub>hex</sub> = 227 <sub>dec</sub>   |
| Max. number of process data       |  | 6 process data   |
| Mass                              |  | 0.2 kg (0.44 lb)   |

55278AXX

1. DIP switches for setting the process data length, PCP length and baud rate
2. Diagnostic LEDs: 4 x green LED (U<sub>L</sub>, RC, BA, TR); 1 x red LED (RD)
3. 9-pin sub D plug: Remote bus input
4. 9-pin sub D socket: Remote bus output

*Pin assignment*

Conductor color abbreviations to IEC 757.



04435AXX

*Figure 9: Assignment of the 9-pin sub D socket of the incoming remote bus cable and the 9-pin sub D plug of the outgoing remote bus cable*

- (1) 9-pin sub D socket of the incoming remote bus cable
- (2) Twist the signal wires together!
- (3) Conductive connection is necessary between the plug housing and the shield!
- (4) 9-pin sub D plug of the outgoing remote bus cable
- (5) Jumper pin 5 with pin 9!



## Installation

### Bus installation for MOVIDRIVE® MDX61B

#### CANopen (DFC11B)

For more information, refer to the "Communication" manual. This manual can be ordered from SEW-EURODRIVE (provisionally from 03/2005).

#### Technical data

|  | Option   | CANopen fieldbus interface type DFC11B   |
|--|--|--|
|  | Part number  | 824 317 4  |
|  | Resources for startup/diagnostics  | MOVITOOLS® software and DBG60B keypad  |
|  | Supported baud rates   | Setting using parameter P894:<br><ul style="list-style-type: none"> <li>• 125 kbaud</li> <li>• 250 kbaud</li> <li>• 500 kbaud</li> <li>• 1000 kbaud</li> </ul> |
|  | Connection   | 9-pin sub D connector (X30)<br>Assignment to CiA standard<br>2-core twisted cable to ISO 11898   |
|  | Bus termination  | Can be activated using DIP switch (120 Ω)  |
|  | Address range  | 1 ... 127, can be selected using DIP switch  |
|  | Mass   | 0.2 kg (0.44 lb)   |
|  | 1. DIP switch for setting the bus terminating resistor<br>2. X31: CAN bus connection<br>3. X30: 9-pin sub D plug: CAN bus connection |  |

#### Connection MOVIDRIVE® - CAN

The DFC11B option is connected to the CAN bus at X30 or X31 in the same way as the SBus in the basic unit (X12). In contrast to the SBus1, SBus2 is electrically isolated and made available via option DFC11B.

#### Pin assignment (X30)




Figure 10: Assignment of 9-pin sub D socket of the bus cable

- (1) 9-pin Sub-D socket
- (2) Twist the signal wires together!
- (3) Conductive connection is necessary between the plug housing and the shield!



### DeviceNet (DFD11B)

For more detailed information, refer to the "MOVIDRIVE® MDX61B Fieldbus Interface DFD11B DeviceNet" manual. This manual can be ordered from SEW-EURODRIVE. You can download the EDS files for MOVIDRIVE® MDX61B from the SEW homepage (under the heading "Software") to facilitate startup.

### Technical data

| Option |   | DeviceNet fieldbus interface type DFD11B  |
|--------|---|---|
|        | Part number   | 824 972 5   |
|        | Resources for startup/diagnostics   | MOVITOOLS® software and DBG60B keypad   |
|        | Supported baud rates  | Can be selected using DIP switch: <ul style="list-style-type: none"> <li>• 125 kbaud</li> <li>• 250 kbaud</li> <li>• 500 kbaud</li> </ul> |
|        | Connection  | 5-pin Phoenix terminal<br>Assignment according to DeviceNet specification (Volume I, Appendix A)  |
|        | Permitted line cross section  | According to DeviceNet specification  |
|        | Bus termination   | Use of bus connectors with integrated bus terminating resistor (120 Ω) at the start and finish of a bus segment.                          |
|        | Address range that can be set (MAC-ID)  | 0 ... 63, can be selected using DIP switch  |
|        | Mass  | 0.2 kg (0.44 lb)  |
|        | <p>1. LED display</p> <p>2. DIP switch for setting the node address (MAC-ID), the process data lengths and baud rate</p> <p>3. 5-pin Phoenix terminal: bus connection</p> |   |
|        | 55280AXX  |   |

### Terminal assignment

The assignment of connecting terminals is described in the DeviceNet specification Volume I, Appendix A.

| Terminal | Description | Color      |
|----------|-------------|------------|
| X30:1    | V- (0V24)   | Black (BK) |
| X30:2    | CAN_L       | Blue (BU)  |
| X30:3    | DRAIN       | Blank      |
| X30:4    | CAN_H       | White (WH) |
| X30:5    | V+ (+24 V)  | Red (RD)   |



# **Installation** Bus installation for MOVIDRIVE® MDX61B

**Ethernet  
 (DFE11B)**

For more detailed information, refer to the "MOVIDRIVE® MDX61B Fieldbus Interface DFE11B Ethernet" manual. This manual can be ordered from SEW-EURODRIVE.

*Technical data*

| Option                            | Ethernet fieldbus interface type DFE11B |
|-----------------------------------|---|
| Part number                       | 1820 036 2                              |
| Resources for startup/diagnostics | MOVITOOLS® software and DBG60B keypad   |
| Automatic baud rate detection     | 10 MBaud / 100 MBaud                    |
| Connection                        | RJ45 modular jack 8-8                   |
| Addressing                        | 4 byte IP address                       |
| Mass                              | 0.2 kg (0.44 lb)                        |

1. DIP switch for setting the least significant bytes (LSB) of the IP address

2. LED "Status" (red/yellow/green), "100 MBit" (green), "link/act" (green)

3. X30: Ethernet connection

4. MAC address

**MOVIDRIVE® /  
 Ethernet  
 connection**

To connect DFE11B to Ethernet, connect the Ethernet interface X30 (RJ45 plug connector) to the hub or switch provided using a twisted-pair cable to category 5, class D in accordance with IEC 11801 edition 2.0. To do this, use a patch cable.




Figure 11: Pin assignment of an RJ45 plug connector

54174AXX

- |                            |                              |
|----------------------------|------------------------------|
| A = Front view             | [1] Pin 1 TX+ Transmit Plus  |
| B = View from back         | [2] Pin 2 TX– Transmit Minus |
| [3] Pin 3 RX+ Receive Plus | [6] Pin 6 RX– Receive Minus  |

If you want to connect the DFE11B option card directly to your project planning computer, you require a cross over cable.



#### 4.4 System bus connection (SBus 1)



Only if P816 "SBus baud rate" = 1000 kbaud:


MOVIDRIVE® compact MCH4\_A units must not be combined with other MOVIDRIVE® units in the same system bus combination.

The units may be combined at baud rates  $\neq$  1000 kbaud.

Max. 64 CAN bus stations can be addressed using the system bus (SBus). Use a repeater after 20 or 30 stations, depending on the length of the cables and the cable capacity. The SBus supports transmission technology compliant with ISO 11898.

The "Serial Communication" manual contains detailed information about the system bus. This manual can be ordered from SEW-EURODRIVE.

#### SBus wiring diagram



54534AEN

Figure 12: System bus connection

**Cable specification**

- Use a 4-core twisted and shielded copper cable (data transmission cable with braided copper shield). The cable must meet the following specifications:

- Core cross section 0.25 ... 0.75 mm<sup>2</sup> (AWG 23 ... AWG 18)
- Line resistance 120  $\Omega$  at 1 MHz
- Capacitance per unit length  $\leq$  40 pF/m (12 pF/ft) at 1 kHz

Suitable cables include CAN bus or DeviceNet cables.

#### Shielding

- Connect the shield to the electronics shield clamp on the inverter or master controller and make sure it is connected over a wide area at both ends.

#### Cable length

- The permitted total cable length depends on the baud rate setting of the SBus (P816):
  - 125 kbaud  $\rightarrow$  320 m (1056 ft)
  - 250 kbaud  $\rightarrow$  160 m (528 ft)
  - **500 kbaud  $\rightarrow$  80 m (264 ft)**
  - 1000 kbaud  $\rightarrow$  40 m (132 ft)

#### Terminating resistor

- Switch on the system bus terminating resistor (S12 = ON) at the start and end of the system bus connection. Switch off the terminating resistor on the other units (S12 = OFF).



- There must not be any potential displacement between the units connected with the SBus. Take suitable measures to avoid potential displacement, such as connecting the unit ground connectors using a separate line.





#### 4.5 Connecting hardware limit switches

The cams of the hardware limit switches must cover the travel range up to the stop.



**Only use hardware limit switches with normally closed contacts (low-active)!**





Figure 13: Connecting hardware limit switches

04437AXX

- CW = Clockwise drive inverter
- X = travel distance
- LS CW = CW hardware limit switch
- LS CCW = CCW hardware limit switch



Make sure the hardware limit switch is assigned correctly. This means clockwise movement (CW) should be towards the clockwise hardware limit switch (LS CW) and counterclockwise movement (CCW) should be towards the counterclockwise hardware limit switch (LS CCW).



## 5 Startup

### 5.1 General information

Correct project planning and installation are the prerequisites for successful startup. Refer to the MOVIDRIVE® MDX60/61B system manual for detailed project planning instructions.

Check the installation, the encoder connection and the installation of the fieldbus cards by following the installation instructions in the MOVIDRIVE® MDX60B/61B operating instructions, in the fieldbus manuals and in this manual (→ Sec. Installation).

Use an absolute encoder as the external encoder (connect to DIP11B, X62). Also note the information on installation and startup in the "MOVIDRIVE® MDX61B Absolute Encoder Card DIP11B" manual.

### 5.2 Preliminary work

Perform the following steps before starting up the "Extended positioning via bus" module:

- Connect the "Xterminal" connection on the inverter to PC-COM via the UWS21A option (serial interface).
- Install the MOVITOOLS® software (version 4.20 or higher).
- Start up the inverter with "MOVITOOLS/Shell."
  - MDX61B with asynchronous motor: **CFC operating modes / VFC n-control**
  - MDX61B with synchronous motor: **SERVO operating modes**
- Only for operation with an external encoder (absolute or incremental encoder):
  - Absolute encoder: Start up the DIP11B absolute encoder card. The parameters P942 ... P944 are set during this process (→ "MOVIDRIVE® MDX61B Absolute encoder Card DIP11B" manual).
  - Incremental encoder: Set the parameters 942 ... P944 *Encoder factor numerator*, *Encoder factor denominator* and *Encoder scaling ext. encoder* in the Shell program. Refer to the "IPOS<sup>plus</sup>® Positioning and Sequence Control System" manual for a detailed description of the parameters.
- In [MOVITOOLS] / [Shell] / choose the menu item [Startup] and select the application "Extended positioning via bus."
- Enter a "0" signal at terminal DIØØ "/CONTROLLER INHIBIT/".



## Startup

Starting the "Extended positioning via bus" program

### 5.3 Starting the "Extended positioning via bus" program

#### General information

- Start [MOVITOOLS] / [Shell].
- Choose [Startup] / [Extended positioning via bus.]




Figure 14: Starting the "Extended positioning via bus" program

11013AEN



### Setting the fieldbus parameters

Once the "Extended positioning via bus" module has been started, all parameters important for extended bus positioning are read.

If a valid application module has not yet been loaded into the inverter, the following window appears after extended positioning via bus has been started:

11014AEN

Figure 15: Setting the fieldbus parameters

You have to make the following settings in this window:

- **Setting the fieldbus parameters:** Set the fieldbus parameters. Fixed parameters are grayed out and cannot be changed.

The system bus (SBus) can always be set; no option is required.

If a fieldbus card (DFP, DFI, DFC, DFD or DFE) is plugged into the fieldbus slot, PROFIBUS, INTERBUS, CAN, DEVICENET or ETHERNET can also be selected.



### Setting the distance and speed scaling factors

You can set the scaling factors for distance and speed in this window.

11015AEN

Figure 16: Setting the scaling

You have to make the following settings in this window:

- **Source actual position selection field:** Select which encoder is to be used for distance measurement in positioning:
  - MOTOR ENCODER (X15)
  - EXT. ENCODER (X14) with an incremental encoder as the external encoder.
  - ABSOLUTE ENCODER (DIP) with an absolute encoder as the external encoder or on the motor shaft.



If you use an absolute encoder, you must start up the DIP11B option **before** you start the "Extended positioning via bus" application module!



### Calculating the scaling factors

- **Example 1: Motor encoder or absolute encoder on the motor shaft (source actual position)**
  - Choose the unit you require in the selection field "Diameter of driving wheel" or "Spindle slope" (only for motor encoder). For the unit you can choose from millimeters [mm] or 1/10 millimeters [1/10 mm].
  - In the "Gearing ratio" input field enter the ratio of the gear unit. In the "External ratio" input field enter the gear ratio of the additional gear.
  - In the "Unit for speed" selection field, choose from [mm/s], [m/min] and [1/min].
  - For positioning with an absolute encoder, in the "Place of absolute encoder" selection field, choose "Motor shaft".
  - Click the <Calculation> button. The "distance" and "speed" scaling factors are calculated by the program.

- **Example 2: External encoder or absolute encoder on the track (source actual position)**

When using an external encoder or an absolute encoder on the track, you have to calculate the distance scaling factor manually. The scaling factor for the speed can be calculated automatically (→ following section) or manually (→ example 2).

#### Automatic calculation of the scaling factor for speed:

- In the "Source actual position" selection field, select the entry "Motor encoder".
- Enter a value in the "Diameter of driving wheel" field or the "Spindle slope" field. Select the unit [mm] or [1/10 mm] in the adjacent selection field.
- In the input fields "Gearing ratio" and "External ratio" enter the respective values for the gear ratios.
- Click the <Calculation> button. The scaling factor for speed is calculated by the program.

#### Calculating the distance scaling factor:

- In the "Source actual position" selection field, select the entry "External encoder" or "Absolute encoder". For positioning with an absolute encoder, in the "Place of absolute encoder" selection field, choose the entry "Way".
- In the group box "Scaling factor for distance", enter the number of pulses supplied by the encoder per travel unit in the "Increments" input field. The unit of the pulses is always increments [inc]. In the "Distance" input field, enter the corresponding track distance.
- In the "Scaling factor for distance" group box, enter the unit of the scaling factor for the distance in the "Unit" input field. Any other information, such as the software limit switch, reference offset or the target position are specified in the selected unit.



## Startup

### Starting the "Extended positioning via bus" program

*Converting the distance resolution into user travel units*

The scaling factor for distance (increments / distance) is used to determine the user travel unit (e.g. mm, revolutions, ft). For positioning with a motor encoder, the scaling factor for distance can be calculated automatically. The following units can be selected for the automatic calculation:

- mm
- 1/10 mm

When using an external encoder or an absolute encoder on the track, you have to calculate the distance scaling factor manually (→ Examples 1 and 2).

**Example 1:** A drive is to be positioned using an **Absolute encoder on the track**. The speed is to be given in the unit [m/min].

- Drive data:
  - Gear unit ratio (i gear unit) = 12.34
  - Gear ratio of the additional gear (i additional gear) = 1
  - Diameter of the carrying wheel = 200 mm
- Encoder data:
  - Type: Stahltronik WCS3 absolute encoder
  - Physical resolution = 1 increment / 0.8mm
  - Encoder scaling P955 = x8 (→ set automatically during startup of the DIP11B option).
- Automatic calculation of the scaling factor for speed:
 

Numerator / denominator = 32759 / 1668 unit [m/min]
- Calculating the scaling factor for distance manually:
  - Electrical resolution = 1 increment / 0.8 mm × P955 encoder scaling
  - Result: 1 increment / 0.8 mm × 8 = 8 [inc/0.8 mm]

**Result:** Pulses / Distance = 80 / 8 [mm]

**Example 2:** A drive is to be positioned using an **external encoder on the track**.

- Drive data:
  - Gear unit ratio (i gear unit) = 12.34
  - Gear ratio of the additional gear (i additional gear) = 1
- Encoder data:
  - Physical resolution = 1024 increments / revolution
  - Diameter of the carrying wheel ( $d_{\text{carrying wheel}}$ ) = 65 mm
  - Encoder scaling P944 = x2
- Calculating the scaling factor for distance manually:
  - Pulses = Number of increments / revolution × 4 × P944
  - Pulses = 1024 increments / revolution × 4 × 2 = 8192 increments
  - Distance =  $\Pi \times d_{\text{carrying wheel}}$
  - Distance = 3.14 × 65 mm = 204.2 mm

**Result:** Pulses / distance = 8192 / 204 unit [mm]



If the numerator (pulses) or denominator (distance) are non-integer values, the conversion can be made more accurate if both numerator and denominator are multiplied by the same expansion factor (e.g. 10, 100, 1000, etc.). This expansion does not limit the maximum travel range. The maximum value for "pulses" or the "distance" is 32767.





### Converting the speed into user travel units

In the group box "Calculation of the scaling", choose one of the three entries in the drop-down menu "Unit for speed". The scaling factors can be calculated automatically. The following speed units are available:

- 1/min
- mm/sec
- m/min

If you want to enter the speed in a different unit, you can calculate the scaling factor for speed (→ following example).

**Example 1:** A drive is to be positioned using an **Absolute encoder on the track**. The speed is to be specified in mm/s.

- Drive data:
  - Gear unit ratio ( $i_{\text{gear unit}}$ ) = 15.5
  - Gear ratio of the additional gear ( $i_{\text{add. gear}}$ ) = 2
  - Diameter of the drive wheel ( $d_{\text{drive wheel}}$ ) = 200 mm
- Encoder data:
  - Type: Stahltronik WCS2 linear distance measuring system
  - Physical resolution = 0.833 mm  $\triangleq$  1.2 increments /mm
  - Encoder scaling P955 = x8 (→ set automatically during startup of the DIP11B option)
- Numerator =  $i_{\text{gear unit}} \times i_{\text{add. gear}} \times 60$   
 Numerator =  $15.5 \times 2 \times 60 = 1860$
- Denominator =  $\pi \times d_{\text{drive wheel}}$  (or spindle slope)  
 Denominator =  $3.14 \times 200 = 628$   
 Unit = mm/s



If the numerator or denominator are non-integer values, the conversion can be made more accurate if both numerator and denominator are multiplied by the same expansion factor (e.g. 10, 100, 1000, etc.). This expansion does not limit the maximum travel range. The maximum value for the numerator or denominator is 32767.



### Setting the ramp times and limits


11016AEN

Figure 17: Setting ramp times and limits

In this window, you can enter the position of the software limit switches, the reference offset, the reference travel type, ramp times and limits. The entries are made in the user units of the scaling.

- In the input fields "Software limit switch CCW / CW", enter the position of the software limit switches. Make sure the positions of the software limit switches are **within** the travel distance of the hardware limit switches and that they do not overlap the reference position. If you enter the value "0" in both input fields, the software limit switches are deactivated.
- In the "Reference offset" input field, enter the reference offset. The machine zero is corrected using the reference offset. The following formula applies:

Machine zero = reference position + reference offset



- Select the correct type of reference travel (0-8) from the "Reference travel type" selection box. The reference travel type specifies the reference travel strategy with which the machine zero of a machine should be established. The IPOS<sup>plus</sup>® variable *H127 ZeroPulse* specifies whether reference travel should react to an edge change of the reference cam ("0") or the following zero pulse of the encoder ("1"). The IPOS<sup>plus</sup>® variable *H127* can be edited using the IPOS Compiler.

|                 |  |
|-----------------|--|
| <p>55260AXX</p> | <p><b>Type 0:</b> The reference position is the first zero pulse CCW of the starting position of the reference travel.</p>   |
| <p>54947AXX</p> | <p><b>Type 1:</b> The reference position is the CCW end of the reference cam.<br/>Machine zero = reference position + reference offset<br/>H127 = "1" Referencing to encoder zero pulse<br/>H127 = "0" Referencing to edge change</p>  |
| <p>54948AXX</p> | <p><b>Type 2:</b> The reference position is the CW end of the reference cam.<br/>Machine zero = reference position + reference offset<br/>H127 = "1" Referencing to encoder zero pulse<br/>H127 = "0" Referencing to edge change</p>   |
| <p>54949AXX</p> | <p><b>Type 3:</b> The reference position is the CW hardware limit switch. No reference cam is required. After leaving the hardware limit switch (positive edge), the drive continues to move clear of it by 4096 increments.<br/>Machine zero = reference position + reference offset – 4096</p>   |
| <p>54950AXX</p> | <p><b>Type 4:</b> The reference position is the CCW hardware limit switch. No reference cam is required. After leaving the hardware limit switch (positive edge), the drive continues to move clear of it by 4096 increments.<br/>Machine zero = reference position + reference offset + 4096</p>  |
| <p>54951AXX</p> | <p><b>Type 5:</b> No reference travel. The reference position is the current position without reference to a zero pulse.<br/>Machine zero = current position + reference offset</p>  |
| <p>54952AXX</p> | <p><b>Type 6:</b> The reference position is the CW end of the reference cam.<br/>Machine zero = reference position + reference offset</p>  |
| <p>54953AXX</p> | <p><b>Type 7:</b> The reference position is the CCW end of the reference cam.<br/>Machine zero = reference position + reference offset</p>   |
| <p>54951AXX</p> | <p><b>Type 8:</b> No reference travel. The reference position is the current position without reference to a zero pulse. In contrast to type 5, type 8 reference travel can also be performed when the system status is not set to "A".<br/>Machine zero = current position + reference offset</p> |



## Startup

### Starting the "Extended positioning via bus" program

*Setting the ramp times in jog and automatic mode*

- In the "Ramp values" group box, enter the ramp times in the input fields "Ramp value jog mode" and "Ramp value auto.mode (1) and (2)". Bit 15 in process output data word 1 is used to change between ramp 1 and ramp 2 in automatic mode. The corresponding acceleration is displayed in the unit [mm/s<sup>2</sup>].




The ramp time always refers to a speed of 3000 min<sup>-1</sup>.

For a ramp time of 1 s the drive would be accelerated to a speed of 1500 min<sup>-1</sup> in 500 ms.

## Download

The download window appears after the settings have been saved.




10824AEN

Figure 18: Download window

Click the <Download> button. All the required settings are made automatically in the inverter, and the IPOS<sup>plus</sup>® program for "Extended positioning via bus" is started.



After the download, the program asks you if you want to start the monitor. In the monitor, you can run a diagnostic of your application and check the control signals.



11023AEN

Figure 19: Start monitor: Yes/No

Select <Yes> to switch to the monitor where you can start it in the required operating mode. Select <No> to switch to MOVITOOLS/Shell.




## Startup

### Starting the "Extended positioning via bus" program

#### Monitor

If "Extended positioning via bus" is started **after** the startup procedure has been performed, the monitor appears immediately.




11018AEN

Figure 20: Extended positioning via bus monitor

- [1] PO1 control word 2, decoded into individual bits
- [2] PI1 status word, decoded into individual bits
- [3] Process data in decimal format and with user units
- [4] Status of the binary inputs of the basic unit
- [5] Position of the software limit switches and current position of the drive

#### Repeated startup

Press <Startup> if you want to repeat startup. A window appears in which you can enter the settings for the fieldbus parameters (→ Section "Setting fieldbus parameters").



## 5.4 Parameters and IPOSplus® variables

The following parameters and IPOSplus® variables are set automatically during startup and are loaded into the inverter during the download:

| Parameter number P... | Index | Description                     | Value                       |
|-----------------------|-------|---------------------------------|-----------------------------|
| 100                   | 8461  | Setpoint source                 | Fieldbus                    |
| 101                   | 8462  | Control signal source           | Fieldbus                    |
|                       |       |                                 |                             |
| 300                   |       | Start/stop speed 1              | 0                           |
| 301                   |       | Minimum speed 1                 | 0                           |
| 302                   |       | Maximum speed 1                 | Can be set in the interface |
|                       |       |                                 |                             |
| 600                   | 8335  | Binary input DI01               | Enable/Rapid stop           |
| 601                   | 8336  | Binary input DI02               | No function                 |
| 602                   | 8337  | Binary input DI03               | Reference cam               |
| 603                   | 8338  | Binary input DI04               | /Right limit switch         |
| 604                   | 8339  | Binary input DI05               | /CCW limit switch           |
| 605                   | 8919  | Binary input DI06 (MDX61B only) | No change                   |
| 606                   | 8920  | Binary input DI07 (MDX61B only) | No change                   |
| 610                   | 8340  | Binary input DI10               | No function                 |
| 611                   | 8341  | Binary input DI11               |                             |
| 612                   | 8342  | Binary input DI12               |                             |
| 613                   | 8343  | Binary input DI13               |                             |
| 614                   | 8344  | Binary input DI14               |                             |
| 615                   | 8345  | Binary input DI15               |                             |
| 616                   | 8346  | Binary input DI16               |                             |
| 617                   | 8347  | Binary input DI17               |                             |
|                       |       |                                 |                             |
| 620                   | 8350  | Binary output D001              | /Fault                      |
| 621                   | 8351  | Binary output D002              | Ready                       |
|                       |       |                                 |                             |
| 630                   | 8352  | Binary output D010              | No function                 |
| 631                   | 8353  | Binary output D011              |                             |
| 632                   | 8354  | Binary output D012              |                             |
| 633                   | 8355  | Binary output D013              |                             |
| 634                   | 8356  | Binary output D014              |                             |
| 635                   | 8357  | Binary output D015              |                             |
| 636                   | 8358  | Binary output D016              |                             |
| 637                   | 8359  | Binary output D017              |                             |
|                       |       |                                 |                             |
| 700                   | 8574  | Operating mode                  | ... & IPOS                  |
| 730                   | 8584  | Brake function 1                | ON                          |
|                       |       |                                 |                             |
| 813                   | 8600  | SBus address                    | Can be set in the interface |
| 815                   | 8602  | SBus timeout delay              |                             |
| 816                   | 8603  | SBus baud rate                  |                             |
| 819                   | 8606  | Fieldbus timeout delay          |                             |
| 831                   | 8610  | Response fieldbus timeout       |                             |
| 836                   | 8615  | Response SBus timeout           |                             |



## Startup Parameters and IPOSplus® variables

| Parameter number P... | Index | Description                  | Value                       |
|-----------------------|-------|------------------------------|-----------------------------|
| 870                   | 8304  | Setpoint description PO1     | Control word 2              |
| 871                   | 8305  | Setpoint description PO2     | IPOS PO-DATA                |
| 872                   | 8306  | Setpoint description PO3     |                             |
| 873                   | 8307  | Actual value description PI1 |                             |
| 874                   | 8308  | Actual value description PI2 |                             |
| 875                   | 8309  | Actual value description PI3 |                             |
| 876                   | 8622  | PO data enable               | ON                          |
| 900                   | 8623  | Reference offset             | Can be set in the interface |
| 903                   | 8626  | Reference travel type        |                             |
| 941                   |       | Source actual position       |                             |

| IPOS <sup>plus</sup> ® variable | Description                             |
|---------------------------------|---|
| H1                              | Max. motor speed in automatic mode      |
| H2                              | Max. motor speed in jog mode            |
| H3                              | Scaling factor for distance numerator   |
| H4                              | Scaling factor for distance denominator |
| H5                              | Scaling factor for speed numerator      |
| H6                              | Scaling factor for speed denominator    |
| H7                              | Ramp 1                                  |
| H8                              | Ramp 2                                  |
| H102                            | Drive wheel diameter (x1000)            |
| H103                            | Gear ratio (x1000)                      |
| H104                            | Additional gear ratio (x1000)           |
| H115                            | Switch SBUS                             |
| H125                            | Pointer to Scope variable H474          |
| H126                            | Pointer to Scope variable H475          |
| H127                            | Referencing to encoder zero pulse       |
| H496 SLS_right                  | Software limit switch CW (INCR)         |
| H497 SLS_left                   | Software limit switch CCW (INCR)        |
| H509 ActPos_Abs                 | Actual position DIP                     |
| H510 ActPos_Ext                 | Actual position X14                     |
| H511 ActPos_Mot                 | Actual position X15                     |
| H1002                           | ScopeDelay                              |



**Do not alter these parameters and IPOS<sup>plus</sup>® variables after startup!**





## 5.5 Recording IPOSplus® variables

IPOSplus® variables can be recorded during operation using the "Scope" program in MOVITOOLS®. This is only possible for the MOVIDRIVE® MDX61B inverter.

The two 32-Bit IPOSplus® variables *H474* and *H475* are available for recording. Two pointer variables (H125/H126) to *H474* and *H475* can be used to record any IPOSplus® variable using the "Scope" program:


- H125 → Scope474Pointer
- H126 → Scope475Pointer

The number of the IPOSplus® variable that is to be recorded in "Scope" must be entered in the variable window of the IPOS Assembler or Compiler in one of the pointer variables H125 or H126.

### Example


The IPOSplus® variable *H511 Current motor position* is to be recorded. Proceed as follows:

- In the "Scope" program, enter the value 511 in variable H125 in the variable window.



10826AXX

- In the "Scope" program, choose [File] / [New]. Set channel 3 to *IPOS variable H474 LOW* and channel 4 to *IPOS variable H474 HIGH*. The "Scope" program now records the value of the IPOSplus® variable H511.



10827AEN



- The pointer variables are copied to the IPOSplus® variable H474 or H475 in TASK 3 of the IPOSplus®.
- The speed (commands / ms) of TASK3 is dependent on the processor utilization of MOVIDRIVE® MDX61B.
- The time (ms) needed in Task 3 to copy the values from the pointer variables to the IPOSplus® variables H474 and H475 is stored in variable H1002. If the value is zero, the copying process lasts less than 1 ms.



## 6 Operation and Service

### 6.1 Starting the drive

Following the download, switch to the "Extended positioning via bus" monitor by selecting "Yes." You can select the operating mode using bits 11 and 12 of "PO1: Control word 2".




Note the following points to start the drive. This procedure applies to all operating modes:

- Binary inputs DIØØ "/CONTROLLER INHIBIT/" and DIØ3 "ENABLE/RAPID STOP" must be assigned a "1" signal.
- **For control via fieldbus or system bus:** Set the control bit PO1:0 "CONTROLLER INHIBIT/ENABLE" = "0" and the control bits PO1:1 "ENABLE/RAPID STOP" and PO1:2 "ENABLE/STOP" = "1".

#### Operating modes

The process output data word 1 (PO1) has the following assignment:

- PO1: Control word 2



The option "Moving clear of the software limit switches" in jog mode (Bit 15:/SWLS) is only available in conjunction with MOVIDRIVE® MDX61B.

- **Jog mode (DI11 = "1" and DI12 = "0")**
  - In jog mode, the drive can be moved CW or CCW via bits 9 and 10 in control word 2 (PO1).
  - The speed in jog mode can be varied and is specified by the PLC via the bus.
- **Referencing mode (DI11 = "0" and DI12 = "1")**

In referencing mode, reference travel can be started via bit 8 in control word 2 (PO1). Reference travel establishes the reference position (machine zero) for absolute positioning operations.



- **Automatic mode (DI11 = "1" and DI12 = "1")**

The target position is based on the machine zero, which was determined beforehand by reference travel. Reference travel is mandatory.




The maximum possible travel distance depends on the travel unit set. Examples:

- Travel unit [1/ 10 mm] → Travel distance = 3.27 m
- Travel unit [mm] → Travel distance = 32.7 m



### 6.2 Monitor mode

The "Extended positioning via bus" monitor mode displays the data that is transmitted via the fieldbus. The process input and output data are read in cyclically and displayed in hexadecimal format.



11018AEN

Figure 21: Monitor mode


- The process input and output data are displayed in the middle of the window.
- You can change the control source by selecting the radio button "Monitor" or "Control":
  - Monitor: The process data are read from a machine control via fieldbus.
  - Control: The process data are specified via a PC. The drive can be controlled with a PC without a machine control. You can use the mouse to set or delete the individual bits in control word PO1. You have to enter the values in the input fields PO2 "Setpoint speed" and PO3 "Target position" as numerical values. To send the process data to the inverter, click the <Send PO> button.



### 6.3 Jog mode

- PO1:12 = "0" and PO1:11 = "1"

You can use the jog mode when the unit is serviced to move the drive independent of the automatic mode. No reference travel is required beforehand.



11019AEN

Figure 22: Jog mode

- Start the drive by setting the control bit PO1:9 "Jog+" or PO1:10 "Jog-". This means you can move the drive in both directions. If the setting "Jog+" or "Jog-" is deleted, the drive stops.
- The speed is specified via PO2: Setpoint speed.




Please also refer to the information in Sec. "Software limit switches."



### 6.4 Referencing mode

- PO1:12 = "1" and PO1:11 = "0"

The reference position is defined by reference travel (e.g. to one of the two hardware limit switches).



11020AEN

Figure 23: Referencing mode

- Ensure that you have set the correct reference travel type (P903) **before starting** reference travel. If this is not the case, restart the startup procedure and set the required type of reference travel.
- Set PO1:8 "Start" to "1" to start reference travel. The "1" signal must be present for the entire duration of the reference travel. Once reference travel has been completed successfully, PI1:2 "IPOS reference" is set. The "1" signal at PO1:8 "Start" can now be revoked. The drive is now referenced.
- You can set the speeds for reference travel in parameters P901 and P902.



- The stop ramp (P136) is used for reference travel. If reference travel is interrupted by revoking the start bit, positioning ramp 1 (P911) is used.
- If referencing is set to the hardware limit switches (type 3 and 4), the drive continues to turn for 4096 increments after leaving the hardware limit switch.
- Please also refer to the information in Sec. "Software limit switches."




### 6.5 Automatic mode

- PO1:12 = "1" and PO1:11 = "1"

In automatic mode, the drive can be positioned absolutely based on the machine zero point (reference position) (the axis must be referenced):

1. The target position is specified via PO2 and PO3, the speed via PO2, the acceleration ramp via PO5 and the brake ramp via PO6.
2. With control via four process data, the positioning ramp can be switched between two ramps specified at startup via PO1:15.
3. If the ramp function (P916) is set to "LINEAR" or "JERK LIMITED", you can change the speed and ramp time while the drive is moving. With all other ramp types, you can only change the speed and the ramp time when the drive is at standstill or if the axis is not enabled.



11021AEN

Figure 24: Automatic mode

- Set PO1:8 "Start" to "1" to start positioning. The "1" signal must be present for the entire duration of the positioning procedure.





- Once positioning has been completed successfully, PI1:3 "Target position reached" is set. The drive comes to a standstill subject to position control.
- The drive moves immediately to a new position if control bit PO1:8 "Start" is set and a new target position is specified via PO3.

The inverter signals the actual position to the control cyclically using process input data words PI2 and PI3. In addition, the inverter signals the actual speed, the active current and the unit utilization to the control via PI4, PI5 and PI6.

**Example: Specify the target position in the double word**

Required target position: +70000 mm (11170 hex).

Content of PO2 and PO3 hexadecimal:

- POSITION HI:1
- POSITION LO:1170

Content of PO2 and PO3 decimal:

- POSITION HI:1
- POSITION LO: 4464

If the PLC specifies a negative target position, this is represented as follows in the two process data words:

- Required position: –70000 mm (FFFF EE90hex)

Content of PO2 and PO3 hexadecimal:

- POSITION HI: FFFF
- POSITION LO: EE90

Content of PO2 and PO3 decimal:

- POSITION HI: – 1
- POSITION LO: 61072



- Parameter P917 Ramp mode is used to determine the use of positioning ramp 2 (P912). If P917 is set to MODE 1, deceleration for travel to target position (spot braking) takes place with positioning ramp 2 (P912).
- If the travel speed changes during travel (P917 = MODE 1), positioning ramp 1 (P911) is used for deceleration.
- If the travel speed changes during travel when P917 is set to MODE 2, positioning ramp 2 (P912) is always used for deceleration.



### 6.6 Cycle diagrams

The following conditions apply to the cycle diagrams:

- DIØØ "/CONTROLLER INHIBIT" = "1" (no lock)
- DIØ1 "ENABLE/RAPID STOP" = "1"
- PO1:1 "ENABLE/RAPID STOP" = "1"
- PA1:2 "ENABLE/STOP" = "1"

The output DB00 "/Brake" is set, the brake is released and the drive stops subject to position control (→ 7-segment display = "A")

#### Jog mode





Figure 25: Cycle diagram: Jog mode

54963AXX

|        |             |   |
|--------|-------------|---|
| PA1:8  | = Start     | [1] = Axis starts when the bit "Jog +" is set |
| PA1:9  | = Jog +     | [2] = Axis starts when the bit "Jog -" is set |
| PA1:10 | = Jog -     |   |
| PA1:11 | = Mode Low  |   |
| PA1:12 | = Mode High |   |



## Referencing mode



54964AXX

Figure 26: Cycle diagram: Referencing mode

PA1:8 = Start  
PA1:11 = Mode Low  
PA1:12 = Mode High  
DIO3 = Reference cam  
PE1:2 = IPOS reference

[1] = Start of reference travel (reference travel type 2)


[2] = Drive reaches reference cam

[3] = Drive leaves reference cam

[4] = When the drive is at a standstill, PE1:2 "IPOS reference" is set. The drive is now referenced.



### Automatic mode



56250AXX

Figure 27: Cycle diagram: Automatic mode

PA1:8 = Start  
 PA1:11 = Mode Low  
 PA1:12 = Mode High  
 PE1:3 = Target position reached

[1] = Automatic absolute selected  
 [2] = Start positioning (target position = PA3)  
 [3] = Target position reached




### Moving clear of hardware limit switches

Once a hardware limit switch (DI04 = "0" or DI05 = "0") has been reached, the bit PE1:5 "Fault" is set and the drive comes to a standstill using an emergency stop.

Proceed as follows to move the drive clear again:

- Jog mode: Set the bits PA1:9 "Jog+" = "0" and PA1:10 "Jog-" = "0".
- Automatic mode: Set bit PA1:8 "Start" = "0".
- Set bit PA1:6 "Reset" to "1". The bit PE1:5 "Fault" is deleted.
- The drive automatically moves clear of the hardware limit switch at the speed specified in *P902 Reference speed 2*.
- Once the drive has moved clear of the hardware limit switch, you can delete PA1:6 "Reset" and select the required operating mode.



54968AXX

Figure 28: Cycle diagram: Moving clear of limit switches

PA1:11= Mode Low

PA1:12= Mode High

PA1:6= Reset

PE1:5= Fault

DI04 = CW limit switch

[1] = The drive has reached the CW hardware limit switch and comes to a halt using an emergency stop ramp.

[2] = PA1:6 "Reset" is set. Drive moves clear of hardware limit switch.

[3] = Drive moves clear of hardware limit switch



If the hardware limit switch with which the drive has come into contact is faulty (no positive edge at DI04 or DI05 as the drive moves clear), the drive must be stopped by revoking the enable (terminal or bus).



### 6.7 Fault information

The fault memory (P080) stores the last five fault messages (faults t-0 to t-4). The oldest fault message is deleted whenever more than five fault messages have occurred. The following information is stored when a malfunction occurs:

Fault that occurred • Status of binary inputs/outputs • Operating status of the inverter • Inverter status • Heat sink temperature • Speed • Output current • Active current • Unit utilization • DC link voltage • ON hours • Enable hours • Parameter set • Motor utilization.

There are three switch-off responses depending on the fault; the inverter remains blocked in fault status:

- **Immediate switch-off:**

The unit can no longer brake the drive; the output stage goes to high resistance in the event of a fault and the brake is applied immediately (DBØØ "/Brake" = "0").

- **Rapid stop:**

The drive is braked with the stop ramp t13/t23. The brake is applied once the stop speed is reached (DBØØ "/Brake" = "0"). The output stage goes to high resistance after the brake reaction time has elapsed (P732 / P735).


- **Emergency stop:**

The drive is braked with the emergency ramp t14/t24. The brake is applied once the stop speed is reached (DBØØ "/Brake" = "0"). The output stage goes to high resistance after the brake reaction time has elapsed (P732 / P735).

#### Reset

A fault message can be acknowledged by:

- Switching the power supply off and on again.  
Recommendation: Observe a minimum switch-off time of 10 s for the supply system contactor K11.
- Reset via binary input DIØ3. Startup of the "Sensor based positioning via bus" application causes this binary input to be assigned with the "Reset" function.
- Only for control with fieldbus/system bus: "0"→∇1"→"1"signal at Bit PO1:6 in control word PO1.
- Press the reset button in the MOVITOOLS® Manager.



10842AEN

Figure 29: Reset with MOVITOOLS®

- Manual reset in MOVITOOLS/Shell (P840 = "YES" or [Parameter] / [Manual reset]).
- Manual reset with DBG60B (MDX61B) or DBG11A (MCH4\_A).

#### Timeout active


If the inverter is controlled via a communication interface (fieldbus, RS485 or SBus) and the power was switched off and back on again or a fault reset was performed, then the enable remains ineffective until the inverter receives valid data again via the interface, which is monitored with a timeout.



## 6.8 Error messages

### Display

The error or warning code is displayed in binary coded format. The following display sequence is adhered to:



Following a reset or if the error or warning code resumes the value "0", the display switches to the operating display again.

### List of errors

The following table shows a selection from the complete error list (→ MOVIDRIVE® operating instructions). Only those errors are listed that can occur specifically with this application.

A dot in the "P" column indicates that the response is programmable (P83\_ Fault response). The factory set fault response appears in the "Response" column.

| Error code | Designation                | Response             | P | Possible cause   | Action  |
|------------|----------------------------|----------------------|---|--|---|
| 00         | No fault                   | -                    |   |  |   |
| 07         | U <sub>Z</sub> overvoltage | Immediate switch-off |   | DC link voltage too high   | <ul style="list-style-type: none"> <li>Extend deceleration ramps</li> <li>Check connection leads to the braking resistor</li> <li>Check technical data of braking resistor</li> </ul>   |
| 08         | n-monitoring               | Immediate switch-off |   | <ul style="list-style-type: none"> <li>Speed controller or current controller (in VFC operating mode without encoder) operating at setting limit due to mechanical overload or phase failure in the power supply or motor.</li> <li>Encoder not connected correctly or incorrect direction of rotation.</li> <li>n<sub>max</sub> is exceeded during torque control.</li> </ul> | <ul style="list-style-type: none"> <li>Reduce load</li> <li>Increase deceleration time setting (P501 or P503)</li> <li>Check encoder connection, swap A/A and B/B pairs if necessary</li> <li>Check encoder voltage supply</li> <li>Check current limitation</li> <li>Extend ramps if necessary</li> <li>Check motor cable and motor</li> <li>Check mains phases</li> </ul> |
| 10         | IPOS-ILLOP                 | Emergency stop       |   | <ul style="list-style-type: none"> <li>Incorrect command detected during running of IPOS<sup>plus</sup>® program.</li> <li>Incorrect conditions during command execution.</li> </ul>   | <ul style="list-style-type: none"> <li>Check program memory content and correct if necessary.</li> <li>Load correct program into program memory.</li> <li>Check program sequence (→ IPOS<sup>plus</sup>® manual)</li> </ul>   |



| Error code | Designation          | Response             | P | Possible cause  | Action   |
|------------|----------------------|----------------------|---|---|--|
| 14         | Encoder              | Immediate switch-off |   | <ul style="list-style-type: none"> <li>Encoder cable or shield not connected correctly</li> <li>Short circuit/broken encoder wire</li> <li>Encoder defective</li> </ul>   | Check encoder cable and shield for correct connection, short circuit and broken wire.  |
| 25         | EEPROM               | Rapid stop           |   | Access to the EEPROM of the memory card has failed  | <ul style="list-style-type: none"> <li>Call up default setting, perform reset and set parameters again.</li> <li>Contact SEW service if the error occurs again.</li> <li>Replace memory card.</li> </ul>   |
| 28         | Fieldbus Timeout     | Rapid stop           |   | No communication between master and slave within the projected response monitoring.   | <ul style="list-style-type: none"> <li>Check communications routine of the master</li> <li>Extend fieldbus timeout time (P819)/deactivate monitoring</li> </ul>  |
| 29         | Limit switch reached | Emergency stop       |   | A limit switch was reached in IPOS <sup>plus</sup> ® operating mode.  | <ul style="list-style-type: none"> <li>Check travel range.</li> <li>Correct user program.</li> </ul>   |
| 31         | TF sensor            | None Response        |   | <ul style="list-style-type: none"> <li>Motor too hot, TF sensor has tripped</li> <li>TF sensor of motor not connected or not connected properly</li> <li>Connection of MOVIDRIVE® and TF on motor interrupted</li> <li>No jumper between X10:1 and X10:2.</li> </ul>                            | <ul style="list-style-type: none"> <li>Let motor cool off and reset fault</li> <li>Check connections/link between MOVIDRIVE® and TF.</li> <li>If no TF is connected: Jumper X10:1 with X10:2.</li> <li>Set P835 to "NO RESPONSE"</li> </ul>  |
| 36         | No option            | Immediate switch-off |   | <ul style="list-style-type: none"> <li>Type of option card not allowed.</li> <li>Setpoint source, control signal source or operating mode not permitted for this option card.</li> <li>Incorrect encoder type set for DIP11A.</li> </ul>  | <ul style="list-style-type: none"> <li>Use correct option card.</li> <li>Set correct setpoint source (P100).</li> <li>Set correct control signal source (P101).</li> <li>Set correct operating mode (P700 or P701).</li> <li>Set the correct encoder type.</li> </ul>  |
| 42         | Lag fault            | Immediate switch-off |   | <ul style="list-style-type: none"> <li>Incremental encoder connected incorrectly</li> <li>Accelerating ramps too short</li> <li>P component of positioning controller too small</li> <li>Speed controller parameters set incorrectly</li> <li>Value of lag fault tolerance too small</li> </ul> | <ul style="list-style-type: none"> <li>Check rotary encoder connection</li> <li>Extend ramps</li> <li>Set P component to higher value</li> <li>Set speed controller parameters again</li> <li>Increase lag fault tolerance</li> <li>Check encoder, motor and mains phase wiring</li> <li>Check mechanical components can move freely, possibly blocked up</li> </ul> |
| 94         | EEPROM checksum      | Immediate switch-off |   | Inverter electronics disrupted, possibly due to effect of EMC or a defect.  | Send the unit in for repair.   |



## 7 Compatibility between MOVIDRIVE® A / B / compact

### 7.1 Important notes

The "Extended positioning via bus" application module for MOVIDRIVE® MDX61B offers a number of additional functions that are not available with MOVIDRIVE® MD\_60A or MOVIDRIVE® compact. This section provides you with information on the differences between the application module when using a MOVIDRIVE® MD\_60A or MOVIDRIVE® compact unit and gives you important information on project planning.

#### **Project planning for MOVIDRIVE® MD\_60A / MOVIDRIVE® compact**

- Drive inverter  
It is essential for the "Extended positioning via bus" application module to have encoder feedback, which means it can only be implemented with the following drive inverters:
  - MOVIDRIVE® MDV60A / MDS60A
  - MOVIDRIVE® compact MCV / MCS
  - MOVIDRIVE® compact MCH41A /MCH42A
- Bus installation for MOVIDRIVE® MDV / MDS60A  
Extended positioning via bus uses 6 process data words. As a result, it is only possible to use the "PROFIBUS" and "INTERBUS with fiber optic cable" fieldbus types. When one of these two fieldbus types is used, MOVIDRIVE® MDV / MDS60A requires one of the options DFP21A, DFP11A or DFI21A.  
Please read the information in the relevant fieldbus manuals.

#### **Compatibility between the hardware terminals**

Compared to MOVIDRIVE® MD\_60A, MOVIDRIVE® MDX61B has two extra digital inputs (DI06, DI07) and three additional digital outputs (DO03, DO04, DO05). The additional hardware inputs and outputs are set to "No function" during initial startup and are not processed in the program.

#### **Software limit switches**

- The function to move clear of the software limit switches is only possible for MOVIDRIVE® MD\_60A, MOVIDRIVE® compact MCx / MCH from the following firmware versions:
- MOVIDRIVE® MD\_60A: 823 854 5.15
  - MOVIDRIVE® compact MCx: 823 859 6.14
  - MOVIDRIVE® compact MCH: 823 947 9.17

#### **Recording IPOS<sup>plus</sup>® variables**

Recording IPOS<sup>plus</sup>® variables using the MOVITOOLS® program "Scope" is only possible with MOVIDRIVE® MDX61B.

#### **SBus send object for DriveSync Slave**

If you use MOVIDRIVE® MD\_60A or MOVIDRIVE® compact MCx / MCH, you do not have the option of setting up an SBus send object to transfer the actual position. It is also not possible to integrate the "DriveSync" application module.

### Wiring diagrams





Figure 30: MOVIDRIVE® compact MCH4\_A

56269AEN



56273AEN

Figure 31: MOVIDRIVE® compact MCV / MCS

## Compatibility between MOVIDRIVE® A / B / compact

### Important notes




Figure 32: MOVIDRIVE® MDV / MDS60\_A

56268AEN



## 8 Index

### A

|  |    |
|--|----|
| Automatic mode .....                   | 52 |
| Automatic operation                    |    |
| <i>Relative positioning mode</i> ..... | 53 |

### B

|                   |    |
|-------------------|----|
| Bus control ..... | 22 |
|-------------------|----|

### C

|  |    |
|--|----|
| Compatibility between MOVIDRIVE® A / B / compact ..... | 61 |
| Cycle diagrams .....                                   | 54 |
| <i>Absolute/relative automatic mode</i> .....          | 56 |
| <i>Jog mode</i> .....                                  | 54 |
| <i>Referencing mode</i> .....                          | 55 |

### E

|                             |    |
|-----------------------------|----|
| Error messages              |    |
| <i>Display</i> .....        | 59 |
| <i>List of errors</i> ..... | 59 |

### I

|  |    |
|--|----|
| Identification .....   | 8  |
| Important notes .....  | 4  |
| <i>Explanation of the icons</i> .....                                  | 4  |
| Installation   |    |
| <i>Application version</i> .....                                       | 20 |
| <i>CANopen (DFC11B)</i> .....  | 26 |
| <i>DeviceNet (DFD11B)</i> .....  | 27 |
| <i>Ethernet (DFE11B)</i> .....   | 28 |
| <i>INTERBUS (DFI11B)</i> .....   | 25 |
| <i>INTERBUS with FO (DFI21B)</i> .....                                 | 24 |
| <i>MDX61B with bus control</i> .....                                   | 22 |
| <i>MOVITOOLS</i> .....   | 20 |
| <i>PROFIBUS (DFP21B)</i> .....   | 23 |
| <i>Software</i> .....  | 20 |
| <i>System bus connection (SBus)</i> .....                              | 29 |
| <i>Wiring diagram for MDX 61B with options DEH11B and DER11B</i> ..... | 21 |

### J

|                |    |
|----------------|----|
| Jog mode ..... | 49 |
|----------------|----|

### M

|   |    |
|---|----|
| Malfunction information .....               | 58 |
| <i>Reset</i> .....                          | 58 |
| <i>Timeout</i> .....                        | 58 |
| Monitor mode .....                          | 48 |
| Move clear of hardware limit switches ..... | 57 |

### O

|                               |    |
|-------------------------------|----|
| Operating modes               |    |
| <i>Automatic mode</i> .....   | 47 |
| <i>Referencing mode</i> ..... | 46 |

### P

|                              |   |
|------------------------------|---|
| Program identification ..... | 8 |
|------------------------------|---|

### Project planning

|  |    |
|--|----|
| <i>Automatic mode</i> .....                                  | 47 |
| <i>Jog mode</i> .....  | 46 |
| <i>Limit switches, reference cams and machine zero</i> ..... | 13 |
| <i>Reference travel</i> .....                                | 46 |
| <i>Safe stop</i> .....                                       | 19 |
| <i>Scaling the drive</i> .....                               | 10 |
| <i>Software limit switches</i> .....                         | 16 |

### R

|                                |    |
|--------------------------------|----|
| Recording IPOS variables ..... | 45 |
| Referencing mode .....         | 50 |

### S

|   |    |
|---|----|
| Safety notes .....  | 5  |
| Scaling the drive .....                                     | 10 |
| <i>Drive with external encoder</i> .....                    | 12 |
| <i>Drive without external encoder</i> .....                 | 11 |
| Shutdown response   |    |
| <i>Emergency stop</i> .....                                 | 58 |
| <i>Immediate switch-off</i> .....                           | 58 |
| <i>Rapid stop</i> .....                                     | 58 |
| Software limit switches .....                               | 16 |
| <i>Moving clear of the software limit switch</i> .....      | 16 |
| Starting the drive .....                                    | 46 |
| Startup .....   | 31 |
| <i>General information</i> .....                            | 31 |
| <i>Parameters and IPOS variables</i> .....                  | 43 |
| <i>Preliminary work</i> .....                               | 31 |
| <i>Setting ramp times and limits</i> .....                  | 38 |
| <i>Setting the distance and speed scaling factors</i> ..... | 34 |
| <i>Setting the fieldbus parameters</i> .....                | 33 |
| <i>Start program</i> .....                                  | 32 |
| System bus (SBus)   |    |
| <i>Connection</i> .....                                     | 29 |

### W

|   |    |
|---|----|
| Wiring diagram for MDX 61B with options DEH11B and DER11B ..... | 21 |
|---|----|



## Address List

### Address List

| Germany                             |  |   |   |
|-------------------------------------|--|---|---|
| Headquarters<br>Production<br>Sales | Bruchsal   | SEW-EURODRIVE GmbH & Co KG<br>Ernst-Blickle-Straße 42<br>D-76646 Bruchsal<br>P.O. Box<br>Postfach 3023 · D-76642 Bruchsal | Tel. +49 7251 75-0<br>Fax +49 7251 75-1970<br><a href="http://www.sew-eurodrive.de">http://www.sew-eurodrive.de</a><br><a href="mailto:sew@sew-eurodrive.de">sew@sew-eurodrive.de</a> |
|                                     |  |   |   |
| Service<br>Competence Center        | Central<br>Gear units /<br>Motors                                | SEW-EURODRIVE GmbH & Co KG<br>Ernst-Blickle-Straße 1<br>D-76676 Graben-Neudorf  | Tel. +49 7251 75-1710<br>Fax +49 7251 75-1711<br><a href="mailto:sc-mitte-gm@sew-eurodrive.de">sc-mitte-gm@sew-eurodrive.de</a>   |
|                                     | Central<br>Electronics   | SEW-EURODRIVE GmbH & Co KG<br>Ernst-Blickle-Straße 42<br>D-76646 Bruchsal   | Tel. +49 7251 75-1780<br>Fax +49 7251 75-1769<br><a href="mailto:sc-mitte-e@sew-eurodrive.de">sc-mitte-e@sew-eurodrive.de</a>   |
|                                     | North  | SEW-EURODRIVE GmbH & Co KG<br>Alte Ricklinger Straße 40-42<br>D-30823 Garbsen (near Hannover)                             | Tel. +49 5137 8798-30<br>Fax +49 5137 8798-55<br><a href="mailto:sc-nord@sew-eurodrive.de">sc-nord@sew-eurodrive.de</a>   |
|                                     | East   | SEW-EURODRIVE GmbH & Co KG<br>Dänkritzter Weg 1<br>D-08393 Meerane (near Zwickau)   | Tel. +49 3764 7606-0<br>Fax +49 3764 7606-30<br><a href="mailto:sc-ost@sew-eurodrive.de">sc-ost@sew-eurodrive.de</a>  |
|                                     | South  | SEW-EURODRIVE GmbH & Co KG<br>Domagkstraße 5<br>D-85551 Kirchheim (near München)  | Tel. +49 89 909552-10<br>Fax +49 89 909552-50<br><a href="mailto:sc-sued@sew-eurodrive.de">sc-sued@sew-eurodrive.de</a>   |
|                                     | West   | SEW-EURODRIVE GmbH & Co KG<br>Siemensstraße 1<br>D-40764 Langenfeld (near Düsseldorf)                                     | Tel. +49 2173 8507-30<br>Fax +49 2173 8507-55<br><a href="mailto:sc-west@sew-eurodrive.de">sc-west@sew-eurodrive.de</a>   |
|                                     | Drive Service Hotline / 24 Hour Service                          |   | +49 180 5 SEWHELP<br>+49 180 5 7394357  |
|                                     | Additional addresses for service in Germany provided on request! |   |   |

| France  |                 |   |  |
|---|-----------------|---|--|
| <b>Production<br/>Sales<br/>Service</b>                         | <b>Hagenau</b>  | SEW-USOCOME<br>48-54, route de Soufflenheim<br>B. P. 20185<br>F-67506 Hagenau Cedex                       | Tel. +33 3 88 73 67 00<br>Fax +33 3 88 73 66 00<br><a href="http://www.usocomme.com">http://www.usocomme.com</a><br><a href="mailto:sew@usocomme.com">sew@usocomme.com</a> |
| <b>Assembly<br/>Sales<br/>Service</b>                           | <b>Bordeaux</b> | SEW-USOCOME<br>Parc d'activités de Magellan<br>62, avenue de Magellan - B. P. 182<br>F-33607 Pessac Cedex | Tel. +33 5 57 26 39 00<br>Fax +33 5 57 26 39 09  |
|   | <b>Lyon</b>     | SEW-USOCOME<br>Parc d'Affaires Roosevelt<br>Rue Jacques Tati<br>F-69120 Vaulx en Velin                    | Tel. +33 4 72 15 37 00<br>Fax +33 4 72 15 37 15  |
|   | <b>Paris</b>    | SEW-USOCOME<br>Zone industrielle<br>2, rue Denis Papin<br>F-77390 Verneuil l'Etang                        | Tel. +33 1 64 42 40 80<br>Fax +33 1 64 42 40 88  |
| Additional addresses for service in France provided on request! |                 |   |  |

| Algeria      |              |   |   |
|--------------|--------------|---|---|
| <b>Sales</b> | <b>Alger</b> | Réducom<br>16, rue des Frères Zaghoun<br>Bellevue El-Harrach<br>16200 Alger | Tel. +213 21 8222-84<br>Fax +213 21 8222-84 |

| Argentina                             |                     |   |   |
|---------------------------------------|---------------------|---|---|
| <b>Assembly<br/>Sales<br/>Service</b> | <b>Buenos Aires</b> | SEW EURODRIVE ARGENTINA S.A.<br>Centro Industrial Garin, Lote 35<br>Ruta Panamericana Km 37,5<br>1619 Garin | Tel. +54 3327 4572-84<br>Fax +54 3327 4572-21<br><a href="mailto:sewar@sew-eurodrive.com.ar">sewar@sew-eurodrive.com.ar</a> |



|   |   |  |  |
|---|---|--|--|
| Australia   |   |  |  |
| Assembly<br>Sales<br>Service                                    | Melbourne   | SEW-EURODRIVE PTY. LTD.<br>27 Beverage Drive<br>Tullamarine, Victoria 3043   | Tel. +61 3 9933-1000<br>Fax +61 3 9933-1003<br><a href="http://www.sew-eurodrive.com.au">http://www.sew-eurodrive.com.au</a><br><a href="mailto:enquires@sew-eurodrive.com.au">enquires@sew-eurodrive.com.au</a> |
|   | Sydney  | SEW-EURODRIVE PTY. LTD.<br>9, Sleigh Place, Wetherill Park<br>New South Wales, 2164  | Tel. +61 2 9725-9900<br>Fax +61 2 9725-9905<br><a href="mailto:enquires@sew-eurodrive.com.au">enquires@sew-eurodrive.com.au</a>  |
| Austria   |   |  |  |
| Assembly<br>Sales<br>Service                                    | Wien  | SEW-EURODRIVE Ges.m.b.H.<br>Richard-Strauss-Strasse 24<br>A-1230 Wien  | Tel. +43 1 617 55 00-0<br>Fax +43 1 617 55 00-30<br><a href="http://sew-eurodrive.at">http://sew-eurodrive.at</a><br><a href="mailto:sew@sew-eurodrive.at">sew@sew-eurodrive.at</a>                              |
| Belgium   |   |  |  |
| Assembly<br>Sales<br>Service                                    | Brüssel   | SEW Caron-Vector S.A.<br>Avenue Eiffel 5<br>B-1300 Wavre   | Tel. +32 10 231-311<br>Fax +32 10 231-336<br><a href="http://www.caron-vector.be">http://www.caron-vector.be</a><br><a href="mailto:info@caron-vector.be">info@caron-vector.be</a>                               |
| Brazil  |   |  |  |
| Production<br>Sales<br>Service                                  | Sao Paulo   | SEW-EURODRIVE Brasil Ltda.<br>Avenida Amâncio Gaiolli, 50<br>Caixa Postal: 201-07111-970<br>Guarulhos/SP - Cep.: 07251-250   | Tel. +55 11 6489-9133<br>Fax +55 11 6480-3328<br><a href="http://www.sew.com.br">http://www.sew.com.br</a><br><a href="mailto:sew@sew.com.br">sew@sew.com.br</a>   |
|   | Additional addresses for service in Brazil provided on request! |  |  |
| Bulgaria  |   |  |  |
| Sales   | Sofia   | BEVER-DRIVE GmbH<br>Bogdanovetz Str.1<br>BG-1606 Sofia   | Tel. +359 2 9532565<br>Fax +359 2 9549345<br><a href="mailto:bever@fastbg.net">bever@fastbg.net</a>  |
| Cameroon  |   |  |  |
| Sales   | Douala  | Electro-Services<br>Rue Drouot Akwa<br>B.P. 2024<br>Douala   | Tel. +237 4322-99<br>Fax +237 4277-03  |
| Canada  |   |  |  |
| Assembly<br>Sales<br>Service                                    | Toronto   | SEW-EURODRIVE CO. OF CANADA LTD.<br>210 Walker Drive<br>Bramalea, Ontario L6T3W1   | Tel. +1 905 791-1553<br>Fax +1 905 791-2999<br><a href="http://www.sew-eurodrive.ca">http://www.sew-eurodrive.ca</a><br><a href="mailto:l.reynolds@sew-eurodrive.ca">l.reynolds@sew-eurodrive.ca</a>             |
|   | Vancouver   | SEW-EURODRIVE CO. OF CANADA LTD.<br>7188 Honeyman Street<br>Delta. B.C. V4G 1 E2   | Tel. +1 604 946-5535<br>Fax +1 604 946-2513<br><a href="mailto:b.wake@sew-eurodrive.ca">b.wake@sew-eurodrive.ca</a>  |
|   | Montreal  | SEW-EURODRIVE CO. OF CANADA LTD.<br>2555 Rue Leger Street<br>LaSalle, Quebec H8N 2V9   | Tel. +1 514 367-1124<br>Fax +1 514 367-3677<br><a href="mailto:a.peluso@sew-eurodrive.ca">a.peluso@sew-eurodrive.ca</a>  |
| Additional addresses for service in Canada provided on request! |   |  |  |
| Chile   |   |  |  |
| Assembly<br>Sales<br>Service                                    | Santiago de Chile   | SEW-EURODRIVE CHILE LTDA.<br>Las Encinas 1295<br>Parque Industrial Valle Grande<br>LAMP<br>RCH-Santiago de Chile<br>P.O. Box<br>Casilla 23 Correo Quilicura - Santiago - Chile | Tel. +56 2 75770-00<br>Fax +56 2 75770-01<br><a href="mailto:ventas@sew-eurodrive.cl">ventas@sew-eurodrive.cl</a>  |
| China   |   |  |  |
| Production<br>Assembly<br>Sales<br>Service                      | Tianjin   | SEW-EURODRIVE (Tianjin) Co., Ltd.<br>No. 46, 7th Avenue, TEDA<br>Tianjin 300457  | Tel. +86 22 25322612<br>Fax +86 22 25322611<br><a href="mailto:gm-tianjin@sew-eurodrive.cn">gm-tianjin@sew-eurodrive.cn</a><br><a href="http://www.sew.com.cn">http://www.sew.com.cn</a>                         |





## Address List

|                                       |                   |  |  |
|---------------------------------------|-------------------|--|--|
| <b>China</b>                          |                   |  |  |
| <b>Assembly<br/>Sales<br/>Service</b> | <b>Suzhou</b>     | SEW-EURODRIVE (Suzhou) Co., Ltd.<br>333, Suhong Middle Road<br>Suzhou Industrial Park<br>Jiangsu Province, 215021<br>P. R. China   | Tel. +86 512 62581781<br>Fax +86 512 62581783<br>suzhou@sew.com.cn   |
| <b>Colombia</b>                       |                   |  |  |
| <b>Assembly<br/>Sales<br/>Service</b> | <b>Bogotá</b>     | SEW-EURODRIVE COLOMBIA LTDA.<br>Calle 22 No. 132-60<br>Bodega 6, Manzana B<br>Santafé de Bogotá                                    | Tel. +57 1 54750-50<br>Fax +57 1 54750-44<br>sewcol@sew-eurodrive.com.co   |
| <b>Croatia</b>                        |                   |  |  |
| <b>Sales<br/>Service</b>              | <b>Zagreb</b>     | KOMPEKS d. o. o.<br>PIT Erdödy 4 II<br>HR 10 000 Zagreb  | Tel. +385 1 4613-158<br>Fax +385 1 4613-158<br>kompeks@net.hr  |
| <b>Czech Republic</b>                 |                   |  |  |
| <b>Sales</b>                          | <b>Praha</b>      | SEW-EURODRIVE CZ S.R.O.<br>Business Centrum Praha<br>Luná 591<br>CZ-16000 Praha 6 - Vokovice                                       | Tel. +420 220121236<br>Fax +420 220121237<br><a href="http://www.sew-eurodrive.cz">http://www.sew-eurodrive.cz</a><br>sew@sew-eurodrive.cz               |
| <b>Denmark</b>                        |                   |  |  |
| <b>Assembly<br/>Sales<br/>Service</b> | <b>Kopenhagen</b> | SEW-EURODRIVEA/S<br>Geminivej 28-30, P.O. Box 100<br>DK-2670 Greve   | Tel. +45 43 9585-00<br>Fax +45 43 9585-09<br><a href="http://www.sew-eurodrive.dk">http://www.sew-eurodrive.dk</a><br>sew@sew-eurodrive.dk               |
| <b>Estonia</b>                        |                   |  |  |
| <b>Sales</b>                          | <b>Tallin</b>     | ALAS-KUUL AS<br>Paldiski mnt.125<br>EE 0006 Tallin   | Tel. +372 6593230<br>Fax +372 6593231<br>veiko.soots@alas-kuul.ee  |
| <b>Finland</b>                        |                   |  |  |
| <b>Assembly<br/>Sales<br/>Service</b> | <b>Lahti</b>      | SEW-EURODRIVE OY<br>Vesimäentie 4<br>FIN-15860 Hollola 2   | Tel. +358 201 589-300<br>Fax +358 3 780-6211<br><a href="http://www.sew-eurodrive.fi">http://www.sew-eurodrive.fi</a><br>sew@sew.fi                      |
| <b>Gabon</b>                          |                   |  |  |
| <b>Sales</b>                          | <b>Libreville</b> | Electro-Services<br>B.P. 1889<br>Libreville  | Tel. +241 7340-11<br>Fax +241 7340-12  |
| <b>Great Britain</b>                  |                   |  |  |
| <b>Assembly<br/>Sales<br/>Service</b> | <b>Normanton</b>  | SEW-EURODRIVE Ltd.<br>Beckbridge Industrial Estate<br>P.O. Box No.1<br>GB-Normanton, West- Yorkshire WF6 1QR                       | Tel. +44 1924 893-855<br>Fax +44 1924 893-702<br><a href="http://www.sew-eurodrive.co.uk">http://www.sew-eurodrive.co.uk</a><br>info@sew-eurodrive.co.uk |
| <b>Greece</b>                         |                   |  |  |
| <b>Sales<br/>Service</b>              | <b>Athen</b>      | Christ. Boznos & Son S.A.<br>12, Mavromichali Street<br>P.O. Box 80136, GR-18545 Piraeus   | Tel. +30 2 1042 251-34<br>Fax +30 2 1042 251-59<br><a href="http://www.boznos.gr">http://www.boznos.gr</a><br>info@boznos.gr                             |
| <b>Hong Kong</b>                      |                   |  |  |
| <b>Assembly<br/>Sales<br/>Service</b> | <b>Hong Kong</b>  | SEW-EURODRIVE LTD.<br>Unit No. 801-806, 8th Floor<br>Hong Leong Industrial Complex<br>No. 4, Wang Kwong Road<br>Kowloon, Hong Kong | Tel. +852 2 7960477 + 79604654<br>Fax +852 2 7959129<br>sew@sewhk.com  |





|                               |                   |   |   |
|-------------------------------|-------------------|---|---|
| <b>Hungary</b>                |                   |   |   |
| <b>Sales Service</b>          | <b>Budapest</b>   | SEW-EURODRIVE Kft.<br>H-1037 Budapest<br>Kunigunda u. 18  | Tel. +36 1 437 06-58<br>Fax +36 1 437 06-50<br>office@sew-eurodrive.hu                            |
| <b>India</b>                  |                   |   |   |
| <b>Assembly Sales Service</b> | <b>Baroda</b>     | SEW-EURODRIVE India Pvt. Ltd.<br>Plot No. 4, Gidc<br>Por Ramangamdi · Baroda - 391 243<br>Gujarat                 | Tel. +91 265 2831086<br>Fax +91 265 2831087<br>mdoffice@seweurodriveindia.com                     |
| <b>Technical Offices</b>      | <b>Bangalore</b>  | SEW-EURODRIVE India Private Limited<br>308, Prestige Centre Point<br>7, Edward Road<br>Bangalore                  | Tel. +91 80 22266565<br>Fax +91 80 22266569<br>salesbang@seweurodriveinindia.com                  |
|                               | <b>Mumbai</b>     | SEW-EURODRIVE India Private Limited<br>312 A, 3rd Floor, Acme Plaza<br>Andheri Kurla Road, Andheri (E)<br>Mumbai  | Tel. +91 22 28348440<br>Fax +91 22 28217858<br>salesmumbai@seweurodriveindia.com                  |
| <b>Ireland</b>                |                   |   |   |
| <b>Sales Service</b>          | <b>Dublin</b>     | Alperston Engineering Ltd.<br>48 Moyle Road<br>Dublin Industrial Estate<br>Glasnevin, Dublin 11                   | Tel. +353 1 830-6277<br>Fax +353 1 830-6458   |
| <b>Israel</b>                 |                   |   |   |
| <b>Sales</b>                  | <b>Tel-Aviv</b>   | Liraz Handasa Ltd.<br>Ahofer Str 34B / 228<br>58858 Holon   | Tel. +972 3 5599511<br>Fax +972 3 5599512<br>lirazhandasa@barak-online.net                        |
| <b>Italy</b>                  |                   |   |   |
| <b>Assembly Sales Service</b> | <b>Milano</b>     | SEW-EURODRIVE di R. Blickle & Co.s.a.s.<br>Via Bernini,14<br>I-20020 Solaro (Milano)                              | Tel. +39 02 96 9801<br>Fax +39 02 96 799781<br>sewit@sew-eurodrive.it                             |
| <b>Ivory Coast</b>            |                   |   |   |
| <b>Sales</b>                  | <b>Abidjan</b>    | SICA<br>Ste industrielle et commerciale pour l'Afrique<br>165, Bld de Marseille<br>B.P. 2323, Abidjan 08          | Tel. +225 2579-44<br>Fax +225 2584-36   |
| <b>Japan</b>                  |                   |   |   |
| <b>Assembly Sales Service</b> | <b>Toyoda-cho</b> | SEW-EURODRIVE JAPAN CO., LTD<br>250-1, Shimoman-no,<br>Iwata<br>Shizuoka 438-0818                                 | Tel. +81 538 373811<br>Fax +81 538 373814<br>sewjapan@sew-eurodrive.co.jp                         |
| <b>Korea</b>                  |                   |   |   |
| <b>Assembly Sales Service</b> | <b>Ansan-City</b> | SEW-EURODRIVE KOREA CO., LTD.<br>B 601-4, Banweol Industrial Estate<br>Unit 1048-4, Shingil-Dong<br>Ansan 425-120 | Tel. +82 31 492-8051<br>Fax +82 31 492-8056<br>master@sew-korea.co.kr                             |
| <b>Latvia</b>                 |                   |   |   |
| <b>Sales</b>                  | <b>Riga</b>       | SIA Alas-Kuul<br>Katlakalna 11C<br>LV-1073 Riga   | Tel. +371 7139386<br>Fax +371 7139386<br>info@alas-kuul.ee  |
| <b>Lebanon</b>                |                   |   |   |
| <b>Sales</b>                  | <b>Beirut</b>     | Gabriel Acar & Fils sarl<br>B. P. 80484<br>Bourj Hammoud, Beirut  | Tel. +961 1 4947-86<br>+961 1 4982-72<br>+961 3 2745-39<br>Fax +961 1 4949-71<br>gacar@beirut.com |



## Address List

| Lithuania                    |              |   |  |
|------------------------------|--------------|---|--|
| Sales                        | Alytus       | UAB Irseva<br>Merkines g. 2A<br>LT-62252 Alytus   | Tel. +370 315 79204<br>Fax +370 315 56175<br>info@irseva.lt<br>http://www.sew-eurodrive.lt         |
| Luxembourg                   |              |   |  |
| Assembly<br>Sales<br>Service | Brüssel      | CARON-VECTOR S.A.<br>Avenue Eiffel 5<br>B-1300 Wavre  | Tel. +32 10 231-311<br>Fax +32 10 231-336<br>http://www.caron-vector.be<br>info@caron-vector.be    |
| Malaysia                     |              |   |  |
| Assembly<br>Sales<br>Service | Johore       | SEW-EURODRIVE SDN BHD<br>No. 95, Jalan Seroja 39, Taman Johor Jaya<br>81000 Johor Bahru, Johor<br>West Malaysia                                     | Tel. +60 7 3549409<br>Fax +60 7 3541404<br>kchtan@pd.jaring.my                                     |
| Mexico                       |              |   |  |
| Assembly<br>Sales<br>Service | Queretaro    | SEW-EURODRIVE, Sales and Distribution,<br>S. A. de C. V.<br>Privada Tequisquiapan No. 102<br>Parque Ind. Queretaro C. P. 76220<br>Queretaro, Mexico | Tel. +52 442 1030-300<br>Fax +52 442 1030-301<br>scmexico@seweurodrive.com.mx                      |
| Morocco                      |              |   |  |
| Sales                        | Casablanca   | S. R. M.<br>Société de Réalisations Mécaniques<br>5, rue Emir Abdelkader<br>05 Casablanca   | Tel. +212 2 6186-69 + 6186-70 + 6186-71<br>Fax +212 2 6215-88<br>srm@marocnet.net.ma               |
| Netherlands                  |              |   |  |
| Assembly<br>Sales<br>Service | Rotterdam    | VECTOR Aandrijftechniek B.V.<br>Industrieweg 175<br>NL-3044 AS Rotterdam<br>Postbus 10085<br>NL-3004 AB Rotterdam                                   | Tel. +31 10 4463-700<br>Fax +31 10 4155-552<br>http://www.vector.nu<br>info@vector.nu              |
| New Zealand                  |              |   |  |
| Assembly<br>Sales<br>Service | Auckland     | SEW-EURODRIVE NEW ZEALAND LTD.<br>P.O. Box 58-428<br>82 Greenmount drive<br>East Tamaki Auckland  | Tel. +64 9 2745627<br>Fax +64 9 2740165<br>sales@sew-eurodrive.co.nz                               |
|                              | Christchurch | SEW-EURODRIVE NEW ZEALAND LTD.<br>10 Settlers Crescent, Ferryroad<br>Christchurch   | Tel. +64 3 384-6251<br>Fax +64 3 384-6455<br>sales@sew-eurodrive.co.nz                             |
| Norway                       |              |   |  |
| Assembly<br>Sales<br>Service | Moss         | SEW-EURODRIVE A/S<br>Solgaard skog 71<br>N-1599 Moss  | Tel. +47 69 241-020<br>Fax +47 69 241-040<br>sew@sew-eurodrive.no                                  |
| Peru                         |              |   |  |
| Assembly<br>Sales<br>Service | Lima         | SEW DEL PERU MOTORES REDUCTORES<br>S.A.C.<br>Los Calderos, 120-124<br>Urbanizacion Industrial Vulcano, ATE, Lima                                    | Tel. +51 1 3495280<br>Fax +51 1 3493002<br>sewperu@sew-eurodrive.com.pe                            |
| Poland                       |              |   |  |
| Assembly<br>Sales<br>Service | Lodz         | SEW-EURODRIVE Polska Sp.z.o.o.<br>ul. Techniczna 5<br>PL-92-518 Lodz  | Tel. +48 42 67710-90<br>Fax +48 42 67710-99<br>http://www.sew-eurodrive.pl<br>sew@sew-eurodrive.pl |



|                                       |                       |   |   |
|---------------------------------------|-----------------------|---|---|
| <b>Portugal</b>                       |                       |   |   |
| <b>Assembly<br/>Sales<br/>Service</b> | <b>Coimbra</b>        | SEW-EURODRIVE, LDA.<br>Apartado 15<br>P-3050-901 Mealhada   | Tel. +351 231 20 9670<br>Fax +351 231 20 3685<br><a href="http://www.sew-eurodrive.pt">http://www.sew-eurodrive.pt</a><br><a href="mailto:infosew@sew-eurodrive.pt">infosew@sew-eurodrive.pt</a>    |
| <b>Romania</b>                        |                       |   |   |
| <b>Sales<br/>Service</b>              | <b>Bucuresti</b>      | Sialco Trading SRL<br>str. Madrid nr.4<br>011785 Bucuresti  | Tel. +40 21 230-1328<br>Fax +40 21 230-7170<br><a href="mailto:sialco@sialco.ro">sialco@sialco.ro</a>   |
| <b>Russia</b>                         |                       |   |   |
| <b>Assembly<br/>Sales<br/>Service</b> | <b>St. Petersburg</b> | ZAO SEW-EURODRIVE<br>P.O. Box 36<br>195220 St. Petersburg Russia  | Tel. +7 812 3332522 +7 812 5357142<br>Fax +7 812 3332523<br><a href="http://www.sew-eurodrive.ru">http://www.sew-eurodrive.ru</a><br><a href="mailto:sew@sew-eurodrive.ru">sew@sew-eurodrive.ru</a> |
| <b>Senegal</b>                        |                       |   |   |
| <b>Sales</b>                          | <b>Dakar</b>          | SENEMECA<br>Mécanique Générale<br>Km 8, Route de Rufisque<br>B.P. 3251, Dakar   | Tel. +221 849 47-70<br>Fax +221 849 47-71<br><a href="mailto:senemeca@sentoo.sn">senemeca@sentoo.sn</a>   |
| <b>Serbia and Montenegro</b>          |                       |   |   |
| <b>Sales</b>                          | <b>Beograd</b>        | DIPAR d.o.o.<br>Kajmakcalanska 54<br>SCG-11000 Beograd  | Tel. +381 11 3088677 / +381 11 3088678<br>Fax +381 11 3809380<br><a href="mailto:dipar@yubc.net">dipar@yubc.net</a>   |
| <b>Singapore</b>                      |                       |   |   |
| <b>Assembly<br/>Sales<br/>Service</b> | <b>Singapore</b>      | SEW-EURODRIVE PTE. LTD.<br>No 9, Tuas Drive 2<br>Jurong Industrial Estate<br>Singapore 638644   | Tel. +65 68621701<br>Fax +65 68612827<br><a href="mailto:sewsingapore@sew-eurodrive.com">sewsingapore@sew-eurodrive.com</a>   |
| <b>Slovakia</b>                       |                       |   |   |
| <b>Sales</b>                          | <b>Sered</b>          | SEW-Eurodrive SK s.r.o.<br>Trnavska 920<br>SK-926 01 Sered  | Tel. +421 31 7891311<br>Fax +421 31 7891312<br><a href="mailto:sew@sew-eurodrive.sk">sew@sew-eurodrive.sk</a>   |
| <b>Slovenia</b>                       |                       |   |   |
| <b>Sales<br/>Service</b>              | <b>Celje</b>          | Pakman - Pogonska Tehnika d.o.o.<br>Ul. XIV. divizije 14<br>SLO – 3000 Celje  | Tel. +386 3 490 83-20<br>Fax +386 3 490 83-21<br><a href="mailto:pakman@siol.net">pakman@siol.net</a>   |
| <b>South Africa</b>                   |                       |   |   |
| <b>Assembly<br/>Sales<br/>Service</b> | <b>Johannesburg</b>   | SEW-EURODRIVE (PROPRIETARY) LIMITED<br>Eurodrive House<br>Cnr. Adcock Ingram and Aerodrome Roads<br>Aeroton Ext. 2<br>Johannesburg 2013<br>P.O.Box 90004<br>Bertsham 2013 | Tel. +27 11 248-7000<br>Fax +27 11 494-3104<br><a href="mailto:dross@sew.co.za">dross@sew.co.za</a>   |
|                                       | <b>Capetown</b>       | SEW-EURODRIVE (PROPRIETARY) LIMITED<br>Rainbow Park<br>Cnr. Racecourse & Omuramba Road<br>Montague Gardens<br>Cape Town<br>P.O.Box 36556<br>Chempet 7442<br>Cape Town     | Tel. +27 21 552-9820<br>Fax +27 21 552-9830<br>Telex 576 062<br><a href="mailto:dswanepoel@sew.co.za">dswanepoel@sew.co.za</a>  |
|                                       | <b>Durban</b>         | SEW-EURODRIVE (PROPRIETARY) LIMITED<br>2 Monaceo Place<br>Pinetown<br>Durban<br>P.O. Box 10433, Ashwood 3605  | Tel. +27 31 700-3451<br>Fax +27 31 700-3847<br><a href="mailto:dtait@sew.co.za">dtait@sew.co.za</a>   |



## Address List

| Spain  |                 |  |   |
|--|-----------------|--|---|
| Assembly<br>Sales<br>Service                                     | Bilbao          | SEW-EURODRIVE ESPAÑA, S.L.<br>Parque Tecnológico, Edificio, 302<br>E-48170 Zamudio (Vizcaya)   | Tel. +34 9 4431 84-70<br>Fax +34 9 4431 84-71<br>sew.spain@sew-eurodrive.es   |
| Sweden   |                 |  |   |
| Assembly<br>Sales<br>Service                                     | Jönköping       | SEW-EURODRIVE AB<br>Gnejsvägen 6-8<br>S-55303 Jönköping<br>Box 3100 S-55003 Jönköping  | Tel. +46 36 3442-00<br>Fax +46 36 3442-80<br><a href="http://www.sew-eurodrive.se">http://www.sew-eurodrive.se</a><br>info@sew-eurodrive.se   |
| Switzerland  |                 |  |   |
| Assembly<br>Sales<br>Service                                     | Basel           | Alfred Imhof A.G.<br>Jurastrasse 10<br>CH-4142 Münchenstein bei Basel  | Tel. +41 61 41717-17<br>Fax +41 61 41717-00<br><a href="http://www.imhof-sew.ch">http://www.imhof-sew.ch</a><br>info@imhof-sew.ch   |
| Thailand   |                 |  |   |
| Assembly<br>Sales<br>Service                                     | Chon Buri       | SEW-EURODRIVE (Thailand) Ltd.<br>Bangpakong Industrial Park 2<br>700/456, Moo.7, Tambol Donhuaroh<br>Muang District<br>Chon Buri 20000 | Tel. +66 38 454281<br>Fax +66 38 454288<br>sewthailand@sew-eurodrive.co.th  |
| Tunisia  |                 |  |   |
| Sales  | Tunis           | T. M.S. Technic Marketing Service<br>7, rue Ibn El Heithem<br>Z.I. SMMT<br>2014 Mégrine Erriadh  | Tel. +216 1 4340-64 + 1 4320-29<br>Fax +216 1 4329-76   |
| Turkey   |                 |  |   |
| Assembly<br>Sales<br>Service                                     | Istanbul        | SEW-EURODRIVE<br>Hareket Sistemleri Sirketi<br>Bagdat Cad. Koruma Cikmazi No. 3<br>TR-34846 Maltepe ISTANBUL                           | Tel. +90 216 4419163 + 216 4419164 +<br>216 3838014<br>Fax +90 216 3055867<br>sew@sew-eurodrive.com.tr  |
| Ukraine  |                 |  |   |
| Sales<br>Service   | Dnepropetrovsk  | SEW-EURODRIVE<br>Str. Rabochaja 23-B, Office 409<br>49008 Dnepropetrovsk   | Tel. +380 56 370 3211<br>Fax +380 56 372 2078<br>sew@sew-eurodrive.ua   |
| USA  |                 |  |   |
| Production<br>Assembly<br>Sales<br>Service                       | Greenville      | SEW-EURODRIVE INC.<br>1295 Old Spartanburg Highway<br>P.O. Box 518<br>Lyman, S.C. 29365  | Tel. +1 864 439-7537<br>Fax Sales +1 864 439-7830<br>Fax Manuf. +1 864 439-9948<br>Fax Ass. +1 864 439-0566<br>Telex 805 550<br><a href="http://www.seweurodrive.com">http://www.seweurodrive.com</a><br>cslyman@seweurodrive.com |
| Assembly<br>Sales<br>Service                                     | San Francisco   | SEW-EURODRIVE INC.<br>30599 San Antonio St.<br>Hayward, California 94544-7101  | Tel. +1 510 487-3560<br>Fax +1 510 487-6381<br>cshayward@seweurodrive.com   |
|  | Philadelphia/PA | SEW-EURODRIVE INC.<br>Pureland Ind. Complex<br>2107 High Hill Road, P.O. Box 481<br>Bridgeport, New Jersey 08014                       | Tel. +1 856 467-2277<br>Fax +1 856 845-3179<br>csbridgeport@seweurodrive.com  |
|  | Dayton          | SEW-EURODRIVE INC.<br>2001 West Main Street<br>Troy, Ohio 45373  | Tel. +1 937 335-0036<br>Fax +1 937 440-3799<br>cstroy@seweurodrive.com  |
|  | Dallas          | SEW-EURODRIVE INC.<br>3950 Platinum Way<br>Dallas, Texas 75237   | Tel. +1 214 330-4824<br>Fax +1 214 330-4724<br>csdallas@seweurodrive.com  |
| Additional addresses for service in the USA provided on request! |                 |  |   |





| Venezuela                             |                 |  |   |
|---------------------------------------|-----------------|--|---|
| <b>Assembly<br/>Sales<br/>Service</b> | <b>Valencia</b> | SEW-EURODRIVE Venezuela S.A.<br>Av. Norte Sur No. 3, Galpon 84-319<br>Zona Industrial Municipal Norte<br>Valencia, Estado Carabobo | Tel. +58 241 832-9804<br>Fax +58 241 838-6275<br>sewventas@cantv.net<br>sewfinanzas@cantv.net |




## Address List

---









## How we're driving the world

With people who think fast and develop the future with you.



With a global presence that offers responsive and reliable solutions. Anywhere.


With a worldwide service network that is always close at hand.

With drives and controls that automatically improve your productivity.



With innovative technology that solves tomorrow's problems today.

With comprehensive knowledge in virtually every branch of industry today.



With online information and software updates, via the Internet, available around the clock.

With uncompromising quality that reduces the cost and complexity of daily operations.

**SEW-EURODRIVE**  
Driving the world



**SEW**  
**EURODRIVE**

SEW-EURODRIVE GmbH & Co KG  
P.O. Box 3023 · D-76642 Bruchsal / Germany  
Phone +49 7251 75-0 · Fax +49 7251 75-1970  
sew@sew-eurodrive.com

→ [www.sew-eurodrive.com](http://www.sew-eurodrive.com)