

```
[
{
  "part_name": "Refrigerator Crisper Drawer Cover 240364787",
  "part_number": "PS2363600",
  "manufacturer": "Kenmore",
  "price": "102.47",
  "description": "This is a cover for the crisper pan in your refrigerator. This cover is designed to allow both crisper drawers to slide in and remain covered, while also offering shelf storage above. This cover is made of durable white plastic that measures 25.75 inches wide and 18.75 inches deep and features two sliders on each side to adjust the humidity as necessary. This cover is only the frame for the crisper drawer assembly and does not come with the necessary glass pane insert. If your current crisper drawer cover is cracked or broken and not able to support the drawers or glass above it, it needs to be replaced. This cover is an OEM part and is sold individually.",
  "rating": "98",
  "troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# 240364787 replaces these: AP4432913, 216979402, 216995502, 240364714, 240364725, 240364747, 240364764, 240364778, 240364794 Back to Top",
  "review_count": "32",
  "appliance": "refrigerator",
  "compatible_models": [
    "25344703000",
    "25344723100",
    "25344723101",
    "25344723102",
    "25344723103",
    "25344723104",
    "25344723105",
```

"25344723106",
"25344723107",
"25344723108",
"25344723109",
"25344723110",
"25344723111",
"25360812710",
"25360813710",
"25360819710",
"25361821010",
"25361821011",
"25361821013",
"25361821014",
"25361827010",
"25361827011",
"25361827013",
"25361827014",
"25361872400",
"25361872402",
"25361872404",
"25361872406",
"25361872407",
"25361872408"

]

},

{

"part_name": "Refrigerator Door Gasket 241872513",

"part_number": "PS2331952",

"manufacturer": "Kenmore",

"price": "111.73",

"description": "This fresh food door gasket is used to seal the refrigerator door when closed to keep the cool air inside and the room air outside.",

"rating": "93",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close | Door Sweating | Fridge too warm | Leaking This part works with the following products: Refrigerator. Part# 241872513 replaces these: AP4374868, 1465365, 241872513, 240370906, 240390701, 240514606, 240514608, 240542106, 240542118, 241872506, 5304439521, 5304439523 Back to Top",

"review_count": "66",

"appliance": "refrigerator",

"compatible_models": [

"25331800102",

"25331800104",

"25331800106",

"25331800108",

"2533180010A",

"2533180010B",

"2533180010C",

"2533180010D",

"25331802102",

"25331802104",

"25331802106",

"25331802108",

```
"2533180210A",  
"2533180210B",  
"2533180210C",  
"2533180210D",  
"25331804102",  
"25331804104",  
"25331804106",  
"25331804108",  
"2533180410A",  
"2533180410B",  
"2533180410C",  
"2533180410D",  
"25331809102",  
"25331809104",  
"25331809106",  
"25331809108",  
"2533180910A",  
"2533180910B"  
]  
,  
{  
  "part_name": "Light Bulb 316538904",  
  "part_number": "PS12751166",  
  "manufacturer": "Kenmore",  
  "price": "19.71",
```

"description": "This OEM 40 watt appliance light bulb is used for some ranges, refrigerators, freezers, and microwaves. Simply locate the existing bulb, unscrew it from its socket, and replace with new light bulb. If the existing bulb is broken in the socket, disconnect the power to the refrigerator and use a pair of needle nose pliers to grip the internal fragments of the bulb to unscrew. Replace with the new bulb and reconnect the power to the refrigerator. These bulbs are sold individually and are a commonly replaced part; consider ordering a spare.",

"rating": "91",

"troubleshooting_tips": "This part works with the following products: Refrigerator, Range, Wall Oven, Microwave Oven Combo. Part# 316538904 replaces these: 08002735, 08037649, 08068090, 171840, 173421, 218926201, 2386-1, 240436701, 240436702, 241529103, 241552901, 241555401, 28078, 3001179, 3001180, 3013071, 3018801, 3051082, 3051513, 316538901 ... Show more , 31956, 3201908, 3202007, 3205941, 37400050001, 374L001P01, 374L002P01, 374T012R01, 374T018P01, 374T018P04, 374T018P05, 374T020P01, 374T025P01, 5300063749, 5303001179, 5303013071, 5303051082, 5303208582, 5303285989, 5304406549, 5304448955, 55771, 7241555401, 732132000@, 75303013071, 8002735, 8006-19, 8006-38-4, 8006-38-7, 8037649, 8063-2, 8068090, 8529, AP067007, C000501851, F002009-000, F4-21, F51461, F73317, FA2009, G10424, G165723, G185162, G25806, G28087, G28178, G30055, G39122, G54494, K1027373, K1027374, K1081270, K1101291, K1134642, K1135453, K1137227, K1144690, K1168823, K1186186, K1227370, M1088506, M1088822, M1090078, P067007, P067018, Q000007422, Q000007428, Q000023556, Q000063746, Q000063749, Q000198580, Q63749, QM000009D1, R000900925, T1506945, T357165, WC501851, WC501868 Show less Back to Top",

"review_count": "11",

"appliance": "refrigerator",

"compatible_models": [

"00462048A",

"00462048B",

"00462048C",

"00462048D",

"11-1153-00-04",

"11-1153-23-04",

"11-1153-45-04",
"11-1153-57-04",
"11-1153-66-04",
"11-1159-00-01",
"11-1159-00-02",
"11-1159-00-03",
"11-1159-00-04",
"11-1159-00-05",
"11-1553-00-04",
"11-1553-23-04",
"11-1553-45-04",
"11-1553-57-04",
"11-1553-66-04",
"11-1559-00-01",
"11-1559-00-02",
"11-1559-00-03",
"11-1559-00-04",
"11-1559-00-05",
"11-1653-00-04",
"11-1653-23-04",
"11-1653-45-04",
"11-1653-57-04",
"11-1653-66-04",
"11-1969-00-01"

]

},

```
{
  "part_name": "Crisper Glass Shelf Insert 240350608",
  "part_number": "PS429963",
  "manufacturer": "Kenmore",
  "price": "113.55",
  "description": "Glass only. This glass insert measures 23.82 x 15.50-in. \r\nThis is an authentic Frigidaire replacement part. The crisper shelf insert is designed by the manufacturer for use in refrigerators. This part is made of glass, and is placed over the crisper pan drawers. No tools are required when replacing this item. Simply remove the old part and slot the new one into place. This item is sold individually.",
  "rating": "94",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 240350608 replaces these: AP2115928, 891117, 240350608, 240350643, 240350650, 240350655, 241711219, 241711220, 241711270, 297012700, 297194400 Back to Top",
  "review_count": "56",
  "appliance": "refrigerator",
  "compatible_models": [
    "25331113300",
    "25331113302",
    "25331113304",
    "25331113308",
    "2533111330A",
    "2533111330B",
    "2533111330C",
    "2533111330D",
    "2533111330E",
    "2533111330F",
    "2533111330G",
```

```
"2533111330H",
"2533111330J",
"2533111330K",
"2533111330L",
"25331115300",
"25331115302",
"25331115304",
"25331115308",
"2533111530A",
"2533111530B",
"2533111530C",
"2533111530D",
"2533111530E",
"2533111530F",
"2533111530G",
"2533111530H",
"2533111530J",
"2533111530K",
"2533111530L"
]
},
{
  "part_name": "Water Filter Cap - Black WP2260518B",
  "part_number": "PS11739970",
  "manufacturer": "Kenmore",
  "price": "23.79",
```


"description": "This black cap covers the water filter.",

"rating": "91",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Ice maker not making ice | Not dispensing water This part works with the following products: Refrigerator. Part# WP2260518B replaces these: AP6006882, 2260502B, 2260518B, WP2260518BVP
Back to Top",

"review_count": "65",

"appliance": "refrigerator",

"compatible_models": [

"10641522500",

"10641523500",

"10641524500",

"10641529500",

"10644022600",

"10644022601",

"10644022602",

"10644022603",

"10644023600",

"10644023601",

"10644023602",

"10644023603",

"10644024600",

"10644029600",

"10644029601",

"10644029602",

"10644029603",

"10644032600",

"10644032601",
"10644032602",
"10644032603",
"10644033600",
"10644033601",
"10644033602",
"10644033603",
"10644034600",
"10644039600",
"10644039601",
"10644039602",
"10644039603"

]

},

{

"part_name": "Door Bin - Clear 240356402",

"part_number": "PS430122",

"manufacturer": "Kenmore",

"price": "80.83",

"description": "This bin can be moved according to space needed. It holds items on the door of your refrigerator. \r\n\r\nNOTE: This bin is only available in clear plastic now.",

"rating": "87",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 240356402 replaces these: AP2549958, 891214, 240356402, 240356407, 240356408, 240356410, 240356411, 240356413, 240356414, 240356415, 240356416, 240430305, 240430307, 240430311, 240430312, 240430325, 241808205, 241808206, 241808221, 241808229 Back to Top",

```
"review_count": "53",  
"appliance": "refrigerator",  
"compatible_models": [  
  "25351692100",  
  "25351692101",  
  "25351692102",  
  "25351692103",  
  "25351692104",  
  "25351692105",  
  "25351693100",  
  "25351693101",  
  "25351693102",  
  "25351693103",  
  "25351693104",  
  "25351693105",  
  "25351693106",  
  "25351694100",  
  "25351694101",  
  "25351694102",  
  "25351694103",  
  "25351694104",  
  "25351694105",  
  "25351699100",  
  "25351699101",  
  "25351699102",  
  "25351699103",
```

"25351699104",

"25351699105",

"25353672301",

"25353672302",

"25353672303",

"25353672304",

"25353673301"

]

},

{

"part_name": "Refrigerator Water Filter FPPWFU01",

"part_number": "PS16218782",

"manufacturer": null,

"price": "78.55",

"description": "The PurePour water filter is compatible with Frigidaire, Frigidaire Gallery and Professional side-by-side and French Door refrigerators with PurePour ice and water filtration. This genuine Frigidaire replacement water filter fits Frigidaire refrigerators which feature a cylindrical filter housing mounted on the refrigerator's ceiling. With the FPPWFU01 filter, you can relax knowing your drinking water is safe, clear and healthy.",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Back to Top",

"review_count": "5",

"appliance": "refrigerator",

"compatible_models": [

"FPRU19F8WF0",

"FPRU19F8WF3",

"FPRU19F8WF4",
"FRFC2323AS0",
"FRFC2323AS1",
"FRFC2323AS2",
"FRFG232LAF0",
"FRFN2823AS0",
"FRFN2823AS1",
"FRFN2823AS2",
"FRFN2823AS3",
"FRFS2823AD1",
"FRFS2823AS1",
"FRFS2823AW1",
"FRFS2823AW3",
"FRFS282LAF0",
"FRFS282LAF1",
"FRFS282LAF2",
"FRSC2333AS0",
"FRSC2333AS2",
"FRSC2333AS3",
"FRSC2333AS4",
"FRSC2333AS5",
"FRSC2333AS6",
"FRSS2323AB0",
"FRSS2323AB1",
"FRSS2323AB3",
"FRSS2323AB5",

"FRSS2323AD0",

"FRSS2323AD1"

]

},

{

"part_name": "Refrigerator Water Filter ULRAWF",

"part_number": "PS2364646",

"manufacturer": null,

"price": "84.19",

"description": "This genuine PureSource Ultra water filter will fit most Frigidaire french door and side by side refrigerators. You will find this filter located in the back, top right of the appliance. It is white in color and the filter has a polypropylene plastic housing and extruded carbon block filter media. Certified by NSF/ANSI to reduce contaminants that may be in your household water supply by 99.8 percent. The operating temperature for this filter is 33-100 degrees Fahrenheit, the flow rate is 0.5 GPM, the working pressure is 30-100 PSI, and it has a micron rating of 1. This filter should be replaced every six months or when the indicator lights up red. Installation is quick and easy. Push on the end face of the older filter to allow it to release. Remove and discard the old filter. Slide the new filter into the housing and press it down until it locks into place. Be sure to run water through the dispenser for about three minutes to prime the filter before use. Discard this water or use it to water plants. Do not forget to reset the indicator by pressing it down for 3-10 seconds. Review the use and care guide before you install for more detailed instructions.",

"rating": "88",

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making ice | Not dispensing water | Leaking | Ice maker dispenses too little ice This part works with the following products: Refrigerator. Part# ULRAWF replaces these: AP4455158, 1534529, ULRAWF, 241791601, 242294401, ULRAWFC Back to Top",

"review_count": "67",

"appliance": "refrigerator",

"compatible_models": [

"242017800",

"242017801",
"242294404",
"A0094E28261",
"BGHS2634KE0",
"BGHS2634KE1",
"BGHS2634KE2",
"BGHS2634KP0",
"BGHS2634KP1",
"BGHS2634KP2",
"BGHS2644KF0",
"BGHS2644KF1",
"BGHS2644KF2",
"CFD26SDS0",
"CFD26WIS0",
"CFD26WIS1",
"CFD26WIS3",
"CFD26WIS4",
"CFD26WIS5",
"CFD26WIS6",
"CFD27SDPS0",
"CFD27WIPB2",
"CFD27WIPB3",
"CFD27WIPS2",
"CFD27WIPS3",
"CFD27WIPW2",
"CFD27WIPW3",

```
"CFD28SDQS0",  
"CFD28SDQSA",  
"CFD28SDS1"  
]  
},  
{  
  "part_name": "Refrigerator Water Filter - White EPTWUFU01",  
  "part_number": "PS11704498",  
  "manufacturer": null,  
  "price": "82.17",  
  "description": "This OEM refrigerator filter is for french door and side-by-side door types  
and is located in the back, top-right of your appliance. By absorbing heavy metals,  
pharmaceuticals, pesticides, chlorine, and much more, this filter provides delicious and  
healthy drinking water. This filter measures 2 inches deep, 9 inches high, 2 inches wide,  
and weighs 0.9 lbs. The installation is quick and easy with a push and twist feature. Don't  
forget to run water through the dispenser for about three minutes or 1.5 gallons to prepare  
the filter before use. For best performance replace this filter every six months.",  
  "rating": "97",  
  "troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making  
ice This part works with the following products: Refrigerator. Part# EPTWUFU01 replaces  
these: AP5962272, 5304519147, 5304520985, 807946701, EPTWUFU01C Back to Top",  
  "review_count": "13",  
  "appliance": "refrigerator",  
  "compatible_models": [  
    "20462151B",  
    "90462157B",  
    "CFEH272ITD0",  
    "CFEH272ITD1",
```


"CFEH272ITS0",
"CFEH272ITS1",
"CFEH272ITW1",
"DGHD2361TF0",
"DGHD2361TF1",
"DGHD2361TF2",
"DGHD2361TF3",
"DGHK2355TF0",
"DGHX2655TF0",
"DGHX2655TF5",
"DGHX2655TF6",
"DGHX2655TF8",
"DGHX2655TF9",
"DGHX2655TFA",
"DGHX2655TFB",
"DGHX2655TFC",
"FFHB2750TD0",
"FFHB2750TD1",
"FFHB2750TD2",
"FFHB2750TD3",
"FFHB2750TD5",
"FFHB2750TD6",
"FFHB2750TD7",
"FFHB2750TD8",
"FFHB2750TE0",
"FFHB2750TE1"

```
]
},
{
  "part_name": "Refrigerator Door Shelf Bin 242126602",
  "part_number": "PS12364199",
  "manufacturer": null,
  "price": "43.00",
  "description": "This manufacturer-certified Refrigerator Door Shelf Bin, also known as a crisper bin or door shelf bin, is made of clear plastic, and is easy to install. It is used to hold items in the fridge, like jars, cans, and condiments and you'll be able to visually see if the part is broken or cracked. This particular shelf attaches to the fridge door. You can check if this model is right for your appliance by checking your user manual and model number. This part should simply snap into place without the need for any tools as part of the repair. Just carefully line up the slots on the door with the slots on the bin and slide the bin down to completely lock it into place. The part is sold individually, and fits many different types of side-by-side refrigerators.",
  "rating": "96",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 242126602 replaces these: AP6278233 Back to Top",
  "review_count": "96",
  "appliance": "refrigerator",
  "compatible_models": [
    "CRSE263TB0",
    "CRSE263TD0",
    "CRSE263TS0",
    "CRSE263TW0",
    "DGHX2655TF0",
    "DGHX2655TF5",
    "DGHX2655TF6",
```

```
"DGHX2655TF8",  
"DGHX2655TF9",  
"DGHX2655TFA",  
"DGHX2655TFB",  
"DGHX2655TFC",  
"FFSS2615TD0",  
"FFSS2615TD1",  
"FFSS2615TD2",  
"FFSS2615TD3",  
"FFSS2615TD4",  
"FFSS2615TE0",  
"FFSS2615TE1",  
"FFSS2615TE2",  
"FFSS2615TE3",  
"FFSS2615TE4",  
"FFSS2615TP0",  
"FFSS2615TP1",  
"FFSS2615TP2",  
"FFSS2615TP3",  
"FFSS2615TP4",  
"FFSS2615TS0",  
"FFSS2615TS1",  
"FFSS2615TS2"  
]  
,  
{
```

"part_name": "Pantry End Cap Kit, LH and RH W10874836",

"part_number": "PS11738134",

"manufacturer": "Kenmore",

"price": "44.15",

"description": "This manufacturer-approved Refrigerator Pantry End Cap Kit, also known as the Refrigerator Drawer Support, is a kit containing all parts of the Pantry End Cap. It snaps into place on the appliance's pantry drawer to help contain the items inside and to keep your refrigerator door from sliding all the way out. It is rated as \"medium\" difficulty to install, is constructed of plastic and comes in white. If broken or missing, the pantry drawer will not stay in place and the part should be replaced. Refer to your user manual and model number to ensure this is the correct part for you. This kit includes both the right and left side end caps, as well as the pins that will hold them in place. To replace an end cap, remove the three screws holding it in place. Then, remove the pin and end cap, replacing the old end cap with the new end cap. In the past, the left and right end caps were sold separately, but the part has been updated and now includes both sides. The part is sold as a kit, and unfortunately, as such none of the parts are available individually.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close | Fridge too cold | Noisy This part works with the following products: Refrigerator. Part# W10874836 replaces these: AP6004794, 12656010, 12656013, 12656014, 12656019, 12656022, 12656023, 12656104, 12656106, 2206738W, 2206740W, 2206764W, 2301453W, 2301455W, 2311704W, 67002757, 67002758, 67003281, 67005694, 67005858 ... Show more , 67005861, 67005863, 8208332, 8208333, W10845508, W10845509, W10870281, W10874836VP, WP12656019, WP12656022, WP12656023, WP12656106 Show less Back to Top",

"review_count": "375",

"appliance": "refrigerator",

"compatible_models": [

"10672012010",

"10672013010",

"10672013017",

"10672019010",

"10678586800",
"59672012010",
"59672012011",
"59672012012",
"59672012014",
"59672012016",
"59672013010",
"59672013011",
"59672013012",
"59672013013",
"59672013014",
"59672013015",
"59672013017",
"59672019010",
"59672019011",
"59672019012",
"59672019014",
"59672019016",
"59673502200",
"59673502201",
"59673502202",
"59673502203",
"59673502300",
"59673503200",
"59673503201",
"59673503202"

```
]
},
{
  "part_name": "Center Rail WPW10326469",
  "part_number": "PS11752912",
  "manufacturer": "Kenmore",
  "price": "27.48",
  "description": "This OEM Center Rail is a white plastic part which supports the crisper frame, which holds the crisper. Fifteen inches long and white in colour, if broken, the support may no longer hold properly. Refer to your model number and user manual to see if this part will be right for your appliance. This part is a very easy repair which only takes a few minutes and does not require any tools. Just slide the crisper drawers out, lift out the glass shelf, slide the new rail into place and replace the glass shelf and crisper drawers. This part is sold individually and not as part of a set.",
  "rating": "97",
  "troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close | Noisy This part works with the following products: Refrigerator. Part# WPW10326469 replaces these: AP6019603, 12796401, 67004514, 8208326, W10326469, W10326469N, WPW10326469VP Back to Top",
  "review_count": "224",
  "appliance": "refrigerator",
  "compatible_models": [
    "10672012010",
    "10672013010",
    "10672013017",
    "10672019010",
    "10678586800",
    "59672012010",
    "59672012011",
```

"59672012012",
"59672012014",
"59672012016",
"59672013010",
"59672013011",
"59672013012",
"59672013013",
"59672013014",
"59672013015",
"59672013017",
"59672019010",
"59672019011",
"59672019012",
"59672019014",
"59672019016",
"59676502500",
"59676503500",
"59676504500",
"59676509500",
"59676512500",
"59676513500",
"59676514500",
"59676519500"

]

},

{

"part_name": "Refrigerator Water Filter WF3CB",

"part_number": "PS3412266",

"manufacturer": null,

"price": "72.47",

"description": "This NSF-Certified OEM filter is white in color with a plastic housing and extruded carbon filter media. It measures 2.3-Inches deep, 9.1-Inches high and 2.3-Inches wide. It fits certain Frigidaire side-by-side models after 2009 that use a water filter located in the back, top right. Filters all dispensed drinking water and the water used for making ice. It minimizes chlorine flavor and smell and cuts down on common contaminants by 99 percent. You will need to replace the filter every six months or when the light indicates. To install the new filter slide it into the housing and push until it locks in place. Press the indicator button for ten seconds to reset after replacing.",

"rating": "92",

"troubleshooting_tips": "This part fixes the following symptoms: Not dispensing water | Ice maker not making ice | Leaking | Ice maker dispenses too little ice This part works with the following products: Refrigerator. Part# WF3CB replaces these: AP4567491, 1706465, WF3CB, 242069601, 242069603, 242294501, P242069601, SWF3CB, WF3CB, WF3CB12, WF3CBC Back to Top",

"review_count": "49",

"appliance": "refrigerator",

"compatible_models": [

"BFHS2611LM0",

"BFHS2611LM1",

"BFHS2611LM2",

"CRSE233TB0",

"CRSE233TS0",

"CRSE233TW0",

"CRSE263TB0",

"CRSE263TD0",


```
"CRSE263TS0",
"CRSE263TW0",
"CRSH232PB0",
"CRSH232PB1",
"CRSH232PB2",
"CRSH232PB3",
"CRSH232PB5",
"CRSH232PB6",
"CRSH232PB7A",
"CRSH232PB8A",
"CRSH232PB9A",
"CRSH232PBBA",
"CRSH232PBEA",
"CRSH232PBFA",
"CRSH232PBHA",
"CRSH232PS0",
"CRSH232PS1",
"CRSH232PS3",
"CRSH232PS4",
"CRSH232PS5A",
"CRSH232PS6A",
"CRSH232PS7A"
]
},
{
  "part_name": "Refrigerator Door Bin 240323001",
```

"part_number": "PS429724",

"manufacturer": "Kenmore",

"price": "46.94",

"description": "This door bin (Bottom Door Bin, Refrigerator Door Bin, Door Shelf Bin, Refrigerator Door Bin) is a movable bin mounted on the inner door to hold food items, bottles, and jars. Over time, a cold refrigerator can cause plastic to become fragile and break down. This can lead to other issues in the refrigerator. When the door bin will not hold securely onto the inner door panel, it must be replaced. This door bin measures 5.75 inches high, 16 inches wide, by 4.25 inches deep and is made of white plastic. Sold individually.",

"rating": "93",

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making ice | Door won't open or close | Noisy | Ice maker won't dispense ice This part works with the following products: Refrigerator. Part# 240323001 replaces these: AP2115741, 890954, 240323001, 240323001, 240323007 Back to Top",

"review_count": "222",

"appliance": "refrigerator",

"compatible_models": [

"25351622100",

"25351622101",

"25351622102",

"25351622103",

"25351622104",

"25351624100",

"25351624101",

"25351624102",

"25351624103",

"25351624104",

"25352612200",

```
"25352612201",
"25352612202",
"25352614200",
"25352614201",
"25352614202",
"25352622200",
"25352622201",
"25352622202",
"25352624200",
"25352624201",
"25352624202",
"25352632200",
"25352632201",
"25352632202",
"25352633200",
"25352634200",
"25352634201",
"25352634202",
"25352639200"
]
},
{
  "part_name": "Evaporator Fan Grommet - Red WR02X12008",
  "part_number": "PS963756",
  "manufacturer": "Kenmore",
  "price": "13.20",
```

"description": "If you notice that your refrigerator or freezer is noisy or too warm, you may need to replace the evaporator fan grommet. This part is red in color, and is about 1 inch in diameter. The evaporator fan grommet is located behind the evaporator fan cover in the back of the freezer. You will need to remove the evaporator fan cover to access the evaporator fan and complete this repair. Before you begin this repair, ensure the power to the refrigerator is disconnected. You will need a pair of needle nose pliers, a small flat blade screw driver and both a 1/4 and 5/16-inch nut driver to complete this repair.",

"rating": "98",

"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Fridge too warm | Clicking sound | Freezer section too warm This part works with the following products: Refrigerator, Freezer. Part# WR02X12008 replaces these: AP3795810, 1091586, WR02X10519, WR2X10519 Back to Top",

"review_count": "22",

"appliance": "refrigerator",

"compatible_models": [

"36211XBMBRWW",

"36211XBMDRWW",

"36211XBMERWW",

"36211XBMFRWW",

"36211XBRERWW",

"36211XBRFRWW",

"36411XBRERWW",

"36411XBRFRWW",

"37511KBSARWW",

"37511KBSERWW",

"38181KBRARWW",

"38185KBRARBB",

"38187KBRARCC",

"38341FBMERWW",

"38341FBMFRWW",
"38351HBMERWW",
"38351HBMFRWW",
"38351HBRERWW",
"38351HBRFRWW",
"38451HBRERWW",
"38451HBRFRWW",
"38481KBRARWW",
"38481KBRCRWW",
"38481KBRDRWW",
"38481KBRKRWW",
"38481KBRORWW",
"38481KBRTRWW",
"38481KBRVRWW",
"38485KBRARBB",
"38485KBRCRBB"

]

},

{

"part_name": "WATER VALVE WITH GUARD WR57X33326",

"part_number": "PS16226572",

"manufacturer": "Kenmore",

"price": "88.98",

"description": "This water inlet valve (Refrigerator Water Inlet Valve Assembly) supplies water to the ice maker and the water dispenser in your refrigerator. It is located at the back of the fridge, beneath the bottom panel. It is connected directly to 2 water supplies, a wiring harness, and your inlet water tube. This part is located at the back of the fridge,

beneath the bottom panel. It is connected directly to 2 water supplies, a wiring harness, and your inlet water tube. Minerals and sediments can build up over time and cause a blockage in your inlet valve. They can also cause the valve to stick open, leading to an overflow of water. If this part is malfunctioning, water flow to your appliance could be compromised. Check for small ice cubes or a lack of ice cubes/water, as this is an obvious sign the part is damaged. The water inlet valve must be replaced if the solenoids no longer have continuity or the valve has internal blockage. Test your water inlet valve with a multimeter. You can test both the water dispenser side and the ice maker side. The part measures approximately 3 inches long and 2.75 inches wide and is constructed of plastic and metal. This replacement part features 1 dual inlet water valve with quick connections. It also has 1/4 and 5/16 John Guest fittings for the outlet lines and a 1/4 compression fitting for the inlet line.",

"rating": "92",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Not dispensing water | Ice maker not making ice | Ice maker won't dispense ice This part works with the following products: Refrigerator. Part# WR57X33326 replaces these: AP6995571, WR57X10032, WR57X10040, WR57X10064 Back to Top",

"review_count": "80",

"appliance": "refrigerator",

"compatible_models": [

"39631UGTAWW",

"39631UGXAWW",

"39639USTAGV",

"39639USXAGV",

"BSS25GFPACC",

"BSS25GFPAWW",

"BSS25GFPCCC",

"BSS25GFPCWW",

"BSS25GFPDCC",

"BSS25GFPDWW",

```
"BSS25GFPECC",
"BSS25GFPEWW",
"BSS25GFPHCC",
"BSS25GFPHWW",
"BSS25JFRFWW",
"BSS25JFRJWW",
"BSS25JFTAWW",
"BSS25JFTBWW",
"BSS25JFTCWW",
"BSS25JFTDWW",
"BSS25JFTEWW",
"BSS25JFTGWW",
"BSS25JFTHWW",
"BSS25JFTIWW",
"BSS25JFTJWW",
"BSS25JFTNWW",
"BSS25JFTPWW",
"BSS25JSRFSS",
"BSS25JSRJSS",
"BSS25JSTASS"
]
},
{
  "part_name": "Light Bulb - 40W 40A15",
  "part_number": "PS217532",
  "manufacturer": "Kenmore",
```

"price": "11.01",

"description": "This 40-Watt light bulb is sold individually and is a genuine OEM replacement option for your home appliances. It is specially designed to withstand extreme temperatures, so this bulb is compatible with a variety of appliance types including refrigerators, ranges, microwaves, and dryers. It features a frosted glass bulb with a standard metal socket base, which allows you to easily unscrew the burnt-out light and twist the new bulb into place. Depending on your appliance, there may be a guard or cover protecting the lightbulb, in which case you may require additional tools to remove the cover. We recommend disconnecting the power supply to your appliance before changing the lightbulb.",

"rating": "93",

"troubleshooting_tips": "This part works with the following products: Refrigerator, Range, Wall Oven, Microwave Oven Combo. Part# 40A15 replaces these: 111257, 293547, 339665, 40A15-2PK, 40A15R, 40A15RVL, 4324154, 4338591, 60A, 60A15RVL, 630610, 65973, 69651, 8004738, 8004883, PM02X0001, PM2X1, STD372401, STD372402, WB02X3551 ... Show more , WB08T10022, WB2X3551, WR02X12289, WR02X12327, WR02X12328, WR02X12530, WX04X0010, WX12X0020, WX12X0109, WX12X109, WX12X1106, WX12X1510, WX12X20, WX4X10 Show less Back to Top",

"review_count": "8",

"appliance": "refrigerator",

"compatible_models": [

"0116387363",

"103281610",

"103285450",

"103285451",

"103291610",

"103291610-S",

"103291820",

"103293060",

"103294060",


```
"103296010",
"103296011",
"103296015",
"103298070",
"10330181",
"1033023200",
"1033023210",
"1033025200",
"1033026520",
"1033026521",
"1033033400",
"1033033410",
"1033035000",
"1033035400",
"1033035500",
"1033035600",
"1033035800",
"1033035900",
"1033036500",
"1033036501",
"1033036540"
]
},
{
  "part_name": "Temperature Sensor WR55X10025",
  "part_number": "PS304103",
```

"manufacturer": "Kenmore",

"price": "22.80",

"description": "This sensor (Temperature Sensor, Thermistor, Refrigerator Temperature Sensor) sends the temperature reading of the compartment to the control board. If you notice your refrigerator is too warm, too cold, or not defrosting properly, then there may be a problem with your sensor. The temperature sensor can break from material fatigue or through normal use, and should be replaced. It is attached to the evaporator and control housing in your appliance. It measures approximately 1.25 inches long with 18 inch wire leads, and is constructed out of plastic. This part comes in white, beige. It includes the sensor, with wire leads.",

"rating": "92",

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Freezer section too warm | Fridge too cold | Freezer not defrosting This part works with the following products: Refrigerator, Freezer, Range. Part# WR55X10025 replaces these: AP3185407, 914093, WR55X10025, WR50X10027, WR50X10034, WR50X10055, WR50X10067, WR55X10025B, WR55X10026, WR55X10027, WR55X10028, WR55X10030, WR55X10087, WR55X10088, WR55X10089, WR55X10367, WR55X10380, WR55X10661, WR55X10711, WR55X10735 ... Show more , WR55X10736, WR55X10737, WR55X10937, WR55X10938, WR55X10939, WR55X11121, WR55X11141, WR55X11150, WR55X11152 Show less Back to Top",

"review_count": "66",

"appliance": "refrigerator",

"compatible_models": [

"39631UGTAWW",

"A4425GDTABB",

"A4425GDTAWW",

"A4425GDTBBB",

"A4425GDTBWW",

"A4425GDTW",

"BSS25GFPACC",

"BSS25GFPAWW",

"BSS25GFPCCC",
"BSS25GFPCWW",
"BSS25GFPDCC",
"BSS25GFPDWW",
"BSS25GFPECC",
"BSS25GFPEWW",
"BSS25GFPHCC",
"BSS25GFPHWW",
"BSS25JFRFWW",
"BSS25JFRJWW",
"BSS25JFTAWW",
"BSS25JFTBWW",
"BSS25JFTCWW",
"BSS25JFTDWW",
"BSS25JFTEWW",
"BSS25JFTGWW",
"BSS25JFTHWW",
"BSS25JFTIWW",
"BSS25JFTJWW",
"BSS25JFTNWW",
"BSS25JFTPWW",
"BSS25JSRFSS"

]

},

{

"part_name": "Module Shelf Insert - Clear WR71X10761",

"part_number": "PS2323438",

"manufacturer": null,

"price": "21.25",

"description": "The Module Shelf Insert is a complete assembly for the module shelf. This repair is rated as \"Easy\" by users. Simply remove the old shelf insert and snap the new one into place using the locking tabs. This part is used to hold items in the fridge, and if broken it should be replaced. Refer to your user manual and model number to ensure this part is right for you.",

"rating": "98",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WR71X10761 replaces these: AP4327432, 1373164, WR71X10289 Back to Top",

"review_count": "69",

"appliance": "refrigerator",

"compatible_models": [

"39631UGXAWW",

"CSHS5UGXBSS",

"CSHS5UGXCSS",

"CSHS6UGZBSS",

"CSHS6UGZESS",

"CSHS6UGZFSS",

"CSS25USWASS",

"CSS25USWCSS",

"CSW25LSWASS",

"CZS22MP2NBS1",

"CZS22MP2NDS1",

"CZS22MP2NES1",

"CZS22MP2NHS1",

"CZS22MSKBHSS",

"CZS22MSKEHSS",

"CZS22MSKKHSS",

"DSD26DGWABG",

"DSD26DGWCBG",

"DSD26DHWABG",

"DSD26DHWCBG",

"DSE25JBLJCTS",

"DSE25JBLKCTS",

"DSE25JEMGCDS",

"DSE25JEMKCDS",

"DSE25JGHBCBB",

"DSE25JGHBCWW",

"DSE25JGHECBB",

"DSE25JGHECWW",

"DSE25JGHKCBB",

"DSE25JGHKCWW"

]

},

{

"part_name": "Door Shelf Bar WR17X11889",

"part_number": "PS964507",

"manufacturer": null,

"price": "30.10",

"description": "This door shelf is a replacement part for your refrigerator. It is very easy to install and requires no tools. Simply pull out the existing shelf bar and snap the new one into place, making sure the locking tabs are secure.",

"rating": "95",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WR17X11889 replaces these: AP3855305, 1169732, WR17X12916 Back to Top",

"review_count": "74",

"appliance": "refrigerator",

"compatible_models": [

"37511KBSARWW",

"37511KBSERWW",

"A3316ABSARBB",

"A3316ABSARWW",

"A3316ABSB",

"A3316ABSBRBB",

"A3316ABSBRWW",

"A3316ABSDRBB",

"A3316ABSDRWW",

"A3316ABSERBB",

"A3316ABSERWW",

"A3316ABSFRBB",

"A3316ABSFRWW",

"A3316ABSGRBB",

"A3316ABSGRWW",

"A3316ABSHRBB",

"A3316ABSHRWW",

"A3316ABSJRBB",

"A3316ABSJRWW",

"A3316ABSW",

"CTH17RBT2RWW",

"CTH17RBTZRWW",

"CTS17RBSARWW",

"CTS17RBSBRWW",

"CTS17RBSDRWW",

"CTS17RBSERWW",

"CTS17RBSEGRWW",

"CTS17RBSHRWW",

"CTS18FBSALWW",

"CTS18FBSARWW"

]

},

{

"part_name": "Evaporator Fan Motor WR60X31522",

"part_number": "PS12741350",

"manufacturer": null,

"price": "70.13",

"description": "This 115-volt 60Hz evaporator fan motor is located in the back of the freezer and circulates air over the refrigerator coils. These coils will convert the heat into cool air, which is then circulated. If the motor has failed, the freezer/refrigerator will become too warm because the fan motor is not circulating the cool air from the freezer into the refrigerator. This is a genuine OEM part. Please remember to disconnect the power to the appliance before starting your repair.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Fridge too warm | Freezer section too warm | Will Not Start This part works with the following products: Refrigerator, Freezer. Part# WR60X31522 replaces these: WR60X10045, WR60X10046, WR60X10072, WR60X10138, WR60X10141, WR60X10346, WR60X23584, WR60X27646, WR60X28783, WR60X28784, WR60X31122 Back to Top",

"review_count": "137",
"appliance": "refrigerator",
"compatible_models": [
"36211XBMBRWW",
"36211XBMDRWW",
"36211XBMERWW",
"36211XBMFRWW",
"36211XBRERWW",
"36211XBRFRWW",
"36411XBRERWW",
"36411XBRFRWW",
"37511KBSARWW",
"37511KBSERWW",
"38341FBMERWW",
"38341FBMFRWW",
"38351HBMERWW",
"38351HBMFRWW",
"38351HBRERWW",
"38351HBRFRWW",
"38451HBRERWW",
"38451HBRFRWW",
"A3315ABRERWW",
"A3315ABRFRWW",
"A3315ABRW",
"A3316ABSARBB",
"A3316ABSARWW",


```
"A3316ABSB",
"A3316ABSBRBB",
"A3316ABSBRWW",
"A3316ABSERBB",
"A3316ABSERWW",
"A3316ABSW",
"A3317ABRERWW"
]
},
{
```

```
"part_name": "BUCKET AUGER WR29X43990",
"part_number": "PS17626595",
"manufacturer": null,
"price": "63.72",
```

"description": "The ice bucket auger is located within the ice bucket assembly in your freezer. It stirs and dispenses the ice in the bucket. You may need to replace the auger if your ice maker is noisy, or not dispensing ice. Disassembly of the ice bucket assembly is necessary to replace this part. Turn off power to the appliance before removing the ice bucket assembly to do this repair."

```
"rating": "96",
```

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker won't dispense ice | Ice maker dispenses too little ice | Ice maker not making ice | Noisy This part works with the following products: Refrigerator. Part# WR29X43990 replaces these: WR17X10835, WR17X11259, WR17X11705, WR17X11939, WR29X42446 Back to Top",

```
"review_count": "204",
"appliance": "refrigerator",
"compatible_models": [
"A4425GDTABB",
```

"A4425GDTAWW",
"A4425GDTBBB",
"A4425GDTBWW",
"A4425GDTW",
"BSS25GFPHCC",
"BSS25GFPHWW",
"BSS25JFRFWW",
"BSS25JFRJWW",
"BSS25JFTAWW",
"BSS25JFTBWW",
"BSS25JFTCWW",
"BSS25JFTDWW",
"BSS25JFTEWW",
"BSS25JFTGWW",
"BSS25JFTHWW",
"BSS25JFTIWW",
"BSS25JFTJWW",
"BSS25JFTNWW",
"BSS25JFTPWW",
"BSS25JSRFSS",
"BSS25JSRJSS",
"BSS25JSTASS",
"BSS25JSTBSS",
"BSS25JSTCSS",
"BSS25JSTDSS",
"BSS25JSTEES",

"BSS25JSTGSS",

"BSS25JSTHSS",

"BSS25JSTISS"

]

},

{

"part_name": "Glass Shelf WR32X21260",

"part_number": "PS11699574",

"manufacturer": null,

"price": "31.91",

"description": "This glass shelf is a genuine OEM replacement part is specially designed for refrigerators. It has a length of approximately 23 inches and a width of 13.5 inches. The glass shelf provides a wide surface for you to store various food items and containers inside your refrigerator. It is designed to easily slide in and out of the fridge as needed. If your glass shelf is cracked or damaged it is recommended to replace it promptly for your safety. No mounting hardware is needed, simply pull out the damaged glass shelf and position the new one its place.",

"rating": "93",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WR32X21260 replaces these: AP5958543 Back to Top",

"review_count": "81",

"appliance": "refrigerator",

"compatible_models": [

"FBS15RCKJRWW",

"FBS15RCKLRWW",

"FBS15RCKMRWW",

"GAS18PGJFRWW",

"GAS18PGJJRWW",

"GAS18PGJLRWW",
"GAS18PSJFRSS",
"GAS18PSJJRSS",
"GAS18PSJLRSS",
"GIE16DGHBRBB",
"GIE16DGHBRWW",
"GIE16DGHCRBB",
"GIE16DGHCRWW",
"GIE16DGHHRBB",
"GIE16DGHHRWW",
"GIE16GSHBRSS",
"GIE16GSHCRSS",
"GIE16GSHHRSS",
"GIE16GSHLRSS",
"GIE16GSHMRSS",
"GIE16GSHPRSS",
"GIE17GSNBRSS",
"GIE17GSNDRSS",
"GIE17GSNERSS",
"GIE18CTHBRBB",
"GIE18CTHBRWW",
"GIE18CTHDRBB",
"GIE18CTHDRWW",
"GIE18CTHERBB",
"GIE18CTHERWW"

]

```
},
```

```
{
```

```
  "part_name": "Refrigerator Ice and Water Filter MWFP",
```

```
  "part_number": "PS8746144",
```

```
  "manufacturer": "Kenmore",
```

```
  "price": "68.37",
```

```
  "description": "This OEM ice and water filter fits side-by-side and bottom-freezer GE models. The most common reason you would need to change this part is if you have never updated your model and it is no longer filtering your water. This also may lead to your refrigerator not dispensing water or ice properly. Manufacturers recommend you change your filter every six months to ensure it properly filters impurities. Depending on the model, a red light might also indicate that the filter is due for a replacement. Note: As per the manufacturer, this is an updated water filter. If you have never installed the updated part or your old model was made by Culligan, you may need the adapter to install the filter. See related parts. This filter is located inside the refrigerators upper right corner. It is common for water to drip from the dispenser when being changed so place a cloth underneath before you begin this repair. To remove the filter, turn it to the left until it releases without pulling down. Fill the new filter with tap water to prepare it. Position the new filter into the holder taking note of the arrows. The arrow on the front should be facing out. Gently push up on the filter and turn it to the right to secure it. Do not over-tighten. To release air in the system run 1-1/2 gallons of water through it. If your model has a reset button, press and hold this for a few seconds to reset it.",
```

```
  "rating": "94",
```

```
  "troubleshooting_tips": "This part fixes the following symptoms: Not dispensing water | Ice maker not making ice | Ice maker dispenses too little ice | Leaking This part works with the following products: Refrigerator, Freezer. Part# MWFP replaces these: AP5788185, 3024481, MWFP, 46-9905, FXRT, GWF, GWF01, GWF06, GWFA, GWFS, HWF, HXRT, MWFP2PK, MWFP, WF, WR02M3552, WR02X11020, WR02X11287, WR02X11290, WR2M3552 ... Show more , WR2X11020, WR2X11287, WR2X11290, WR97X10006, WR97X10018 Show less Back to Top",
```

```
  "review_count": "76",
```

```
  "appliance": "refrigerator",
```

```
  "compatible_models": [
```

"3613970232000",
"3613970247000",
"3613970622000",
"3613978892890",
"3613978892891",
"3613978892892",
"3613978892894",
"3613978892896",
"3613978892897",
"3613978892898",
"3613978895890",
"3613978895891",
"3613978895892",
"3613978895894",
"3613978895896",
"3613978895897",
"3613978895898",
"3613978897890",
"3613978897891",
"3613978897892",
"3613978897894",
"3613978897896",
"3613978897897",
"3613978897898",
"3613979472991",
"3613979477991",

"3613979479991",

"3613979492991",

"3613979499991",

"3613979522994"

]

},

{

"part_name": "Refrigerator Center Crisper Drawer Slide Rail - White WPW10671238",

"part_number": "PS11757048",

"manufacturer": "Kenmore",

"price": "50.67",

"description": "This is a center crisper rail for your refrigerator. This part acts as a support rail for the crisper drawer by holding the center of the crisper frame. You will need to replace this part if your current drawer is not opening or closing properly. This crisper rail is white and it is made entirely of plastic. It is roughly 13.5 inches long, and 2.5 inches wide. This is an easy repair which requires no tools.",

"rating": "90",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close | Noisy | Fridge too cold | Leaking This part works with the following products: Refrigerator. Part# WPW10671238 replaces these: AP6023702, 12530701, 12530701N, 14217493, 67001057, 8208354, 97001057, W10671238, W10671238N Back to Top",

"review_count": "173",

"appliance": "refrigerator",

"compatible_models": [

"10669312310",

"10672002010",

"10672002011",

"10672002013",

"10672002015",
"10672003010",
"10672003011",
"10672003012",
"10672003013",
"10672003014",
"10672003016",
"10672003017",
"10672003018",
"10672009010",
"10672009011",
"10672009013",
"10672009015",
"596379243017",
"596467934251",
"596467934351",
"596467934451",
"596467934951",
"59662212200",
"59662213200",
"59662214200",
"59662219200",
"59662222200",
"59662224200",
"59662232200",
"59662234200"

]

},

{

"part_name": "Whirlpool EveryDrop3 Refrigerator Water Filter EDR3RXD1",

"part_number": "PS11722128",

"manufacturer": null,

"price": "83.97",

"description": "This EveryDrop Filter3 is certified to reduce the most contaminants with Triple Filtration Technology. Now, you and your family can enjoy the enriching benefits of cleaner, freshly filtered ice & water. Not just in beverages, but for preparing meals, too. This advanced generation of ice and water refrigerator filters from EveryDrop Filters are certified to reduce more contaminants with Triple Filtration Technology. Filter 5 reduces 16 contaminants, so you can feel reassured that you and your family are getting the most out of your water. Remember to replace your refrigerator filter every 6 months to maximize contaminant reduction.",

"rating": "95",

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making ice | Not dispensing water | Leaking | Ice maker won't dispense ice This part works with the following products: Refrigerator. Part# EDR3RXD1 replaces these: AP5983563, 2313412, 4396710, 4396710P, 4396711, 4396841, 4396841B, 4396841P, 4396842, 8212650, 9020B, 9030B, 9920, 9953, EDR3RXD2, FILTER3, W10121145, W10121146, W10565739A, W10754687 ... Show more , W10776411 Show less Back to Top",

"review_count": "111",

"appliance": "refrigerator",

"compatible_models": [

"10645422800",

"10645422801",

"10645423800",

"10645423801",

"10645429800",

"10645429801",
"10645432800",
"10645432801",
"10645433800",
"10645433801",
"10645439800",
"10645439801",
"10657782701",
"10657782702",
"10657782703",
"10657782704",
"10657782705",
"10657783701",
"10657783702",
"10657783703",
"10657783704",
"10657783705",
"10657784701",
"10657784702",
"10657784703",
"10657784704",
"10657784705",
"10657786701",
"10657786702",
"10657786703"

]

```
},
```

```
{
```

```
"part_name": "Refrigerator Door Shelf Bin WPW10321304",
```

```
"part_number": "PS11752778",
```

```
"manufacturer": "Kenmore",
```

```
"price": "36.18",
```

```
"description": "This manufacturer-certified Refrigerator Door Shelf Bin, also known as the crisper bin and door shelf bin, is made of clear plastic, and is easy to install. It is used to hold items in the fridge door, like jars, bottles, cans, and condiments, and this item is clear with white trim around its top edge and you'll be able to visually see if the part is broken. This particular shelf attaches to the fridge door. You can check if this model is right for your appliance by checking your user manual and model number. This individually-sold door bin fits many different models of side-by-side refrigerator, and can be installed with the use of no tools.",
```

```
"rating": "97",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close | Ice maker won't dispense ice | Leaking This part works with the following products: Refrigerator. Part# WPW10321304 replaces these: AP6019471, 2171046, 2171047, 2179574, 2179575, 2179607, 2179607K, 2198449, 2198449K, 2304235, 2304235K, W10321302, W10321303, W10321304, W10549739, WPW10321304VP Back to Top",
```

```
"review_count": "304",
```

```
"appliance": "refrigerator",
```

```
"compatible_models": [
```

```
"WDT780SAEM1",
```

```
"10640262010",
```

```
"10640263010",
```

```
"10640263011",
```

```
"10640269010",
```

```
"10640562010",
```

"10640563010",
"10640563011",
"10640569010",
"10640569011",
"10641262800",
"10641262801",
"10641263800",
"10641263801",
"10641263802",
"10641263804",
"10641264800",
"10641264801",
"10641269800",
"10641269801",
"10641562800",
"10641562801",
"10641562802",
"10641563800",
"10641563801",
"10641563802",
"10641563803",
"10641563805",
"10641564800",
"10641564801",
"10641564802"

]

```
},
```

```
{
```

```
  "part_name": "Refrigerator Handle set (2 pieces) - White 5304506469",
```

```
  "part_number": "PS11770473",
```

```
  "manufacturer": null,
```

```
  "price": "75.68",
```

```
  "description": "This Refrigerator Handle set comes in 2 pieces, and measures roughly 17\
```

in length. It can be installed with a screwdriver to allow the door to be opened and closed. If your handle is visibly broken then it should be replaced. Refer to your model number, and user manual to see if this part is right for you. These door handles are not sold individually, so we recommend replacing both handles at one time, or keeping the second one as a spare in case of future repairs. If you require the mounting blocks for the handle, these are sold separately. To make the repair, simply remove the screws at the top of the lower door, and replace the handle, screwing it into place.",

```
  "rating": "92",
```

```
  "troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# 5304506469 replaces these: AP6036330, 242059501, 242059504, 5304486359, 5304497105, 5304504507, 5304510038, 5304510040, P242059504 Back to Top",
```

```
  "review_count": "123",
```

```
  "appliance": "refrigerator",
```

```
  "compatible_models": [
```

```
    "CFHT1814LZ0",
```

```
    "CFHT1814LZ1",
```

```
    "CFHT1814LZ3",
```

```
    "CFHT1814LZ4",
```

```
    "CFHT1826LP0",
```

```
    "CFHT1826LP1",
```

```
    "CFHT1826LP2",
```

```
"CFHT1826LP3",  
"CFHT1826LP4",  
"CFHT1826LP5",  
"CFHT1826LP6",  
"CFHT1826LP7",  
"CFHT1843LW0",  
"CFHT1843LW1",  
"CFHT1843LW2",  
"CFHT1843LW3",  
"CFHT1843LW4",  
"CFHT1843LW5",  
"CFHT1843LW6",  
"CFHT1843LW7",  
"CFHT1843LW8",  
"CFHT1843LW9",  
"CFTR1826LW0",  
"CFTR1826LW1",  
"CFTR1826LW2",  
"CFTR1826LW3",  
"CFTR1826LW4",  
"CFTR1826LW5",  
"CFTR1826LW7",  
"CFTR1826LW8"  
]  
,  
{
```

"part_name": "Door Rack 240535101",

"part_number": "PS735091",

"manufacturer": "Kenmore",

"price": "39.17",

"description": "The Door Rack (also known as a retainer bar) is a 23\" white plastic part used to hold small items inside the fridge door. If broken, it should be replaced. Refer to your user manual and model number to determine if this part is correct for you. This is a simple part to repair and should not require any tools. Most customers found it to be very easy to simply snap the old rack out of place and snap the new one back in, making sure the locking tabs are secure. This part is sold individually and not as a part of a kit. It is certified by the original manufacturer.",

"rating": "91",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# 240535101 replaces these: AP3214801, 948956, 240535101 Back to Top",

"review_count": "75",

"appliance": "refrigerator",

"compatible_models": [

"25331430104",

"25331430105",

"25331430106",

"25331432103",

"25331432104",

"25331432105",

"25331432106",

"25331434103",

"25331434104",

"25331434105",

```
"25331434106",
"25331437103",
"25331437104",
"25331437105",
"25331437106",
"25331438103",
"25331438104",
"25331438105",
"25331438106",
"25331439103",
"25331439104",
"25331439105",
"25331439106",
"25331440300",
"25331440301",
"25331440302",
"25331442300",
"25331442301",
"25331442302",
"25331444300"
]
},
{
  "part_name": "Refrigerator Door Shelf Retainer Bin 240337901",
  "part_number": "PS429868",
  "manufacturer": "Kenmore",
```


"price": "41.52",

"description": "This refrigerator door shelf attaches to the inside of the refrigerator door, typically holds jars and bottles, The manufacturer-approved Refrigerator Door Shelf Retainer Bar, sometimes known as the door rack or bar retainer, is a white, plastic part which can be easily installed onto your fridge door. Just snap the old part up and out of place, and push to snap the new part in its place. This part holds items in your fridge like jars and bottles and will show physical damage if broken, at which time it should be replaced. Check your user manual and model number to see if this part is right for you, as there are likely to be several different sizes and part numbers for the various different door racks in your fridge. You want to make sure you've selected the right one! This part is 24.25 inches wide and 3.75 inches deep and features open square latches. This part is sold individually.",

"rating": "98",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close | Noisy | Touchpad does not respond This part works with the following products: Refrigerator. Part# 240337901 replaces these: AP2115858, 891047, 240337901, 240337904, 240337905 Back to Top",

"review_count": "175",

"appliance": "refrigerator",

"compatible_models": [

"25360112410",

"25360113410",

"25360113411",

"25360119410",

"25360602410",

"25360602411",

"25360602412",

"25360602413",

"25360602414",

"25360602415",

```
"25360602416",
"25360603410",
"25360603411",
"25360603412",
"25360603413",
"25360603414",
"25360603415",
"25360603416",
"25360604410",
"25360604411",
"25360604412",
"25360604413",
"25360604414",
"25360604415",
"25360604416",
"25360609410",
"25360609411",
"25360609412",
"25360609413",
"25360609414"
]
},
{
  "part_name": "Ice Bucket WPW10670845",
  "part_number": "PS11757044",
  "manufacturer": "Kenmore",
```

"price": "102.49",

"description": "Bucket only. All other parts sold separately. This part holds the ice once it's released from the icemaker.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Ice maker won't dispense ice | Ice maker not making ice This part works with the following products: Refrigerator. Part# WPW10670845 replaces these: AP6023698, 1115342, 1115372, 2152701, 2152702, 2182099, 2182100, 2196091, W10670845 Back to Top",

"review_count": "55",

"appliance": "refrigerator",

"compatible_models": [

"1064650043714",

"10650022210",

"10650022211",

"10650023210",

"10650023211",

"10650029210",

"10650029211",

"10650029213",

"10650042710",

"10650042711",

"10650042713",

"10650042714",

"10650042717",

"10650043710",

"10650043711",

"10650043713",

```
"10650043714",
"10650043717",
"10650045710",
"10650045711",
"10650045713",
"10650045715",
"10650049710",
"10650049711",
"10650049713",
"10650049714",
"10650049717",
"10650502990",
"10650502991",
"10650503990"
]
},
{
  "part_name": "Replacement Ice Maker 4317943",
  "part_number": "PS358591",
  "manufacturer": "Kenmore",
  "price": "131.03",
```

"description": "This ice maker (Complete Icemaker Assembly, Whirlpool Icemaker Kit, Ice Maker Assembly, Refrigerator Ice Maker, Icemaker) receives water from the water inlet valve, freezes it, and dispenses it into the ice bucket until the bucket is full. Ice makers will need to be replaced every 3-10 years depending on the frequency of usage, and water quality. You can perform a voltage test with a multimeter or perform an inlet valve test. If you're unable to make ice, or notice leaks then it may be a sign your ice maker is damaged and could be in need of a replacement. This model measures approximately 11x5 inches, is

constructed of plastic and metal, and comes in black/silver. This ice maker is a complete assembly; the whole assembly attaches to the wall of your freezer. ***NOTE: Ice maker does NOT come with the bail or shut off arm. You must order them separately if required. It does come complete with flat and round plug wiring harness, the mounting hardware, and the instructions. The harness can be reused. The ice maker will not fit refrigerators that have the ice auger mounted on the door.",

"rating": "96",

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making ice | Leaking | Ice maker won't dispense ice | Ice maker dispenses too little ice This part works with the following products: Refrigerator, Ice Maker, Wine and Beverage Cooler. Part# 4317943 replaces these: AP2984633, 1857, 4317943, 4210317, 4211173, 4317943, 4317943R, 4317943VP, 46000978556, 46004211173, 480616, 480617, 482014, 482015, 482016, 482017, 482018, 482019, 482020, 482394 ... Show more , 482433, 482990, 625601, 625603, 625610, 625611, 625622, 625625, 625653, 625656, 625660, 626002, 626201, 626237, 626366, 626461, 626489, 626608, 626609, 626626, 626636, 626640, 626670, 626687, 627572, 68972-4, 797991, 8114, 833701, 978552, 978553, 978556, 99989730, IC14B, M626687, W10122496, W10190952, W10281545, W10632400 Show less Back to Top",

"review_count": "222",

"appliance": "refrigerator",

"compatible_models": [

"1061105299",

"10647021790",

"10647021791",

"10647022790",

"10647022791",

"10647028790",

"10647028791",

"106482394",

"10648562893",

"10650022000",

```
"10650022004",
"10650027001",
"10650027002",
"10650027003",
"10650027004",
"10650032000",
"10650032003",
"10650032004",
"10650037000",
"10650037001",
"10650037004",
"10650202991",
"10650202992",
"10650202993",
"10650203993",
"10650209991",
"10650257000",
"10650257001",
"10650259001",
"10650259002"
]
},
{
  "part_name": "Door Cam - Black WPW10329686",
  "part_number": "PS11752991",
  "manufacturer": "Kenmore",
```

"price": "10.55",

"description": "The Door Cam is a black plastic part which helps the door pivot shut while keeping the door and hinge in proper alignment. Lubricating this part upon installation may help it move easier. It attaches onto the door hinge and should be replaced if broken or if there is noticeable damage. Refer to your model number and user manual to ensure this is the correct part for you. To do this repair you will need a 5/6 nut driver, a 5/16 socket, and a ratchet. For safety purposes, do not forget to turn off your appliance before making this repair. Note that this piece is black, and as per the manufacturer requires a new screw to mount the door cam which is sold individually. Please also note that this is the closing cam for the lower door, and the upper door cam is sold as a separate kit.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close | Clicking sound | Fridge too warm | Noisy This part works with the following products: Refrigerator, Freezer. Part# WPW10329686 replaces these: AP6019682, 1115901, 2155309, 2155310, 2155311, 2159138, 986759, W10329686, WPW10329686VP Back to Top",

"review_count": "64",

"appliance": "refrigerator",

"compatible_models": [

"10640212010",

"10640212011",

"10640262010",

"10640263010",

"10640263011",

"10640269010",

"10640562010",

"10640563010",

"10640563011",

"10640569010",

```
"10640569011",  
"10641012100",  
"10641012101",  
"10641012104",  
"10641014100",  
"10641014101",  
"10641014104",  
"10641212100",  
"10641212101",  
"10641214100",  
"10641214101",  
"10641262800",  
"10641262801",  
"10641263800",  
"10641263801",  
"10641263802",  
"10641263804",  
"10641264800",  
"10641264801",  
"10641269800"  
]  
,  
{  
  "part_name": "Lower Door Closing Cam WP2182179",  
  "part_number": "PS11739042",  
  "manufacturer": "Kenmore",
```


"price": "7.70",

"description": "The lower door closing cam is used in refrigerator doors, it can be located on the fresh food side or the freezer side. It helps hold the door open. This cam is made out of plastic, so it might crack or wear down over time. If your door will not open and close properly you may need to replace the door closing cam. To successfully install this part, you will need a 5/16 nut driver and a small flat blade screwdriver. Before you begin, unplug your appliance and disconnect the water supply. Lubricating this part may help with installation. This replacement part is sold individually. This part will fit both the left and right side of your refrigerator door. To make the repair, remove the top hinge cover, then the top hinge support. Lift the door from the bottom support and remove the old door cams. Replace the cams, using a little lubricant if necessary, and place the door back on the lower hinge support. Replace the top hinge support and your repair is complete!",

"rating": "91",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close | Clicking sound | Fridge too warm | Noisy This part works with the following products: Refrigerator. Part# WP2182179 replaces these: AP6005980, 2182178, 2182179, WP2182179VP Back to Top",

"review_count": "87",

"appliance": "refrigerator",

"compatible_models": [

"10640212010",

"10640212011",

"10640262010",

"10640263010",

"10640263011",

"10640269010",

"10640562010",

"10640563010",

"10640563011",

"10640569010",

```
"10640569011",
"10641012100",
"10641012101",
"10641012104",
"10641014100",
"10641014101",
"10641014104",
"10641122210",
"10641122211",
"10641122212",
"10641122213",
"10641123210",
"10641123211",
"10641123212",
"10641124210",
"10641129210",
"10641129211",
"10641129212",
"10641129213",
"10641152210"
]
},
{
  "part_name": "Refrigerator Crisper Drawer With Handle WP2188664",
  "part_number": "PS11739122",
  "manufacturer": "Kenmore",
```

"price": "56.48",

"description": "This OEM, clear convertible meat drawer can be used to store meats or vegetables and is designed for the lower portion of your refrigerator, generally. It has its own cold air duct to allow cold air from the freezer to flow into the drawer. You could have a broken or faulty drawer if you find that the food is kept within is spoiling or drying out quickly. The drawer should slide open and closed with ease. If your drawer will not easily slide open or closed, check the tracks that the drawer slides on. If the tracks are not damaged, the drawer itself could be at fault and should be replaced. Inspect it for visible damage like cracking or warping, which should be obvious. This part measures approximately 16 7/16 inches wide x 14 5/16 inches deep x 7 5/8 inches high and is a genuine OEM replacement part. It is sold individually. Note that there are several different types and options for the lower vegetable and meat drawers for your refrigerator, and you should check your user manual carefully to ensure that this is the drawer you are looking for.",

"rating": "96",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# WP2188664 replaces these: AP6006058, 2173385, 2173387, 2173696, 2175073, 2175076, 2179276, 2179279, 2179282, 2179348, 2188654, 2188664, 2188665, 2188724, 2189530, 2189630, 2194074, 2194076, 2194079, 2194082 ... Show more , 2194088, 2194648, 2196162, 2196228, 2196231, 2196480, 2197835, 2313312, W10153777, WP2188664VP, WP2313312 Show less Back to Top",

"review_count": "120",

"appliance": "refrigerator",

"compatible_models": [

"10640212010",

"10640212011",

"10640262010",

"10640263010",

"10640263011",

"10640269010",

"10640562010",

```
"10640563010",  
"10640563011",  
"10640569010",  
"10640569011",  
"10641012100",  
"10641012101",  
"10641012104",  
"10641014100",  
"10641014101",  
"10641014104",  
"10641122210",  
"10641122211",  
"10641122212",  
"10641122213",  
"10641123210",  
"10641123211",  
"10641123212",  
"10641124210",  
"10641129210",  
"10641129211",  
"10641129212",  
"10641129213",  
"10641152210"  
]  
,  
{
```

"part_name": "Refrigerator Crisper Drawer with Humidity Control WP2188656",

"part_number": "PS11739119",

"manufacturer": "Kenmore",

"price": "79.56",

"description": "The crisper drawer (Crisper Pan, Refrigerator Crisper Drawer) with humidity control is meant to keep your vegetables and fruit as fresh as possible by allowing you to regulate the humidity levels within the drawer. It attaches on the inside of your refrigerator to the bottom of the crisper shelf. This drawer can break from misuse or accidental damage. It is also subject to material fatigue over time. If broken or damaged, it may be difficult to slide the drawer in and out, and it should be replaced. This plastic drawer measures 14.92 inches long, 7.6 inches high, and 16.5 inches wide and comes in white/clear.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close | Ice maker not making ice | Leaking | Touchpad does not respond This part works with the following products: Refrigerator. Part# WP2188656 replaces these: AP6006055, 2173384, 2173386, 2173694, 2173714, 2173715, 2174109, 2174416, 2175075, 2179281, 2179347, 2188652, 2188656, 2189529, 2189629, 2194072, 2194078, 2194081, 2194087, 2194904 ... Show more , 2194914, 2194978, 2194979, 2196160, 2196230, 2196232, 2197834, WP2188656VP Show less Back to Top",

"review_count": "404",

"appliance": "refrigerator",

"compatible_models": [

"10640262010",

"10640263010",

"10640263011",

"10640269010",

"10640562010",

"10640563010",

"10640563011",

```
"10640569010",  
"10640569011",  
"10641152210",  
"10641152211",  
"10641153210",  
"10641153211",  
"10641154210",  
"10641159210",  
"10641159211",  
"10641159212",  
"10641262800",  
"10641262801",  
"10641263800",  
"10641263801",  
"10641263802",  
"10641263804",  
"10641264800",  
"10641264801",  
"10641269800",  
"10641269801",  
"10641512100",  
"10641512101",  
"10641514100"  
]  
,  
{
```

"part_name": "Refrigerator Door Shelf Bin - White WP2187172",

"part_number": "PS11739091",

"manufacturer": "Kenmore",

"price": "37.67",

"description": "This refrigerator door shelf bin, also known as the door bin, or sometimes just a \"bucket\", is an authentic manufacturer-certified part made of white plastic and is easy to install. It is used to hold items in the fridge door, like jars, cans, and bottles, and you'll be able to visually see if the part is broken or warped. This particular shelf attaches directly to the fridge door; you should be able to pull out the old bin and snap the new one into place by observing the slots and pushing the bin down into them. You can check if this model is right for your appliance by checking your user manual and model number. The door bin measures about 18 inches wide, 4.5 inches high, by 7 inches deep. This door shelf bin is sold individually, so if your refrigerator takes multiple bins, which many do, you will need to order the appropriate amount of bins.",

"rating": "99",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Door won't open or close | Ice maker not making ice This part works with the following products: Refrigerator. Part# WP2187172 replaces these: AP6006028, 2187172, 2187172K, 2187194, 2187194K, WP2187172VP Back to Top",

"review_count": "234",

"appliance": "refrigerator",

"compatible_models": [

"10641012101",

"10641012104",

"10641014101",

"10641014104",

"10641212101",

"10641214101",

"10641512101",

"10641514100",

```
"10641514101",
"10641519101",
"10648212500",
"10650029213",
"10650222010",
"10650512001",
"10650517000",
"10650517001",
"10650517003",
"10651512101",
"10651514101",
"10651522100",
"10651524100",
"10652232101",
"10652234101",
"10652242102",
"10652534101",
"10652542100",
"10652542102",
"10652544100",
"10652544102",
"10653282300"
]
},
{
  "part_name": "Crisper Support - Rear 241993001",
```


"part_number": "PS2358879",

"manufacturer": "Kenmore",

"price": "13.19",

"description": "This authentic rear crisper support is a white, plastic part which is rated as \"easy\" to install by our customers. This OEM part replaces the rear crisper cover support in your fridge and mounts to the inside cabinet wall. If there is visible damager or your crisper stops fitting properly, it may be time to replace the part. Check your user manual and model number to ensure this part is what you need. Replacing the rear crisper support in your refrigerator is an easy job. This part is made from plastic and mounts on the inside of the wall. To complete this repair you will need a small putty knife, a punch or a short flat blade screwdriver, and a small hammer. You may need to replace your rear crisper support if you find that the door will not open or close. In order to complete this repair, you will need to remove all the shelves above the crisper in order to have ample room to work. It is also good to have duct tape on hand, which can be used to protect the liner around the support. This part is sold individually. Please note that the rear and front crisper support are different parts; this is the one you are looking for if it is your rear support that needs replacing.",

"rating": "95",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# 241993001 replaces these: AP4393090, 1513081, 241993001, 240350802, 7240423701, 7241993001 Back to Top",

"review_count": "19",

"appliance": "refrigerator",

"compatible_models": [

"25344302400",

"25344302401",

"25344303400",

"25344303401",

"25344303402",

"25344303403",

"25344304400",
"25344304401",
"25344309400",
"25344309401",
"25344333600",
"25344333601",
"25344333602",
"25344333603",
"25344333604",
"25344333605",
"25344333606",
"25344333607",
"25344333608",
"25344333609",
"2534433360A",
"25344352400",
"25344352401",
"25344352403",
"25344352404",
"25344352405",
"25344352406",
"25344352407",
"25344352408",
"25344352409"

]

},

```
{
```

```
"part_name": "Refrigerator Door Shelf Bin 240338101",
```

```
"part_number": "PS429873",
```

```
"manufacturer": "Kenmore",
```

```
"price": "49.33",
```

```
"description": "This retainer bar (Refrigerator Door Shelf Bin, Refrigerator Door Shelf, Door Shelf Bin, Refrigerator Door Bin) holds items on the refrigerator door shelf. The plastic retainer can become brittle with time and crack or break under the strain of normal use. It can also break if heavy items are placed in the door shelf. If this part will no longer hold securely onto the inner door panel it will need to be replaced. This model is white plastic, and measures 26 by 5 inches. Sold individually.",
```

```
"rating": "93",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# 240338101 replaces these: AP2115860, 891051, 240338101, 240338104 Back to Top",
```

```
"review_count": "146",
```

```
"appliance": "refrigerator",
```

```
"compatible_models": [
```

```
"25331143300",
```

```
"25331143302",
```

```
"25331145300",
```

```
"25331145302",
```

```
"25331145303",
```

```
"25360112410",
```

```
"25360113410",
```

```
"25360113411",
```

```
"25360119410",
```

```
"25360602410",
```

```
"25360602411",
"25360602412",
"25360602413",
"25360602414",
"25360602415",
"25360602416",
"25360603410",
"25360603411",
"25360603412",
"25360603413",
"25360603414",
"25360603415",
"25360603416",
"25360604410",
"25360604411",
"25360604412",
"25360604413",
"25360604414",
"25360604415",
"25360604416"
]
},
{
  "part_name": "Refrigerator Water Inlet Valve 242252702",
  "part_number": "PS7784018",
  "manufacturer": "Kenmore",
```

"price": "90.98",

"description": "The function of the Refrigerator Water Inlet Valve (Triple Solenoid Water-Valve, Water Valve, Water Inlet Valve, Refrigerator Water Inlet Valve Assembly) is to release water from the supply line when activated, and send it through to your water dispenser or ice maker in your refrigerator. The water inlet valve is located at the back of the refrigerator, and connects to the water supply. The valve can break from material fatigue or normal use. If your water inlet valve is malfunctioning, you could be getting a lack of water to the inside of your refrigerator. Your ice maker may not produce cubes or your water dispenser may not work. The water inlet valve must be replaced if the solenoids no longer have continuity or the valve has internal blockage. This valve measures approximately 7 inches long and 4.5 inches wide, and is constructed of plastic and metal. It comes in blue, and includes the valve and mounting bracket.",

"rating": "93",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Ice maker not making ice | Not dispensing water | Ice maker won't dispense ice This part works with the following products: Refrigerator. Part# 242252702 replaces these: AP5671757, 2692163, 242252702, 240321801, 240505101, 240505102, 240508101, 240508102, 240531101, 241734301, 241734302, 7241734301 Back to Top",

"review_count": "111",

"appliance": "refrigerator",

"compatible_models": [

"25344302400",

"25344302401",

"25344303400",

"25344303401",

"25344303402",

"25344303403",

"25344304400",

"25344304401",

"25344309400",

```
"25344309401",  
"25344333600",  
"25344333601",  
"25344333602",  
"25344333603",  
"25344333604",  
"25344333605",  
"25344333606",  
"25344333607",  
"25344333608",  
"25344333609",  
"2534433360A",  
"25344352400",  
"25344352401",  
"25344352403",  
"25344352404",  
"25344352405",  
"25344352406",  
"25344352407",  
"25344352408",  
"25344352409"  
]  
,  
{  
  "part_name": "ROLLER 5304508016",  
  "part_number": "PS12071116",
```

"manufacturer": "Kenmore",

"price": "7.23",

"description": "This crisper pan roller is sourced directly from the manufacturer for use in your refrigerator. It is a genuine OEM part that is designed to fit just like the original for your convenience. The roller is a plastic wheel-like component that attached to the sides of the crisper pan and allows it slide in and out of the refrigerator smoothly. The rollers allow users to easily and conveniently access the contents of the drawers. Over time, the roller may wear down, break, or fall off. If the roller is faulty, you may notice difficulty sliding the drawer in and out, or the drawer may feel loose and unstable when you pull it out. Each crisper pan roller is sold individually. Ensure that you order the correct number of rollers for your refrigerator.",

"rating": "70",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# 5304508016 replaces these: AP6230456 Back to Top",

"review_count": "2",

"appliance": "refrigerator",

"compatible_models": [

"20462151B",

"2537034241E",

"2537034241F",

"2537034241H",

"2537034241J",

"2537034341F",

"2537034341G",

"2537034341H",

"2537034341J",

"25370347411",

"2537034941H",

```
"2537034941J",
"2537041341C",
"2537041341F",
"2537041341H",
"25370417410",
"25370417412",
"2537041941C",
"2537041941D",
"2537042341A",
"2537044341A",
"2537044341C",
"2537044341D",
"2537044341E",
"25370447411",
"90462157B",
"CFD28SDQSA",
"CFD28WQBC",
"CFD28WQBF",
"CFD28WQSC"
]
},
{
  "part_name": "Upper or Lower Mullion Hinge Pin 241779401",
  "part_number": "PS2358752",
  "manufacturer": "Kenmore",
  "price": "23.15",
```


"description": "This mullion hinge pin is a genuine OEM replacement part, measuring 1.5 inches by 1.25 inches by 0.85 inches. It is specially designed to secure the mullion in refrigerators, allowing it to pivot and ensure smooth door movement. The mullion acts as a barrier between the refrigerator and freezer to maintain the desired temperatures for each section. A damaged or loose hinge pin will result in temperature fluctuations, frost buildup along the door edges, and difficulties opening and closing the door. Therefore, it is important that you replace the pin as soon as it is no longer functioning. Note that your appliance may require two hinge pins, one near the top of the mullion and one near the bottom. Remove the mullion cover, detach the hinge pin, and install a the new one into the hinge assembly. Place the cover back on and verify that the hinge assembly is working by carefully opening and closing the refrigerator doors to check that they are moving smoothly. Each sold individually.",

"rating": "55",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close | Door Sweating This part works with the following products: Refrigerator. Part# 241779401 replaces these: AP4393564, 7241779401 Back to Top",

"review_count": "4",

"appliance": "refrigerator",

"compatible_models": [

"20462151B",

"2537034241E",

"2537034241F",

"2537034241H",

"2537034241J",

"2537034341F",

"2537034341G",

"2537034341H",

"2537034341J",

"25370347411",

"2537034941H",

```
"2537034941J",  
"2537041341C",  
"2537041341F",  
"2537041341H",  
"25370417410",  
"25370417412",  
"2537041941C",  
"2537041941D",  
"2537042341A",  
"2537044341A",  
"2537044341C",  
"2537044341D",  
"2537044341E",  
"25370447411",  
"90462157B",  
"CFD26SDS0",  
"CFD26WIS0",  
"CFD26WIS1",  
"CFD26WIS3"  
]  
,  
{  
  "part_name": "Air Filter EAFCBF",  
  "part_number": "PS1993820",  
  "manufacturer": "Kenmore",  
  "price": "31.72",
```

"description": "This manufacturer-approved air filter system for refrigerators eliminates odors and any impurities. It does this by neutralizing and removing odor-causing molecules. For best results, it is important to change the filter every 6 months to ensure that food is kept fresh, and the humidity is controlled. This part measures about 7 inches wide and 5 inches deep. Follow installation instructions provided by the manufacturer when installing this part to ensure accurate results and further guidance. Remember to unplug the refrigerator from the power source before starting this project. The air filter may be located in different places depending on your appliance, but is usually on the inner right or left side. See your manual for exact location. Our customers rated this as a very easy repair that takes only a few minutes; just locate and remove the old air filter and insert the new one to complete the repair, which requires no tools.",

"rating": "92",

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Ice maker not making ice | Fridge too cold | Noisy This part works with the following products: Refrigerator, Freezer, Wine and Beverage Cooler. Part# EAFCBF replaces these: AP4323287, 1381501, 241754001, 242047801, 242047804, 242061001 Back to Top",

"review_count": "17",

"appliance": "refrigerator",

"compatible_models": [

"25344743110",

"25344743111",

"25344753110",

"25370342210",

"25370342410",

"25370342411",

"25370342412",

"25370342413",

"25370342414",

"25370342415",

"25370342416",

```
"25370342417",
"25370342418",
"25370342419",
"2537034241A",
"2537034241B",
"2537034241C",
"2537034241D",
"2537034241E",
"2537034241F",
"2537034241H",
"2537034241J",
"25370343210",
"25370343410",
"25370343411",
"25370343412",
"25370343413",
"25370343414",
"25370343415",
"25370343416"
]
},
{
  "part_name": "Refrigerator Door Shelf Bin 240338001",
  "part_number": "PS429871",
  "manufacturer": "Kenmore",
  "price": "50.84",
```

"description": "This manufacturer-approved Refrigerator Door Shelf Bin is made of white plastic and is easy to install. It is used to hold heavier items in the fridge, and you'll be able to visually see if the part is broken. This particular shelf attaches to the fridge door and is designed for the UPPER shelf. You can check if this model is right for your appliance by checking your user manual and model number. This model is just over 26\" wide, just over 4\" tall and just over 7\" deep - front to back. This is a simple repair that requires only that you snap the old part out of place and snap the new one into place.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close | Noisy This part works with the following products: Refrigerator. Part# 240338001 replaces these: AP2115859, 891049, 240338001, 240338005 Back to Top",

"review_count": "197",

"appliance": "refrigerator",

"compatible_models": [

"25344703000",

"25344723100",

"25344723101",

"25344723102",

"25344723103",

"25344723104",

"25344723105",

"25344723106",

"25344723107",

"25344723108",

"25344723109",

"25344723110",

"25344723111",

"25360112410",

"25360113410",
"25360113411",
"25360119410",
"25360602410",
"25360602411",
"25360602412",
"25360602413",
"25360602414",
"25360602415",
"25360602416",
"25360603410",
"25360603411",
"25360603412",
"25360603413",
"25360603414",
"25360603415"

]

},

{

"part_name": "Crisper Cover Support - Front 241993101",

"part_number": "PS2358880",

"manufacturer": "Kenmore",

"price": "11.87",

"description": "This crisper cover front support is used to keep the crisper shelf in place and may need replacing if the door will not open or close. This white, OEM part measures roughly 1 inch in diameter and can be used for the front and the rear support, as designed by the manufacturer, and mounts to the inside cabinet wall. Replacing this part is an easy

repair, and will require a small flat blade screwdriver, a putty knife, and a soft hammer. Remove the crisper and shelf from the refrigerator before replacing the support. The crisper cover front support is held in place with a locking pin. To remove the old part, you will first need to push the pin into the interior of the cabinet using the screwdriver, and then you can pull the support out with a putty knife. If you cannot get the pin out you can use a flat-blade screwdriver to push it down and out of sight and it will not harm anything in your refrigerator. After removing the pin and attaching the new support, simply use the soft hammer to lock the new pin in place.",

"rating": "96",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# 241993101 replaces these: AP4427109, 1513082, 240423701, 7241993101 Back to Top",

"review_count": "78",

"appliance": "refrigerator",

"compatible_models": [

"25344302400",

"25344302401",

"25344303400",

"25344303401",

"25344303402",

"25344303403",

"25344304400",

"25344304401",

"25344309400",

"25344309401",

"25344333600",

"25344333601",

"25344333602",

"25344333603",

"25344333604",

"25344333605",

"25344333606",

"25344333607",

"25344333608",

"25344333609",

"2534433360A",

"25344352400",

"25344352401",

"25344352403",

"25344352404",

"25344352405",

"25344352406",

"25344352407",

"25344352408",

"25344352409"

]

},

{

"part_name": "Door Gasket - Gray W10830162",

"part_number": "PS11759515",

"manufacturer": "Kenmore",

"price": "188.09",

"description": "This door gasket is used to seal the refrigerator door when closed to keep the cool air inside and the room air out.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Door Sweating | Door won't open or close | Fridge too cold | Fridge too warm This part works with the following products: Refrigerator. Part# W10830162 replaces these: AP6027233, 12723206AP, W10179332, W10179332N, W10199876, W10443225, W10571956 Back to Top",

"review_count": "37",

"appliance": "refrigerator",

"compatible_models": [

"10672002010",

"10672003010",

"10672003011",

"10672003012",

"10672003013",

"10672003014",

"10672003016",

"10672003017",

"10672003018",

"10672009010",

"10672012010",

"10672013010",

"10672013017",

"10672019010",

"10678586800",

"59672002010",

"59672003010",

"59672003011",

"59672003012",

"59672003013",

"59672003014",

"59672003016",

"59672003017",

"59672003018",

"59672009010",

"59672012010",

"59672012011",

"59672012012",

"59672012014",

"59672013010"

]

},

{

"part_name": "EveryDrop Water Filter EDR5RXD1",

"part_number": "PS11722132",

"manufacturer": null,

"price": "85.14",

"description": "This EveryDrop Filter5 is certified to reduce the most contaminants with Triple Filtration Technology. Now, you and your family can enjoy the enriching benefits of cleaner, freshly filtered ice & water. Not just in beverages, but for preparing meals, too. This advanced generation of ice and water refrigerator filters from EveryDrop Filters are certified to reduce more contaminants with Triple Filtration Technology. Filter 5 reduces 16 contaminants, so you can feel reassured that you and your family are getting the most out of your water. Remember to replace your refrigerator filter every 6 months to maximize contaminant reduction.",

"rating": "87",

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making ice | Leaking | Not dispensing water | Ice maker won't dispense ice This part works with the following products: Refrigerator. Part# EDR5RXD1 replaces these: AP5983565, 2186444,

2200203, 2203220, 2203221, 2255518, 2255519, 2255709, 4392857, 4392857R, 4392922, 4396163, 4396164, 4396508, 4396509, 4396510, 4396547, 4396548, 8212652, EVFILTER5 ... Show more , FILTER5, L400, L400V, L500, NL240, NL240V, NL300, W10141392, W10168990, WF-L400, WF-L400V, WF-L500, WF-LC400, WF-NL240, WF-NL240V, WF-NL300, WF-NLC250 Show less Back to Top",

"review_count": "48",

"appliance": "refrigerator",

"compatible_models": [

"10650502990",

"10650503990",

"10650504990",

"10650509990",

"10652574200",

"10658282890",

"10658282891",

"10658285890",

"10658285891",

"10658287890",

"10658287891",

"10658289990",

"10658582890",

"10658582891",

"10658582892",

"10658585890",

"10658585891",

"10658585892",

"1065858782",

"10658587890",

"10658587891",

"10658587892",

"10658599890",

"10658599891",

"10658782890",

"10658782891",

"10658782892",

"10658785890",

"10658785891",

"10658785892"

]

},

{

"part_name": "Refrigerator Ice Maker Assembly W10884390",

"part_number": "PS11765620",

"manufacturer": "Kenmore",

"price": "93.63",

"description": "This is an ice maker assembly for various models of refrigerator. This ice maker assembly is used to freeze and eject ice into the ice bucket, then dispense the ice. This ice maker comes with the necessary shut-off arm, as well as a wire harness to properly install it into the freezer compartment of your refrigerator. If your current ice maker is either not producing ice or not breaking the ice up properly, it will need to be replaced. This ice maker assembly is an OEM part and is sold on its own, without any other parts or accessories.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making ice | Ice maker won't dispense ice | Ice maker dispenses too much ice | Leaking This part

works with the following products: Refrigerator. Part# W10884390 replaces these:
AP6030643, W10377152, W10469286, W10793298, WPW10377152, WPW10469286
Back to Top",

"review_count": "66",

"appliance": "refrigerator",

"compatible_models": [

"10672002011",

"10672002013",

"10672002015",

"10672003012",

"10672003013",

"10672003014",

"10672003016",

"10672003017",

"10672003018",

"10672009011",

"10672009013",

"10672009015",

"10672013017",

"596467934251",

"596467934351",

"596467934451",

"596467934951",

"59672002011",

"59672002013",

"59672002015",

"59672003012",

"59672003013",

"59672003014",

"59672003016",

"59672003017",

"59672003018",

"59672009011",

"59672009013",

"59672009015",

"59672012012"

]

},

{

"part_name": "Refrigerator Ice Maker Assembly 241798231",

"part_number": "PS12364147",

"manufacturer": "Kenmore",

"price": "153.27",

"description": "This 8-cube ice maker is used to create ice for your refrigerator. The ice maker receives water from the water inlet valve and will freeze until ice cubes are formed. Once the water has been frozen the cubes will be ejected from the mold in to the ice bucket. The ice maker will continue the process until the ice bucket has reached the limit. If your ice maker is not making ice you may need to replace this part. Please remember to disconnect the power and water supply before starting your repair. This ice maker is a genuine OEM part.",

"rating": "98",

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making ice | Ice maker won't dispense ice | Won't start | Noisy This part works with the following products: Refrigerator, Freezer, Ice Maker. Part# 241798231 replaces these: AP6332951, 241642501, 241642503A, 241642511, 241798201, 241798209, 241798211, 241798220, 241798223, 241798224, 3206327, 3206329, 5303320545, 5304445222, 5304456669,

5304456671, 5304456672, 75304445222, 75304456669, 75304456671 ... Show more ,
75304456672 Show less Back to Top",

"review_count": "83",

"appliance": "refrigerator",

"compatible_models": [

"25326092100",

"25326092101",

"25326093100",

"25331133300",

"25331133302",

"25331133303",

"25331133306",

"25331135300",

"25331135302",

"25331135303",

"25331135306",

"25331143300",

"25331143302",

"25331143303",

"25331145300",

"25331145302",

"25331145303",

"25331440300",

"25331440301",

"25331440302",

"25331440303",

"25331442300",

"25331442301",

"25331442302",

"25331442303",

"25331444300",

"25331444301",

"25331444302",

"25331444303",

"25331447300"

]

},

{

"part_name": "Drawer Support Rail - Left Side 240530601",

"part_number": "PS430916",

"manufacturer": "Kenmore",

"price": "48.77",

"description": "This drawer rail supports the left hand side of the sliding drawer.",

"rating": "93",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# 240530601 replaces these: AP2116589, 917557, 240530601, 240460401 Back to Top",

"review_count": "57",

"appliance": "refrigerator",

"compatible_models": [

"25331123300",

"25331123302",

"25331125300",

"25331125302",
"25331133300",
"25331133302",
"25331133303",
"25331133306",
"25331135300",
"25331135302",
"25331135303",
"25331135306",
"25331840100",
"25331840102",
"25331840104",
"25331840106",
"25331840108",
"2533184010A",
"2533184010B",
"2533184010C",
"25331842100",
"25331842102",
"25331842104",
"25331842106",
"25331842108",
"2533184210A",
"2533184210B",
"2533184210C",
"25331844100",

"25331844102"

]

},

{

"part_name": "Drawer Support Rail - Right Side 240530701",

"part_number": "PS430917",

"manufacturer": "Kenmore",

"price": "50.29",

"description": "This manufacturer-certified drawer support rail supports the right side of the sliding drawer. It is a track that helps the drawer slide open and closed with ease. If you are having trouble opening or closing your fresh food drawer, check the support rails for any blockage, or visible damage. If the rail is damaged, it should be replaced to ensure no further damage is done to the drawer itself. The repair is straightforward: unscrew and remove the existing support rail, then fasten the new rail in place. This genuine OEM replacement part is made of plastic and is white in color. NOTE: This part is sold separately from the left side drawer support rail. The part measures approximately 16 inches long by 1 inch high.",

"rating": "91",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# 240530701 replaces these: AP2116590, 917558, 240530701, 240460501 Back to Top",

"review_count": "145",

"appliance": "refrigerator",

"compatible_models": [

"25331123300",

"25331123302",

"25331125300",

"25331125302",

"25331133300",

"25331133302",
"25331133303",
"25331133306",
"25331135300",
"25331135302",
"25331135303",
"25331135306",
"25331840100",
"25331840102",
"25331840104",
"25331840106",
"25331840108",
"2533184010A",
"2533184010B",
"2533184010C",
"25331842102",
"25331842104",
"25331842106",
"25331842108",
"2533184210A",
"2533184210B",
"2533184210C",
"25331844102",
"25331844104",
"25331844106"

]

```
},
```

```
{
```

```
"part_name": "Refrigerator Crisper Pan 240337103",
```

```
"part_number": "PS429854",
```

```
"manufacturer": "Kenmore",
```

```
"price": "116.78",
```

```
"description": "This manufacturer-certified Refrigerator Crisper Pan is a clear plastic pan which easily inserts into your fridge's crisper area in order to hold items. In some models of refrigerator this model is the same pan for both the meat and vegetable bins, but please note that this part is sold individually and not part of a complete kit. If broken then the part should be replaced. Refer to your user manual and model number to see if this crisper is right for your fridge. This bin measures approximately 11 inches deep and 22 inches long.",
```

```
"rating": "100",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close | Leaking This part works with the following products: Refrigerator. Part# 240337103 replaces these: AP2115849, 891037, 240337103, 240337102, 240337103, 240337105, 240337107, 240337108, 240337109 Back to Top",
```

```
"review_count": "32",
```

```
"appliance": "refrigerator",
```

```
"compatible_models": [
```

```
"25331113300",
```

```
"25331113302",
```

```
"25331113304",
```

```
"25331113308",
```

```
"2533111330A",
```

```
"2533111330B",
```

```
"2533111330C",
```

```
"2533111330D",
```

"2533111330E",
"2533111330F",
"2533111330G",
"2533111330H",
"2533111330J",
"2533111330K",
"2533111330L",
"25331115300",
"25331115302",
"25331115304",
"25331115308",
"2533111530A",
"2533111530B",
"2533111530C",
"2533111530D",
"2533111530E",
"2533111530F",
"2533111530G",
"2533111530H",
"2533111530J",
"2533111530K",
"2533111530L"

]

},

{

"part_name": "Door Shelf Retainer Bar 240534701",

"part_number": "PS734936",

"manufacturer": "Kenmore",

"price": "51.05",

"description": "The Door Shelf Retainer Bar, also known as a refrigerator door rack, is a white, plastic part which can be easily installed onto your fridge door. It holds items in your fridge and will show physical damage if broken, at which time it should be replaced. Check your user manual and model number to see if this part is right for you. To install this part, you will need to remove the old one by unlocking the tabs, which can be slid with your fingers. To install the new shelf, line it up with the shelf cut-outs, over the tabs, and gently press it down to lock it into place. This part generally fits the middle door shelf of refrigerators. This is a part that frequently requires multiple parts per refrigerator. Because it is sold individually, you will need to purchase as many door racks as necessary to complete your repair.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# 240534701 replaces these: AP3214631, 948952, 240534701 Back to Top",

"review_count": "80",

"appliance": "refrigerator",

"compatible_models": [

"25331113300",

"25331113302",

"25331113304",

"25331113308",

"2533111330A",

"2533111330B",

"2533111330C",

"2533111330D",

"2533111330E",

"2533111330F",
"2533111330G",
"2533111330H",
"2533111330J",
"2533111330K",
"2533111330L",
"25331115300",
"25331115302",
"25331115304",
"25331115308",
"2533111530A",
"2533111530B",
"2533111530C",
"2533111530D",
"2533111530E",
"2533111530F",
"2533111530G",
"2533111530H",
"2533111530J",
"2533111530K",
"2533111530L"

]

},

{

"part_name": "Door Shelf Retainer Bar 240534901",

"part_number": "PS734935",

"manufacturer": "Kenmore",

"price": "41.39",

"description": "This door shelf retaining bar, also known as refrigerator door bar retainer or fridge door rack, is a genuine part sourced from the original manufacturer. It is a white This manufacturer-certified Door Shelf Retainer Bar, sometimes otherwise known as the door rack or bar retainer, is a white, plastic part which can be easily installed onto the inside of the refrigerator or freezer door to hold items on the door shelves. It holds items in your fridge and will show physical damage if broken or warped, at which time it should be replaced. Check your user manual and model number to see if this part is right for you. No tools are required for this installation, the part should simply snap into place. This part measures roughly 25 inches wide, 3 inches high, and 5 inches deep. This part is sold individually, and we recommend checking the other door shelf retaining bars on your refrigerator or freezer at the same time as ordering this part to ensure that no others need to be replaced, as they often wear or warp at similar speeds.",

"rating": "95",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close | Leaking This part works with the following products: Refrigerator. Part# 240534901 replaces these: AP3214630, 948954, 240534901 Back to Top",

"review_count": "169",

"appliance": "refrigerator",

"compatible_models": [

"25331113300",

"25331113302",

"2533111330A",

"2533111330C",

"2533111330D",

"2533111330F",

"2533111330H",

"2533111330K",

"2533111330L",


```
"25331115300",  
"25331115302",  
"25331115308",  
"2533111530F",  
"2533111530H",  
"2533111530K",  
"2533111530L",  
"25331123300",  
"25331125300",  
"25331133300",  
"25331133303",  
"25331133306",  
"25331135300",  
"25331135303",  
"25331810300",  
"25331812300",  
"25331814300",  
"25331817300",  
"25331840106",  
"25331840108",  
"2533184010A"  
]  
},  
{  
  "part_name": "BASKET,DOOR MAN64890501",  
  "part_number": "PS16662680",
```

"manufacturer": "LG",

"price": "46.93",

"description": "This door basket, also known as a door shelf or door bin, is compatible with LG refrigerators. It is an authentic manufacturer replacement part, sourced directly from LG. It is made of clear plastic and it hooks into place on the inside of the fridge door. The door basket is perfect for storing bottles and jars in an organized manner. Over time, it is common for the door basket to become discolored, warped, or cracked. It is recommended to replace it in order to continue storing your items safely. Each door basket is sold individually.",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Back to Top",

"review_count": "2",

"appliance": "refrigerator",

"compatible_models": [

"LRSDS2706D",

"LRSDS2706S",

"LRSOC2306D",

"LRSOC2306S",

"LRSOS2706D",

"LRSOS2706S",

"LRSXC2306S",

"LRSXC2306V",

"LRSXS2706B",

"LRSXS2706S",

"LRSXS2706V",

"LRSXS2706W"

]

```
},  
{  
  "part_name": "Door Bin - White/Clear AAP73631501",  
  "part_number": "PS8748026",  
  "manufacturer": "LG",  
  "price": "35.45",  
  "description": "This bin is white in color with a clear front insert. Sold individually.",  
  "rating": "96",  
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#  
AAP73631501 replaces these: AP5782456, AAP72909205, AAP72909207, AAP72909216  
Back to Top",  
  "review_count": "30",  
  "appliance": "refrigerator",  
  "compatible_models": [  
    "1867",  
    "48231784207",  
    "48231784214",  
    "48231784221",  
    "84275789",  
    "GC-L288NQJP",  
    "GC-L288NQRP",  
    "GC-L288NSJP",  
    "GC-L288NSRP",  
    "GC-L28ANSPP",  
    "GR-L288KVJP",  
    "LFX28977SB",  
    "LFX28977ST",
```

```
"LFX28977SW",
"LFX28978SB",
"LFX28978ST",
"LFX28978SW",
"LFX28978WH",
"LFX28979SB",
"LFX28979ST",
"LFX28979SW",
"LFX28991ST",
"LFX28995ST",
"LMX28983ST",
"LMX28987ST",
"LMX28988SB",
"LMX28988ST",
"LMX28988SW",
"LMX28994ST"
]
},
{
```

```
"part_name": "Roller Assembly AHJ72909001",
```

```
"part_number": "PS3532772",
```

```
"manufacturer": "LG",
```

```
"price": "11.47",
```

"description": "This is a drawer roller for the freezer compartment of your LG refrigerator. This roller is made of white plastic, and acts as a wheel to allow the drawer to glide smoothly back and forth when you open and close the freezer compartment. Over time and with further frequent use, this roller can crack, break, or stop rolling smoothly, at which

point it will need replacing. Your refrigerator comes with two rollers, and this roller is sold individually, so consider how many rollers you require before ordering.",

"rating": "89",

"troubleshooting_tips": "This part works with the following products: Refrigerator, Freezer. Part# AHJ72909001 replaces these: AP4671331 Back to Top",

"review_count": "11",

"appliance": "refrigerator",

"compatible_models": [

"1867",

"48231784207",

"48231784214",

"48231784221",

"48231784412",

"70355",

"70357",

"71032",

"71043",

"71049",

"71052",

"71053",

"71054",

"71056",

"71059",

"71355",

"72022",

"72023",

"72029",

```
"73102",
"73105",
"73107",
"73109",
"73115",
"74102",
"74105",
"74109",
"79570322310",
"79570322311",
"79570322312"
]
},
{
  "part_name": "Refrigerator Water Filter AGF80300702",
  "part_number": "PS12724833",
  "manufacturer": "LG",
  "price": "80.19",
  "description": "This refrigerator water filter replacement is for 2010 LG refrigerators that have either forward French doors or are the four-door dispensing models. This filter is designed to minimize impurities that can cause ill-tasting water or an unpleasant smell. It reduces sediment, dirt, rust, limescale, sand, and many other contaminants that can be harmful to your health and the life of your appliance. This filter should be replaced every 6 months or 200 gallons to ensure top quality performance.\n\n\nTo remove your unwanted filter, press the push button to open the filter cover (water may spill from the hole), pull out the old cartridge in a downward motion. To install the new filter, make it so the ears are in the horizontal position and push the new cartridge into the housing until it stops. Push the filter upward until it is secure. Click the cover to lock it in place. Run water
```

for approximately 5 minutes to prep the filter for use, and discard water. Reset the “filter reset” button if applicable.",

"rating": "99",

"troubleshooting_tips": "This part works with the following products: Refrigerator, Freezer. Part# AGF80300702 replaces these: ADQ36006101, ADQ36006103, ADQ36006105, ADQ36006113, AGF80300701 Back to Top",

"review_count": "18",

"appliance": "refrigerator",

"compatible_models": [

"1867",

"48231784207",

"48231784214",

"48231784221",

"48231784412",

"71052",

"71053",

"71054",

"71059",

"71079",

"71092",

"71093",

"71099",

"71322",

"72033",

"72034",

"72036",

"72039",

"72042",

"72043",

"72049",

"72052",

"72053",

"72059",

"72062",

"72063",

"72069",

"72092",

"72093",

"72099"

]

},

{

"part_name": "Water filter AGF80300704",

"part_number": "PS12724834",

"manufacturer": "LG",

"price": "80.96",

"description": "The Water filter reduces contaminants such as lead, iron, and chlorine from drinking water. This OEM filter is a genuine part manufactured by LG for use in refrigerators. We recommend you replace every 6 months or 200 gallons for best performance.",

"rating": "95",

"troubleshooting_tips": "This part works with the following products: Refrigerator, Range. Part# AGF80300704 replaces these: ADQ74793501, ADQ74793503, ADQ74793506, ADQ74793507, ADQ75805901, AGF80300703, AGF80300705, AGM76550101, MDJ64844601 Back to Top",


```
"review_count": "4",  
"appliance": "refrigerator",  
"compatible_models": [  
  "74142",  
  "74149",  
  "79572595710",  
  "79572597710",  
  "79573105710",  
  "79574077610",  
  "79574113710",  
  "79574305810",  
  "9980",  
  "AGF80300704",  
  "LFCC22426S",  
  "LFCC23596S",  
  "LFCS28768S",  
  "LFXC22526S",  
  "LFXC22596S",  
  "LFXC24796D",  
  "LFXC24796S",  
  "LFXS26566M",  
  "LFXS26566S",  
  "LFXS26596M",  
  "LFXS26596S",  
  "LFXS26973D",  
  "LFXS26973S",
```

"LFXS27466S",

"LFXS28566",

"LFXS28566D",

"LFXS28566M",

"LFXS28566S",

"LFXS28596D"

]

},

{

"part_name": "BASKET ASSEMBLY,DOOR AAP73631702",

"part_number": "PS7786027",

"manufacturer": "LG",

"price": "29.91",

"description": "This is an OEM door shelf designed for LG refrigerators. This shelf measures 8 inches deep and 14 inches wide, is made of white and clear plastic, and hooks into the side of the door within the refrigerator. This shelf is used to hold any condiments, cups, or food items that you would need it to hold and secure. If the shelf in your refrigerator is chipped, cracked, or broken, it will need to be replaced to continue to hold anything.",

"rating": "89",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# AAP73631702 replaces these: AP5673817 Back to Top",

"review_count": "7",

"appliance": "refrigerator",

"compatible_models": [

"48231784412",

"72493",

"72495",

"73052",
"73053",
"73054",
"73055",
"73059",
"73063",
"73065",
"79572493610",
"79572493611",
"79572495610",
"79572495611",
"79573052410",
"79573053410",
"79573054410",
"79573055410",
"79573059410",
"79573063410",
"79573065410",
"GC-J288GSXM",
"GC-J28AGKXM",
"GC-L288GKXM",
"GC-L288GQXM",
"GC-L288GQXP",
"GC-L288GSXM",
"GC-L288GSXP",
"GC-L28AGKXM",

```
"GC-L28AGSXM"
]
},
{
  "part_name": "refrigerator Door Shelf Bin - White AAP73631602",
  "part_number": "PS7786023",
  "manufacturer": "LG",
  "price": "30.47",
  "description": "Refrigerator door basket shelf bin assembly for some models of LG
fridges.\r\n\r\nThis is a genuine OEM item made by LG",
  "rating": "84",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
AAP73631602 replaces these: AP5673813 Back to Top",
  "review_count": "21",
  "appliance": "refrigerator",
  "compatible_models": [
    "48231784412",
    "72493",
    "72495",
    "73052",
    "73053",
    "73054",
    "73055",
    "73059",
    "79572493610",
    "79572493611",
    "79572495610",
```

```
"79572495611",
"79573052410",
"79573053410",
"79573054410",
"79573055410",
"79573059410",
"GC-B288GQNP",
"GC-B288G SNP",
"GC-L288GKXM",
"GC-L288GQXM",
"GC-L288GQXP",
"GC-L288GSXM",
"GC-L288GSXP",
"GC-L28AGKXM",
"GC-L28AGSXM",
"LFC28768SB",
"LFC28768ST",
"LFC28768SW",
"LFX28968D"
]
},
{
  "part_name": "FILTER ASSEMBLY,AIR CLEANER ADQ73214408",
  "part_number": "PS16222687",
  "manufacturer": "LG",
  "price": "48.56",
```

"description": "Refrigerator Air Filters are a key component for neutralizing odors and ensuring a fresh stream of air into your refrigerator. Swapping your old filter out for a fresh one isn't difficult and should take less than five minutes. This OEM filter measures approximately 3 inches (length) x 3 inches (height) x 5 inches (Depth). Air filters should be changed every 6 months depending on usage.",

"rating": "89",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# ADQ73214408 replaces these: AP6990312, ADQ73214402, ADQ73214404, ADQ73214405, ADQ73214406, LT120F, LT120P Back to Top",

"review_count": "16",

"appliance": "refrigerator",

"compatible_models": [

"70355",

"70357",

"71355",

"72042",

"72043",

"72049",

"72052",

"72053",

"72059",

"72069",

"72092",

"72093",

"72099",

"72182",

"72183",

"72189",

```
"72193",
"72353",
"72372",
"72373",
"72379",
"72482",
"72483",
"72489",
"72493",
"72495",
"72597",
"73052",
"73053",
"73054"
]
},
{
  "part_name": "BASKET,DOOR MAN63948502",
  "part_number": "PS12715906",
  "manufacturer": "LG",
  "price": "47.07",
```

"description": "This is a right-side door basket designed for use within LG refrigerators. This door basket is used to hold whatever condiments, containers, and food items are necessary. This basket is made of clear plastic and measures approximately 13.5 inches wide, 8 inches deep, and 3 inches tall. If your current refrigerator door basket is broken, cracked, or simply support any food items, it must be replaced immediately. To replace this shelf, simply lift the old one off its rear hooks, and install the new one by pushing its hooks into the door. Depending on your model, you may require more than one of this shelf, so

consider that before ordering. This door basket is sold individually and does not come with any other parts.",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# MAN63948502 replaces these: MAN63948501 Back to Top",

"review_count": "2",

"appliance": "refrigerator",

"compatible_models": [

"70355",

"70357",

"72595",

"72597",

"73102",

"73105",

"73107",

"73109",

"73115",

"74102",

"74105",

"74109",

"79572595710",

"79572595711",

"79572597710",

"79573105710",

"79574033414",

"79574102810",

"79574109810",


```
"79574109811",
"79574109812",
"79574149910",
"LFCC22426S",
"LFCC23596S",
"LFCS27596S",
"LFCS28768S",
"LFXC22526D",
"LFXC22526S",
"LFXS26566S",
"LFXS26973D"
]
},
{
  "part_name": "Door Basket AAP73631502",
  "part_number": "PS7786020",
  "manufacturer": "LG",
  "price": "37.21",
  "description": "This door bin is for refrigerators.\r\n\r\nDoor bin attaches to the inside of the refrigerator door and typically holds jars and bottles.",
  "rating": "94",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# AAP73631502 replaces these: AP5673810 Back to Top",
  "review_count": "25",
  "appliance": "refrigerator",
  "compatible_models": [
    "48231784412",
```

"72493",
"72495",
"73052",
"73053",
"73054",
"73055",
"73059",
"79572493610",
"79572493611",
"79572495610",
"79572495611",
"79573052410",
"79573053410",
"79573054410",
"79573055410",
"79573059410",
"GC-B288GQNP",
"GC-B288G SNP",
"GC-L288GKXM",
"GC-L288GQXM",
"GC-L288GQXP",
"GC-L288GSXM",
"GC-L288GSXP",
"GC-L28AGKXM",
"GC-L28AGSXM",
"LFC28768SB",

"LFC28768ST",

"LFC28768SW",

"LFX28968D"

]

},

{

"part_name": "Door Shelf Retainer Bar End Cap WP2156003",

"part_number": "PS11738927",

"manufacturer": "Kenmore",

"price": "13.16",

"description": "The door shelf retainer bar end cap connects to the retainer bar on your refrigerator's door shelf, and attaches it to the refrigerator door. If your shelf retainer bar has become disconnected, a damaged end cap could be the cause. To remove the end cap, first unhook the release tab on both ends of the retainer bar. Slide out the bar and the end caps, and slide out the defective cap. Now, simply replace the end cap and snap the bar with end caps back in place on the refrigerator door. This part is made of white plastic and is sold individually.",

"rating": "83",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WP2156003 replaces these: AP6005865, 2156003 Back to Top",

"review_count": "9",

"appliance": "refrigerator",

"compatible_models": [

"10632842010",

"10632852010",

"10632852011",

"10632853010",

"10632853011",

"10632862010",
"10632862011",
"10632863010",
"10632863011",
"10632872010",
"10632873010",
"10660232900",
"10660232902",
"10660232903",
"10660232904",
"10660233900",
"10660233902",
"10660233903",
"10660233904",
"10660234900",
"10660234902",
"10660234903",
"10660234904",
"10660239900",
"10660239902",
"10660239903",
"10660239904",
"10660522900",
"10660522901",
"10660528900"

]

```
},
```

```
{
```

```
"part_name": "Bi-Metal Defrost Thermostat WPW10225581",
```

```
"part_number": "PS11750673",
```

```
"manufacturer": "Kenmore",
```

```
"price": "46.55",
```

```
"description": "If you have ice building up in your freezer, or if your freezer is getting too warm during the defrost cycle you may need to replace the bi-metal defrost thermostat. The function of the defrost bi-metal thermostat is to clip onto the evaporator and protect your evaporator from overheating during the defrost cycle. If your refrigerator does not defrost properly you can test both the thermostat and the heater to figure out which part is at fault. For this repair, you will need a Phillips screwdriver, a 1/4 inch nut driver, a flat blade screwdriver, a pair of wire strippers, a roll of electrical tape, and a few butt splice connectors.",
```

```
"rating": "93",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Freezer not defrosting | Freezer section too warm | Fridge and Freezer are too warm This part works with the following products: Refrigerator. Part# WPW10225581 replaces these: AP6017375, 2149849, 2161331, 2176066, 2188824, 2196155, 2266066, 2266067, 2315504, 2317087, 2319914, 2321799, 2321802, 4387498, W10225581, W10260437, WPW10225581VP Back to Top",
```

```
"review_count": "27",
```

```
"appliance": "refrigerator",
```

```
"compatible_models": [
```

```
"10632842010",
```

```
"10632852010",
```

```
"10632852011",
```

```
"10632853010",
```

```
"10632853011",
```

```
"10632862010",
```

```
"10632862011",  
"10632863010",  
"10632863011",  
"10632872010",  
"10632873010",  
"10632882010",  
"10632883010",  
"10632889010",  
"10640212010",  
"10640212011",  
"10640262010",  
"10640263010",  
"10640263011",  
"10640269010",  
"10640562010",  
"10640563010",  
"10640563011",  
"10640569010",  
"10640569011",  
"10641012100",  
"10641012101",  
"10641012104",  
"10641014100",  
"10641014101"  
]  
},
```

```
{
```

```
"part_name": "Capacitor WPW10662129",
```

```
"part_number": "PS11757023",
```

```
"manufacturer": "Kenmore",
```

```
"price": "53.67",
```

```
"description": "This capacitor (Refrigerator and Freezer Compressor Run Capacitor, Run Capacitor) provides the voltage or energy current required to start the compressor and keep it running. It allows the compressor in your appliance to easily cycle on and off. This capacitor mounts directly onto the compressor starting relay. If the capacitor is faulty the compressor may get unusually hot and draw excessive amperage. If the compressor overheats, it may fail to run until it cools down again. The compressor may also get noisy from overheating. If this part is totally electrically open, it is defective (often due to overheating) and needs to be replaced. The part measures 1 inch by 1-1/2 inches, and is constructed of plastic with two metal wire terminals. This item includes 1 capacitor, sold individually. This part comes in black.",
```

```
"rating": "85",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Will Not Start | Fridge and Freezer are too warm | Freezer section too warm This part works with the following products: Refrigerator, Freezer. Part# WPW10662129 replaces these: AP6023677, 09100136, 09100156, 09100173, 1100804, 1114291, 1118576, 1118581, 14201635, 14224144, 2169136, 2169373, 2169383, 2188516, 2264017, 4312484, 4356442, 4356601, 4356995, 4357055 ... Show more , 4357094, 4390503, 4390930, 60001028, 65889-2, 65889-6, 68001280, 69001105, 8199858, 945508, 999532, C8931601, C8931602, C8931607, R0213143, R0213187, R0651012, R0660030, R0950186, R9800532, W10590083, W10658690, W10662129, WPW10662129VP, Y09100136, Y09100156, Y09100173 Show less Back to Top",
```

```
"review_count": "39",
```

```
"appliance": "refrigerator",
```

```
"compatible_models": [
```

```
"10631400200",
```

```
"10631402200",
```

```
"10631404200",
```

"10631409200",
"10631410200",
"10631412200",
"10631414200",
"10631419200",
"10632242101",
"10632243101",
"10632249101",
"10632842010",
"10632852011",
"10632853011",
"10632862011",
"10632863011",
"10632942101",
"10632943101",
"10632949101",
"10640562010",
"10640563010",
"10640563011",
"10640569010",
"10640569011",
"10641122210",
"10641123210",
"10641124210",
"10641129210",
"10641133715",


```
"10641173716"
]
},
{
  "part_name": "Crisper Pan WP2256704",
  "part_number": "PS11739936",
  "manufacturer": "Kenmore",
  "price": "101.63",
  "description": "This crisper pan, or drawer, is made for your refrigerator. The drawer has a controlled environment to ensure a proper humidity level to keep your produce fresh for longer. It is clear in color and made of plastic. It is approximately 13 inches by 10 inches at the base of the pan.",
  "rating": "86",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WP2256704 replaces these: AP6006849, 2256704 Back to Top",
  "review_count": "14",
  "appliance": "refrigerator",
  "compatible_models": [
    "10632852010",
    "10632852011",
    "10632853010",
    "10632853011",
    "10632862010",
    "10632862011",
    "10632863010",
    "10632863011",
    "10632872010",
```

```
"10632873010",
"10632882010",
"10632883010",
"10632889010",
"10660522900",
"10660522901",
"10660528900",
"10660528901",
"10660529900",
"10660529901",
"10660932900",
"10660932901",
"10660933900",
"10660933901",
"10660934900",
"10660934901",
"10660939900",
"10660939901",
"10662972900",
"10662972901",
"10662973900"
]
},
{
  "part_name": "ICEMAKER W11510803",
  "part_number": "PS16660327",
```

"manufacturer": "Kenmore",

"price": "127.05",

"description": "This genuine OEM ice maker kit is designed to fit refrigerators that did not originally come with an ice maker. This kit contains everything needed to install the new ice maker on your refrigerator including: the ice maker, ice bin, inlet valve, fill tube, and hardware. If your new ice maker does not function properly after being installed, check the freezer temperature. The freezer must to be around zero degrees Fahrenheit. Remember to disconnect the power and water supply to your refrigerator before beginning this installation. Make sure to check that your model is compatible with this part before ordering.\n\nNote: The manufacturer has updated this part. It may differ in appearance but will function the same as the original.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making ice | Ice maker won't dispense ice | Leaking This part works with the following products: Refrigerator, Freezer. Part# W11510803 replaces these: 2155468, 2155469, 2155469A, 2171811, 8560, ECKMF94, ECKMF95, IMKIT94, KIMS9, W10670871, W10715708, W11534202, WPW10715708 Back to Top",

"review_count": "26",

"appliance": "refrigerator",

"compatible_models": [

"10631400200",

"10631402200",

"10631404200",

"10631409200",

"10631410200",

"10631412200",

"10631414200",

"10631419200",

"10632242101",

"10632243101",

```
"10632249101",  
"10632842010",  
"10632852010",  
"10632852011",  
"10632853010",  
"10632853011",  
"10632862010",  
"10632862011",  
"10632863010",  
"10632863011",  
"10632872010",  
"10632873010",  
"10632882010",  
"10632883010",  
"10632889010",  
"10632942101",  
"10632943101",  
"10632949101",  
"10639420990",  
"10639422990"  
]  
,  
{  
  "part_name": "Meat Drawer Shelf W10861519",  
  "part_number": "PS11731608",  
  "manufacturer": null,
```

"price": "54.13",

"description": "This is a meat drawer shelf frame for some models of refrigerator. This white plastic frame measures approximately 12-inches wide and 16 inches long, and is used to allow the meat drawer to easily slide in and out of the fridge. If your meat drawer is currently sagging and this frame is damaged and not supporting it enough, it needs to be replaced. Replacing this frame requires you to remove the meat drawer and the glass shelf above it, so you can flip it over and slide out the old frame, and slide in the new. This frame is supplied by the original equipment manufacturer and is sold individually, so it does not include any other parts for the meat drawer or shelf above it.",

"rating": "94",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# W10861519 replaces these: AP5999492, W10628698 Back to Top",

"review_count": "56",

"appliance": "refrigerator",

"compatible_models": [

"5GT311FFEW00",

"5WT511SFEG00",

"5WT511SFEW00",

"5WT519SFEG00",

"5WT519SFEW00",

"MRT711SMFZ02",

"WRT148FZDB00",

"WRT148FZDB03",

"WRT148FZDB04",

"WRT148FZDM00",

"WRT148FZDM03",

"WRT148FZDM04",

"WRT148FZDW00",

```
"WRT148FZDW03",
"WRT148FZDW04",
"WRT311FZDB00",
"WRT311FZDB01",
"WRT311FZDB02",
"WRT311FZDM00",
"WRT311FZDM01",
"WRT311FZDM02",
"WRT311FZDT00",
"WRT311FZDT01",
"WRT311FZDT02",
"WRT311FZDW00",
"WRT311FZDW01",
"WRT311FZDW02",
"WRT311FZDZ00",
"WRT311FZDZ01",
"WRT311FZDZ02"
]
},
{
  "part_name": "Refrigerator Ice Maker W10873791",
  "part_number": "PS11738120",
  "manufacturer": "Kenmore",
  "price": "97.53",
  "description": "This ice maker is for refrigerators.\r\n\r\nIce maker includes the ice mold
and the control device. The ice maker receives water from the water inlet valve and then
holds the water in the ice mold until the water freezes solid. It then automatically ejects the
```

ice and refills to continue the process until the ice storage in is full.\r\n\r\nSafely store any food that could deteriorate while the power is off and unplug the refrigerator when installing this part. Wear work gloves to protect your hands.",

"rating": "89",

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making ice | Ice maker won't dispense ice | Leaking This part works with the following products: Refrigerator. Part# W10873791 replaces these: AP6026347, W10760070, W10798411, W10847507, W10873791VP, W11130444, W11646278 Back to Top",

"review_count": "43",

"appliance": "refrigerator",

"compatible_models": [

"1064651339710",

"1064651773510",

"10651132213",

"10651133213",

"10651134213",

"10651135610",

"10651139213",

"10651139214",

"10651332710",

"10651335710",

"10651335713",

"10651339710",

"10651762510",

"10651762511",

"10651763510",

"10651763511",

"10651764510",
"10651764511",
"10651769510",
"10651769511",
"10651769512",
"10651772510",
"10651773510",
"10651779510",
"10651779511",
"10651782412",
"10651782413",
"10651783412",
"10651783416",
"10651789412"

]

},

{

"part_name": "Gallon Door Bin - Clear WPW10710203",

"part_number": "PS11757236",

"manufacturer": "Kenmore",

"price": "42.88",

"description": "Sold individually. This door bin is for refrigerators.\r\n\r\nThe door bin attaches to the inside of the refrigerator door and typically holds jars and bottles.",

"rating": "93",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WPW10710203 replaces these: AP6023888, W10451871, W10463668, W10710203, WPW10710203VP Back to Top",

"review_count": "69",
"appliance": "refrigerator",
"compatible_models": [
"10641122210",
"10641122211",
"10641122212",
"10641122213",
"10641123210",
"10641123211",
"10641123212",
"10641124210",
"10641129210",
"10641129211",
"10641129212",
"10641129213",
"10641152210",
"10641152211",
"10641153210",
"10641153211",
"10641154210",
"10641159210",
"10641159211",
"10641159212",
"10650022210",
"10650022211",
"10650023210",

```
"10650023211",  
"10650029210",  
"10650029211",  
"10651113210",  
"10651122210",  
"10651122211",  
"10651123210"  
]  
},  
{  
  "part_name": "Water Filter EDR2RXD1",  
  "part_number": "PS11722126",  
  "manufacturer": "Kenmore",  
  "price": "90.65",
```

"description": "This water filter is a genuine replacement for bottom-freezer refrigerators that accept a Filter 2. it is certified to remove up to 24 different contaminants which include pharmaceuticals, waterborne parasites, lead, and pesticides. The filter should be replaced every six months, or when 200 gallons of water have passed through, to ensure optimum contaminant reduction. The filter is found in the top right corner of your fridge, and replacing it is easy. Simply pop out the old one (keep a bucket underneath to catch any water) and slide in the new one. You will hear a click once it has locked into place. You should run water through the filter for a couple minutes prior to use. This filter measures approximately two inches wide, two inches deep, and 7.5 inches long.",

```
"rating": "96",
```

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making ice This part works with the following products: Refrigerator, Freezer. Part# EDR2RXD1 replaces these: AP5983562, FILTER 2, FILTER2, W10238154, W10413645, W10413645A, W10609378, W10680605 Back to Top",

```
"review_count": "36",
```

"appliance": "refrigerator",

"compatible_models": [

"10673002510",

"10673002511",

"10673003510",

"10673003511",

"10673009510",

"10673009511",

"10679472410",

"59672382410",

"596723824102",

"59672382413",

"59672383410",

"596723834102",

"59672383413",

"59672389410",

"59672389412",

"59672389413",

"59673002510",

"59673003510",

"59673009510",

"7MF2976AEM00",

"7MF2976AEM01",

"7MF2976AEM02",

"7MF2976AEM03",

"7WF736SDAM10",

"7WF736SDAM11",

"7WF736SDAM12",

"7WF736SDAM13",

"7WF736SDAM14",

"ALOVE18FLC00",

"ALOVE24FLC00"

]

},

{

"part_name": "Refrigerator Air Filter W10311524",

"part_number": "PS2580853",

"manufacturer": "Kenmore",

"price": "21.54",

"description": "This Refrigerator Air Filter is a white 1.8x3.2\" plastic filter which neutralizes odor and bacteria in the air. It should be replaced every six months at a minimum. Refer to your user manual and model number to see if this filter is right for your fridge. Location for storage of the air filter may vary from model to model, but generally, you will find a small cover on the back-middle-top of your fridge, which can be popped off to reveal the air filter, which can be easily changed out from there. This part does not come sold with the indicator; it is the filter only. Sold individually.",

"rating": "95",

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too cold | Fridge too warm | Ice maker not making ice | Noisy This part works with the following products: Refrigerator. Part# W10311524 replaces these: AP4538127, 2319308, AIR 1, AIR1, W10315189, W10335147 Back to Top",

"review_count": "43",

"appliance": "refrigerator",

"compatible_models": [

"10632242101",

"10632243101",
"10632249101",
"10632942101",
"10632943101",
"10632949101",
"10641162310",
"10641163310",
"10641169310",
"1064651773510",
"10651132210",
"10651132213",
"10651133210",
"10651133213",
"10651134210",
"10651134213",
"10651135610",
"10651136210",
"10651139210",
"10651139213",
"10651139214",
"10651142110",
"10651142111",
"10651143110",
"10651143111",
"10651149110",
"10651149111",

```
"10651149112",  
"10651152110",  
"10651152112"  
]  
},  
{  
  "part_name": "Refrigerator Ice and Water Filter EDR1RXD1",  
  "part_number": "PS11701542",  
  "manufacturer": "Kenmore",  
  "price": "103.87",  
  "description": "This is an OEM replacement ice and water filter for your refrigerator. In  
side-by-side refrigerators, it is found in the top right corner or the bottom left grille. In  
bottom-freezer refrigerators, the filter is in the bottom left grille. In top-freezer units, the  
filter is located in the middle of the refrigerator. This NSF certified filter reduces 28  
contaminants including pharmaceuticals, metals, minerals, pesticides, cysts, industrial  
chemicals, Class I Particulates and chlorine. It is made up of coconut carbon block and  
has three layers of filtration. The first layer is particle filtration that helps block larger  
contaminants. The second layer is micro-filtration, which prevents medium-sized  
impurities from passing. The third layer is called absorption filtration, which absorbs  
microscopic-sized pollutants. It measures 2 inches deep, 2 inches wide, 1-1/2 inches high,  
and weighs 0.5 lbs. To ensure your filter is working its best, it needs to be replaced every six  
months. This single filter has a simple, quick-turn installation feature that does not require  
any tools.",  
  "rating": "96",  
  "troubleshooting_tips": "This part fixes the following symptoms: Not dispensing water |  
Ice maker not making ice | Ice maker won't dispense ice | Leaking This part works with the  
following products: Refrigerator. Part# EDR1RXD1 replaces these: AP5982535, 9900,  
9981, FILTER 1, FILTER1, W10217316, W10291030, W10295370, W10295370A,  
W10569758, W10569760, W10569761, W10735398 Back to Top",  
  "review_count": "103",  
  "appliance": "refrigerator",
```

"compatible_models": [

"10650022210",

"10650022211",

"10650023210",

"10650023211",

"10650029210",

"10650029211",

"10650029213",

"10651122211",

"10651123211",

"10651124211",

"10651129211",

"10651129212",

"10651132210",

"10651132213",

"10651133210",

"10651133213",

"10651134210",

"10651134213",

"10651135610",

"10651136210",

"10651139210",

"10651139213",

"10651139214",

"10651142111",

"10651143111",

"10651149111",

"10651149112",

"10651152112",

"10651182112",

"10651183112"

]

},

{

"part_name": "Light Bulb - 120V 25W WPA3073101",

"part_number": "PS11747806",

"manufacturer": null,

"price": "17.09",

"description": "This light bulb is a 120 volt, 25 watt incandescent appliance light bulb with a small base screw-in that fits in a variety of appliances such as microwaves, refrigerators, freezers, cooktops, or stoves. Its purpose is to light up the appliance when the door is open. This is a genuine OEM part. You may need to replace the light bulb if the existing bulb is burnt out or broken. This light bulb is sold individually and is a common wear part, it is recommended to order a spare.",

"rating": "82",

"troubleshooting_tips": "This part works with the following products: Refrigerator, Freezer, Microwave, Wall Oven. Part# WPA3073101 replaces these: AP6014564, 0044462, 0056371, 040672-01, 040672-04, 040672-05, 045606-01, 05200256, 09100073, 14200025, 14205551, 14206369, 14218316, 14218317, 14218659, 14218667, 20174-1, 20174-2, 20174-3, 20174-4 ... Show more , 20174-5, 2223678, 2309101, 2326255, 24836P01, 4164470, 4174873, 4312826, 4358971, 4713-001172, 4713-001197, 52001003, 53001359, 53001773, 54001046, 56001350, 58001043, 58001101, 58001310, 60001060, 61003236, 61004862, 6521, 67006179, 68001062, 8190269, 90051, 92045-1, A0385501, A30731-1, A3073101, A30790-1, A30790-2, A3079001, A3079001Q, A3079002, A3079003, A3079007, A307901, A3709001, M9D29, R0213161, R0662001, R0812001, R0812005, R0862001, R9900292, W10904371, W10904373,

WP2326255, WP61003236, Y0044462, Y0056371, Y04067201, Y04067204, Y09100073
Show less Back to Top",

"review_count": "10",

"appliance": "refrigerator",

"compatible_models": [

"10641522500",

"10641523500",

"10641524500",

"10641529500",

"10644022600",

"10644022601",

"10644022602",

"10644022603",

"10644023600",

"10644023601",

"10644023602",

"10644023603",

"10644024600",

"10644029600",

"10644029601",

"10644029602",

"10644029603",

"10644032600",

"10644032601",

"10644032602",

"10644032603",

"10644033600",

"10644033601",

"10644033602",

"10644033603",

"10644034600",

"10644039600",

"10644039601",

"10644039602",

"10644039603"

]

},

{

"part_name": "Refrigerator Door Bin WPW10289497",

"part_number": "PS11752093",

"manufacturer": "Kenmore",

"price": "48.68",

"description": "This door bin is for refrigerators.\r\n\r\nThe door bin attaches to the inside of the refrigerator door and typically holds jars and bottles.\r\n\r\nFollow the instructions in the owner's manual for installing this part. Sold individually.",

"rating": "95",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WPW10289497 replaces these: AP6018790, 12699206, 12699206SP, 12699208, 12699208SP, 67002733, 67003603, 67003768, 67005258, W10289497 Back to Top",

"review_count": "17",

"appliance": "refrigerator",

"compatible_models": [

"10678586800",

"59673502200",
"59673502201",
"59673502202",
"59673502203",
"59673502300",
"59673503200",
"59673503201",
"59673503202",
"59673503203",
"59673503300",
"59673504200",
"59673504201",
"59673504202",
"59673504203",
"59673504300",
"59673509200",
"59673509201",
"59673509202",
"59673509203",
"59673509300",
"59675502400",
"59675503400",
"59675504400",
"59675509400",
"59675512400",
"59675513400",

"59675514400",

"59675519400",

"59675522400"

]

},

{

"part_name": "Replacement Ice Maker D7824706Q",

"part_number": "PS2121513",

"manufacturer": null,

"price": "115.96",

"description": "This ice maker (Ice Maker Assembly, Refrigerator Ice Maker) produces ice cubes that are ejected into the storage bucket. It is located in the freezer section of your appliance, mounted on the freezer wall. The ice maker can break from normal wear and accidental damage. If this happens, your refrigerator may no longer make ice cubes, or may not make enough cubes, and the part should be replaced. This model measures approximately 11 inches long and 5 inches wide. It's constructed of plastic and metal, and comes in black/white/silver. This assembly includes the ice mold and the control device.",

"rating": "95",

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making ice | Leaking | Ice maker won't dispense ice | Ice maker dispenses too little ice This part works with the following products: Refrigerator, Ice Maker. Part# D7824706Q replaces these: AP4135008, 915772, D7824706Q, 0056504, 0056599, 0056605, 0056606, 0311155, 0312578, 0312738, 0312739, 0312740, 10549201, 10563707, 10563708, 14211407, 61005508, 61005508A, 67001263, 68111-1 ... Show more , 68972-1, 68972-4, 8170937, 95091-1, 95098-1, 95109-1, D7767601, D7824701, D7824702, D7824703, D7824704, D7824705, D7824705Q, D7824706, D7824706Q, D7824706QVP, R0154025, R0156628, R0156629, R0156669, R0161059, R0161061, R0167201, R0183135, R0194462, R0194462A, R0194666, R0950064, W10122519, W10190978, Y0056504, Y0056599, Y0056606, Y0312578, Y0312738, Y0312740, Y689724, YR0161061 Show less
Back to Top",

"review_count": "152",

"appliance": "refrigerator",

"compatible_models": [

"10672002010",

"10672003010",

"10672003011",

"10672009010",

"10672012010",

"10672013010",

"10672019010",

"12001294",

"12001302",

"12500048",

"17694",

"17794A",

"18103-0",

"18103-0A",

"181040",

"18914A",

"19123-0",

"19124-0",

"19133-0A",

"191340",

"191347",

"19143-0A",

"19143-0B",

"191450",

```
"191457",  
"19153-1",  
"191550",  
"191557",  
"19163-0A",  
"191650"  
]  
},  
{  
  "part_name": "Light Bulb - 40W 8009",  
  "part_number": "PS884734",  
  "manufacturer": "Kenmore",  
  "price": "11.72",
```

"description": "This an authentic OEM 40-Watt replacement light bulb, used in a number of household appliances. It is specially designed to withstand extreme temperatures, which is why these replacement bulbs are most often used to light the inside of refrigerators and ranges. It features a standard socket base, which means you simply unscrew the burnt-out bulb and screw in the replacement. Depending on the appliance you may require a screwdriver or nut driver to access the light bulb. We recommend you wear work gloves while handling this replacement part. It is constructed of glass and metal and is sold individually. Depending on the appliance and location of the bulb within it, you may want to consider disconnecting power and using a flashlight for easier access to unscrewing and re-screwing in your bulb during this repair.",

"rating": "93",

"troubleshooting_tips": "This part works with the following products: Refrigerator, Range, Wall Oven, Dryer. Part# 8009 replaces these: AP3607217, 1958, 8009, 0020478, 0020571, 0042175, 0047146, 0053950, 0056713, 0057030, 0057035, 0088673, 0089290, 03055001, 0311700, 040672-02, 05600070, 0B00300199, 0B00300299, 0B00300399 ... Show more , 0L01500199, 10664502, 10664503, 1077-202, 1077202, 14001021, 14201304, 14205456, 14206578, 14207674, 14211172, 14214978, 14903, 15199, 15779, 187, 19447, 19950037, 20100751, 20102977, 20478, 2252969, 2252970,

2255743, 2262969, 2311792, 233056, 2386, 2386001, 240673, 241006, 245388, 247591, 25916P01, 259957, 260929, 279666, 3-0909, 3-909, 300909, 304-3, 311255, 311255D, 31956, 31956-1, 31956A, 40A15, 41275, 4157019, 4159006, 4165252, 4165697, 4166357, 4169617, 4173062, 4211947, 42585, 4319603, 4324154, 4338591, 4355037, 4355534, 4355679, 4364092, 4371303, 4372020, 4389460, 4390465, 5-20021, 5-50733, 5-70019, 50062-3, 501358, 50302, 509602, 517949, 51945P01, 520021, 526949, 527949, 540611, 540614, 54494, 547949, 550733, 570019, 63001035, 67003883, 67003883A, 68001557, 68001575, 68123-1, 68123-2, 7-1159, 7-66096, 7-70121, 7-70852, 7-71133, 7-7319, 7-90064, 701159, 707319, 72001067, 7407P002-60, 7407P026-60, 7407P091-60, 7407P095-60, 7407P103-60, 7407P114-60, 766096, 770121, 770852, 771133, 786571, 786742, 790064, 8009, 816389, 816641, 8171221, 8208190, 837, 865000, 878122, 878937, 879350, 880010, 88008545, 8935, 93-0B-00300-19, 93-0B-00300-199, 976110, 98004498, A0282801, A0282803, A0282803A, A0282803Q, A0282806, A0282810, A0282812, A2828-3, A282803, JA99707319, M9D1, M9D37, M9D49, M9D51, R0130419, R0130884, R0157675, R0157818, R0165001, R0165007, R0712010, R0762002, R0762003, R0950124, STD398091, W10126566, W10132113, W10132131, W10346855, WB8T10022, Y0020478, Y0020571, Y0042175, Y0047146, Y0053950, Y0056713, Y0057030, Y0057035, Y0088673, Y0089290, Y03055001, Y0311700, Y04067202, Y05600070, Y0B00300199, Y0B00300299, Y0B00300399, Y0L01500199, Y701159, Y707319 Show less Back to Top",

"review_count": "66",

"appliance": "refrigerator",

"compatible_models": [

"102000",

"102001",

"102002",

"1035",

"1037",

"1058AF-CW",

"1058AF-CZ",

"1058AH-W",

```
"1058AH-Z",
"1058WF-CW",
"1058WF-CZ",
"1058WH-W",
"106106-8130600",
"106106-8130610",
"106106-8130620",
"106106-8130630",
"106106-8130640",
"106106-8130650",
"106106-8130660",
"106106-8130680",
"106106-8130690",
"1061068130670",
"10631400200",
"10631402200",
"10631404200",
"10631409200",
"10631410200",
"10631412200",
"10631414200",
"10631419200"
]
},
{
  "part_name": "Refrigerator Water Filter 11034152",
```


"part_number": "PS16556076",

"manufacturer": null,

"price": "68.72",

"description": "This genuine Bosch water filter is used to help reduce contaminants in the water supply including chlorine and lead. The water filter measures approximately 2 inches in diameter and is 9 inches long. It is recommended by the manufacturer to replace the water filter every 6 months for best performance.",

"rating": "60",

"troubleshooting_tips": "This part works with the following products: Freezer, Refrigerator. Part# 11034152 replaces these: 00499850, 00641425, 00644845, 00649379, 00713913, 00740560, 00740570, 00740574, 00741509, 11028820, 11028821, 11034151, 17005585, 499850, 641425, 644845, 649379, 713913, 740560, 740570 ... Show more , 740574, 741509 Show less Back to Top",

"review_count": "1",

"appliance": "refrigerator",

"compatible_models": [

"00740570",

"11028820",

"B18ID80NLP",

"B18ID80NRP",

"B18IF70NSP",

"B18IF800SP",

"B22CS30SNI",

"B22CS30SNS",

"B22CS30SNS-01",

"B22CS50SNB",

"B22CS50SNB01",

"B22CS50SNS",

```
"B22CS50SNS/01",
"B22CS50SNW",
"B22CS50SNW01",
"B22CS80SNS",
"B22CS80SNS-01",
"B22CS80SNS-02",
"B22CS80SNS-03",
"B24ID80NLP",
"B24ID80NRP",
"B24IF70NSP",
"B26FT50SNS",
"B26FT70SNS",
"B26FT70SNS-01",
"B26FT80SNS",
"B30BB830SS",
"B30IF70NSP",
"B36BT830NS",
"B36ET71SN"
]
},
{
  "part_name": "Evaporator Fan Blade WP2169142",
  "part_number": "PS11738973",
  "manufacturer": "Kenmore",
  "price": "37.10",
```

"description": "If your refrigerator or freezer is too warm, or making noises, you may need to replace the fan blade. The fan blade attaches to the evaporator motor, which is in the freezer section, to help circulate the cold air into the refrigerator and freezer sections. The fan blade is white in color and made from plastic. This is a genuine OEM part. Please be sure to disconnect the power to your refrigerator before starting your repair.",

"rating": "60",

"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Fridge too warm
This part works with the following products: Refrigerator, Freezer. Part# WP2169142
replaces these: AP6005911, 12217201, 2154800, 2169142, 2208959, 2208968,
2223733, 2223986, 67005684, 8170544, 8201663, 8208312, Y67005684 Back to Top",

"review_count": "4",

"appliance": "refrigerator",

"compatible_models": [

"10640212010",

"10640212011",

"10640262010",

"10640263010",

"10640263011",

"10640269010",

"10640562010",

"10640563010",

"10640563011",

"10640569010",

"10640569011",

"10641012100",

"10641012101",

"10641012104",

"10641014100",

```
"10641014101",
"10641014104",
"10641122210",
"10641122211",
"10641122212",
"10641122213",
"10641123210",
"10641123211",
"10641123212",
"10641124210",
"10641129210",
"10641129211",
"10641129212",
"10641129213",
"10641132710"
]
},
{
  "part_name": "Pivot Block WP67003405",
  "part_number": "PS11743531",
  "manufacturer": "Kenmore",
  "price": "11.09",
  "description": "This is a replacement pivot block for your refrigerator. It is made of white plastic and is approximately 4 inches long and 1 inch wide. The pivot block catches and holds the door mullion cover when you close the door. If your refrigerator door will not close properly, you may need to replace the pivot block. This part is sold individually and is an OEM part sourced directly from the manufacturer."
```

"rating": "99",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# WP67003405 replaces these: AP6010352, 12698403, 67003194, 67003405, 8208254 Back to Top",

"review_count": "14",

"appliance": "refrigerator",

"compatible_models": [

"10672002011",

"10672002013",

"10672002015",

"10672003010",

"10672003011",

"10672003012",

"10672003013",

"10672003014",

"10672003016",

"10672003017",

"10672003018",

"10672009010",

"10672009011",

"10672009013",

"10672009015",

"10672013017",

"10678586800",

"596379243017",

"59672002013",

"59672002015",

"59672003012",

"59672003013",

"59672003014",

"59672003016",

"59672003017",

"59672003018",

"59672009013",

"59672009015",

"59672012014",

"59672012016"

]

},

{

"part_name": "Pantry End Cap - Left Side WP12656105",

"part_number": "PS11738573",

"manufacturer": null,

"price": "38.39",

"description": "The pantry end cap is also known as a drawer support or a door shelf trim. This specific piece is sold individually and is meant for the left side of your refrigerator. It snaps into place on the door of your fridge, which allows it to hold items on the door shelf. To change the left side end cap on your refrigerator you will need a 1/4 inch nut driver. Users have ranked this installation as easy to do, with a less than thirty minute repair time.",

"rating": "99",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# WP12656105 replaces these: AP6005524, 12656103, 12656105, 67002326, 67005862, 8171058 Back to Top",

"review_count": "88",

"appliance": "refrigerator",

"compatible_models": [

"5GFB2058EA00",

"5GFC20PRAA00",

"5GFC20PRAW00",

"5GFC20PRYA0",

"5GFC20PRYW0",

"5GX0FHTXAF01",

"5KBFS20EAX01",

"5KRFX9000M00",

"6GX0FHDXXY0",

"6GX0FHDXXY1",

"6GX0FHDXXY2",

"AB2026LEKS",

"AB2026LEKS0",

"AB2026PEKB",

"AB2026PEKW",

"AB2026REKS",

"AB2026REKS0",

"ABC2037DEB",

"ABC2037DEB14",

"ABC2037DEQ",

"ABC2037DES",

"ABC2037DEW",

"ABC2037DEW14",

"ABC2037DPS",

"ABC2037DTB",

```
"ABC2037DTS",
"ABC2037DTS14",
"ABC2037DTW",
"ABL2037FES",
"ABL2037FES0"
]
},
{
  "part_name": "Refrigerator Door Gasket - White W10830189",
  "part_number": "PS11759516",
  "manufacturer": "Kenmore",
  "price": "158.94",
  "description": "The door gasket is used to make an air-tight seal for the cabinet when the
door is closed.",
  "rating": "96",
  "troubleshooting_tips": "This part fixes the following symptoms: Door Sweating | Door
won't open or close | Fridge too warm | Fridge too cold This part works with the following
products: Refrigerator. Part# W10830189 replaces these: AP6027234, 12723206W,
67002715, 67002997, 67003382, 67003546, 8208244, W10137006, W10163894,
W10163894N, W10443221, W10571959 Back to Top",
  "review_count": "22",
  "appliance": "refrigerator",
  "compatible_models": [
    "10672002010",
    "10672002011",
    "10672002013",
    "10672002015",
```


"10672003010",
"10672009010",
"10672009011",
"10672009013",
"10672009015",
"10672012010",
"10672013010",
"10672019010",
"10678586800",
"59672002010",
"59672002011",
"59672002013",
"59672002015",
"59672003010",
"59672009010",
"59672009011",
"59672009013",
"59672009015",
"59672012010",
"59672012011",
"59672012012",
"59672012014",
"59672012016",
"59672013010",
"59672013011",
"59672013012"

]

},

{

"part_name": "Crisper Drawer WP67002659",

"part_number": "PS11743502",

"manufacturer": null,

"price": "103.35",

"description": "The crisper drawer in your refrigerator is used for storing various items. If you notice that your current crisper drawer is damaged, you may need to replace it. You may notice that your refrigerator door does not open or close properly, which is a sign that your crisper drawer is damaged. This crisper drawer is made of clear plastic and is roughly 20 inches in length. This part is sold individually and does not come with the plastic faceplate on it. If your current crisper has one, you will need to remove it and transfer it to the new crisper. NOTE: As per the manufacture the crisper drawer has been updated from the original. A new crisper cover may need to be purchased for the drawers to work. Factory dimensions - 12.847\" Depth X 15.217\" Width X 6.93 High.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# WP67002659 replaces these: AP6010323, 12531105, 12531105SP, 12724110, 67002243, 67002659, 67004823, 8171053, 8171207 Back to Top",

"review_count": "83",

"appliance": "refrigerator",

"compatible_models": [

"59666942401",

"59666944400",

"59666944401",

"59666992400",

"59666992401",

"59667942600",
"59667949600",
"59667992600",
"59667993600",
"5GFB2058EA00",
"5GFC20PRAA00",
"5GFC20PRAW00",
"5GFC20PRYA0",
"5GFC20PRYW0",
"5GX0FHTXAF01",
"5KBFS20EAX01",
"5KRFX9000M00",
"6GX0FHDXXY0",
"6GX0FHDXXY1",
"6GX0FHDXXY2",
"AB2026LEKS",
"AB2026LEKS0",
"AB2026PEKB",
"AB2026PEKW",
"AB2026REKS",
"AB2026REKS0",
"ABC2037DEB",
"ABC2037DEQ",
"ABC2037DES",
"ABC2037DEW"

]

```
},
```

```
{
```

```
"part_name": "Door Switch W11396033",
```

```
"part_number": "PS12731166",
```

```
"manufacturer": "Kenmore",
```

```
"price": "27.62",
```

```
"description": "This light switch may also be known as a refrigerator door switch or a light switch kit, and is compatible with your refrigerator. The function of the refrigerator door switch is to turn on the light when your fridge door is open, and to make sure it is off when your refrigerator door is closed. The reason you would need to replace this part is if your light is not turning on when your door is open. For this repair, you will need a putty knife, and a small flat-blade screwdriver.",
```

```
"rating": "97",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Light not working | Ice maker not making ice | Not dispensing water | Ice maker won't dispense ice This part works with the following products: Refrigerator. Part# W11396033 replaces these: AP6973145, 12002646, 12466101, 12466103, 12466105, 12466105SP, 12466114, 61003254, 61003661, 61005052, 67005653, 8170842, 8208349, C3680312, W10656771, W10847848, W10847849, WPW10656771 Back to Top",
```

```
"review_count": "35",
```

```
"appliance": "refrigerator",
```

```
"compatible_models": [
```

```
"10641162310",
```

```
"10641163310",
```

```
"10641169310",
```

```
"10650042717",
```

```
"10650043717",
```

```
"10650049717",
```

```
"10651132213",
```

```
"10651133213",  
"10651134213",  
"10651139213",  
"10651142111",  
"10651143111",  
"10651149111",  
"10651149112",  
"10651172310",  
"10651173310",  
"10651179310",  
"10651182112",  
"10651183112",  
"10651189112",  
"10651335713",  
"10651712410",  
"10651712411",  
"10651713410",  
"10651713411",  
"10651719410",  
"10651719411",  
"10651719413",  
"10651752717",  
"10651752718"  
]  
,  
{
```

"part_name": "Refrigerator Pantry Drawer Door Cover W10827015",

"part_number": "PS11723190",

"manufacturer": "Kenmore",

"price": "115.92",

"description": "This pantry drawer lid is also known as a pantry drawer door or pantry drawer cover. This is a genuine OEM part, and is sold individually. This part helps keep everything inside the drawer. It acts as a cover, and also keeps your drawer at the proper temperature by creating a seal. You may need to replace this part if door does not open or close, or if the drawer is too cold. No tools are required for this replacement, simply push the hinge pins aside to remove the old lid. Consider checking the pantry end cap kit for damage before ordering the pantry drawer lid, as they are often purchased together.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close | Fridge too cold This part works with the following products: Refrigerator. Part# W10827015 replaces these: AP5985816, 12656813, 12656814, 12656815, 12656816, 12656818, 67002319, 67002812, 67003170, 67003305, 67003332, 67003333, 67004643, 67004698, 67005899, 67005900, 67005903, 67005910, 67006736, 8171060 ... Show more , 8171122 Show less Back to Top",

"review_count": "77",

"appliance": "refrigerator",

"compatible_models": [

"10672012010",

"10672013010",

"10672013017",

"10672019010",

"10678586800",

"59672012010",

"59672012011",

"59672012014",

"59672012016",
"59672013010",
"59672013011",
"59672013013",
"59672013014",
"59672013015",
"59672013017",
"59672019010",
"59672019011",
"59672019014",
"59672019016",
"59673502200",
"59673502201",
"59673502202",
"59673502203",
"59673502300",
"59673503200",
"59673503201",
"59673503202",
"59673503203",
"59673503300",
"59673504200"

]

},

{

"part_name": "Refrigerator Door Switch W11384469",

"part_number": "PS12728638",

"manufacturer": "Kenmore",

"price": "38.37",

"description": "Door switch turns the light off when you close the door.",

"rating": "92",

"troubleshooting_tips": "This part fixes the following symptoms: Light not working This part works with the following products: Refrigerator, Freezer, Ice Maker. Part# W11384469 replaces these: AP6893312, 0054153, 0086495, 046789-01, 1021, 1107734, 1108055, 1108112, 1118894, 1118895, 12466102, 14001066, 14200201, 14205646, 14210229, 14214567, 1547075, 1549695, 2-32164-001, 2154668 ... Show more , 2321286, 4312314, 4339476, 4343259, 4343930, 4344314, 4344571, 4356873, 4390513, 46000549702, 547075, 548472, 548897, 549695, 549697, 549702, 55732-1, 61003026, 66987-1, 68001061, 68001324, 7050-0058, 8119, 8170294, 989282, 99989727, C36803-4, C3680301, C3680304, C3680307, C3680308, C3680310, C3680310V, C3680314, R0130445, R0130879, R0213159, R9800565, W10656773, W10847853, W11123941, W11234536, W11428639, WP1118894, WPC3680310, WPW10656773, Y0054153, Y0086495, Y04678901 Show less Back to Top",

"review_count": "85",

"appliance": "refrigerator",

"compatible_models": [

"103200",

"103210",

"106106-8130600",

"106106-8130610",

"106106-8130620",

"106106-8130630",

"106106-8130640",

"106106-8130650",

"106106-8130660",


```
"106106-8130680",
"106106-8130690",
"1061068130670",
"10631400200",
"10631402200",
"10631404200",
"10631409200",
"10631410200",
"10631412200",
"10631414200",
"10631419200",
"10632242101",
"10632243101",
"10632249101",
"10632842010",
"10632852010",
"10632852011",
"10632853010",
"10632853011",
"10632862010",
"10632862011"
]
},
{
  "part_name": "Refrigerator Water Filter EDR4RXD1",
  "part_number": "PS11722130",
```

"manufacturer": null,

"price": "103.87",

"description": "This water filter (Whirlpool EveryDrop Refrigerator Water Filter, Single Turn Filter) purifies water going to the water dispenser and sometimes the icemaker as well. This part should be replaced if it is causing reduced water flow or just replaced periodically per the owner manual. Replacing this water filter may fix a noisy or leaking fridge, a fridge that is not dispensing water (or reduced flow rate), and an ice maker that is not making ice at all, or not making enough ice. This filter is white, sold individually and measures 8 inches by 3 inches in diameter. This water filter has been updated by the manufacturer. It may appear different but will still function the same. It is sold individually.",

"rating": "93",

"troubleshooting_tips": "This part fixes the following symptoms: Not dispensing water | Ice maker not making ice | Leaking | Ice maker dispenses too little ice This part works with the following products: Refrigerator. Part# EDR4RXD1 replaces these: AP5983564, 12589201, 12589203, 12589206, 12589208, 12589210, 13040201, 13040210, 13040214, 13040216, 13040216N, 13040218, 4396395, 67002269, 67002671, 67003523, 67003523A, 67003526, 67003591, 67003640 ... Show more , 67003727, 67006464, 67006467, 67006468, 67006469, 67006470, 67006470A, 67006474, 67006475, 67006476, 67006477, 67006633, 67006634, 67006637, 8171032, 8171249, 9006, 9984, 9992, EVFILTER4, FILTER4, UKF8001, UKF8001AXX, UKF9001, UKF9001AXX, W10181835, W10336197, W10336197N, W10735404, W11256384, WF-50, WF50, WF50-NI300, WF50-NI500 Show less Back to Top",

"review_count": "94",

"appliance": "refrigerator",

"compatible_models": [

"10672002011",

"10672002013",

"10672002015",

"10672003010",

"10672003011",

"10672003012",

```
"10672003013",  
"10672003014",  
"10672003016",  
"10672003017",  
"10672003018",  
"10672009010",  
"10672009011",  
"10672009013",  
"10672009015",  
"10672013017",  
"4609005000",  
"4609006000",  
"4609084",  
"469005",  
"469005750",  
"469006",  
"469006200",  
"469006750",  
"469084",  
"469992",  
"469992100",  
"596379243017",  
"59650002100",  
"59650003100"  
]  
},
```

```
{
  "part_name": "Timer WP8535369",
  "part_number": "PS11746201",
  "manufacturer": "Kenmore",
  "price": "337.49",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WP8535369 replaces these: AP6012980, 3379501, 8535369 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "110773811",
    "110773812",
    "110773813",
    "110773881",
    "110773882",
    "110773883",
    "66515641891",
    "66515645891",
    "66515662990",
    "66515662992",
    "66515662993",
    "66515669990",
    "66515669992",
    "66515669993",
```

"66515701890",
"66515701891",
"66515701892",
"66515702990",
"66515705890",
"66515705891",
"66515705892",
"66515707990",
"66515708890",
"66515708891",
"66515708892",
"66515709990",
"66515751790",
"66515751791",
"66515755790",
"66515755791"

]

},

{

"part_name": "Timer WP8535368",

"part_number": "PS11746200",

"manufacturer": null,

"price": "278.53",

"description": "The purpose of a dishwasher timer is to control the unit's cycles by regulating the length of time that power is directed to each component.",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WP8535368 replaces these: 3376032, 8535368 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"DU850DWGB0",

"DU850DWGB1",

"DU850DWGB2",

"DU850DWGQ0",

"DU850DWGQ1",

"DU850DWGQ2",

"DU850DWGT2",

"DU850DWGX0",

"DU850DWGX1",

"DU850DWGX2",

"DU850SWKB0",

"DU850SWKQ0",

"DU850SWKT0",

"DU850SWLB0",

"DU850SWLQ0",

"DU850SWPB0",

"DU850SWPB1",

"DU850SWPB2",

"DU850SWPQ0",

"DU850SWPQ1",

"DU850SWPQ2",

```
"DU850SWPS0",
"DU850SWPS1",
"DU850SWPS2",
"DU850SWPT1",
"DU850SWPT2",
"DU850SWPU0",
"DU850SWPU1",
"DU850SWPU2",
"DU851SWPS0"
]
},
{
  "part_name": "TIMER WD21X10473",
  "part_number": "PS8756302",
  "manufacturer": null,
  "price": "23.30",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Back  
to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "ADW1100N35BB",
    "ADW1100N35WW",
    "GSD1300N35WW",
```

```
"HDA1100F00WH",
"HDA1100N35WH"
]
},
{
  "part_name": "Timer WPW10199588",
  "part_number": "PS11750162",
  "manufacturer": null,
  "price": "252.89",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#
WPW10199588 replaces these: W10039490, W10199588 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "ADB1000AWB1",
    "ADB1000AWD1",
    "ADB1000AWQ1",
    "ADB1000AWS1",
    "ADB1000AWW0",
    "ADB1000AWW1",
    "CDB4000AWB0",
    "CDB4000AWW0",
    "CDB4000WQ0",
    "CDB4000WU0",
```


"CDB4000XB0",
"CDB4000XQ0",
"CUD4000WQ0",
"CUD4000WQ1",
"CUD4000WU0",
"CUD4000WU1",
"DU400SWWW0",
"DU400SWWW1",
"DU810SWPQ3",
"DU810SWPQ4",
"DU810SWPT3",
"DU810SWPT4",
"DU810SWPU3",
"DU810SWPU4",
"DU811SWPQ3",
"DU811SWPQ4",
"DU811SWPU3",
"DU811SWPU4",
"IPC25054",
"IUD4000RQ3"

]

},

{

"part_name": "Timer WD21X10013",
"part_number": "PS260070",
"manufacturer": "Kenmore",

"price": "154.76",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WD21X10013 replaces these: AP2039699, 271324, 65893, WD21X10104 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"36314061790",

"36314061791",

"36314071790",

"36314071791",

"36314071792",

"36314071793",

"36314071794",

"36314072790",

"36314072791",

"36314072792",

"36314072793",

"36314072794",

"36314072795",

"36314074790",

"36314074791",

"36314074792",

"36314074793",

"36314074794",

"36314075790",
"36314075791",
"36314075792",
"36314075793",
"36314075794",
"36314081990",
"36314081991",
"36314081992",
"36314081993",
"36314081994",
"36314171790",
"36314171791"

]

},

{

"part_name": "FOOT 00617586",

"part_number": "PS8728142",

"manufacturer": "Kenmore",

"price": "16.25",

"description": "",

"rating": "20",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 00617586 replaces these: AP4483219, 00614052, 00616864, 00621472, 614052, 616864, 617586, 621472 Back to Top",

"review_count": "1",

"appliance": "dishwasher",

"compatible_models": [

"63013902010",
"63013902011",
"63013903010",
"63013903011",
"63013909010",
"63013909011",
"63013909012",
"63013912010",
"63013912011",
"63013913010",
"63013913011",
"63013919010",
"63013919011",
"63013919012",
"S36KMK12UC",
"S36KMK12UC-05",
"S36KMK15UC",
"S36KMK15UC-05",
"S36KMK16UC",
"S36KMK16UC-05",
"S46KMK12UC",
"S46KMK12UC-05",
"S46KMK15UC",
"S46KMK15UC-05",
"S46KMK16UC",
"S46KMK16UC-05",

```
"SHE3AR52UC",
"SHE3AR52UC/06",
"SHE3AR52UC/07",
"SHE3AR55UC"
]
},
{
  "part_name": "Leveling Leg WD2X320",
  "part_number": "PS261477",
  "manufacturer": "Kenmore",
  "price": "8.06",
  "description": "This leveling leg is located under the dishwasher cabinet. It is sold individually.",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WD2X320 replaces these: AP2038545, 271202, WD02X10059 Back to Top",
  "review_count": "1",
  "appliance": "dishwasher",
  "compatible_models": [
    "1858",
    "18585",
    "361402891",
    "36314031000",
    "36314031001",
    "36314032000",
    "36314032001",
    "36314038000",
```

```
"36314038001",
"36314039000",
"36314039001",
"36314071792",
"36314071793",
"36314071794",
"36314072793",
"36314072794",
"36314072795",
"36314074792",
"36314074793",
"36314074794",
"36314075792",
"36314075793",
"36314075794",
"36314081991",
"36314081992",
"36314081993",
"36314081994",
"36314151000",
"36314152000",
"36314158000"
]
},
{
  "part_name": "Control Panel - Black WD34X11829",
```

```
"part_number": "PS8756578",
"manufacturer": null,
"price": "45.53",
"description": "This part is a control panel assembly for your dishwasher. Its job is to
allow you to choose the function that your dishwasher performs on any given cycle. Control
panel only. Control board and buttons are NOT included.",
"rating": "20",
"troubleshooting_tips": "This part works with the following products: Dishwasher. Part#
WD34X11829 replaces these: AP5793231 Back to Top",
"review_count": "2",
"appliance": "dishwasher",
"compatible_models": [
"GDT530PSD0SS",
"GDT530PSD1SS",
"GDT530PSD2SS",
"GDT530PSD4SS",
"GDT530PSD6SS"
]
},
{
"part_name": "PANEL-FACIA 00683961",
"part_number": "PS8734598",
"manufacturer": null,
"price": "149.39",
"description": "",
"rating": null,
```

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure This part works with the following products: Dishwasher. Part# 00683961 replaces these: AP4483920, 683961 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"SHE55P05UC",

"SHE55P05UC-53"

]

},

{

"part_name": "Exterior Control Panel - Black 00665888",

"part_number": "PS8732687",

"manufacturer": null,

"price": "131.08",

"description": "",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 00665888 replaces these: AP4300437, 665888 Back to Top",

"review_count": "5",

"appliance": "dishwasher",

"compatible_models": [

"SHE55M06UC",

"SHE55M06UC-48",

"SHE55M16UC",

"SHE55M16UC-59"

]


```
},  
  
{  
  "part_name": "PANEL-FACIA 00478808",  
  "part_number": "PS8717584",  
  "manufacturer": null,  
  "price": "154.59",  
  "description": "",  
  "rating": null,  
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#  
00478808 replaces these: AP4300286, 478808 Back to Top",  
  "review_count": null,  
  "appliance": "dishwasher",  
  "compatible_models": [  
    "SHE43M05UC",  
    "SHE43M05UC/43",  
    "SHE43M05UC/46",  
    "SHE43M05UC/47",  
    "SHE43M05UC/48",  
    "SHE43M05UC/50",  
    "SHE43M05UC/52",  
    "SHE43M05UC/53"  
  ]  
},  
  
{  
  "part_name": "Black Access Panel W10827631",  
  "part_number": "PS11727780",
```

"manufacturer": "Kenmore",

"price": "91.37",

"description": "",

"rating": "56",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# W10827631 replaces these: W10369023, W10369024, W10369027, W10799402, WPW10369023, WPW10369024, WPW10369027 Back to Top",

"review_count": "5",

"appliance": "dishwasher",

"compatible_models": [

"2212413N414",

"2213092N413",

"2213099N413",

"2214545N711",

"66512413N413",

"66513092N413",

"66513093N413",

"66513202N412",

"66513202N413",

"66513203N412",

"66513203N413",

"66513204N412",

"66513204N413",

"66513209N412",

"66513209N413",

"66513492N411",

"66513493N411",

"66513499N411",

"66514502N020",

"66514503N020",

"66514509N020",

"66514542N710",

"66514543N711",

"66514545N710",

"66514545N711",

"66514549N710",

"66514549N711",

"66514552N610",

"66514553N610",

"66514559N610"

]

},

{

"part_name": "PANEL-BASE 00668687",

"part_number": "PS8733028",

"manufacturer": "Kenmore",

"price": "56.40",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 00668687 replaces these: AP4355234, 00448741, 00709955, 448741, 668687, 709955
Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"63013902010",

"63013902011",

"63013903010",

"63013903011",

"63013909010",

"63013909011",

"63013912010",

"63013912011",

"63013913010",

"63013913011",

"63013919010",

"63013919011",

"63013919012",

"63013952010",

"63013952011",

"63013953010",

"63013953011",

"63013959010",

"63013959011",

"63016302402",

"63016302403",

"63016302404",

"63016302405",

"63016302406",

"63016303402",

```
"63016303403",
"63016303404",
"63016303405",
"63016303406",
"63016304401"
]
},
{
  "part_name": "Dishwasher Detergent Dispenser W11032769",
  "part_number": "PS11773088",
  "manufacturer": null,
  "price": "140.94",
  "description": "",
  "rating": "82",
  "troubleshooting_tips": "This part fixes the following symptoms: Will not dispense detergent | Leaking | Door latch failure | Not cleaning dishes properly This part works with the following products: Dishwasher, Washer Dryer Combo. Part# W11032769 replaces these: AP6039090, W10304407, W10304408, W10304410, W10409521, W10629971, W10723269, W10901088, WPW10304407, WPW10304408, WPW10304410, WPW10409521, WPW10629971, WPW10723269 Back to Top",
  "review_count": "13",
  "appliance": "dishwasher",
  "compatible_models": [
    "7WDT790SAYM0",
    "7WDT790SAYM2",
    "7WDT790SAYM3",
    "7WDT950SAYM0",
```

"7WDT950SAYM1",
"7WDT950SAYM2",
"7WDT950SAYM3",
"ADB1700ADB1",
"ADB1700ADS1",
"ADB1700ADW1",
"BLB14BRANA0",
"IDT870SAGX0",
"IDT930SAGX0",
"IUD7500BS0",
"IUD7500BS1",
"IUD7500BS2",
"IUD7555DS0",
"IUD7555DS1",
"IUD8010DS0",
"IUD8010DS1",
"IUD8500BX0",
"IUD8500BX1",
"IUD8555DX0",
"IUD8555DX1",
"IUD8555DX2",
"IUD8555DX3",
"IUD8555DX4",
"JDB8000AWB0",
"JDB8000AWB1",
"JDB8000AWB2"

```
]
},
{
  "part_name": "Detergent Cup Shaft and Lever WD16X313",
  "part_number": "PS259474",
  "manufacturer": "Kenmore",
  "price": "22.15",
  "description": "Cover is not included. Must order cover separately.",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Will not dispense  
detergent | Door latch failure | Not cleaning dishes properly This part works with the  
following products: Dishwasher. Part# WD16X313 replaces these: AP2039379, 2330,  
WD16X0302, WD16X0313, WD16X302 Back to Top",
  "review_count": "2",
  "appliance": "dishwasher",
  "compatible_models": [
    "1200L02",
    "18385",
    "1858",
    "3000B10",
    "3000W10",
    "361402891",
    "3631401190",
    "3631401191",
    "3631401590",
    "3631401591",
    "3631401592",
```

"3631401890",
"3631401891",
"3631401892",
"3631402190",
"3631402191",
"3631402192",
"3631402590",
"3631402591",
"3631402592",
"3631402890",
"3631402891",
"3631402892",
"36314031000",
"36314031001",
"36314032000",
"36314032001",
"36314038000",
"36314038001",
"36314039000"

]

},

{

"part_name": "Detergent Cup Cover WD16X297",
"part_number": "PS259460",
"manufacturer": "Kenmore",
"price": "8.54",

"description": "",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Will not dispense detergent | Door latch failure | Leaking | Door won't close This part works with the following products: Dishwasher. Part# WD16X297 replaces these: AP2039368, 270966, WD12X24237, WD16M0025, WD16M0029, WD16M25, WD16M29, WD16X0297 Back to Top",

"review_count": "1",

"appliance": "dishwasher",

"compatible_models": [

"1200L02",

"18385",

"1858",

"3000B10",

"3000W10",

"361402891",

"3631401190",

"3631401191",

"3631401590",

"3631401591",

"3631401592",

"3631401890",

"3631401891",

"3631401892",

"3631402190",

"3631402191",

"3631402192",

```
"3631402590",  
"3631402591",  
"3631402592",  
"3631402890",  
"3631402891",  
"3631402892",  
"36314031000",  
"36314031001",  
"36314032000",  
"36314032001",  
"36314038000",  
"36314038001",  
"36314039000"  
]
```

```
},
```

```
{
```

```
"part_name": "Detergent and Rinse Dispenser with Cap 154574401",
```

```
"part_number": "PS1524979",
```

```
"manufacturer": "Kenmore",
```

```
"price": "64.74",
```

```
"description": "This detergent and rinse dispenser with cap may also be known as the  
dishwasher dispenser assembly and is a part for your dishwasher. The function of this part  
is to attach to the inside door panel of your dishwasher and hold the dishwasher detergent  
and rinse in a closed compartment. The manufacturer has redesigned this part and  
although it may appear different than the original, it will have the same functionality, which  
is to release the detergent and rinse aid into the dishwasher. To complete this installation,  
you will need a Phillips screwdriver, and a pair of needle-nose pliers.",
```

```
"rating": "99",
```

"troubleshooting_tips": "This part fixes the following symptoms: Will not dispense detergent | Door latch failure | Not cleaning dishes properly | Door won't close This part works with the following products: Dishwasher. Part# 154574401 replaces these: AP3958766, 1196189, 154574401, 154230101, 154230103, 154230105, 154542101 Back to Top",

"review_count": "11",

"appliance": "dishwasher",

"compatible_models": [

"58714000100",

"58714000101",

"58714000102",

"58714001990",

"58714001991",

"58714001992",

"58714001993",

"58714002990",

"58714002991",

"58714002992",

"58714002993",

"58714003100",

"58714008001",

"58714008002",

"58714008003",

"58714009100",

"58714009101",

"58714009102",

"58714012400",

```
"58714012401",
"58714012402",
"58714012403",
"58714012404",
"58714012405",
"58714012406A",
"58714012407A",
"58714012408A",
"58714013400",
"58714013401",
"58714013402"
]
},
{
  "part_name": "Detergent Dispenser with Rinse Cap WD12X10163",
  "part_number": "PS958966",
  "manufacturer": null,
  "price": "83.92",
  "description": "This detergent dispenser assembly is attached to the inner door panel of a dishwasher. This part holds detergent and dishwasher rinse products in a covered container. If your dispenser will not open, close, dispense detergent properly, or the dishes are coming out of the dishwasher dirty, replacing this part can solve these problems. The tools needed for this installation project are a #2 Phillips screwdriver and needle-nose pliers. To repair, first remove screws from the bottom of the inner door panel. Next, remove connectors, wires, and screws from the dispenser to access it and replace with new dispenser. Refer to the manual provided by the manufacturer for further installation instructions and guidance. Unplug dishwasher from power source as a safety precaution.",
  "rating": "99",
```

"troubleshooting_tips": "This part fixes the following symptoms: Will not dispense detergent | Door latch failure | Not cleaning dishes properly | Door won't close This part works with the following products: Dishwasher. Part# WD12X10163 replaces these: AP3767572, 1055139, WD12X10046, WD12X10112, WD12X10162, WD12X10196, WD12X10205, WD12X10207, WD12X10237, WD12X10239, WD12X10240, WD12X10241 Back to Top",

"review_count": "26",

"appliance": "dishwasher",

"compatible_models": [

"40201-0",

"402011",

"40205-0",

"402051",

"40206-0",

"402061",

"402070",

"403110",

"403111",

"405010",

"405011",

"405012",

"405050",

"405051",

"405052",

"405060",

"405061",

"405062",

```
"4070100",
"4070110",
"4070500",
"4070510",
"4070600",
"4070610",
"4070800",
"4070810",
"4071100",
"4071110",
"4071120",
"4071500"
]
},
{
  "part_name": "DISPENSER 12008380",
  "part_number": "PS11724987",
  "manufacturer": null,
  "price": "63.49",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Will not dispense detergent | Leaking This part works with the following products: Dishwasher. Back to Top",
  "review_count": "1",
  "appliance": "dishwasher",
  "compatible_models": [
```

"DWHD440MFP",
"DWHD640JFP",
"SGE53U52UC",
"SGE53U55UC",
"SGE53U56UC",
"SGV68U53UC",
"SGX68U55UC",
"SGX68U55UC-D5",
"SHE3AR72UC",
"SHE3AR75UC",
"SHE3AR76UC",
"SHE3ARF2UC",
"SHE3ARF5UC",
"SHE3ARF6UC",
"SHE53T52UC",
"SHE53T55UC",
"SHE53T56UC",
"SHE53TF2UC",
"SHE53TF5UC",
"SHE53TF6UC",
"SHE53TL2UC",
"SHE65T52UC",
"SHE65T55UC",
"SHE65T56UC",
"SHE68T52UC",
"SHE68T55UC",

```
"SHE68T56UC",  
"SHE68TL5UC",  
"SHE7PT52UC",  
"SHE7PT55UC"
```

```
]
```

```
},
```

```
{
```

```
"part_name": "Lower Spray Arm W10837249",
```

```
"part_number": "PS11727921",
```

```
"manufacturer": null,
```

```
"price": "85.61",
```

```
"description": "This lower spray arm is an authentic OEM part that is compatible with dishwashers. It is found at the bottom of the dishwasher where it is attached to a rotating mechanism. When the dishwasher is in operation, water is pumped through the spray arm, which rotates to distribute this water through the dishwasher. This rotation ensures that water reaches all areas of the dishwasher tub for a thorough cleaning. If the spray arm is faulty, you may notice that some of your dishes are still dirty at the end of the cycle or you may hear unusual rattling noises while the dishwasher is running. The spray arm will need to be replaced if it can no longer function properly.",
```

```
"rating": "100",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Not cleaning dishes properly This part works with the following products: Dishwasher. Part# W10837249 replaces these: AP5988717, W10629546, W10838302 Back to Top",
```

```
"review_count": "2",
```

```
"appliance": "dishwasher",
```

```
"compatible_models": [  
  "WDF760SADB0",  
  "WDF760SADB1",  
  "WDF760SADB2",  
]
```


"WDF760SADB3",
"WDF760SADM0",
"WDF760SADM1",
"WDF760SADM2",
"WDF760SADM3",
"WDF760SADT0",
"WDF760SADT1",
"WDF760SADT2",
"WDF760SADT3",
"WDF760SADW0",
"WDF760SADW1",
"WDF760SADW2",
"WDF760SADW3",
"WDF770SAFZ0",
"WDF770SAFZ1",
"WDF770SAFZ2",
"WDT750SAHB0",
"WDT750SAHM0",
"WDT750SAHV0",
"WDT750SAHW0",
"WDT750SAHZ0",
"WDT920SADE0",
"WDT920SADE1",
"WDT920SADE2",
"WDT920SADE3",
"WDT920SADH0",

```
"WDT920SADH1"
]
},
{
  "part_name": "Center Spray Arm 5304506740",
  "part_number": "PS11770527",
  "manufacturer": null,
  "price": "40.16",
  "description": "This is an OEM center spray arm, which works with dishwashers.",
  "rating": "94",
  "troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Leaking This part works with the following products: Dishwasher. Part# 5304506740 replaces these: AP6036364, 5304498136 Back to Top",
  "review_count": "12",
  "appliance": "dishwasher",
  "compatible_models": [
    "004621710A",
    "004621711A",
    "804621670A",
    "804621671A",
    "804655850A",
    "804655851A",
    "CDB350NB10B",
    "CDB350NB3A",
    "CDB350NB4A",
    "CDB350NB5A",
    "CDB350NB6B",
```

```
"CDB350NB7B",
"CDB350NB8B",
"CDB350NB9B",
"CDB350NW10B",
"CDB350NW3A",
"CDB350NW4A",
"CDB350NW5A",
"CDB350NW6B",
"CDB350NW7B",
"CDB350NW8B",
"CDB350NW9B",
"CDB500NB2A",
"CDB500NB3A",
"CDB500NB4A",
"CDB500NB5B",
"CDB500NS2A",
"CDB500NS3A",
"CDB500NS4A",
"CDB500NS5B"
]
},
{
  "part_name": "Lower Spray Arm WPW10491331",
  "part_number": "PS11755592",
  "manufacturer": null,
  "price": "43.25",
```

"description": "This is a lower spray arm for a dishwasher. The lower spray arm allows water to be spread evenly throughout the dishwasher tub with the proper force so dishes come out clean. This spray arm is gray in color and is about 20 inches long. You may need to replace this part if the water is not being distributed.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Leaking | Noisy This part works with the following products: Dishwasher. Part# WPW10491331 replaces these: AP6022259, W10491331 Back to Top",

"review_count": "18",

"appliance": "dishwasher",

"compatible_models": [

"7WDF530PAYM3",

"7WDF530PAYM4",

"7WDF530PAYM5",

"7WDF530PAYM6",

"7WDF530PAYM7",

"7WDT770PAYM3",

"7WDT770PAYM4",

"7WDT770PAYW3",

"7WDT770PAYW4",

"7WDT790SAYM2",

"7WDT790SAYM3",

"7WDT950SAYM1",

"7WDT950SAYM2",

"7WDT950SAYM3",

"ADB1400AGB3",

"ADB1400AGS2",

```
"ADB1400AGS3",  
"ADB1400AGW3",  
"ADB1400AMB0",  
"ADB1400AMS0",  
"ADB1400AMW0",  
"ADB1500ADB1",  
"ADB1500ADB2",  
"ADB1500ADB3",  
"ADB1500ADB4",  
"ADB1500ADS1",  
"ADB1500ADS2",  
"ADB1500ADS3",  
"ADB1500ADS4",  
"ADB1500ADW1"  
]  
,  
{  
  "part_name": "ORBITAL SPRAYER 5304517982",  
  "part_number": "PS12717897",  
  "manufacturer": null,  
  "price": "60.23",
```

```
  "description": "This orbital sprayer is an authentic OEM replacement part that is  
designed to fit with various models of dishwashers. It is blue in color and has a diameter of  
8 inches. The sprayer is located at the bottom of the dishwasher beneath the lower dish  
rack. It is responsible for directing pressurized water and detergent onto dishes during the  
cleaning process. This ensures that the dishes are cleaned thoroughly and evenly. The  
orbital movement of the sprayer helps to maximize cleaning efficiency reaching into hard-
```

to-reach places. Replacing the sprayer is a simple process, simply twist off the faulty sprayer and snap the new one into place.",

"rating": "80",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher. Back to Top",

"review_count": "4",

"appliance": "dishwasher",

"compatible_models": [

"FGID2468UD0A",

"FGID2468UD1A",

"FGID2468UD2A",

"FGID2468UF0A",

"FGID2468UF1A",

"FGID2468UF2A",

"FGIP2468UD0A",

"FGIP2468UD1A",

"FGIP2468UD2A",

"FGIP2468UF0A",

"FGIP2468UF1A",

"FGIP2468UF2A"

]

},

{

"part_name": "Lower Spray Arm 5304506660",

"part_number": "PS11770509",

"manufacturer": null,

"price": "52.79",

"description": "This spray arm is for dishwashers.\r\n\r\nThe spray arm rotates and sprays water to clean the dishes inside the dishwasher tub.\r\n\r\nWear work gloves to protect your hands during this repair.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Leaking This part works with the following products: Dishwasher. Part# 5304506660 replaces these: AP6038456, 154830302, 154830303, 5304496886, 5304496936, 5304506532, 5304507040 Back to Top",

"review_count": "18",

"appliance": "dishwasher",

"compatible_models": [

"CDBEH960TD0A",

"CDBEH960TS0A",

"DGBD2438PF0A",

"DGBD2438PF1A",

"DGBD2438PF3A",

"DGBD2438PF4A",

"DGBD2438PF5A",

"DGBD2438PF6A",

"DGBD2438PF7A",

"DGBD2438PF8B",

"DGCD2444SA0A",

"DGCD2444SA1A",

"DGCD2444SA2A",

"DGCD2444SD0A",

"FFID2426TB0A",

"FFID2426TB1A",

"FFID2426TB2A",

"FFID2426TB3A",

"FFID2426TD0A",

"FFID2426TD1A",

"FFID2426TD2A",

"FFID2426TD3A",

"FFID2426TD4A",

"FFID2426TD5A",

"FFID2426TS0A",

"FFID2426TS1A",

"FFID2426TS2A",

"FFID2426TS3A",

"FFID2426TS4A",

"FFID2426TS5A"

]

},

{

"part_name": "Lower Spray Arm 5304507158",

"part_number": "PS11770610",

"manufacturer": null,

"price": "56.68",

"description": "The spray arm rotates and sprays water to clean the dishes inside the dishwasher tub.\r\n\r\nThis part works with the following brands: Frigidaire, White Westinghouse, Kelvinator, Gibson, Kenmore, Sears, Tappan, & Electrolux.\r\n\r\nPossible Repair Solution For:\r\n\r\nNot cleaning properly, unusual noises, leaking water.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Leaking This part works with the following products: Dishwasher. Part# 5304507158 replaces these: AP6036393, 154821902, 154821903, 5304496935, 5304498139, 5304507159 Back to Top",

"review_count": "29",

"appliance": "dishwasher",

"compatible_models": [

"004621710A",

"004621711A",

"804655850A",

"804655851A",

"FGHD2465NB0A",

"FGHD2465NB1A",

"FGHD2465NB2A",

"FGHD2465NF0A",

"FGHD2465NF1A",

"FGHD2465NF2A",

"FGHD2465NW0A",

"FGHD2465NW1A",

"FGHD2465NW2A",

"FGID2466QB0A",

"FGID2466QB1A",

"FGID2466QB2A",

"FGID2466QB3A",

"FGID2466QB4A",

"FGID2466QB5A",

"FGID2466QB6A",

"FGID2466QB7A",
"FGID2466QD0A",
"FGID2466QD1A",
"FGID2466QD2A",
"FGID2466QF0A",
"FGID2466QF1A",
"FGID2466QF2A",
"FGID2466QF3A",
"FGID2466QF4A",
"FGID2466QF5A"

]

},

{

"part_name": "Lower Spray Arm Support 5304518968",

"part_number": "PS12712289",

"manufacturer": "Kenmore",

"price": "11.26",

"description": "This lower spray arm is a genuine OEM part for various makes and models of dishwasher and is sold as an individual part. This part attaches to the lower spray assembly of your dishwasher and the lower spray arm itself clips into this part to facilitate its spinning movement during the washing cycle. To replace it, remove the spray arm by pulling it out, remove the surrounding circular clip and then twist to remove this bit. Made completely of plastic, this part measures approximately 3-inches deep, 2-inches wide, and 3.125-inches tall.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Noisy | Leaking | Not draining This part works with the following products: Dishwasher. Part# 5304518968 replaces these: 154252101, 154292901, 154294101, 154294102, 5304506515 Back to Top",

```
"review_count": "17",  
"appliance": "dishwasher",  
"compatible_models": [  
  "004621710A",  
  "004621711A",  
  "58714022200A",  
  "58714023200A",  
  "58714024200A",  
  "58714028200A",  
  "58714029200A",  
  "58714102800",  
  "58714112400",  
  "58714112401",  
  "58714112402",  
  "58714113400",  
  "58714113401",  
  "58714113402",  
  "58714114400",  
  "58714114401",  
  "58714114402",  
  "58714119400",  
  "58714119401",  
  "58714119402",  
  "58714131100",  
  "58714131101",  
  "58714131102",
```

"58714132100",

"58714132101",

"58714132102",

"58714134100",

"58714134101",

"58714134102",

"58714139100"

]

},

{

"part_name": "Middle Spray Arm Kit 675808",

"part_number": "PS382824",

"manufacturer": "Kenmore",

"price": "27.12",

"description": "This middle spray arm kit includes an upper spray arm, a holder or hanger, water supply tube or delivery tube, split ring seal, and a screw. The function of these parts is to spray water to all levels of the dishwasher so the dishes will come out completely clean. This kit has recently been redesigned. It does not include the upper support or mount, so consider ordering those parts as well if necessary. The spray arm is approximately 18 inches long, and all parts are white in colour. The only tool you will need to complete this repair is a Phillips screw driver.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Leaking | Noisy | Will not fill with water This part works with the following products: Dishwasher. Part# 675808 replaces these: AP3115182, 679719, 675808, 3378147, 3379644, 675808, 675808VP, 9742989, 9742992, 9742995, 9743210 Back to Top",

"review_count": "128",

"appliance": "dishwasher",

"compatible_models": [

"110773811",

"110773812",

"110773813",

"110773881",

"110773882",

"110773883",

"66515701890",

"66515701891",

"66515705890",

"66515705891",

"66515708890",

"66515708891",

"66515772990",

"66515777990",

"66515779990",

"66515791791",

"66515791792",

"66515791793",

"66515795790",

"66515795791",

"66515795792",

"66515795793",

"66515798792",

"66515798793",

"66515801890",

```
"66515801891",  
"66515805890",  
"66515805891",  
"66515808890",  
"66515808891"
```

```
]
```

```
},
```

```
{
```

```
"part_name": "SPRAY ARM 5304518927",
```

```
"part_number": "PS12705424",
```

```
"manufacturer": "Kenmore",
```

```
"price": "41.21",
```

"description": "This lower spray arm assembly is a device in your dishwasher that distributes water and detergent during the washing cycle. Its rotating motion sprays water in multiple directions, ensuring thorough cleaning. Typically, it is attached to a support or hub at the bottom of the dishwasher. When this part is broken, there are noticeable signs to be aware of. You might hear knocking or banging sounds coming from the dishwasher. The spray arm may be wobbly or unable to rotate. If a broken arm assembly is not replaced, your dishes may still have dirt on them even after a wash cycle. Additionally, leftover food residue can result in an unpleasant smell within the dishwasher. To remove the existing arm assembly, simply grasp the center of it and lift it up so that it unsnaps from your dishwasher. Please note that this OEM-sourced part is sold individually.",

```
"rating": "94",
```

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Leaking | Noisy | Not drying dishes properly This part works with the following products: Dishwasher. Part# 5304518927 replaces these: AP6810011, 154335802, 154414201, 154496901, 154496902, 154550002, 154567701, 154567702, 5304507175
Back to Top",

```
"review_count": "71",
```

```
"appliance": "dishwasher",
```

"compatible_models": [

"58714000100",

"58714000101",

"58714000102",

"58714001990",

"58714001991",

"58714001992",

"58714001993",

"58714002990",

"58714002991",

"58714002992",

"58714002993",

"58714003100",

"58714008001",

"58714008002",

"58714008003",

"58714009100",

"58714009101",

"58714009102",

"58714012400",

"58714012407A",

"58714012408A",

"58714012409B",

"58714012410B",

"58714012411B",

"58714012412B",

"58714012413B",

"58714012414B",

"58714012416B",

"58714013400",

"58714013401"

]

},

{

"part_name": "Lower Spray Arm 5304517203",

"part_number": "PS12585623",

"manufacturer": "Kenmore",

"price": "35.34",

"description": "The Lower Spray Arm is used in your dishwasher to spray water and clean your dishes. If broken there will be visible damage or your dishes may no longer be cleaned properly. If your spray arm is broken (due to general wear or high heat), it should be replaced. Your lower spray arm will be located at the bottom of your dishwasher tub. Check your user manual and model number to ensure this model is right for you. This version is plastic and metal and comes in gray/blue. We recommend you wear work gloves to keep your hands safe when installing and disconnect power to the appliance. You will also want to make sure that you turn off the water supply to your dishwasher. From here, you will want to open the dishwasher, pull out the lower rack and set it aside. Remove the lower wash arm. On each side of the bottom of the spray arm, there are small locking tabs that can be pushed aside using a flathead screwdriver. Once released, the spray arm can easily be pulled off the dishwasher. Put the new lower wash arm in place and push it down to lock it in. Ensure it is spinning freely and does not hit the heating element. Return the lower dish rack into place and then close the dishwasher door.",

"rating": "95",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Leaking | Noisy | Not draining This part works with the following products: Dishwasher. Part# 5304517203 replaces these: 154250801, 154250901, 154281101, 154414101, 154414102, 154568001, 154568002, 5304506526 Back to Top",


```
"review_count": "123",  
"appliance": "dishwasher",  
"compatible_models": [  
  "58714022200A",  
  "58714023200A",  
  "58714024200A",  
  "58714028200A",  
  "58714029200A",  
  "58714102800",  
  "58714153400",  
  "58714154400",  
  "58714209200",  
  "58714309200",  
  "58715102800",  
  "58715102801",  
  "58715103800",  
  "58715103801",  
  "58715104800",  
  "58715104801",  
  "58715109800",  
  "58715109801",  
  "58715159400",  
  "58715169400",  
  "58715232901A",  
  "58715233901A",  
  "58715234901A",
```

"58715238901A",

"58715239901A",

"58715252400",

"58715252401",

"58715252402",

"58715253400",

"58715253401"

]

},

{

"part_name": "Grommet WPW10538166",

"part_number": "PS11756098",

"manufacturer": "Kenmore",

"price": "32.42",

"description": "This pump inlet grommet is a genuine OEM replacement part that is compatible with various models of dishwashers. It is made of rubber and has a diameter of approximately 2.5 inches. The grommet is used to create a watertight seal in the area between the inlet hose and the circulation pump. This prevents the dishwasher from leaking, and it also helps to absorb minor shocks and vibrations that occur while the dishwasher is running. It is normal for the grommet to wear down over time or become damaged from exposure to water, heat, and chemicals.",

"rating": "90",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# WPW10538166 replaces these: AP6022761, W10195068, W10538166, W11182008, WPW10538166VP Back to Top",

"review_count": "6",

"appliance": "dishwasher",

"compatible_models": [

"2212413N414",
"2213092N413",
"2213099N413",
"2213222N414",
"2213223N414",
"2213229N414",
"2213479N413",
"2213809N710",
"2214523N611",
"2214545N711",
"2214715N710",
"2214792N512",
"2214793N512",
"2217383N710",
"2217389N710",
"66213032K112",
"66213273K112",
"66512093K210",
"66512413N410",
"66512413N411",
"66512413N412",
"66512413N413",
"66512723K310",
"66512723K311",
"66512762K312",
"66512763K312",

```
"66512763K313",
"66512769K312",
"66512769K313",
"66512772K312"
]
},
{
  "part_name": "Screw WP681249",
  "part_number": "PS11743743",
  "manufacturer": "Kenmore",
  "price": "5.41",
  "description": "Sold individually.",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator,
Dishwasher, Ice Maker, Microwave. Part# WP681249 replaces these: AP6010560, 309965,
312799, 415014-103, 415014-35, 4157319, 4171126, 4176298, 489166, 489276,
621249, 68124-9, 681249, 8170933, 830043, 95106-1 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "1061118553",
    "1061118555",
    "1062155184",
    "10632242101",
    "10632243101",
    "10632249101",
    "10632942101",
```

```
"10632943101",  
"10632949101",  
"10641522500",  
"10641523500",  
"10641524500",  
"10641529500",  
"10642102300",  
"10642102301",  
"10642104300",  
"10642106300",  
"10642106301",  
"1064211173",  
"1064317943",  
"10644022600",  
"10644022601",  
"10644022602",  
"10644022603",  
"10644023600",  
"10644023601",  
"10644023602",  
"10644023603",  
"10644024600",  
"10644029600"  
]  
,  
{
```

"part_name": "Torx Screw WP3368921",

"part_number": "PS11741257",

"manufacturer": "Kenmore",

"price": "6.53",

"description": "7-18 x 3/4-Inch - sold individually.",

"rating": null,

"troubleshooting_tips": "This part fixes the following symptoms: Gas igniter glows | but will not light | Will Not Start This part works with the following products: Range, Dishwasher, Cooktop, Mixer. Part# WP3368921 replaces these: AP6008125, 3368921, 3400701, 7101P685-60, WP3368921VP Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"110723120",

"3KSM6583TER0",

"3KSM6583TGU0",

"3KSM6583TWH0",

"3KSMC895TWH0",

"5KSM6583CBF0",

"5KSM6583CER0",

"5KSM6583CES0",

"5KSM6583CGU0",

"5KSM6583CIC0",

"5KSM6583CWH0",

"5KSM6583PER0",

"5KSM6583PWH0",

"5KSM6583RCU0",

"5KSM6583RPA0",
"5KSM6583ZPA0",
"5KSM6585GAQ0",
"5KSM6585GDR0",
"5KSM6585GOB0",
"5KSM6585GPA0",
"5KSM7580XEBK0",
"5KSM7580XEDR0",
"5KSM7591XBLS0",
"5KSM7591XEOB0",
"5KSM7591XESL0",
"5KSM7990XBLS0",
"5KSM7990XESL0",
"66475272502",
"66475273502",
"66475274502"

]

},

{

"part_name": "Rubber Washer WP717273",

"part_number": "PS11743934",

"manufacturer": "Kenmore",

"price": "7.75",

"description": "The rubber washer is a part which is specific to dishwashers and should not be substituted by a similar part. It works with the heating element to seal the receptacle opening where the heating element is attached. The rubber washer is used to prevent water leaking from your dishwasher during its cycle. Before making any repairs to

your dishwasher make sure that you disconnect the power by finding the breaker for the dishwasher, and turning it off. The tools you will need to complete this repair include an adjustable wrench, and a 1/4 inch nut driver. This specific rubber washer is sold individually.",

"rating": null,

"troubleshooting_tips": "This part fixes the following symptoms: Not drying dishes properly | Leaking | Will Not Start | Not cleaning dishes properly This part works with the following products: Dishwasher. Part# WP717273 replaces these: AP6010750, 680862, 717273 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"110723120",

"110773811",

"110773812",

"110773813",

"110773881",

"110773882",

"110773883",

"66213032K112",

"66213273K112",

"665110739120",

"665110739130",

"665110739140",

"665110739190",

"66512093K210",

"66512782K310",

"66513012K110",

"66513012K111",

"66513012K112",

"66513012K113",

"66513013K110",

"66513013K111",

"66513013K112",

"66513013K113",

"66513014K110",

"66513014K111",

"66513014K112",

"66513014K113",

"66513019K110",

"66513019K111",

"66513019K112"

]

},

{

"part_name": "Retainer Clip - White WPW10503549",

"part_number": "PS11755737",

"manufacturer": "Kenmore",

"price": "7.40",

"description": "This part is used to hold the access panel in place. Sold individually.",

"rating": "74",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WPW10503549 replaces these: AP6022404, 3400836, W10331793, W10503549, WPW10503549VP Back to Top",

"review_count": "13",

"appliance": "dishwasher",

"compatible_models": [

"2213092N413",

"2213099N413",

"2213222N414",

"2213223N414",

"2213229N414",

"2213479N413",

"2213809N710",

"2217383N710",

"2217389N710",

"66213032K112",

"66213033K112",

"66213043K112",

"66213044K112",

"66213049K112",

"66213273K112",

"66213279K112",

"66213282K112",

"66213289K112",

"66213292K112",

"66512762K311",

"66512762K312",

"66512763K311",

"66512763K312",

"66512763K313",

```
"66512769K312",
"66512769K313",
"66512772K311",
"66512772K312",
"66512772K313",
"66512772K314"
]
},
{
  "part_name": "CLIP W10919676",
  "part_number": "PS11770115",
  "manufacturer": "Kenmore",
  "price": "14.03",
  "description": "",
  "rating": "89",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# W10919676 replaces these: AP6037221, W10752617 Back to Top",
  "review_count": "11",
  "appliance": "dishwasher",
  "compatible_models": [
    "2213222N414",
    "2213223N414",
    "2213229N414",
    "2214523N611",
    "2214545N711",
    "2214715N710",
```

"2214792N512",
"2214793N512",
"66512772K314",
"66512773K314",
"66512779K314",
"66512782K313",
"66512783K313",
"66512789K313",
"66512793K313",
"66513222N412",
"66513222N413",
"66513223N412",
"66513223N413",
"66513223N414",
"66513229N412",
"66513229N413",
"66513229N414",
"66513402N412",
"66513402N413",
"66513403N412",
"66513403N413",
"66513409N412",
"66513409N413",
"66513542N412"

]

},

```
{
  "part_name": "Door Handle Fastener WR01X11007",
  "part_number": "PS6447735",
  "manufacturer": null,
  "price": "13.11",
  "description": "This is a door handle fastener to secure the handle to your refrigerator drawer. It is also known as a mounting bolt or screw. It is approximately 1 inch in total length, and is made of metal.",
  "rating": "95",
  "troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator, Range, Dishwasher. Part# WR01X11007 replaces these: AP5668500 Back to Top",
  "review_count": "8",
  "appliance": "dishwasher",
  "compatible_models": [
    "ABE20EGEARBS",
    "ABE20EGEARWS",
    "ABE20EGEBRBS",
    "ABE20EGEBRWS",
    "ABE20EGHBRBS",
    "ABE20EGHBRWS",
    "ABE21DGKARBS",
    "ABE21DGKARWS",
    "C2S900P2M1S1",
    "C2S900P2M2S1",
    "C2S900P3M1D1",
    "C2S900P4M1W2",
```

```
"C2S900P4M2W2",
"C2S950P2M1S1",
"C2S950P2M2S1",
"C2S950P3M1D1",
"C2S950P3M2D1",
"C2S950P4M1W2",
"C2S950P4M2W2",
"C2S986SEL2SS",
"C2S995SEL2SS",
"C2Y366P2M1S1",
"C2Y366P2T1S1",
"C2Y366P3M1D1",
"C2Y366P3T1D1",
"C2Y366P4M1W2",
"C2Y486P2M1S1",
"C2Y486P2T1S1",
"C2Y486P4T1W2",
"CDD420P2T0S1"
]
},
{
  "part_name": "Heating Element Brass Nut 154106202",
  "part_number": "PS1524878",
  "manufacturer": "Kenmore",
  "price": "7.82",
```

"description": "The heating element nut is used to connect the heating element to the dishwasher tub. If water is leaking from underneath your dishwasher, you may need to tighten or replace the heating element nut. Replacing the nut is an easy job, does not require any specialty tools, and should not take you more than 10 minutes. For our step by step guide, click the video below. The brass nut measures 7 inches in length x 1 inch in width x 5 inches in height, and fits most dishwashers. To see if this part is compatible with your dishwasher, check the list of compatible brands below.",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Dishwasher, Air Conditioner. Part# 154106202 replaces these: AP3965251, 1196115, 08014807, 0806834, 154106201, 3018118, 3351029, 40571, 4162518, 5300806834, 5303351029, 8-6834, 80-6834, 8014807, 806834, 89637-1, S000007201, WS7201 Back to Top",

"review_count": "8",

"appliance": "dishwasher",

"compatible_models": [

"004621710A",

"004621711A",

"1031-005A",

"1041-002A",

"1071-003A",

"1081-000A",

"5661558580",

"5871400090",

"5871400091",

"5871400190",

"5871400191",

"58714001990",

"58714001991",

"58714002990",

```
"5871400890",
"5871400891",
"587140091",
"5871400990",
"5871400991",
"58714012407A",
"58714012408A",
"58714012409B",
"58714012410B",
"58714012411B",
"58714012412B",
"58714012413B",
"58714012414B",
"58714012416B",
"58714013401",
"58714013408A"
]
},
{
  "part_name": "Wash Arm Retainer Nut WP9742945",
  "part_number": "PS11747063",
  "manufacturer": "Kenmore",
  "price": "16.71",
  "description": "Use this part to secure the lower spray arm of your dishwasher.",
  "rating": "97",
```


"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Noisy | Leaking | Not draining This part works with the following products: Dishwasher. Part# WP9742945 replaces these: AP6013836, 9742945, WP9742945VP Back to Top",

"review_count": "18",

"appliance": "dishwasher",

"compatible_models": [

"110773811",

"110773812",

"110773813",

"110773881",

"110773882",

"110773883",

"66515701890",

"66515701891",

"66515702990",

"66515705890",

"66515705891",

"66515707990",

"66515708890",

"66515708891",

"66515709990",

"66515722990",

"66515727990",

"66515729990",

"66515772990",

"66515777990",

"66515779990",
"66515791790",
"66515791791",
"66515791792",
"66515791793",
"66515795790",
"66515795791",
"66515795792",
"66515795793",
"66515798790"

]

},

{

"part_name": "Retainer Clip - Black WPW10503548",

"part_number": "PS11755736",

"manufacturer": "Kenmore",

"price": "26.71",

"description": "This part is used to hold the access panel in place. Sold individually.",

"rating": "87",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WPW10503548 replaces these: AP6022403, W10331789, W10503548, WPW10503548VP
Back to Top",

"review_count": "17",

"appliance": "dishwasher",

"compatible_models": [

"2212413N414",

"2213092N413",

"2213099N413",
"2213222N414",
"2213223N414",
"2213229N414",
"2213479N413",
"2214545N711",
"2217383N710",
"2217389N710",
"66213032K112",
"66213033K112",
"66213039K112",
"66213043K112",
"66213044K112",
"66213049K112",
"66213273K112",
"66213279K112",
"66213282K112",
"66213283K112",
"66213289K112",
"66213292K112",
"66512093K210",
"66512413N410",
"66512413N411",
"66512413N412",
"66512413N413",
"66512723K310",

```
"66512723K311",
"66512762K311"
]
},
{
  "part_name": "Heating Element WP99002360",
  "part_number": "PS11747670",
  "manufacturer": null,
  "price": "96.58",
  "description": "This dishwasher heating element is not designed to heat the water that enters it, but is designed to maintain the heat of the water that enters the dishwasher. It is located on the bottom of the dishwasher.",
  "rating": null,
  "troubleshooting_tips": "This part fixes the following symptoms: Not drying dishes properly This part works with the following products: Dishwasher. Part# WP99002360 replaces these: 99002360 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "ADW662EAB",
    "ADW662EAB-PADW662EAB0",
    "ADW662EAC",
    "ADW662EAC-PADW662EAC0",
    "ADW662EAS",
    "ADW662EAW",
    "ADW662EAW-PADW662EAW0",
    "ADW862EAB",
```

```
"ADW862EAC",
"ADW862EAS",
"ADW862EAW",
"CDB3100AWE",
"CDB3100AWT",
"CDB3100AWX",
"CDB6100AWE",
"CDB6100AWN",
"CDB6100AWX",
"CDC450B",
"CDC610B",
"CDU250B",
"CDU250V",
"CDU510B",
"CDU510V",
"CDU600B",
"CDU600V",
"CDU610B",
"CDU610N",
"CDU610V",
"CDU810B",
"CDU810V"
]
},
{
  "part_name": "Delta Frame Surface Unit - 8 Inch 326789",
```

"part_number": "PS340503",

"manufacturer": null,

"price": "91.44",

"description": "This electric range delta frame surface element with looped terminal ends measures eight inches and has five turns. It carries 2600 watts the center medallion is black in color.",

"rating": null,

"troubleshooting_tips": "This part fixes the following symptoms: Element will not heat
This part works with the following products: Range, Cooktop, Dishwasher. Part# 326789
replaces these: AP3095827, 2749, 14211071, 242418, 255300, 255378, 255379, 255636, 255650, 255651, 255652, 255749, 255750, 256805, 256806, 256816, 256817, 256898, 256901, 263091 ... Show more , 263143, 263149, 263316, 263377, 263559, 263568, 263881, 269671, 270393, 270396, 270649, 3177567, 3186568, 325503, 326789, 4170091, 4325661, 4332741, 4350119, 4350124, 4350834, 4350884, 4350947, 4350948, 4351008, 4351213, 4351226, 4351252, 4351289, 4351330, 4355040, 4355482, 6610005, 80326789 Show less Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"2118A30",

"2118A40",

"2118A50",

"2118A60",

"2118A70",

"2118C30",

"2118C40",

"2118C50",

"2118C60",

"2118C70",

```
"2118H30",
"2118H40",
"2118H50",
"2118H60",
"2118H70",
"2118L30",
"2118P40",
"2118P50",
"2118P60",
"2118P70",
"2118T40",
"2118T50",
"2118T60",
"2118T70",
"2118X30",
"2118X40",
"2118X50",
"2118X60",
"2118X70",
"2177"
]
},
{
  "part_name": "Heater WPW10082894",
  "part_number": "PS11748195",
  "manufacturer": "Kenmore",
```

"price": "69.41",

"description": "This dishwasher heating element is not designed to heat the water that enters it, but is designed to maintain the heat of the water that enters the dishwasher. It is located on the bottom of the dishwasher.",

"rating": "90",

"troubleshooting_tips": "This part fixes the following symptoms: Not drying dishes properly | Not cleaning dishes properly This part works with the following products: Dishwasher. Part# WPW10082894 replaces these: 3369069, 3372378, 3372523, 3377913, 3379269, 3379739, 8519827, W10082894 Back to Top",

"review_count": "2",

"appliance": "dishwasher",

"compatible_models": [

"110723120",

"66514212K900",

"66514212K901",

"66514213K900",

"66514213K901",

"66514214K900",

"66514214K901",

"66514219K900",

"66514219K901",

"6651514590",

"6651514591",

"6651514593",

"6651514594",

"6651544590",

"6651544591",

"6651544593",
"6651544594",
"6651644590",
"6651644591",
"6651644593",
"6651644594",
"6651711590",
"6651711591",
"6651711592",
"6651741590",
"6651741591",
"6651741592",
"66517422990",
"66517422991",
"66517422992"

]

},

{

"part_name": "Heater Assembly 5301DD1001G",

"part_number": "PS3527787",

"manufacturer": "LG",

"price": "106.90",

"description": "",

"rating": "90",

"troubleshooting_tips": "This part fixes the following symptoms: Not drying dishes properly This part works with the following products: Dishwasher. Part# 5301DD1001G replaces these: AP5272210, 5301DD1001A, 5301DD1001L, 6323DD3001A Back to Top",

```
"review_count": "2",  
"appliance": "dishwasher",  
"compatible_models": [  
  "D1401TB",  
  "D1401TB1",  
  "D1412TB",  
  "D1414TB",  
  "D1435BB",  
  "D1435TB",  
  "D1435WB",  
  "D1436TB",  
  "D1470BB",  
  "D1470TB",  
  "D1470TBR",  
  "D1470WB",  
  "D1607BB",  
  "D1607TB",  
  "D1607WB",  
  "D1608BB",  
  "D1608TB",  
  "D1608WB",  
  "D1613BB",  
  "D1613TB",  
  "D1613WB",  
  "D1616TB",  
  "LD-6090BB1",
```

```
"LD-6090BB2",
"LD-6090TB1",
"LD-6090TB2",
"LD-6090WB1",
"LD-6090WB2",
"LD-6100BB1",
"LD-6100TB1"
]
},
{
  "part_name": "HEATER ASSEMBLY AEG72950001",
  "part_number": "PS7788065",
  "manufacturer": "LG",
  "price": "88.04",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part fixes the following symptoms: Not drying dishes properly This part works with the following products: Dishwasher. Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "14693",
    "14697",
    "39232533",
    "72214697610",
    "D1425TB",
```

"D1426DB1",
"D1426TB",
"D1426TB1",
"D1438DB",
"D1438TB",
"D1471BB",
"D1471BB1",
"D1471DB1",
"D1471DBK",
"D1471TB",
"D1471TB1",
"D1471TBK",
"D1471WB",
"D1471WB1",
"D1472TB",
"D1472TB1",
"D1475TUR1",
"D1539TU",
"D15ASTUL",
"LDF7061ST",
"LDF7551BB",
"LDF7551ST",
"LDF7551WW",
"LDF7561ST",
"LDF7774BB"

]

},

{

"part_name": "Heating Element WPW10082892",

"part_number": "PS11748194",

"manufacturer": "Kenmore",

"price": "52.87",

"description": "This dishwasher heating element is not designed to heat the water that enters it, but is designed to maintain the heat of the water that enters the dishwasher. It is located on the bottom of the dishwasher.",

"rating": "75",

"troubleshooting_tips": "This part fixes the following symptoms: Not drying dishes properly | Will Not Start | Not cleaning dishes properly This part works with the following products: Dishwasher. Part# WPW10082892 replaces these: AP6014924, 8537057, 8564032, 8564056, W10082892 Back to Top",

"review_count": "4",

"appliance": "dishwasher",

"compatible_models": [

"66513102K900",

"66513102K901",

"66513102K902",

"66513103K900",

"66513103K901",

"66513103K902",

"66513104K900",

"66513104K901",

"66513104K902",

"66513109K900",

```
"66513109K901",
"66513109K902",
"66513112K700",
"66513112K701",
"66513112K702",
"66513113K700",
"66513113K701",
"66513113K702",
"66513114K700",
"66513114K701",
"66513114K702",
"66513119K700",
"66513119K701",
"66513119K702",
"66513122K700",
"66513122K701",
"66513122K702",
"66513122K703",
"66513123K700",
"66513123K701"
]
},
{
  "part_name": "Heating Element 154665201",
  "part_number": "PS2355742",
  "manufacturer": "Kenmore",
```

"price": "60.09",

"description": "This part is not designed to heat the water that enters it, but is designed to maintain the heat of the water that enters the dishwasher and is located on the bottom of the dishwasher.\r\n\r\nGrommets are included with this part.",

"rating": "95",

"troubleshooting_tips": "This part fixes the following symptoms: Not drying dishes properly | Leaking | Not cleaning dishes properly This part works with the following products: Dishwasher. Part# 154665201 replaces these: AP4424048, 1472862, 154665201, 154247601, 154665201 Back to Top",

"review_count": "4",

"appliance": "dishwasher",

"compatible_models": [

"58714000100",

"58714000101",

"58714000102",

"58714001990",

"58714001991",

"58714001992",

"58714001993",

"58714002990",

"58714002991",

"58714002992",

"58714002993",

"58714003100",

"58714008001",

"58714008002",

"58714008003",

"58714009100",
"58714009101",
"58714009102",
"58714012400",
"58714012401",
"58714012402",
"58714012403",
"58714012404",
"58714012405",
"58714012406A",
"58714013400",
"58714013401",
"58714013402",
"58714013403",
"58714013404"

]

},

{

"part_name": "Heating Element 154825001",

"part_number": "PS3653449",

"manufacturer": "Kenmore",

"price": "73.42",

"description": "This dishwasher heating element is not designed to heat the water that enters it, but is designed to maintain the heat of the water that enters the dishwasher. It is located on the bottom of the dishwasher.\r\nNOTE: Brass nuts are NOT included. Must be ordered separately.",

"rating": "93",

"troubleshooting_tips": "This part fixes the following symptoms: Not drying dishes properly | Leaking | Not cleaning dishes properly This part works with the following products: Dishwasher. Part# 154825001 replaces these: AP5628696, 2308825, 154825001, 154482901, 154663801 Back to Top",

"review_count": "8",

"appliance": "dishwasher",

"compatible_models": [

"004621710A",

"004621711A",

"58714012407A",

"58714012408A",

"58714012409B",

"58714012410B",

"58714012411B",

"58714012412B",

"58714012413B",

"58714012414B",

"58714012416B",

"58714013408A",

"58714013409A",

"58714013410B",

"58714013411B",

"58714013412B",

"58714013413B",

"58714013414B",

"58714013415B",

"58714013416B",

"58714013417B",

"58714014407A",

"58714014408A",

"58714014409B",

"58714014410B",

"58714014411B",

"58714014412B",

"58714014413B",

"58714019407A",

"58714019408A"

]

},

{

"part_name": "Dishwasher Heating Element W10703867",

"part_number": "PS9494999",

"manufacturer": "Kenmore",

"price": "87.61",

"description": "The heating element is not designed to heat the water that enters it, but is designed to maintain the heat of the water that enters the dishwasher. It is located on the bottom of the dishwasher.",

"rating": "91",

"troubleshooting_tips": "This part fixes the following symptoms: Not drying dishes properly | Not cleaning dishes properly | Leaking This part works with the following products: Dishwasher. Part# W10703867 replaces these: AP5809076, W10195052, W10329322, W10473250, W10518402, W10687954, W10696509 Back to Top",

"review_count": "17",

"appliance": "dishwasher",

"compatible_models": [

"2213222N414",

"2213223N414",

"2213229N414",

"2214545N711",

"2214715N710",

"2214792N512",

"2214793N512",

"66512762K312",

"66512762K313",

"66512763K312",

"66512763K313",

"66512769K312",

"66512769K313",

"66512772K312",

"66512772K313",

"66512772K314",

"66512773K313",

"66512773K314",

"66512774K312",

"66512774K313",

"66512776K312",

"66512776K314",

"66512779K312",

"66512779K313",

"66512779K314",

"66512782K310",

"66512782K312",

"66512782K313",

"66512783K311",

"66512783K312"

]

},

{

"part_name": "Dishwasher Heating Element W10518394",

"part_number": "PS8260087",

"manufacturer": "Kenmore",

"price": "66.09",

"description": "This manufacturer-certified heating element is used to create heat during the dry cycle and increase water temperature during portions of the wash cycle when certain options are selected. If your dishes are not drying or the water in the dishwasher is not getting hot you may need to replace the element. This kit includes the heater, two heater fasteners, and is a genuine OEM part. Please remember to disconnect the power before starting the repair. Use a multi-meter to test your heating element for continuity to determine whether this is the part that is causing your symptom. This part does not include any washers. To make your repair, disconnect the wires from the bottom of the element in the back, remove the plastic nuts holding it in place, remove the element, and repeat these steps in reverse order to install your new part. This is an easy repair that requires only a screwdriver, wrench set, and should take less than 30 minutes.",

"rating": "90",

"troubleshooting_tips": "This part fixes the following symptoms: Not drying dishes properly | Not cleaning dishes properly | Will Not Start | Leaking This part works with the following products: Dishwasher. Part# W10518394 replaces these: AP5690151, 2977737, W10518394, 8194250, 8563007, 8563464, 8572861, W10134009, W10441445, W10518394VP Back to Top",

"review_count": "89",

"appliance": "dishwasher",

"compatible_models": [

"2212413N414",

"2213092N413",

"2213099N413",

"2213479N413",

"2213809N710",

"2217383N710",

"2217389N710",

"66213032K112",

"66512093K210",

"66512413N410",

"66512413N411",

"66512413N412",

"66512413N413",

"66512723K310",

"66512723K311",

"66513002N510",

"66513002N511",

"66513003N510",

"66513003N511",

"66513004N510",

"66513004N511",

"66513009N510",

"66513009N511",

"66513012K110",

```
"66513012K111",
"66513012K112",
"66513012K113",
"66513013K110",
"66513013K111",
"66513013K112"
]
},
{
  "part_name": "Door Latch - Black W10619006",
  "part_number": "PS8770043",
  "manufacturer": "Kenmore",
  "price": "44.07",
  "description": "NOTE: This part has been redesigned, it may appear different but will still function the same as the original.",
  "rating": "86",
  "troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Will Not Start | Door won't close | Leaking This part works with the following products: Dishwasher. Part# W10619006 replaces these: AP5805371, W10195093, W10370003, W10380262, W10550100, W10619006VP Back to Top",
  "review_count": "21",
  "appliance": "dishwasher",
  "compatible_models": [
    "66213043K112",
    "66213049K112",
    "66213273K112",
    "66213282K112",
```

"66213289K112",
"66512093K210",
"66512723K310",
"66512782K310",
"66513032K110",
"66513032K111",
"66513032K112",
"66513032K113",
"66513032K114",
"66513033K110",
"66513033K111",
"66513033K112",
"66513033K113",
"66513033K114",
"66513039K110",
"66513039K111",
"66513039K112",
"66513039K113",
"66513039K114",
"66513042K110",
"66513042K111",
"66513042K112",
"66513042K113",
"66513042K114",
"66513043K110",
"66513043K111"

```
]
},
{
  "part_name": "Door Latch and Gasket 5304442175",
  "part_number": "PS979852",
  "manufacturer": "Kenmore",
  "price": "63.70",
  "description": "Black in color. No longer available in almond.\r\nThis door latch prohibits the dishwasher from operating when the door is open. The gasket is used around the door to keep the dishwasher from leaking.",
  "rating": "94",
  "troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Will Not Start | Door won't close | Leaking This part works with the following products: Dishwasher. Part# 5304442175 replaces these: AP3774457, 1063307, 5304442175, 154211201, 154211202, 154211301, 154211303, 154293101, 154293103, 154308101, 154308102, 154308103, 154316201, 154316301, 154316303, 154361201, 154361202, 154361203, 154434101, 154434102 ... Show more , 154434103, 154434105 Show less Back to Top",
  "review_count": "13",
  "appliance": "dishwasher",
  "compatible_models": [
    "58714000100",
    "58714000101",
    "58714000102",
    "58714001990",
    "58714001991",
    "58714001992",
    "58714001993",
```


"58714002990",
"58714002991",
"58714002992",
"58714002993",
"58714003100",
"58714008001",
"58714008002",
"58714008003",
"58714009100",
"58714009101",
"58714009102",
"58714131100",
"58714131101",
"58714131102",
"58714132100",
"58714132101",
"58714132102",
"58714134100",
"58714139100",
"58714139101",
"58714139102",
"58714202200",
"58714209200"

]

},

{

"part_name": "Latch Striker WD13X10071",

"part_number": "PS8690622",

"manufacturer": null,

"price": "8.06",

"description": "This dishwasher latch strike is a manufacturer-approved replacement part for your appliance. The latch strike is an important component in your dishwasher door assembly, and adds an extra layer of security in keeping the door closed. This part may become damaged if the door has been opened during a wash cycle. It can also wear out over time. It is fairly easy to replace, simply pop out the old door strike using a screwdriver for leverage, and insert the new one.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start | Door latch failure | Door won't close This part works with the following products: Dishwasher. Part# WD13X10071 replaces these: AP5781915 Back to Top",

"review_count": "3",

"appliance": "dishwasher",

"compatible_models": [

"ADT521PGF0BS",

"ADT521PGF0WS",

"ADT521PGF2BS",

"ADT521PGF2WS",

"ADT521PGF4BS",

"ADT521PGF4WS",

"ADT521PGF6BS",

"ADT521PGF6WS",

"ADT521PGJ0BS",

"ADT521PGJ0WS",

"ADT521PGJ2BS",

```
"ADT521PGJ2WS",
"ADT521PGJBS",
"ADT521PGJWS",
"CDT706P2M4S1",
"CDT706P2M5S1",
"CDT800P2N0S1",
"CDT800P2N2S1",
"CDT800P2N3S1",
"CDT800P2N4S1",
"CDT800P2N5S1",
"CDT805M5N0S5",
"CDT805M5N2S5",
"CDT805M5N3S5",
"CDT805M5N4S5",
"CDT805P2N0S1",
"CDT805P2N1S1",
"CDT805P2N2S1",
"CDT805P2N3S1",
"CDT805P2N4S1"
]
},
{
  "part_name": "Door Latch Assembly W10862259",
  "part_number": "PS11731673",
  "manufacturer": null,
  "price": "62.10",
```

"description": "This replacement part is a door latch assembly for a dishwasher. The latch keeps the appliance door closed while it is running, and prohibits the dishwasher from starting when the door is open. Depending on your model, you will need to remove approximately eleven screws to remove the inner panel and access the latch assembly. The latch assembly is connected by two wiring harnesses that are nearly identical, so it is recommended to make note of where each harness goes before continuing with the repair. You will need a Torx screwdriver to complete the repair. Disconnect the dishwasher from the power source before beginning this repair.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close | Will Not Start This part works with the following products: Dishwasher. Part# W10862259 replaces these: AP5999602, 99002988, 99002989, 99002990, 99003358, 99003359, 99003428, W10130697, W10130698, W10130699, WPW10130699 Back to Top",

"review_count": "123",

"appliance": "dishwasher",

"compatible_models": [

"ADB1200AWB",

"ADB1200AWQ",

"ADB1200AWS",

"ADB1200AWW",

"ADB1500AWB",

"ADB1500AWQ",

"ADB1500AWS",

"ADB1500AWW",

"ADB1500AWZ",

"ADB2200AWB",

"ADB2200AWQ",

"ADB2200AWS",

```
"ADB2200AWW",
"ADB2500AWB",
"ADB2500AWB1",
"ADB2500AWB2",
"ADB2500AWB3",
"ADB2500AWQ",
"ADB2500AWQ1",
"ADB2500AWQ2",
"ADB2500AWQ3",
"ADB2500AWS",
"ADB2500AWS1",
"ADB2500AWS2",
"ADB2500AWS3",
"ADB2500AWW",
"ADB2500AWW1",
"ADB2500AWW2",
"ADB2500AWW3",
"ADB3500AWB"
]
},
{
  "part_name": "LATCH ASSEMBLY 5304525219",
  "part_number": "PS16218717",
  "manufacturer": "Kenmore",
  "price": "52.66",
  "description": "This is an OEM door latch (black), which works with dishwashers.",
```

"rating": "87",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Will Not Start This part works with the following products: Dishwasher. Part# 5304525219 replaces these: 5304500345, 5304500348, 5304517278, 5304517280 Back to Top",

"review_count": "9",

"appliance": "dishwasher",

"compatible_models": [

"58714012416B",

"58714013412B",

"58714013413B",

"58714013414B",

"58714013415B",

"58714013416B",

"58714013417B",

"58714019411B",

"58714019412B",

"58714019413B",

"58714019414B",

"58714019415B",

"58714019416B",

"CDB350NB10B",

"CDB350NB4A",

"CDB350NB5A",

"CDB350NB6B",

"CDB350NB7B",

"CDB350NB8B",

"CDB350NB9B",

"CDB500NB3A",
"CDB500NB4A",
"CDB500NB5B",
"CDB500NS3A",
"CDB500NS4A",
"CDB500NS5B",
"FBD2400KB10B",
"FBD2400KB11B",
"FBD2400KB12B",
"FBD2400KB8B"

]

},

{

"part_name": "Door Latch - Black WPW10653840",

"part_number": "PS11756967",

"manufacturer": "Kenmore",

"price": "36.55",

"description": "This is a door latch for various dishwashers. Door latches are designed to communicate with the control board of the dishwasher when the door is closed and latched shut. If your dishwasher is not latching shut properly, or if your dishwasher will not start when the door is shut, then this latch is likely broken or bad. To replace this door latch, you will need a screwdriver or drill, and a set of pliers. This latch is sold individually, and does not come with any securing screws or other parts.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close | Will Not Start | Leaking This part works with the following products: Dishwasher. Part# WPW10653840 replaces these: AP6023622, W10574864, W10653840
Back to Top",

```
"review_count": "10",  
"appliance": "dishwasher",  
"compatible_models": [  
  "2212413N414",  
  "2213092N413",  
  "2213099N413",  
  "2213222N414",  
  "2213229N414",  
  "2213479N413",  
  "2214523N611",  
  "2214545N711",  
  "2214715N710",  
  "2214792N512",  
  "2214793N512",  
  "66512413N410",  
  "66512413N411",  
  "66512413N412",  
  "66512413N413",  
  "66512723K311",  
  "66512762K312",  
  "66512762K313",  
  "66512763K312",  
  "66512763K313",  
  "66512769K312",  
  "66512769K313",  
  "66512772K311",
```


"66512772K312",

"66512772K313",

"66512772K314",

"66512773K311",

"66512773K313",

"66512773K314",

"66512774K311"

]

},

{

"part_name": "Door Latch WD21X10490",

"part_number": "PS6447681",

"manufacturer": null,

"price": "44.19",

"description": "This is replacement door latch for your dishwasher. The door latch is attached to the tub frame, and connects to the door strike to keep your dishwasher door closed during operation. If you have a broken or faulty door latch, your dishwasher door may not stay closed, and this can prevent the dishwasher from running. This item is sold individually, and if your door strike is also damaged, you will need to replace that part separately. This is an OEM part sourced directly from the manufacturer.",

"rating": "91",

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start | Door latch failure | Door won't close This part works with the following products: Dishwasher. Part# WD21X10490 replaces these: AP5668411 Back to Top",

"review_count": "49",

"appliance": "dishwasher",

"compatible_models": [

"ADT521PGF0BS",

"ADT521PGF0WS",
"ADT521PGF2BS",
"ADT521PGF2WS",
"ADT521PGF4BS",
"ADT521PGF4WS",
"ADT521PGF6BS",
"ADT521PGF6WS",
"ADT521PGJ0BS",
"ADT521PGJ0WS",
"ADT521PGJ2BS",
"ADT521PGJ2WS",
"ADT521PGJBS",
"ADT521PGJWS",
"CDT706P2M4S1",
"CDT706P2M5S1",
"CDT725SSF0SS",
"CDT725SSF2SS",
"CDT725SSF4SS",
"CDT725SSF6SS",
"CDT725SSF7SS",
"CDT765SSF0SS",
"CDT765SSF1SS",
"CDT765SSF7SS",
"CDT800P2N0S1",
"CDT800P2N2S1",
"CDT800P2N3S1",

```
"CDT800P2N4S1",
"CDT800P2N5S1",
"CDT805M5N0S5"
]
},
{
  "part_name": "Latch 5304525218",
  "part_number": "PS16218716",
  "manufacturer": "Kenmore",
  "price": "42.58",
  "description": "This door latch with the switches is a simple on/off mechanism that prohibits the dishwasher from operating when the door is open.",
  "rating": "96",
  "troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Will Not Start | Door won't close | Leaking This part works with the following products: Dishwasher. Part# 5304525218 replaces these: 154543901, 154722401, 154758101, 5304516818, 5304527418 Back to Top",
  "review_count": "17",
  "appliance": "dishwasher",
  "compatible_models": [
    "004621710A",
    "004621711A",
    "58715202800",
    "58715202801",
    "58715202802",
    "58715202803A",
    "58715203800",
```

```
"58715203801",  
"58715203802",  
"58715203803A",  
"58715313000A",  
"58715372100A",  
"58715372100B",  
"58715373100A",  
"58715373100B",  
"58715378100A",  
"58715378100B",  
"58715379100A",  
"58715379100B",  
"58715382100A",  
"58715382100B",  
"58715383100A",  
"58715383100B",  
"58715389100A",  
"58715389100B",  
"58715392100A",  
"58715393100A",  
"58715399100A",  
"605222850A",  
"804621670A"  
]  
,  
{
```

"part_name": "Drain and Wash Impeller Kit 675806",

"part_number": "PS382822",

"manufacturer": "Kenmore",

"price": "92.87",

"description": "This dishwasher drain and wash impeller kit comes with both the drain and wash impeller, gaskets, chopper, and installation screw. This part helps stop your dishwasher from leaking and helps with the proper draining of the dishwasher. If you notice that your dishes are not cleaning, the dishwasher is not draining properly, or is making any unusually loud sounds or grinding noises, this could indicate the impeller and seal kit have broken down and need to be replaced. You will need a #15 and #20 torx driver, a small flat-blade screwdriver, 1/4-inch nut driver, adjustable wrench, and a small hammer and a sharp chisel.",

"rating": "98",

"troubleshooting_tips": "This part fixes the following symptoms: Not draining | Noisy | Not cleaning dishes properly | Leaking This part works with the following products: Dishwasher. Part# 675806 replaces these: AP3115180, 679717, 675806, 302706, 302718, 303032, 303510, 303539, 3376402, 3378175, 3378176, 675495, 675500, 675501, 675514, 675705, 675806, 8193522 Back to Top",

"review_count": "18",

"appliance": "dishwasher",

"compatible_models": [

"110773811",

"110773812",

"110773813",

"110773881",

"110773882",

"110773883",

"56461040",

"56461042",

```
"56461044",  
"56461047",  
"66513402K900",  
"66513402K901",  
"66513409K900",  
"66513409K901",  
"66513442K900",  
"66513442K901",  
"66513443K900",  
"66513443K901",  
"66513444K900",  
"66513444K901",  
"66513449K900",  
"66513449K901",  
"66513492K600",  
"66513499K600",  
"66513592K600",  
"66513593K600",  
"66513594K600",  
"66513599K600",  
"66513692K600",  
"66513699K600"  
]  
,  
{  
  "part_name": "Sump WD18X10026",
```

"part_number": "PS959014",

"manufacturer": null,

"price": "37.58",

"description": "This works in conjunction with the pump and filtration system. It is used to receive drainage for disposal.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Not cleaning dishes properly | Not draining This part works with the following products: Dishwasher. Part# WD18X10026 replaces these: AP3728341, 1088559 Back to Top",

"review_count": "20",

"appliance": "dishwasher",

"compatible_models": [

"CDW9380N00SS",

"CDW9380N20SS",

"CDWT280V00SS",

"CDWT280V05SS",

"CDWT280V50SS",

"CDWT980R10SS",

"CDWT980R30SS",

"CDWT980V00SS",

"CDWT980V05SS",

"CDWT980V50SS",

"EDWF800P00BB",

"EDWF800P00WW",

"EDWF860P00SS",

"GDWF100R10BB",

"GDWF100R10WW",

"GDWF100R30BB",
"GDWF100R30WW",
"GDWF100V40BB",
"GDWF100V40WW",
"GDWF100V50BB",
"GDWF100V50WW",
"GDWF100V55BB",
"GDWF100V55WW",
"GDWF100V70WW",
"GDWF106V00WW",
"GDWF150V40ES",
"GDWF150V50ES",
"GDWF150V55ES",
"GDWF160R10SS",
"GDWF160R30SS"

]

},

{

"part_name": "Drain Pump - 55Hz 00611332",

"part_number": "PS8727352",

"manufacturer": "Kenmore",

"price": "59.36",

"description": "The pump ejects the water from the dishwasher through the drain hose.",

"rating": "90",

"troubleshooting_tips": "This part fixes the following symptoms: Not draining | Noisy | Will Not Start This part works with the following products: Dishwasher. Part# 00611332 replaces these: AP4339596, 611332 Back to Top",


```
"review_count": "8",  
"appliance": "dishwasher",  
"compatible_models": [  
  "63013003012",  
  "63013003015",  
  "63013003016",  
  "63013003017",  
  "63013003018",  
  "63013023010",  
  "63013023011",  
  "63013023015",  
  "63013023016",  
  "63013023017",  
  "63013023018",  
  "63013902010",  
  "63013902011",  
  "63013903010",  
  "63013903011",  
  "63013909010",  
  "63013909011",  
  "63013909012",  
  "63013912010",  
  "63013912011",  
  "63013913010",  
  "63013913011",  
  "63013919010",
```

"63013919011",

"63013919012",

"63013993010",

"63013993012",

"63013993015",

"63013993016",

"63013993017"

]

},

{

"part_name": "Drain Pump WPW10531320",

"part_number": "PS11756031",

"manufacturer": "Kenmore",

"price": "69.00",

"description": "This drain pump is an authentic OEM replacement part for models of dishwasher. It is responsible for removing wastewater from the dishwasher during the drainage cycle. It is located at the bottom of the dishwasher and can be accessed by removing the lower access panel or by tipping the dishwasher on to its rear side. When activated, the drain pump pushes the wastewater through the drain hose and into the household plumbing system or garbage disposal. If the drain pump malfunctions or becomes clogged, it can lead to drainage issues, resulting in water pooling at the bottom of the dishwasher, foul odors and potentially resulting in incomplete cleaning of dishes.",

"rating": "84",

"troubleshooting_tips": "This part fixes the following symptoms: Not draining | Noisy | Leaking This part works with the following products: Dishwasher. Part# WPW10531320 replaces these: AP6022694, W10314713, W10531320, WPW10531320VP Back to Top",

"review_count": "5",

"appliance": "dishwasher",

"compatible_models": [

"2214715N710",
"2214792N512",
"2214793N512",
"66512762K312",
"66512763K312",
"66512763K313",
"66512769K312",
"66512769K313",
"66512772K312",
"66512772K314",
"66512773K313",
"66512773K314",
"66512774K312",
"66512774K313",
"66512776K311",
"66512776K312",
"66512776K314",
"66512779K312",
"66512779K313",
"66512779K314",
"66512782K310",
"66512782K312",
"66512782K313",
"66512783K311",
"66512783K312",
"66512783K313",

```
"66512789K311",
"66512789K312",
"66512789K313",
"66512793K312"
]
},
{
  "part_name": "Circulation Pump WD26X23258",
  "part_number": "PS11772000",
  "manufacturer": null,
  "price": "125.04",
  "description": "This part contains the Piranha clamps in kit WD35X10382",
  "rating": "93",
  "troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Leaking | Will Not Start This part works with the following products: Dishwasher. Part# WD26X23258 replaces these: WD26X22285, WD26X22518, WD26X22826 Back to Top",
  "review_count": "14",
  "appliance": "dishwasher",
  "compatible_models": [
    "ADT521PGJ0BS",
    "ADT521PGJ0WS",
    "ADT521PGJ2BS",
    "ADT521PGJ2WS",
    "CDT706P2M4S1",
    "CDT706P2M5S1",
    "CDT725SSF7SS",
```

```
"CDT805P2N0S1",  
"CDT835SMJ0DS",  
"CDT835SMJ2DS",  
"CDT835SMJ4DS",  
"CDT835SMJ5DS",  
"CDT835SSJ0SS",  
"CDT835SSJ2SS",  
"CDT835SSJ4SS",  
"CDT835SSJ5SS",  
"CDT836P2M4S1",  
"CDT836P2M5S1",  
"CDT836P3M4D1",  
"CDT836P3M5D1",  
"CDT836P4M4W2",  
"CDT836P4M5W2",  
"CDT845P2N0S1",  
"CDT845P3N0D1",  
"CDT845P4N0W2",  
"DDT575SGF7BB",  
"DDT575SGF7WW",  
"DDT575SGF8BB",  
"DDT575SGF8WW",  
"DDT575SMF7ES"  
]  
,  
{
```

"part_name": "Dishwasher Drain Pump W10876537",

"part_number": "PS11738151",

"manufacturer": "Kenmore",

"price": "76.68",

"description": "This drain pump is for dishwashers.\r\n\r\nDrain pump removes the water from the dishwasher tub during the drain phase of the dishwashing cycle.\r\n\r\nUnplug the dishwasher and shut off the water supply before installing this part. Wear work gloves to protect your hands.",

"rating": "93",

"troubleshooting_tips": "This part fixes the following symptoms: Not draining | Leaking
This part works with the following products: Dishwasher. Part# W10876537 replaces these: AP6004843, W10724439, W10876537VP Back to Top",

"review_count": "14",

"appliance": "dishwasher",

"compatible_models": [

"2212413N414",

"2213092N413",

"2213099N413",

"2213222N414",

"2213223N414",

"2213229N414",

"2213479N413",

"2213804N710",

"2213809N710",

"2214523N611",

"2214545N711",

"2217383N710",

```
"2217389N710",
"66512413N412",
"66512413N413",
"66513002N510",
"66513002N511",
"66513003N510",
"66513003N511",
"66513004N510",
"66513004N511",
"66513009N510",
"66513009N511",
"66513073K217",
"66513092N412",
"66513092N413",
"66513093N412",
"66513093N413",
"66513099N412",
"66513202N412"
]
},
{
  "part_name": "Dishwasher Circulation Pump with Heater 12008381",
  "part_number": "PS11724988",
  "manufacturer": null,
  "price": "145.82",
```

"description": "This circulation pump with heater is for dishwashers.\r\n\r\nCirculation pump with heater moves heated water through the spray arm to clean the dishes.\r\n\r\nUnplug the dishwasher before installing this part. Wear work gloves to protect your hands.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Not drying dishes properly | Not cleaning dishes properly | Noisy | Will Not Start This part works with the following products: Dishwasher. Back to Top",

"review_count": "5",

"appliance": "dishwasher",

"compatible_models": [

"DWHD440MFP",

"SHE3AR72UC",

"SHE3AR75UC",

"SHE3AR76UC",

"SHE3ARF2UC",

"SHE3ARF5UC",

"SHE3ARF6UC",

"SHE53T52UC",

"SHE53T55UC",

"SHE53T56UC",

"SHE53TF2UC",

"SHE53TF5UC",

"SHE53TF6UC",

"SHE53TL2UC",

"SHE65T52UC",

"SHE65T55UC",


```
"SHE65T56UC",
"SHE68T52UC",
"SHE68T55UC",
"SHE68T56UC",
"SHE68TL5UC",
"SHE7PT52UC",
"SHE7PT55UC",
"SHE7PT56UC",
"SHE863WF2N",
"SHE863WF5N",
"SHE863WF6N",
"SHE878WD2N",
"SHE878WD5N",
"SHE878WD6N"
]
},
{
  "part_name": "Dishwasher Drain Pump WPW10348269",
  "part_number": "PS11753379",
  "manufacturer": "Kenmore",
  "price": "72.39",
```

"description": "This drain pump is used in dishwashers to remove water from the dishwasher tub. If the impeller in the dishwasher is damaged or the motor has been shorted out and will not drain, it is possible the body is cracked, causing leakage. To prevent this from happening, replace the drain pump. The tools needed for this installation are: Phillips screwdriver, 5/16 inch nut driver, 5/8 inch wrench, and a flathead screwdriver. Remember to unplug your dishwasher from the power source before beginning this

installation project. Refer to the manual provided by the manufacturer for further installation instructions.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Not draining | Leaking | Noisy | Not cleaning dishes properly This part works with the following products: Dishwasher. Part# WPW10348269 replaces these: AP6020066, 661662, 8558995, 8565839, W10084573, W10158351, W10348269, WPW10348269VP Back to Top",

"review_count": "57",

"appliance": "dishwasher",

"compatible_models": [

"66213032K112",

"66213273K112",

"66512093K210",

"66512413N410",

"66512413N411",

"66512723K310",

"66512723K311",

"66513012K110",

"66513012K111",

"66513012K112",

"66513012K113",

"66513013K110",

"66513013K111",

"66513013K112",

"66513013K113",

"66513014K110",

"66513014K111",

```
"66513014K112",  
"66513014K113",  
"66513019K110",  
"66513019K111",  
"66513019K112",  
"66513019K113",  
"66513023K110",  
"66513023K111",  
"66513023K112",  
"66513023K113",  
"66513032K110",  
"66513032K111",  
"66513032K112"  
]  
,  
{  
  "part_name": "Drain Pump -120V 60Hz A00126401",  
  "part_number": "PS8689824",  
  "manufacturer": "Kenmore",  
  "price": "100.36",
```

"description": "This is a drain pump assembly for various compatible models of dishwashers, that is responsible for draining the water from the dishwasher after every cycle. This drain pump assembly is made of plastic and fits within the sump assembly, which controls the flow of water into the drain. This drain pump assembly is a genuine OEM part and is made of a high-quality plastic but is sold as an individual component without any other parts, like its drain pump check ball which works within the pump to prevent water from backwashing into the pump, as well as the drain pump cover. If you notice your dishwasher is not draining or has a lot of water buildup at the bottom of the sump

assembly, this filter may be damaged, clogged or broken, and in need of a replacement. To replace this pump assembly, you will only need a Philips-head screwdriver, but should start by removing your dishwasher racks. Then, pull up on the lower spray arm, and drain trap to remove them. Next, rotate the spray arm support and pull that up to remove it, at which point you can remove the base and filter for the drain pump. With those out, you can use your Philips-head screwdriver to disconnect and remove the cover and drain pump assembly. With the pump removed, you can inspect it or install the new drain pump assembly, with the same hardware as before. Then it is as simple as reassembling the rest of your dishwasher, ensuring each connection point is fastened tightly.",

"rating": "98",

"troubleshooting_tips": "This part fixes the following symptoms: Not draining | Noisy This part works with the following products: Dishwasher. Part# A00126401 replaces these: AP5690431, 154736201, 5304492415 Back to Top",

"review_count": "16",

"appliance": "dishwasher",

"compatible_models": [

"004621710A",

"004621711A",

"58714012409B",

"58714012410B",

"58714012411B",

"58714012412B",

"58714012413B",

"58714012414B",

"58714012416B",

"58714013410B",

"58714013411B",

"58714013412B",

"58714013413B",

"58714013414B",
"58714013415B",
"58714013416B",
"58714013417B",
"58714014409B",
"58714014410B",
"58714014411B",
"58714014412B",
"58714014413B",
"58714019409B",
"58714019410B",
"58714019411B",
"58714019412B",
"58714019413B",
"58714019414B",
"58714019415B",
"58714019416B"

]

},

{

"part_name": "Micro Filter 00615079",

"part_number": "PS8727803",

"manufacturer": "Kenmore",

"price": "62.44",

"description": "This micro filter basket assembly is used in dishwashers. The filter is responsible for filtering the water inside the dishwasher. All of the food and debris particles that are removed from your dishes need somewhere to go, this filter works to remove that

stuff from the water so the drain will not get clogged. Filters are supposed to be self-cleaning, however if you have hard water, or if you are using the wrong detergent they might get a build-up on them. You can clean these filters, but once they are worn out they will need to be replaced. This filter has a diameter of four inches, and it is five inches in length.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Not draining This part works with the following products: Dishwasher. Part# 00615079 replaces these: AP4372139, 00170841, 00174936, 170841, 174936, 615079
Back to Top",

"review_count": "5",

"appliance": "dishwasher",

"compatible_models": [

"63016302400",

"63016302401",

"63016302402",

"63016302403",

"63016302404",

"63016302405",

"63016302406",

"63016303400",

"63016303401",

"63016303402",

"63016303403",

"63016303404",

"63016303405",

"63016303406",

"63016304400",

"63016304401",

```
"63016304402",
"63016304403",
"63016304404",
"63016304405",
"63016304406",
"63016309400",
"63016309401",
"63016309402",
"63016309403",
"63016309404",
"63016309405",
"63016309406",
"63017303400",
"63017303401"
]
},
{
  "part_name": "VENT FILTER WD24X10057",
  "part_number": "PS8756365",
  "manufacturer": null,
  "price": "7.77",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Back to Top",
  "review_count": "1",
```

"appliance": "dishwasher",

"compatible_models": [

"ADT521PGF0BS",

"ADT521PGF0WS",

"ADT521PGF2BS",

"ADT521PGF2WS",

"ADT521PGF4BS",

"ADT521PGF4WS",

"ADT521PGF6BS",

"ADT521PGF6WS",

"ADT521PGJ0BS",

"ADT521PGJ0WS",

"ADT521PGJ2BS",

"ADT521PGJ2WS",

"ADT521PGJBS",

"ADT521PGJWS",

"CDT706P2M4S1",

"CDT706P2M5S1",

"CDT725SSF0SS",

"CDT725SSF2SS",

"CDT725SSF4SS",

"CDT725SSF6SS",

"CDT725SSF7SS",

"CDT765SSF0SS",

"CDT765SSF1SS",

"CDT765SSF7SS",


```
"CDT805P2N0S1",
"CDT835SMJ0DS",
"CDT835SMJ2DS",
"CDT835SMJ4DS",
"CDT835SMJ5DS",
"CDT835SSJ0SS"
]
},
{
  "part_name": "DRAIN FILTER A00201409",
  "part_number": "PS12071530",
  "manufacturer": null,
  "price": "52.51",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#
A00201409 replaces these: AP6230767, A00201402 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "905045720A",
    "E24ID74QPS0A",
    "E24ID74QPS1A",
    "E24ID74QPS3A",
    "E24ID74QPS4A",
    "E24ID75SPS0A",
```

"E24ID75SPS1A",
"E24ID75SPS2A",
"E24ID75SPS3A",
"EDSH4944AS0A",
"EI24CD35RS2A",
"EI24CD35RS3A",
"EI24CD35RS4A",
"EI24ID30QB0A",
"EI24ID30QB0B",
"EI24ID30QB3B",
"EI24ID30QS0A",
"EI24ID30QS0B",
"EI24ID30QS3B",
"EI24ID30QS4B",
"EI24ID30QS5B",
"EI24ID30QW0A",
"EI24ID30QW0B",
"EI24ID30QW3B",
"EI24ID50QS0A",
"EI24ID50QS0B",
"EI24ID50QS1A",
"EI24ID50QS1B",
"EI24ID50QS4B",
"EI24ID50QS5B"

]

},

```
{
  "part_name": "Drain Trap 154252701",
  "part_number": "PS420500",
  "manufacturer": "Kenmore",
  "price": "50.90",
  "description": "Part is found under the lower spray arm.",
  "rating": "87",
  "troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Not draining This part works with the following products: Dishwasher. Part# 154252701 replaces these: AP2109132, 419238 Back to Top",
  "review_count": "3",
  "appliance": "dishwasher",
  "compatible_models": [
    "58714102800",
    "58714112400",
    "58714112401",
    "58714112402",
    "58714113400",
    "58714113401",
    "58714113402",
    "58714114400",
    "58714114401",
    "58714114402",
    "58714119400",
    "58714119401",
    "58714119402",
    "58714131100",
```

"58714131101",
"58714131102",
"58714132100",
"58714132101",
"58714132102",
"58714134100",
"58714134101",
"58714134102",
"58714139100",
"58714139101",
"58714139102",
"58714153400",
"58714153401",
"58714153402",
"58714154400",
"58714154401"

]

},

{

"part_name": "Filter Base 5304506533",

"part_number": "PS11770494",

"manufacturer": "Kenmore",

"price": "17.79",

"description": "Located at the bottom of the dishwasher, this filter keep large particles of food and foreign objects away from the pump.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Not draining This part works with the following products: Dishwasher. Part# 5304506533 replaces these: AP6036343, 154252201, 154252301, 154252302, 154332601, 154332602, 154758901, 154775401, 154775402, 154776101 Back to Top",

"review_count": "3",

"appliance": "dishwasher",

"compatible_models": [

"004621710A",

"004621711A",

"58714000100",

"58714000101",

"58714000102",

"58714001990",

"58714001991",

"58714001992",

"58714001993",

"58714002990",

"58714002991",

"58714002992",

"58714002993",

"58714003100",

"58714008001",

"58714008002",

"58714008003",

"58714009100",

"58714009101",

"58714009102",

"58714012400",
"58714012401",
"58714012402",
"58714012403",
"58714012404",
"58714012405",
"58714012406A",
"58714012407A",
"58714012408A",
"58714012409B"

]

},

{

"part_name": "Screen WPW10463906",

"part_number": "PS11755148",

"manufacturer": "Kenmore",

"price": "35.70",

"description": "This is a screen filter, designed to keep food particles, gunk, and debris from entering the pump of your dishwasher. If this filter is missing, damaged, or simply unusable, it will need to be replaced so you can effectively clean your dishes. Replacing this filter is simple, as you only need to twist and remove the lower filter, before you can carefully lift this filter out. This filter is an OEM part and is sold individually.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Not draining This part works with the following products: Dishwasher. Part# WPW10463906 replaces these: AP6021820, W10195360, W10463906, WPW10195360
Back to Top",

"review_count": "6",

"appliance": "dishwasher",

"compatible_models": [

"2212413N414",

"2213092N413",

"2213099N413",

"2213222N414",

"2213223N414",

"2213229N414",

"2213479N413",

"2213809N710",

"2214523N611",

"2214545N711",

"2214715N710",

"2214792N512",

"2214793N512",

"2217383N710",

"2217389N710",

"66512093K210",

"66512413N410",

"66512413N411",

"66512413N412",

"66512413N413",

"66512723K310",

"66512723K311",

"66512762K312",

"66512763K313",

```
"66512769K313",  
"66512773K313",  
"66512773K314",  
"66512776K311",  
"66512782K310",  
"66512782K312"
```

```
]
```

```
},
```

```
{
```

```
"part_name": "FILTER-MICRO 00645038",
```

```
"part_number": "PS8730270",
```

```
"manufacturer": "Kenmore",
```

```
"price": "37.40",
```

```
"description": "This micro filter is a genuine OEM replacement part that is compatible with dishwashers. Its primary function is to catch and trap small particles of food, debris, and other contaminants that may be present in the water circulating inside the dishwasher during the wash and rinse cycles. This filter helps prevent these particles from clogging the pump or recirculating back onto the dishes. Signs of a faulty micro filter include poor cleaning performance, slow drainage, stagnant water at the bottom of the tub, and loud and unusual noises when the dishwasher is running. It is recommended to clean the filter once a month for optimal performance.",
```

```
"rating": "99",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Not draining This part works with the following products: Dishwasher. Part# 00645038 replaces these: AP4339631, 00651097, 645038, 651097 Back to Top",
```

```
"review_count": "15",
```

```
"appliance": "dishwasher",
```

```
"compatible_models": [  
"63013003012",
```


"63013003015",
"63013003016",
"63013003017",
"63013003018",
"63013023010",
"63013023011",
"63013023015",
"63013023016",
"63013023017",
"63013023018",
"63013902010",
"63013902011",
"63013903010",
"63013903011",
"63013909010",
"63013909011",
"63013909012",
"63013912010",
"63013912011",
"63013913010",
"63013913011",
"63013919010",
"63013919011",
"63013919012",
"63013993010",
"63013993012",

```
"63013993015",
"63013993016",
"63013993017"
]
},
{
  "part_name": "Dishwasher Filter W10872845",
  "part_number": "PS11759673",
  "manufacturer": "Kenmore",
  "price": "50.44",
  "description": "This filter works with the water pump in your dishwasher. It prevents debris from entering the pump and causing damage. As a result, the filter can occasionally become clogged or damaged, and will need to be replaced. A good indication of a damaged filter is if your dishwasher is not draining or cleaning the dishes properly. This filter has a gray plastic top and bottom that are approximately 5 inches in diameter. This is a genuine OEM part that comes directly from the manufacturer. To replace the filter, simply turn it counterclockwise to unlock, and then screw in the new filter",
  "rating": "99",
  "troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Not draining | Not drying dishes properly | Leaking This part works with the following products: Dishwasher. Part# W10872845 replaces these: AP6030094, 8579307, W10056425, W10056426, W10142911, W10234631, W10300746, W10393351, W10393352, W10393354, W10425171, W10455262, W10455263, W10465373, W10465374, W10465375, W10465377, W10465378, W10465379, W10693534 ... Show more , W10789806, W10789814, WPW10693534 Show less Back to Top",
  "review_count": "33",
  "appliance": "dishwasher",
  "compatible_models": [
    "2212413N414",
    "2213092N413",
```

"2213099N413",
"2213222N414",
"2213223N414",
"2213229N414",
"2213479N413",
"2213809N710",
"2214523N611",
"2214545N711",
"2214715N710",
"2214792N512",
"2214793N512",
"2217383N710",
"2217389N710",
"66213032K112",
"66512093K210",
"66512413N410",
"66512413N411",
"66512413N412",
"66512413N413",
"66512723K310",
"66512723K311",
"66512762K312",
"66512763K312",
"66512763K313",
"66512769K312",
"66512769K313",

```
"66512772K312",  
"66512772K313"  
]  
,  
{  
  "part_name": "Dishwasher Filter 5304506525",  
  "part_number": "PS11770489",  
  "manufacturer": "Kenmore",  
  "price": "21.60",  
  "description": "This filter is for dishwashers.\r\n\r\nThe filter removes food particles and  
debris from the water to prevent the drain from clogging.\r\n\r\nFollow the instructions in  
the manual when installing this part.",  
  "rating": "100",  
  "troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes  
properly | Not draining | Noisy This part works with the following products: Dishwasher.  
Part# 5304506525 replaces these: AP6036340, 154252401 Back to Top",  
  "review_count": "1",  
  "appliance": "dishwasher",  
  "compatible_models": [  
    "004621710A",  
    "004621711A",  
    "58714000100",  
    "58714000101",  
    "58714000102",  
    "58714001990",  
    "58714001991",  
    "58714001992",
```

"58714001993",
"58714002990",
"58714002991",
"58714002992",
"58714002993",
"58714003100",
"58714008001",
"58714008002",
"58714008003",
"58714009100",
"58714009101",
"58714009102",
"58714012400",
"58714012401",
"58714012402",
"58714012403",
"58714012404",
"58714012405",
"58714012406A",
"58714012407A",
"58714012408A",
"58714012409B"

]

},

{

"part_name": "Soil Trap 5304506518",

"part_number": "PS11770485",
"manufacturer": "Kenmore",
"price": "17.14",
"description": "Dishwasher Filter",
"rating": "90",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher. Part# 5304506518 replaces these: AP6036337, 154252702 Back to Top",

"review_count": "4",
"appliance": "dishwasher",
"compatible_models": [

"004621710A",
"004621711A",
"58714022200A",
"58714023200A",
"58714024200A",
"58714028200A",
"58714029200A",
"58715202800",
"58715202801",
"58715202802",
"58715202803A",
"58715203800",
"58715203801",
"58715203802",
"58715203803A",
"58715313000A",

"58715372100A",
"58715372100B",
"58715373100A",
"58715373100B",
"58715378100A",
"58715378100B",
"58715379100A",
"58715379100B",
"58715382100A",
"58715382100B",
"58715383100A",
"58715383100B",
"58715389100A",
"58715389100B"

]

},

{

"part_name": "HOSE-DRAIN 00668108",

"part_number": "PS8732952",

"manufacturer": "Kenmore",

"price": "30.43",

"description": "",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Not draining
This part works with the following products: Dishwasher. Part# 00668108 replaces these:
AP4339801, 668108 Back to Top",

"review_count": "3",

"appliance": "dishwasher",

"compatible_models": [

"63013902010",

"63013902011",

"63013903010",

"63013903011",

"63013909010",

"63013909011",

"63013909012",

"63013912010",

"63013912011",

"63013913010",

"63013913011",

"63013919010",

"63013919011",

"63013919012",

"63013952010",

"63013952011",

"63013953010",

"63013953011",

"63013959010",

"63013959011",

"63077932010",

"63077932011",

"63077933010",

"63077933011",

"63077942011",

"63077943011",

"DF251760",

"DWHD410GFM",

"DWHD410GFM-53",

"DWHD410GPR"

]

},

{

"part_name": "Dishwasher Drain Hose AEM69493808",

"part_number": "PS11760658",

"manufacturer": "LG",

"price": "73.58",

"description": "This corrugated drain hose assembly directs wastewater from your dishwasher to the household drainage system. Positioned at the rear of the unit, it connects the pump to the sink drain or garbage disposal. If the hose becomes damaged or punctured, you may observe water leakage beneath the dishwasher or standing water within it. Please keep in mind that this genuine OEM replacement part is sold separately from the drain pump.",

"rating": "95",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Not draining
This part works with the following products: Dishwasher. Part# AEM69493808 replaces these: AP6028364, AEM69493805 Back to Top",

"review_count": "8",

"appliance": "dishwasher",

"compatible_models": [

"14693",

"14697",

"72214697610",
"D1426DB1",
"D1426TB1",
"D1438DB",
"D1471BB1",
"D1471DB1",
"D1471DBK",
"D1471TB",
"D1471TB1",
"D1471TBK",
"D1471WB1",
"D1472TB1",
"D1475TUR1",
"D1539TU",
"D15ASTUL",
"LDF7061ST",
"LDF7551BB",
"LDF7551ST",
"LDF7551WH",
"LDF7551WW",
"LDF7561ST",
"LDF7774BB",
"LDF7774BD",
"LDF7774ST",
"LDF7774WW",
"LDF8072ST",

```
"LDF8574ST",  
"LDF8764ST"  
]  
},  
{  
  "part_name": "CONDUIT MID BLASTER Assembly WD21X20309",  
  "part_number": "PS11729194",  
  "manufacturer": null,  
  "price": "48.01",
```

"description": "This middle conduit assembly, also known as the middle spray arm water supply tube, is an authentic OEM replacement part designed for dishwashers. It is a gray, plastic tube that connects the main water supply line to the middle spray arm. The conduit ensures that sufficient water is released for thorough and efficient cleaning while the dishwasher is running. If the conduit assembly is damaged or faulty, there will be little to no water released during the wash cycle and you may also notice water leaking from the dishwasher. It is important to replace this part promptly to ensure the efficient running of your dishwasher.",

```
"rating": "100",
```

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher. Back to Top",

```
"review_count": "8",
```

```
"appliance": "dishwasher",
```

```
"compatible_models": [  
  "CDT706P2M4S1",  
  "CDT706P2M5S1",  
  "CDT765SSF0SS",  
  "CDT765SSF1SS",  
  "CDT765SSF7SS",
```

"CDT800P2N0S1",
"CDT800P2N2S1",
"CDT800P2N3S1",
"CDT800P2N4S1",
"CDT800P2N5S1",
"CDT805M5N0S5",
"CDT805M5N2S5",
"CDT805M5N3S5",
"CDT805M5N4S5",
"CDT805P2N0S1",
"CDT805P2N1S1",
"CDT805P2N2S1",
"CDT805P2N3S1",
"CDT805P2N4S1",
"CDT805P2N5S1",
"CDT805P2N8S1",
"CDT835SMJ0DS",
"CDT835SMJ2DS",
"CDT835SMJ4DS",
"CDT835SMJ5DS",
"CDT835SSJ0SS",
"CDT835SSJ2SS",
"CDT835SSJ4SS",
"CDT835SSJ5SS",
"CDT836P2M4S1"

]

```
},
```

```
{
```

```
  "part_name": "HOSE-DRAIN 00744881",
```

```
  "part_number": "PS8737004",
```

```
  "manufacturer": null,
```

```
  "price": "24.83",
```

```
  "description": "",
```

```
  "rating": "84",
```

```
  "troubleshooting_tips": "This part fixes the following symptoms: Leaking | Not draining  
This part works with the following products: Dishwasher. Part# 00744881 replaces these:  
AP5691300, 744881 Back to Top",
```

```
  "review_count": "5",
```

```
  "appliance": "dishwasher",
```

```
  "compatible_models": [
```

```
    "DWHD440MFP",
```

```
    "SHE53T52UC",
```

```
    "SHE53T55UC",
```

```
    "SHE53T56UC",
```

```
    "SHE53TF2UC",
```

```
    "SHE53TF5UC",
```

```
    "SHE53TF6UC",
```

```
    "SHE53TL2UC",
```

```
    "SHE65T52UC",
```

```
    "SHE65T55UC",
```

```
    "SHE65T56UC",
```

```
    "SHE68T52UC",
```

```
    "SHE68T55UC",
```

```
"SHE68T56UC",
"SHE68TL5UC",
"SHE7PT52UC",
"SHE7PT55UC",
"SHE7PT56UC",
"SHE863WF2N",
"SHE863WF5N",
"SHE863WF6N",
"SHE878WD2N",
"SHE878WD5N",
"SHE878WD6N",
"SHE8PT55UC",
"SHEM63W52N",
"SHEM63W55N",
"SHEM63W56N",
"SHEM78W52N",
"SHEM78W55N"
]
},
{
  "part_name": "Sump Drain Hose 00645149",
  "part_number": "PS8730294",
  "manufacturer": "Kenmore",
  "price": "19.26",
  "description": "",
  "rating": "100",
```

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# 00645149 replaces these: AP4339847, 645149 Back to Top",

"review_count": "2",

"appliance": "dishwasher",

"compatible_models": [

"63013902010",

"63013902011",

"63013903010",

"63013903011",

"63013909010",

"63013909011",

"63013909012",

"63013912010",

"63013912011",

"63013913010",

"63013913011",

"63013919010",

"63013919011",

"63013919012",

"S36KMK12UC",

"S36KMK12UC-05",

"S36KMK15UC",

"S36KMK15UC-05",

"S36KMK16UC",

"S36KMK16UC-05",

"S46KMK12UC",

"S46KMK12UC-05",

"S46KMK15UC",

"S46KMK15UC-05",

"S46KMK16UC",

"S46KMK16UC-05",

"SHE3AR52UC",

"SHE3AR52UC/06",

"SHE3AR52UC/07",

"SHE3AR55UC"

]

},

{

"part_name": "Drain Hose 8269144A",

"part_number": "PS2358130",

"manufacturer": "Kenmore",

"price": "31.57",

"description": "This drain hose is 6 and 1/2 feet.",

"rating": "99",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Not draining | Not cleaning dishes properly This part works with the following products: Dishwasher. Part# 8269144A replaces these: AP4399659, 1489097, 8269144 Back to Top",

"review_count": "21",

"appliance": "dishwasher",

"compatible_models": [

"2212413N414",

"2213092N413",

"2213099N413",

"2213222N414",
"2213223N414",
"2213229N414",
"2213809N710",
"2214545N711",
"2214715N710",
"2214793N512",
"2217383N710",
"2217389N710",
"66213032K112",
"66213273K112",
"665110739120",
"665110739130",
"665110739140",
"665110739190",
"66512093K210",
"66512413N410",
"66512413N411",
"66512413N412",
"66512413N413",
"66512723K310",
"66512723K311",
"66512762K312",
"66512763K312",
"66512763K313",
"66512769K312",

```
"66512769K313"
]
},
{
  "part_name": "Drain Hose WPW10545278",
  "part_number": "PS11756139",
  "manufacturer": "Kenmore",
  "price": "48.17",
  "description": "This part is used to drain water from your dishwasher.",
  "rating": "83",
  "troubleshooting_tips": "This part fixes the following symptoms: Leaking | Not draining | Not cleaning dishes properly This part works with the following products: Dishwasher. Part# WPW10545278 replaces these: AP6022802, W10137608, W10193583, W10195750, W10418848, W10418849, W10481093, W10545278, W10688890, WPW10545278VP Back to Top",
  "review_count": "7",
  "appliance": "dishwasher",
  "compatible_models": [
    "2212413N414",
    "2213092N413",
    "2213099N413",
    "2213222N414",
    "2213223N414",
    "2213229N414",
    "2213479N413",
    "2213809N710",
    "2214523N611",
```

"2214545N711",
"2214715N710",
"2214792N512",
"2214793N512",
"2217383N710",
"2217389N710",
"66213032K112",
"66213273K112",
"66512093K210",
"66512413N410",
"66512413N411",
"66512413N412",
"66512413N413",
"66512723K310",
"66512723K311",
"66512762K312",
"66512763K312",
"66512763K313",
"66512769K312",
"66512769K313",
"66512772K311"

]

},

{

"part_name": "Water Supply Feed Tube 5304507087",

"part_number": "PS11770593",

"manufacturer": "Kenmore",

"price": "55.15",

"description": "Water is supplied to the upper arm through this tube via the pump assembly.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# 5304507087 replaces these: AP6037539, 154464101, 154824201 Back to Top",

"review_count": "2",

"appliance": "dishwasher",

"compatible_models": [

"004621710A",

"004621711A",

"58714022200A",

"58714023200A",

"58714024200A",

"58714028200A",

"58714029200A",

"58714102800",

"58715102800",

"58715102801",

"58715103800",

"58715103801",

"58715104800",

"58715104801",

"58715109800",

"58715109801",

"58715202800",
"58715202801",
"58715202802",
"58715202803A",
"58715203800",
"58715203801",
"58715203802",
"58715203803A",
"58715212900",
"58715213900",
"58715214900",
"58715219900",
"58715252400",
"58715252401"

]

},

{

"part_name": "CONDUIT MID Assembly WD22X10094",

"part_number": "PS6883615",

"manufacturer": null,

"price": "24.66",

"description": "",

"rating": "99",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher. Part# WD22X10094 replaces these: WD22X10090 Back to Top",

"review_count": "11",

"appliance": "dishwasher",

"compatible_models": [

"ADT521PGF0BS",

"ADT521PGF0WS",

"ADT521PGF2BS",

"ADT521PGF2WS",

"ADT521PGF4BS",

"ADT521PGF4WS",

"ADT521PGF6BS",

"ADT521PGF6WS",

"ADT521PGJ0BS",

"ADT521PGJ0WS",

"ADT521PGJ2BS",

"ADT521PGJ2WS",

"ADT521PGJBS",

"ADT521PGJWS",

"DDT575SGF2BB",

"DDT575SGF2WW",

"DDT575SGF4BB",

"DDT575SGF4WW",

"DDT575SGF5BB",

"DDT575SGF5WW",

"DDT575SGF6BB",

"DDT575SGF6WW",

"DDT575SGF7BB",

"DDT575SGF7WW",

```
"DDT575SGF8BB",  
"DDT575SGF8WW",  
"DDT575SMF2ES",  
"DDT575SMF4ES",  
"DDT575SMF5ES",  
"DDT575SMF6ES"
```

```
]
```

```
},
```

```
{
```

```
"part_name": "Dishwasher Drain Hose 807117001",
```

```
"part_number": "PS9494138",
```

```
"manufacturer": "Kenmore",
```

```
"price": "26.66",
```

```
"description": "If your dishwasher is leaking or not draining properly, you may need to  
replace the drain hose. The drain hose connects to the pump located below the lower spray  
arm and aids in proper dishwasher drainage. This white and black plastic hose is 7.5 feet  
long. For this repair, you will need either a 1/4-inch or 5/16-inch nut driver, depending on  
your model. You will need to remove the lower access panel on your dishwasher to  
complete this repair; it is often easier to remove the dishwasher from the cabinet to do so.  
Be sure to disconnect the dishwasher from both the power and water supply before  
completing this repair.",
```

```
"rating": "100",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Not draining |  
Not cleaning dishes properly This part works with the following products: Dishwasher.  
Part# 807117001 replaces these: AP5806794, 154369601, 154411001, 154411002,  
154411003, 154525301, 154606701, 154753201, 5304435286 Back to Top",
```

```
"review_count": "20",
```

```
"appliance": "dishwasher",
```

```
"compatible_models": [
```

"004621710A",
"004621711A",
"58714000101",
"58714000102",
"58714001992",
"58714001993",
"58714002992",
"58714002993",
"58714003100",
"58714008002",
"58714008003",
"58714009101",
"58714009102",
"58714012400",
"58714012401",
"58714012402",
"58714012403",
"58714012404",
"58714012405",
"58714012406A",
"58714012407A",
"58714012408A",
"58714012409B",
"58714012410B",
"58714012411B",
"58714012412B",


```
"58714012413B",
"58714012414B",
"58714012416B",
"58714013400"
]
},
{
  "part_name": "TOP MOUNT BRACKETS 5001DD4001B",
  "part_number": "PS3655985",
  "manufacturer": "LG",
  "price": "37.90",
  "description": "",
  "rating": "70",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Back
to Top",
  "review_count": "4",
  "appliance": "dishwasher",
  "compatible_models": [
    "14693",
    "14697",
    "72214697610",
    "D1425TB",
    "D1426DB1",
    "D1426TB",
    "D1426TB1",
    "D1435BB",
```

```
"D1435TB",  
"D1435WB",  
"D1436TB",  
"D1438DB",  
"D1438TB",  
"D1470BB",  
"D1470TB",  
"D1470TBR",  
"D1470WB",  
"D1471BB",  
"D1471BB1",  
"D1471DB1",  
"D1471DBK",  
"D1471TB",  
"D1471TB1",  
"D1471TBK",  
"D1471WB",  
"D1471WB1",  
"D1472TB",  
"D1472TB1",  
"D1475TUR1",  
"D1539TU"  
]  
,  
{  
  "part_name": "Spray Arm Tube Hanger WP8268349",
```

"part_number": "PS11745439",

"manufacturer": "Kenmore",

"price": "15.72",

"description": "",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher. Part# WP8268349 replaces these: 8268349 Back to Top",

"review_count": "1",

"appliance": "dishwasher",

"compatible_models": [

"66513212K901",

"66513212K902",

"66513213K900",

"66513213K901",

"66513213K902",

"66513219K901",

"66513219K902",

"66513752K600",

"66513752K601",

"66513752K602",

"66513752K603",

"66513753K600",

"66513753K601",

"66513753K602",

"66513753K603",

"66513754K600",

"66513754K601",

"66513754K602",

"66513754K603",

"66513759K600",

"66513759K601",

"66513759K602",

"66513759K603",

"66513762K600",

"66513762K601",

"66513762K602",

"66513762K603",

"66513763K600",

"66513763K601",

"66513763K602"

]

},

{

"part_name": "MOUNTING BRACKET 00611955",

"part_number": "PS8727456",

"manufacturer": "Kenmore",

"price": "6.73",

"description": "",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 00611955 replaces these: AP4355306, 611955 Back to Top",

"review_count": "1",

"appliance": "dishwasher",

"compatible_models": [

"63013902010",

"63013902011",

"63013903010",

"63013903011",

"63013909010",

"63013909011",

"63013909012",

"63013912010",

"63013912011",

"63013913010",

"63013913011",

"63013919010",

"63013919011",

"63013919012",

"DWHD410GFM-53",

"DWHD410GPR-53",

"DWHD630GCM",

"DWHD630GCP",

"DWHD630GPR",

"S36KMK12UC",

"S36KMK12UC-05",

"S36KMK15UC",

"S36KMK15UC-05",

"S36KMK16UC",

```
"S36KMK16UC-05",
"S46KMK12UC",
"S46KMK12UC-05",
"S46KMK15UC",
"S46KMK15UC-05",
"S46KMK16UC"
]
},
{
  "part_name": "BRACKET W10837623",
  "part_number": "PS11727941",
  "manufacturer": "Kenmore",
  "price": "22.20",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#
W10837623 replaces these: W10195690 Back to Top",
  "review_count": "2",
  "appliance": "dishwasher",
  "compatible_models": [
    "2213222N414",
    "2213223N414",
    "2213229N414",
    "2214523N611",
    "2214545N711",
    "2214715N710",
```

"66512762K312",
"66512763K312",
"66512763K313",
"66512769K312",
"66512769K313",
"66512772K312",
"66512772K313",
"66512772K314",
"66512773K312",
"66512773K313",
"66512773K314",
"66512774K312",
"66512774K313",
"66512776K311",
"66512776K312",
"66512776K314",
"66512779K312",
"66512779K313",
"66512779K314",
"66512782K312",
"66512782K313",
"66512783K311",
"66512783K312",
"66512783K313"

]

},

```
{  
  "part_name": "Heating Element Support Bracket 154465101",  
  "part_number": "PS975933",  
  "manufacturer": "Kenmore",  
  "price": "11.26",  
  "description": "Sold individually.",  
  "rating": null,  
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#  
154465101 replaces these: AP3773586, 1061898 Back to Top",  
  "review_count": null,  
  "appliance": "dishwasher",  
  "compatible_models": [  
    "004621710A",  
    "004621711A",  
    "58714012407A",  
    "58714012408A",  
    "58714012409B",  
    "58714012410B",  
    "58714012411B",  
    "58714012412B",  
    "58714012413B",  
    "58714012414B",  
    "58714012416B",  
    "58714013408A",  
    "58714013409A",  
    "58714013410B",  
  ]  
}
```



```
"58714013411B",
"58714013412B",
"58714013413B",
"58714013414B",
"58714013415B",
"58714013416B",
"58714013417B",
"58714014407A",
"58714014408A",
"58714014409B",
"58714014410B",
"58714014411B",
"58714014412B",
"58714014413B",
"58714019407A",
"58714019408A"
]
},
{
  "part_name": "Side Mounting Bracket Kit 8212560",
  "part_number": "PS1487167",
  "manufacturer": "Kenmore",
  "price": "18.64",
  "description": "This mounting kit can be used on solid surface countertops.",
  "rating": "98",
```

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 8212560 replaces these: AP3953705, 1201084, 8212560 Back to Top",

"review_count": "7",

"appliance": "dishwasher",

"compatible_models": [

"2212413N414",

"2213092N413",

"2213099N413",

"2213222N414",

"2213223N414",

"2213229N414",

"2213479N413",

"2213804N710",

"2213809N710",

"2214523N611",

"2214545N711",

"2214715N710",

"2214792N512",

"2214793N512",

"2217383N710",

"2217389N710",

"66213032K112",

"66213273K112",

"66512093K210",

"66512413N410",

"66512413N411",

"66512413N412",

"66512413N413",

"66512723K310",

"66512723K311",

"66512762K312",

"66512762K313",

"66512763K312",

"66512763K313",

"66512769K312"

]

},

{

"part_name": "Tine Bracket 5304506508",

"part_number": "PS11770479",

"manufacturer": "Kenmore",

"price": "8.08",

"description": "This bracket is designed for use in dishwashers, and it is a genuine replacement part. It is used in the upper dishrack to hold tines in place. This part is made out of plastic. Please note it is sold individually, therefore you will need to order the quantity you require. NOTE: This part has been updated by the manufacture but will still work like the original.",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 5304506508 replaces these: AP6038444, 154242001, 154242002, 154242003, 154242004 Back to Top",

"review_count": "1",

"appliance": "dishwasher",

"compatible_models": [

"004621710A",
"004621711A",
"58715202800",
"58715202801",
"58715202802",
"58715202803A",
"58715203800",
"58715203801",
"58715203802",
"58715203803A",
"58715313000A",
"58715372100A",
"58715372100B",
"58715373100A",
"58715373100B",
"58715378100A",
"58715378100B",
"58715379100A",
"58715379100B",
"58715382100A",
"58715382100B",
"58715383100A",
"58715383100B",
"58715389100A",
"58715389100B",
"58715392100A",

"58715393100A",

"58715399100A",

"804655850A",

"804655851A"

]

},

{

"part_name": "Countertop Bracket WD01X21740",

"part_number": "PS11700868",

"manufacturer": null,

"price": "7.50",

"description": "This mounting bracket is manufactured to secure your dishwasher to your countertop. Mounting brackets should be installed so the dishwasher doesn't tip forward. You can fit the bracket to either the cabinet or countertop. This part is about 3 inches long and is made of metal. This kit does not include the screws, please order screws separately if necessary.",

"rating": "96",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WD01X21740 replaces these: AP5981620, WD01X10598 Back to Top",

"review_count": "5",

"appliance": "dishwasher",

"compatible_models": [

"ADT521PGF0BS",

"ADT521PGF0WS",

"ADT521PGF2BS",

"ADT521PGF2WS",

"ADT521PGF4BS",

"ADT521PGF4WS",
"ADT521PGF6BS",
"ADT521PGF6WS",
"ADT521PGJ0BS",
"ADT521PGJ0WS",
"ADT521PGJ2BS",
"ADT521PGJ2WS",
"ADT521PGJBS",
"ADT521PGJWS",
"CDT706P2M4S1",
"CDT706P2M5S1",
"CDT725SSF0SS",
"CDT725SSF2SS",
"CDT725SSF4SS",
"CDT725SSF6SS",
"CDT725SSF7SS",
"CDT765SSF0SS",
"CDT765SSF1SS",
"CDT765SSF7SS",
"CDT800P2N0S1",
"CDT800P2N2S1",
"CDT800P2N3S1",
"CDT800P2N4S1",
"CDT800P2N5S1",
"CDT805M5N0S5"

]

```
},
{
  "part_name": "Mounting Bracket 00619985",
  "part_number": "PS8728568",
  "manufacturer": "Kenmore",
  "price": "8.67",
  "description": "Sold individually.",
  "rating": "60",
  "troubleshooting_tips": "This part fixes the following symptoms: Door latch failure This part works with the following products: Dishwasher. Part# 00619985 replaces these: AP4538351, 00605007, 00628371, 605007, 619985, 628371 Back to Top",
  "review_count": "6",
  "appliance": "dishwasher",
  "compatible_models": [
    "63013952010",
    "63013952011",
    "63013953010",
    "63013953011",
    "63013959010",
    "63013959011",
    "63016302406",
    "63016303406",
    "63016304406",
    "63016309406",
    "63077932010",
    "63077932011",
    "63077933010",
```

```
"63077933011",
"63077942011",
"63077943011",
"DF251760",
"DWHD410GFM",
"DWHD410GPR",
"DWHD410HFM",
"DWHD410HPR",
"DWHD410JFM",
"DWHD410JFP",
"DWHD410JPR",
"DWHD43CF",
"DWHD43CS",
"DWHD440MFM",
"DWHD440MFP",
"DWHD440MPR",
"DWHD44EF"
]
},
{
  "part_name": "Mounting Bracket WP8269145",
  "part_number": "PS11745496",
  "manufacturer": "Kenmore",
  "price": "10.03",
```

"description": "The mounting bracket is sold individually, without screws. This part secures the upper side of the dishwasher to the underside of the counter or cabinet to prevent the dishwasher from moving, shaking, or tilting forward. The bracket is made

entirely of metal. It is recommended to check all brackets, if applicable, because they often wear at the same rate and both may need to be replaced. This is an OEM part that is sourced from the authentic manufacturer. Tools needed are a pair of needle nose pliers and a screwdriver.",

"rating": "91",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close | Leaking This part works with the following products: Dishwasher. Part# WP8269145 replaces these: AP6012289, 8269145, WP8269145VP Back to Top",

"review_count": "13",

"appliance": "dishwasher",

"compatible_models": [

"2212413N414",

"2213092N413",

"2213099N413",

"2213222N414",

"2213223N414",

"2213229N414",

"2213479N413",

"2213809N710",

"2214523N611",

"2214545N711",

"2214715N710",

"2214792N512",

"2214793N512",

"2217383N710",

"2217389N710",

"66213032K112",

"66213273K112",

"665110739120",

"665110739130",

"665110739140",

"665110739190",

"66512093K210",

"66512413N410",

"66512413N411",

"66512413N412",

"66512413N413",

"66512723K310",

"66512723K311",

"66512762K312",

"66512762K313"

]

},

{

"part_name": "Spring Linkage 154325201",

"part_number": "PS420766",

"manufacturer": "Kenmore",

"price": "31.41",

"description": "This linkage attaches to the door spring.",

"rating": "80",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close This part works with the following products: Dishwasher. Part# 154325201 replaces these: AP2109352, 419477 Back to Top",

"review_count": "2",

"appliance": "dishwasher",

"compatible_models": [

"58714000100",

"58714000101",

"58714000102",

"58714001990",

"58714001991",

"58714001992",

"58714001993",

"58714002990",

"58714002991",

"58714002992",

"58714002993",

"58714003100",

"58714008001",

"58714008002",

"58714008003",

"58714009100",

"58714009101",

"58714009102",

"58714012400",

"58714012401",

"58714012402",

"58714012403",

"58714012404",

"58714012405",

"58714012406A",

"58714012407A",

"58714012408A",

"58714012409B",

"58714012410B",

"58714012411B"

]

},

{

"part_name": "Door Hinge Cable WD01X10393",

"part_number": "PS2345660",

"manufacturer": null,

"price": "15.43",

"description": "This part is the replacement door hinge cable for your dishwasher. The door hinge cable connects the door spring to the door hinge, and allows the door to open in a controlled fashion. If you open your dishwasher and the door drops down quickly, your door hinge cable may need to be replaced. Be sure to disconnect the water and power sources from the dishwasher before you begin this repair. The door hinge cable is sold individually.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close This part works with the following products: Dishwasher. Part# WD01X10393 replaces these: AP4368163, 1475199, WD01X10235 Back to Top",

"review_count": "9",

"appliance": "dishwasher",

"compatible_models": [

"CDW9380N00SS",

"CDW9380N20SS",

"CDWT280V00SS",
"CDWT280V05SS",
"CDWT280V50SS",
"CDWT980R10SS",
"CDWT980R30SS",
"CDWT980V00SS",
"CDWT980V05SS",
"CDWT980V50SS",
"EDWF800P00BB",
"EDWF800P00WW",
"EDWF860P00SS",
"GDWT100R00BB",
"GDWT100R00WW",
"GDWT100R05BB",
"GDWT100R05WW",
"GDWT100R10BB",
"GDWT100R10WW",
"GDWT100R30BB",
"GDWT100R30WW",
"GDWT160R00SS",
"GDWT160R05SS",
"GDWT160R10SS",
"GDWT160R30SS",
"GDWT200R10BB",
"GDWT200R10WW",
"GDWT200R30BB",

"GDWT200R30WW",

"GDWT260R10SS"

]

},

{

"part_name": "Door Cable WD01X10569",

"part_number": "PS7320283",

"manufacturer": null,

"price": "13.07",

"description": "This part is the replacement door hinge cable for your dishwasher. The door hinge cable connects the door spring to the door hinge, and allows the door to drop down slowly when it is opened. If you open your dishwasher and the door drops down quickly, your door hinge cable may need to be replaced. Be sure to disconnect the water and power sources from the dishwasher before you begin this repair. The door hinge cable is sold individually.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure This part works with the following products: Dishwasher. Part# WD01X10569 replaces these: AP5670562 Back to Top",

"review_count": "6",

"appliance": "dishwasher",

"compatible_models": [

"ADT521PGF0BS",

"ADT521PGF0WS",

"ADT521PGF2BS",

"ADT521PGF2WS",

"ADT521PGF4BS",

"ADT521PGF4WS",

"ADT521PGF6BS",
"ADT521PGF6WS",
"ADT521PGJ0BS",
"ADT521PGJ0WS",
"ADT521PGJ2BS",
"ADT521PGJ2WS",
"ADT521PGJBS",
"ADT521PGJWS",
"CDT725SSF0SS",
"DDT575SGF0BB",
"DDT575SGF0WW",
"DDT575SGF2BB",
"DDT575SGF2WW",
"DDT575SGF4BB",
"DDT575SGF4WW",
"DDT575SGF5BB",
"DDT575SGF5WW",
"DDT575SGF6BB",
"DDT575SGF6WW",
"DDT575SGF7BB",
"DDT575SGF7WW",
"DDT575SGF8BB",
"DDT575SGF8WW",
"DDT575SMF0ES"

]

},

```
{  
  "part_name": "Dishwasher Door Cable 00610087",  
  "part_number": "PS8727128",  
  "manufacturer": "Kenmore",  
  "price": "13.01",  
  "description": "This door cable is for dishwashers. Door cable helps balance and  
support the weight of the door as it opens and closes.",  
  "rating": "80",  
  "troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door  
won't close This part works with the following products: Dishwasher. Part# 00610087  
replaces these: AP5263691, 610087 Back to Top",  
  "review_count": "2",  
  "appliance": "dishwasher",  
  "compatible_models": [  
    "63013909012",  
    "63013919012",  
    "DWHD440MFP",  
    "SGI33E05TR",  
    "SGI33E15TR",  
    "SGI33E22EU",  
    "SGI33E24EU",  
    "SGI33E25EU",  
    "SGI33E35EU",  
    "SGI33E45EU",  
    "SGI43E25AU",  
    "SGI43E45EU",  
    "SGI43E55EU",  
  ]  
}
```



```
"SGI43E75EU",  
"SGI45E05SA",  
"SGI45E12GB",  
"SGI45E12UK",  
"SGI45E15GB",  
"SGI45E15UK",  
"SGI45E16GB",  
"SGI45E16UK",  
"SGI45E25EU",  
"SGI45M55EU",  
"SGI45N05EU",  
"SGI45N15EU",  
"SGI45N25EU",  
"SGI46E05EU",  
"SGI46E25EU",  
"SGI46E35EU",  
"SGI46E42EP"
```

```
]
```

```
},
```

```
{
```

```
"part_name": "Door Spring Linkage WP912653",
```

```
"part_number": "PS11746857",
```

```
"manufacturer": null,
```

```
"price": "11.09",
```

```
"description": "The door spring retainer is used in dishwashers. It attaches and holds the  
door spring to the support frame. If your dishwashers door keeps crashing, or both the door  
and dish rack are falling apart, then replacing the door spring retainer, which provides more
```

flexibility, could be the solution to your symptoms. Before starting this project make sure to unplug the dishwasher as well as shut off the water supply before installing the spring retainer. Tools are not needed for this easy repair. Refer to the manufacturers installation instructions for best results and accuracy.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close | Leaking This part works with the following products: Dishwasher. Part# WP912653 replaces these: AP6013630, 9-12653, 912653 Back to Top",

"review_count": "16",

"appliance": "dishwasher",

"compatible_models": [

"ADW662EAB",

"ADW662EAB-PADW662EAB0",

"ADW662EAC",

"ADW662EAC-PADW662EAC0",

"ADW662EAS",

"ADW662EAW",

"ADW662EAW-PADW662EAW0",

"ADW862EAB",

"ADW862EAC",

"ADW862EAS",

"ADW862EAW",

"CDB3100AWE",

"CDB3100AWT",

"CDB3100AWX",

"CDB6100AWE",

"CDB6100AWN",

```
"CDB6100AWX",  
"CDC400B",  
"CDC450B",  
"CDC5J",  
"CDC610B",  
"CDU20J",  
"CDU250B",  
"CDU250V",  
"CDU2J",  
"CDU2J3",  
"CDU400B",  
"CDU450B",  
"CDU450V",  
"CDU510B"  
]  
,  
{  
  "part_name": "Door Cable Link WP99003446",  
  "part_number": "PS11747772",  
  "manufacturer": null,  
  "price": "11.13",
```

```
  "description": "This is a part for your dishwasher. The door cable link helps to keep the  
door steady and give support to the weight of the door when it is being opened or closed. If  
you notice the door latch has failed or the door is not closing properly, this might indicate a  
need to have the door cable link replaced. To perform this repair, you will start by turning  
the power off from the appliance. You will need to pull the unit out of installation. To access  
the cables, you will need to remove the side panel. You should be able to see the cables  
underneath the panel once removed.",
```

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close This part works with the following products: Dishwasher. Part# WP99003446 replaces these: AP6014532, 99002605, 99002606, 99003446 Back to Top",

"review_count": "6",

"appliance": "dishwasher",

"compatible_models": [

"ADB1200AWB",

"ADB1200AWQ",

"ADB1200AWS",

"ADB1200AWW",

"ADB1500AWB",

"ADB1500AWB0",

"ADB1500AWB1",

"ADB1500AWB10",

"ADB1500AWB2",

"ADB1500AWB3",

"ADB1500AWB37",

"ADB1500AWB41",

"ADB1500AWB46",

"ADB1500AWQ",

"ADB1500AWQ0",

"ADB1500AWQ1",

"ADB1500AWQ10",

"ADB1500AWQ2",

"ADB1500AWQ3",

"ADB1500AWQ37",

"ADB1500AWQ41",
"ADB1500AWQ46",
"ADB1500AWS",
"ADB1500AWS0",
"ADB1500AWS1",
"ADB1500AWS10",
"ADB1500AWS2",
"ADB1500AWS3",
"ADB1500AWS37",
"ADB1500AWS41"

]

},

{

"part_name": "Hinge Arm Link WD14X10009",
"part_number": "PS259336",
"manufacturer": "Kenmore",
"price": "8.54",

"description": "The hinge link on your dishwasher connects the spring to the dishwasher door hinge. If the hinge link becomes cracked or damaged, you may not be able to shut or lock your dishwasher door properly. In this case, you will need to replace the hinge link. Pull out your dishwasher to inspect the hinge and spring, if the link is broken, it may be disconnected and on the ground already. If not, you can remove the hinge arm link by simply disconnecting it from the hinge and spring, then replacing it with the new part. The hinge arm link is a small piece of white plastic about an inch and a half long. It is sold individually, and is an OEM part from the manufacturer.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close This part works with the following products: Dishwasher. Part# WD14X10009 replaces these: AP2039321, 270839 Back to Top",

```
"review_count": "9",  
"appliance": "dishwasher",  
"compatible_models": [  
  "36314031000",  
  "36314031001",  
  "36314032000",  
  "36314032001",  
  "36314038000",  
  "36314038001",  
  "36314039000",  
  "36314039001",  
  "36314061791",  
  "36314071791",  
  "36314071792",  
  "36314071793",  
  "36314071794",  
  "36314072791",  
  "36314072792",  
  "36314072793",  
  "36314072794",  
  "36314072795",  
  "36314074791",  
  "36314074792",  
  "36314074793",  
  "36314074794",  
  "36314075791",
```

"36314075792",

"36314075793",

"36314075794",

"36314081990",

"36314081991",

"36314081992",

"36314081993"

]

},

{

"part_name": "Friction Sleeve WP8268961",

"part_number": "PS11745488",

"manufacturer": "Kenmore",

"price": "7.49",

"description": "This part helps to keep your door quiet when it opens and closes.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close | Noisy This part works with the following products: Dishwasher. Part# WP8268961 replaces these: AP6012281, 8268961, WP8268961VP Back to Top",

"review_count": "34",

"appliance": "dishwasher",

"compatible_models": [

"2212413N414",

"2213092N413",

"2213099N413",

"2213479N413",

"2213804N710",

"2213809N710",
"2217383N710",
"2217389N710",
"66213013K112",
"66213014K112",
"66213019K112",
"66213023K112",
"66213032K112",
"66213033K112",
"66213043K112",
"66213044K112",
"66213049K112",
"66213273K112",
"66213282K112",
"66213289K112",
"66512093K210",
"66512413N410",
"66512413N411",
"66512413N412",
"66512413N413",
"66512723K310",
"66512723K311",
"66513002N510",
"66513002N511",
"66513003N510"

]


```
},
```

```
{
```

```
  "part_name": "Hinge Cable 4933DD3001B",
```

```
  "part_number": "PS3524406",
```

```
  "manufacturer": "LG",
```

```
  "price": "17.88",
```

```
  "description": "This dishwasher door hinge cable assembly connects the door to the spring. The door hinge cable and the door spring apply tension to the door to prevent it from dropping open too quickly. This part contains two plastic pieces which are approximately 2 inches in length by 3/4-inch in width, as well as a rope portion that measures approximately 8 inches in length. When beginning this repair, be sure to use caution when replacing the door hinge cable. The spring to which the door hinge cable attaches is under tension and could snap. This part is sold individually.",
```

```
  "rating": "100",
```

```
  "troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close This part works with the following products: Dishwasher. Part# 4933DD3001B replaces these: AP4511304, 4933DD3001A, 4933DD3001B Back to Top",
```

```
  "review_count": "27",
```

```
  "appliance": "dishwasher",
```

```
  "compatible_models": [
```

```
    "14693",
```

```
    "39232533",
```

```
    "D1401TB",
```

```
    "D1401TB1",
```

```
    "D1412TB",
```

```
    "D1414TB",
```

```
    "D1425TB",
```

```
    "D1426DB1",
```

```
"D1426TB",
"D1426TB1",
"D1435BB",
"D1435TB",
"D1435WB",
"D1436TB",
"D1438DB",
"D1438TB",
"D1454CFN",
"D1470BB",
"D1470TB",
"D1470TBR",
"D1470WB",
"D1471BB",
"D1471BB1",
"D1471DB1",
"D1471TB",
"D1471TB1",
"D1471TBK",
"D1471WB",
"D1471WB1",
"D1472TB"
]
},
{
  "part_name": "Door Balance Link Kit 8194001",
```

"part_number": "PS972325",

"manufacturer": "Kenmore",

"price": "33.09",

"description": "This part is a door balance link kit, also sometimes known as door cable or door spring cable kit, that helps support the door as it opens and closes by connecting to the dishwasher door hinges. The kit includes two door balance links and two door balance mounts with wheels, which will replace both the left and right sides. The only tool needed is a 5/16 nut driver. Before removing the existing kit, take note of how the door balance link kit is assembled for a smooth replacement process. It is recommended to check the door springs in case they need to be replaced as well.",

"rating": "98",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close | Noisy | Leaking This part works with the following products: Dishwasher. Part# 8194001 replaces these: AP3775412, 1059756, 8194001, 8194001, 8194001VP, 8270018, 8270021, 8270022, 8524474, 8535568, W10158291 Back to Top",

"review_count": "201",

"appliance": "dishwasher",

"compatible_models": [

"2213222N414",

"2213223N414",

"2213229N414",

"2214523N611",

"2214545N711",

"2214715N710",

"2214792N512",

"2214793N512",

"665110739120",

"665110739130",

"665110739140",

"665110739190",
"66512762K312",
"66512762K313",
"66512763K312",
"66512763K313",
"66512769K312",
"66512769K313",
"66512772K312",
"66512772K313",
"66512772K314",
"66512773K313",
"66512773K314",
"66512774K313",
"66512776K311",
"66512776K312",
"66512776K314",
"66512779K312",
"66512779K313",
"66512779K314"

]

},

{

"part_name": "Dishrack Assembly 3751DD1001J",
"part_number": "PS12075784",
"manufacturer": "LG",
"price": "202.50",

"description": "This is the lower dishrack assembly for various models of LG dishwashers. This dishrack is an OEM part that is designed to hold dishes and cutlery during the wash cycle of the dishwasher. This dishrack is made of a coated metal to prevent rusting, cracking, and peeling. However, over time and through further exposure to hot temperatures from the heating element, the coated material of the dishwasher rack can begin to peel, at which time it needs replacing. This dishrack comes as an individual part and does not come with any other parts or accessories, such as its accompanying cutlery basket.",

"rating": "94",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 3751DD1001J replaces these: AP6231085, 3751DD1001B, 3751DD1001C, MGR47998602
Back to Top",

"review_count": "3",

"appliance": "dishwasher",

"compatible_models": [

"14693",

"39232533",

"72214697610",

"D1425TB",

"D1426DB1",

"D1426TB",

"D1426TB1",

"D1436TB",

"D1438DB",

"D1438TB",

"D1471BB",

"D1471TB",

"D1471WB",

"D1472TB",

```
"D1472TB1",
"LDF6810ST-00",
"LDF7061ST",
"LDF7551BB",
"LDF7551ST",
"LDF7551WH",
"LDF7551WW",
"LDF7561ST",
"LDF7774BB",
"LDF7774BD",
"LDF7774ST",
"LDF7774WW",
"LDF8072ST",
"LDF8574ST",
"LDF8764ST",
"LDF8874ST"
]
},
{
  "part_name": "Silverware Basket with Lids WD28X10177",
  "part_number": "PS1016011",
  "manufacturer": null,
  "price": "31.74",
  "description": "This is a basket for washing flatware or silverware in your dishwasher.",
  "rating": "95",
```

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher. Part# WD28X10177 replaces these: AP3860905, 1168340, WD28X10048, WD28X10052, WD28X10079, WD28X10238, WD34X10294 Back to Top",

"review_count": "23",

"appliance": "dishwasher",

"compatible_models": [

"400910",

"400911",

"400912",

"400913",

"4070100",

"4070110",

"4070500",

"4070510",

"4070600",

"4070610",

"4070800",

"4070810",

"EDW2020F00BB",

"EDW2020F01BB",

"EDW2030F00WW",

"EDW2030F01WW",

"EDW2030F02WW",

"EDW2050F00CC",

"EDW2050F01CC",

"EDW2050F02CC",

"EDW2060F00SS",
"EDW2060F02SS",
"EDW3000G00BB",
"EDW3000G00CC",
"EDW3000G00WW",
"EDW3000G01BB",
"EDW3000G01CC",
"EDW3000G01WW",
"EDW3000G02BB",
"EDW3000G02CC"

]

},

{

"part_name": "Upper Dishrack with Wheels 5304475618",

"part_number": "PS2379463",

"manufacturer": "Kenmore",

"price": "123.64",

"description": "This dish rack includes the wheels. It is used in the dishwasher.",

"rating": "74",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 5304475618 replaces these: AP4508570, 5304484728 Back to Top",

"review_count": "6",

"appliance": "dishwasher",

"compatible_models": [

"58715412100A",

"58715413100A",


```
"58715423100A",
"FGHD2472PB0",
"FGHD2472PF0",
"FGHD2472PF1A",
"FGHD2472PW0",
"FGHD2491LB0",
"FGHD2491LW0",
"FPHD2491KF0"
]
},
{
  "part_name": "Lower Dishrack 5304475624",
  "part_number": "PS2379469",
  "manufacturer": "Kenmore",
  "price": "127.76",
  "description": "This lower rack does NOT include the wheels. Must be ordered separately.",
  "rating": "84",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 5304475624 replaces these: AP4508576 Back to Top",
  "review_count": "6",
  "appliance": "dishwasher",
  "compatible_models": [
    "58715423100A",
    "FGHD2472PB0",
    "FGHD2472PF0",
    "FGHD2472PF1A",
```

```
"FGHD2472PW0",
"FGHD2491LB0",
"FGHD2491LW0",
"FPHD2491KF0"
]
},
{
  "part_name": "Tine Holder 00418498",
  "part_number": "PS8712513",
  "manufacturer": "Kenmore",
  "price": "7.58",
  "description": "This plastic holder is also known as a tine clip, or a rack flip tine clip. It is used in the lower rack of a dishwasher, it is part of the rack assembly that allows to convert your rack to better the dishes you need washed. When you select the position you want the tines to be in, this clip hold the tines in place. This clip is designed to hold two tine rows in place. This tine clip is simple to install, you do not need any tools, it simply snaps into place on the dishrack.",
  "rating": "98",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 00418498 replaces these: AP3193592, 418498 Back to Top",
  "review_count": "7",
  "appliance": "dishwasher",
  "compatible_models": [
    "63016302400",
    "63016302401",
    "63016302402",
    "63016302403",
    "63016302404",
```

"63016302405",
"63016302406",
"63016303400",
"63016303401",
"63016303402",
"63016303403",
"63016303404",
"63016303405",
"63016303406",
"63016304400",
"63016304401",
"63016304402",
"63016304403",
"63016304404",
"63016304405",
"63016304406",
"63016309400",
"63016309401",
"63016309402",
"63016309403",
"63016309404",
"63016309405",
"63016309406",
"63017303400",
"63017303401"

]

},

{

"part_name": "Lower Dishrack W10728159",

"part_number": "PS10057160",

"manufacturer": "Kenmore",

"price": "214.12",

"description": "Dishrack ONLY.",

"rating": "79",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# W10728159 replaces these: AP5951852, 8193785, 8268635, 8268638, 8268781, 8268788, 8268805, 8268806, 8519616, 8519646, 8519667, 8519668, 8519680, 8519681, 8539257, W10056271, W10082825, W10199765, W10312777, W10315890 ... Show more , W10525645, W10525646, W10525651, W10889106, WPW10078180 Show less Back to Top",

"review_count": "23",

"appliance": "dishwasher",

"compatible_models": [

"2214792N512",

"2214793N512",

"66512762K312",

"66512762K313",

"66512763K312",

"66512763K313",

"66512769K312",

"66512769K313",

"66512772K312",

"66512772K313",

```
"66512772K314",
"66512773K313",
"66512773K314",
"66512774K312",
"66512774K313",
"66512776K312",
"66512776K314",
"66512779K312",
"66512779K313",
"66512779K314",
"66512782K310",
"66512782K312",
"66512782K313",
"66512783K311",
"66512783K312",
"66512783K313",
"66512789K311",
"66512789K312",
"66512789K313",
"66512793K312"
]
},
{
  "part_name": "Dishwasher Lower Dish Rack with Wheels - Gray WD28X10384",
  "part_number": "PS8746204",
  "manufacturer": null,
```

"price": "188.38",

"description": "This genuine OEM lower rack assembly is compatible with various dishwashers. It is located at the bottom of the dishwasher. Each rack has a series of tines and dividers designed to accommodate different sizes and shapes of dishes. The assembly includes 8 rollers/wheels to allow users to easily slide the rack in and out of the dishwasher cavity. The rack holds larger items such as plates and bowls and keeps them secure and stable while the dishwasher is running. If the rack or wheels are damaged, then you will need to replace the assembly to avoid damage to the interior of the dishwasher or to your dishes.",

"rating": "88",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher. Part# WD28X10384 replaces these: AP5788827, 2979581, WD28X10165, WD28X10166, WD28X10206, WD28X10309 Back to Top",

"review_count": "40",

"appliance": "dishwasher",

"compatible_models": [

"4070100",

"4070110",

"4070500",

"4070510",

"4070600",

"4070610",

"4070800",

"4070810",

"4071100",

"4071110",

"4071120",

"4071500",

```
"4071510",
"4071520",
"4071600",
"4071610",
"4071620",
"EDW5000L00BB",
"EDW5000L00CC",
"EDW5000L00WW",
"EDW5000L15BB",
"EDW5000L15CC",
"EDW5000L15WW",
"EDW5060L00SS",
"EDW5060L15SS",
"EDW5100N00BB",
"EDW5100N00CC",
"EDW5100N00WW",
"EDW5100N10BB",
"EDW5100N10CC"
]
},
{
  "part_name": "Dishwasher Silverware Basket WP8531233",
  "part_number": "PS11746119",
  "manufacturer": null,
  "price": "53.44",
```

"description": "This silverware basket holds utensils in your dishwasher. If it becomes damaged or goes missing, you can replace it with this part. No disassembly is required to replace this part; simply remove the existing basket and replace it with the new one. To keep the basket in good shape, place silverware carefully inside, and be careful when removing and replacing the basket when unloading utensils.",

"rating": "98",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Leaking This part works with the following products: Dishwasher. Part# WP8531233 replaces these: AP6012898, 8531233, WP8531233VP Back to Top",

"review_count": "116",

"appliance": "dishwasher",

"compatible_models": [

"KUDK01ILBS0",

"KUDK01ILBS1",

"KUDK01ILBS2",

"KUDK01ILBS3",

"KUDK01ILBS5",

"KUDK01ILBS6",

"KUDK30IVBS0",

"KUDK30IVBS2",

"KUDK30IVBS3",

"KUDK30IVBS4",

"KUDK30IVSS3",

"KUDK30IVSS4",

"KUDL01ILBS0",

"KUDL01ILBS1",

"KUDL01ILBS2",

"KUDL01ILBS3",

"KUDL01ILBS5",
"KUDL01ILBS6",
"KUDM03FTBL3",
"KUDM03FTSS3",
"KUDM03FTWH3",
"KUDP01DLBL0",
"KUDP01DLBL1",
"KUDP01DLBL2",
"KUDP01DLBL3",
"KUDP01DLBL5",
"KUDP01DLBL6",
"KUDP01DLBL7",
"KUDP01DLBS0",
"KUDP01DLBS1"

]

},

{

"part_name": "Silverware Basket WD28X10128",

"part_number": "PS959351",

"manufacturer": null,

"price": "32.32",

"description": "This is a basket for washing flatware or silverware in your dishwasher.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Leaking This part works with the following products: Dishwasher. Part# WD28X10128 replaces these: AP3772889, 1088673, WD28X10128, WD28X10127, WD28X10132 Back to Top",

"review_count": "102",
"appliance": "dishwasher",
"compatible_models": [
"CDW9380N00SS",
"CDW9380N20SS",
"CDWT280V00SS",
"CDWT280V05SS",
"CDWT280V50SS",
"CDWT980R10SS",
"CDWT980R30SS",
"CDWT980V00SS",
"EDWF800P00BB",
"EDWF800P00WW",
"EDWF860P00SS",
"GDWF100R10BB",
"GDWF100R10WW",
"GDWF100R30BB",
"GDWF100R30WW",
"GDWF100V40BB",
"GDWF100V40WW",
"GDWF100V50BB",
"GDWF100V50WW",
"GDWF100V55BB",
"GDWF100V55WW",
"GDWF100V70WW",
"GDWF106V00WW",

"GDWF150V40ES",

"GDWF150V50ES",

"GDWF150V55ES",

"GDWF160R10SS",

"GDWF160R30SS",

"GDWF160V00SS",

"GDWF160V10SS"

]

},

{

"part_name": "Dishwasher Dish Rack Adjuster Kit - Left and Right Side W10712394",

"part_number": "PS10064063",

"manufacturer": "Kenmore",

"price": "46.62",

"description": "This rack adjuster kit (Dishrack Adjuster Kit, Adjuster Kit, Dishwasher Rack Adjuster) will adjust the height of the upper rack of your dishwasher. It connects to the dishrack. The kit is constructed of grey plastic and metal, and measures approximately 12 inches wide and 6.5 inches tall. The rack adjuster can break from material fatigue or prolonged high temperature exposure. High temperature exposure can compromise the integrity of the materials. If the rack adjuster breaks, your upper rack may fall down, may be unlevel, or the door may not close. This kit includes the parts to replace the left and right-side rack adjusters and has been upgraded to a more durable metal design (2 adjuster assemblies, 1 left hand and 1 right hand actuator cover, 2 gray adjuster covers, and 2 gray adjuster housings)",

"rating": "92",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't close | Not cleaning dishes properly | Door latch failure | Leaking This part works with the following products: Dishwasher. Part# W10712394 replaces these: AP5956100, W10238418, W10253546, W10350376, W10712394VP, WPW10350376 Back to Top",

"review_count": "1025",

"appliance": "dishwasher",

"compatible_models": [

"66213042K112",

"66213043K112",

"66213044K112",

"66213049K112",

"66213282K112",

"66213283K112",

"66213289K112",

"66213292K112",

"66213293K112",

"66213299K112",

"66512776K310",

"66512813K312",

"66513042K110",

"66513042K111",

"66513042K112",

"66513042K113",

"66513042K114",

"66513042K115",

"66513042K116",

"66513043K110",

"66513043K111",

"66513043K112",

"66513043K113",

"66513043K114",

"66513043K115",

"66513043K116",

"66513044K110",

"66513044K111",

"66513044K112",

"66513044K113"

]

},

{

"part_name": "Water Inlet Valve 807445903",

"part_number": "PS9494157",

"manufacturer": null,

"price": "35.75",

"description": "",

"rating": null,

"troubleshooting_tips": "This part fixes the following symptoms: Will not fill with water |
Leaking This part works with the following products: Dishwasher. Part# 807445903
replaces these: AP5806799 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"E24ID74QPS0A",

"E24ID74QPS1A",

"E24ID74QPS3A",

"E24ID74QPS4A",

"EI24CD35RS2A",

"EI24CD35RS3A",

"EI24CD35RS4A",
"EI24ID30QB0A",
"EI24ID30QB0B",
"EI24ID30QB3B",
"EI24ID30QS0A",
"EI24ID30QS0B",
"EI24ID30QS3B",
"EI24ID30QS4B",
"EI24ID30QW0A",
"EI24ID30QW0B",
"EI24ID30QW3B",
"EI24ID50QS0A",
"EI24ID50QS0B",
"EI24ID50QS1A",
"EI24ID50QS1B",
"EI24ID50QS4B",
"EI24ID50QS5B",
"EW24ID70QT0A",
"EW24ID70QT3A",
"EW24ID70QT4A",
"EW24ID80QS0A",
"EW24ID80QS1A",
"EW24ID80QS2A",
"EW24ID80QS3A"

]

},

```
{  
  "part_name": "Piston and Nut Assembly WD24X10018",  
  "part_number": "PS260690",  
  "manufacturer": "Kenmore",  
  "price": "24.32",  
  "description": "This is used for the check valve.",  
  "rating": "94",  
  "troubleshooting_tips": "This part fixes the following symptoms: Not draining | Not  
cleaning dishes properly | Leaking This part works with the following products: Dishwasher.  
Part# WD24X10018 replaces these: AP2617344, 821081, WD22X133, WD24X0199,  
WD24X0220, WD24X199, WD24X220 Back to Top",  
  "review_count": "19",  
  "appliance": "dishwasher",  
  "compatible_models": [  
    "1200L02",  
    "3000B10",  
    "3000W10",  
    "36314231100",  
    "36314232100",  
    "36314234100",  
    "36314238100",  
    "36314239100",  
    "36314251100",  
    "36314252100",  
    "36314254100",  
    "36314259100",  
    "36314382000",
```

"36314387000",
"36314389000",
"36314482100",
"36314484100",
"36314487100",
"36314489100",
"36314572000",
"36314573000",
"36314577000",
"36314579000",
"36314582100",
"36314584100",
"36314587100",
"36314589100",
"36314672100",
"36314673100",
"36314674100"

]

},

{

"part_name": "Water Inlet Valve W10648041",

"part_number": "PS8760080",

"manufacturer": "Kenmore",

"price": "61.47",

"description": "This water inlet valve should be located behind the lower kickplate panel in either the right or left corner. The attaching solenoids on the valve open and close according to the desired amount of water needed.",

"rating": "95",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Will not fill with water | Not cleaning dishes properly | Noisy This part works with the following products: Dishwasher. Part# W10648041 replaces these: AP5802887, W10195048, W10195049, W10219505, W10219506, W10219595, W10648041VP, W10865472, WPW10195049 Back to Top",

"review_count": "14",

"appliance": "dishwasher",

"compatible_models": [

"66512772K311",

"66512773K311",

"66512776K311",

"66512782K311",

"66512833K311",

"66513102K900",

"66513102K901",

"66513102K902",

"66513103K900",

"66513103K901",

"66513103K902",

"66513104K900",

"66513104K901",

"66513104K902",

"66513109K900",

"66513109K901",

"66513109K902",

"66513112K701",

"66513112K702",

"66513113K701",

"66513113K702",

"66513114K701",

"66513114K702",

"66513119K701",

"66513119K702",

"66513122K700",

"66513122K702",

"66513122K703",

"66513123K700",

"66513123K702"

]

},

{

"part_name": "Water Inlet Valve W10844024",

"part_number": "PS11730996",

"manufacturer": "Kenmore",

"price": "55.41",

"description": "This water inlet valve should be located behind the lower kickplate panel in either the right or left corner. The attaching solenoids on the valve open and close according to the desired amount of water needed. NOTE: As per the manufacture this part has been updated from the original part. It may be a different color, and you may need to order an elbow (# W10685193) for the new designed valve to work.",

"rating": "86",

"troubleshooting_tips": "This part fixes the following symptoms: Will not fill with water | Leaking | Not cleaning dishes properly | Not draining This part works with the following products: Dishwasher. Part# W10844024 replaces these: AP5989613, 3378779, 3379356,

3384890, 8274221, 8283345, 8283346, 9743175, 9743559, 9744029, 9744284,
9744468, W10219643, W10327248, W10844024VP, WP9744468, WPW10219643 Back to
Top",

"review_count": "15",

"appliance": "dishwasher",

"compatible_models": [

"110723120",

"110773811",

"110773812",

"110773813",

"110773881",

"110773882",

"110773883",

"65715755791",

"66513206K902",

"66513402K900",

"66513402K901",

"66513409K900",

"66513409K901",

"66513442K900",

"66513442K901",

"66513443K900",

"66513443K901",

"66513444K900",

"66513444K901",

"66513449K900",

"66513449K901",

"66513492K600",

"66513499K600",

"66513592K600",

"66513593K600",

"66513594K600",

"66513599K600",

"66513692K600",

"66513699K600",

"66513922K010"

]

},

{

"part_name": "VALVE 5304482406",

"part_number": "PS3496157",

"manufacturer": "Kenmore",

"price": "62.79",

"description": "",

"rating": "90",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Will not fill with water This part works with the following products: Dishwasher. Part# 5304482406 replaces these: AP5178459, 5304470247, 5304475608 Back to Top",

"review_count": "2",

"appliance": "dishwasher",

"compatible_models": [

"58712332510A",

"58712332F01B",

"58712333510A",

"58712333F01B",
"58712339510A",
"58712339F01B",
"58714652110",
"58714652200A",
"58714652201B",
"58714659110",
"58714659200A",
"58714659201B",
"58714662110",
"58714662200A",
"58714662201B",
"58714663110",
"58714663200A",
"58714663201B",
"58714669110",
"58714669200A",
"58714669201B",
"58715412100A",
"58715413100A",
"58715423100A",
"EIDW1805KS0A",
"EIDW1805KS1B",
"EIDW5705PB0A",
"EIDW5705PS0A",
"EIDW5705PW0A",

```
"FDB2410HIB0"
]
},
{
  "part_name": "Water Inlet Valve WPW10158389",
  "part_number": "PS11749213",
  "manufacturer": "Kenmore",
  "price": "59.44",
  "description": "This water inlet valve should be located behind the lower kickplate panel
in either the right or left corner. The attaching solenoids on the valve open and close
according to the desired amount of water needed.",
  "rating": "97",
  "troubleshooting_tips": "This part fixes the following symptoms: Leaking | Will not fill
with water | Not cleaning dishes properly | Noisy This part works with the following
products: Dishwasher. Part# WPW10158389 replaces these: AP6015932, 8558986,
8558987, 8558988, 8563405, 8563406, 8563407, W10158387, W10158389,
WPW10158389VP Back to Top",
  "review_count": "55",
  "appliance": "dishwasher",
  "compatible_models": [
    "66513112K700",
    "66513113K700",
    "66513114K700",
    "66513119K700",
    "66513122K700",
    "66513122K701",
    "66513123K700",
    "66513123K701",
```

```
"66513124K700",  
"66513124K701",  
"66513129K700",  
"66513129K701",  
"66513132K700",  
"66513132K701",  
"66513133K700",  
"66513133K701",  
"66513139K700",  
"66513139K701",  
"66513152K700",  
"66513152K701",  
"66513153K700",  
"66513153K701",  
"66513154K700",  
"66513154K701",  
"66513159K700",  
"66513159K701",  
"66513163K700",  
"66513163K701",  
"66513169K700",  
"66513169K701"  
]  
,  
{  
  "part_name": "Water Inlet Valve 807047901",
```

"part_number": "PS9865067",

"manufacturer": "Kenmore",

"price": "48.22",

"description": "This water inlet valve is for dishwashers.\r\n\r\nWater inlet valve supplies water to the dishwasher.\r\n\r\nUnplug the dishwasher and shut off the water supply before installing this part",

"rating": "98",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Will not fill with water | Not cleaning dishes properly This part works with the following products: Dishwasher. Part# 807047901 replaces these: AP5948913 Back to Top",

"review_count": "14",

"appliance": "dishwasher",

"compatible_models": [

"58714012413B",

"58714012414B",

"58714012416B",

"58714013414B",

"58714013415B",

"58714013416B",

"58714013417B",

"58714014413B",

"58714019413B",

"58714019414B",

"58714019415B",

"58714019416B",

"CDB350NB10B",

"CDB350NB2A",

"CDB350NB3A",
"CDB350NB4A",
"CDB350NB5A",
"CDB350NB6B",
"CDB350NB7B",
"CDB350NB8B",
"CDB350NB9B",
"CDB350NW10B",
"CDB350NW2A",
"CDB350NW3A",
"CDB350NW4A",
"CDB350NW5A",
"CDB350NW6B",
"CDB350NW7B",
"CDB350NW8B",
"CDB350NW9B"

]

},

{

"part_name": "Water Inlet Valve WD15X10014",

"part_number": "PS3654179",

"manufacturer": null,

"price": "43.78",

"description": "This water inlet valve should be located behind the lower kickplate panel in either the right or left corner. The attaching solenoid on the valve open and close according to the desired amount of water needed.",

"rating": "95",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Will not fill with water | Not cleaning dishes properly This part works with the following products: Dishwasher. Part# WD15X10014 replaces these: AP5632416, 2309993, WD15X10014, WD15X10011 Back to Top",

"review_count": "54",

"appliance": "dishwasher",

"compatible_models": [

"ADW1100N00BB",

"ADW1100N00WW",

"ADW1100N10BB",

"ADW1100N10WW",

"ADW1100N15BB",

"ADW1100N15WW",

"ADW1100N20BB",

"ADW1100N20WW",

"ADW1100N30BB",

"ADW1100N35BB",

"ADW1100N35WW",

"ADW1100NB",

"ADW1100NW",

"CDW9380N00SS",

"CDW9380N20SS",

"CDWT280V00SS",

"CDWT280V05SS",

"CDWT280V50SS",

"CDWT980R10SS",

"CDWT980R30SS",

"CDWT980V00SS",
"CDWT980V05SS",
"CDWT980V50SS",
"EDWF800P00BB",
"EDWF800P00WW",
"EDWF860P00SS",
"GDWF100R10BB",
"GDWF100R10WW",
"GDWF100R30BB",
"GDWF100R30WW"

]

},

{

"part_name": "Dishwasher INLET VALVE W11175771",

"part_number": "PS12578165",

"manufacturer": "Kenmore",

"price": "63.96",

"description": "This water inlet valve should be located behind the lower kick plate panel in either the right or left corner. The attaching solenoids on the valve open and close according to the desired amount of water needed.",

"rating": "90",

"troubleshooting_tips": "This part fixes the following symptoms: Will not fill with water | Leaking | Not cleaning dishes properly This part works with the following products: Dishwasher. Part# W11175771 replaces these: AP6339872, W10195047, W10327250, W10872255, W11130744 Back to Top",

"review_count": "29",

"appliance": "dishwasher",

"compatible_models": [

"2212413N414",

"2213092N413",

"2213099N413",

"2213222N414",

"2213223N414",

"2213229N414",

"2213479N413",

"2213809N710",

"2214523N611",

"2214545N711",

"2217383N710",

"2217389N710",

"66512413N410",

"66512413N411",

"66512413N412",

"66512413N413",

"66512762K312",

"66512763K312",

"66512763K313",

"66512769K312",

"66512769K313",

"66512772K312",

"66512773K312",

"66512774K312",

"66512776K312",

"66512779K312",

"66512782K310",

"66512782K312",

"66512783K311",

"66512783K312"

]

},

{

"part_name": "Water Inlet Valve - 120V 60Hz 154637401",

"part_number": "PS1990907",

"manufacturer": "Kenmore",

"price": "56.98",

"description": "This water inlet valve is usually located behind the lower kickplate panel in either the right or left corner of the dishwasher. The attaching solenoids on the valve open and close according to the desired amount of water needed. The water inlet valve on your dishwasher supplies water to the dishwasher. If your dishwasher is leaking because it has overflowed, the water inlet valve may be the cause. If your dishwasher continues to fill above the heating element, try opening the door latch to see if it stops filling. If it continues to fill, you have a defective inlet valve that will need to be replaced.",

"rating": "89",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Will not fill with water | Not cleaning dishes properly | Not draining This part works with the following products: Dishwasher. Part# 154637401 replaces these: AP4321824, 1378823, 154637401, 154219601, 154219602, 154359801, 154359802, 154373301, 154373303, 154445901, 154476101 Back to Top",

"review_count": "43",

"appliance": "dishwasher",

"compatible_models": [

"58714001990",

"58714001991",
"58714002990",
"58714012407A",
"58714012408A",
"58714012409B",
"58714012410B",
"58714012411B",
"58714012412B",
"58714013401",
"58714013408A",
"58714013409A",
"58714013410B",
"58714013411B",
"58714013412B",
"58714013413B",
"58714014407A",
"58714014408A",
"58714014409B",
"58714014410B",
"58714014411B",
"58714014412B",
"58714019406A",
"58714019407A",
"58714019408A",
"58714019409B",
"58714019410B",

"58714019411B",

"58714019412B",

"58714022200A"

]

},

{

"part_name": "Door Spring WP912652",

"part_number": "PS11746856",

"manufacturer": null,

"price": "13.16",

"description": "The door spring puts tension on the dishwasher door through the hinge. This keeps it from falling or dropping abruptly when opening and closing. Please note: The spring for either side of the door is sold individually. If you see that your dishwasher is leaking, the door will not close or open properly, or it gets stuck, then replacing the spring could be a solution to these symptoms. During installation, remember there is potential for the door spring to snap if it is under too much pressure. For safety precautions, make sure you unplug the dishwasher from the power source before beginning your project.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close | Leaking This part works with the following products: Dishwasher. Part# WP912652 replaces these: AP6013629, 9-12652, 912652 Back to Top",

"review_count": "3",

"appliance": "dishwasher",

"compatible_models": [

"CDC400B",

"CDC450B",

"CDC5J",

"CDU20J",

"CDU250B",
"CDU250V",
"CDU2J",
"CDU2J3",
"CDU400B",
"CDU450B",
"CDU450V",
"CDU5J",
"CDU5JV",
"CDU600B",
"CDU600V",
"CDU8000B",
"CDU8J",
"DC4000B",
"DC4500B",
"DC5J",
"DDW2470AWP",
"DU2000B",
"DU2000B-C",
"DU2000V",
"DU2000V-C",
"DU2000W",
"DU20J",
"DU20J-CAN",
"DU20JV",
"DU2100B"


```
]
```

```
},
```

```
{
```

```
"part_name": "Spring, Lid WP8066018",
```

```
"part_number": "PS11744874",
```

```
"manufacturer": "Kenmore",
```

```
"price": "7.95",
```

```
"description": "The dishwasher lid spring helps open the dispenser cover in the soap box when the control releases the latch. If your dishwasher does not dispense detergent, is broken and worn out, or the door is not opening properly, replacing the dispenser spring could be the solution. For this replacement you will need needle nose pliers. First, release the cover on the detergent dispenser, then remove the cover from the shaft it hinges on. Pull the shaft from one side and remove the spring from the shaft. Next, replace with the new spring and engage the two open hooks into the soap cover. Finally, grasp the hook and pull it over tab on the side of the wash cup. Verify that it works properly by opening and closing the cap. Refer to the manual provided by the manufacturer for further instructions.",
```

```
"rating": "87",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Will not dispense detergent | Door latch failure | Not cleaning dishes properly | Door won't close This part works with the following products: Dishwasher. Part# WP8066018 replaces these: AP6011676, 300106, 8066018, 99989653 Back to Top",
```

```
"review_count": "12",
```

```
"appliance": "dishwasher",
```

```
"compatible_models": [
```

```
"110723120",
```

```
"110773811",
```

```
"110773812",
```

```
"110773813",
```

```
"110773881",
```

"110773882",
"110773883",
"19385",
"19585",
"19985",
"5648600110",
"5648600140",
"5648600160",
"5648600180",
"601W",
"60W",
"61W",
"65715755791",
"66513402K900",
"66513402K901",
"66513409K900",
"66513409K901",
"66513442K900",
"66513442K901",
"66513443K900",
"66513443K901",
"66513444K900",
"66513444K901",
"66513449K900",
"66513449K901"

]

```
},
```

```
{
```

```
"part_name": "Spring WPW10337934",
```

```
"part_number": "PS11753142",
```

```
"manufacturer": "Kenmore",
```

```
"price": "30.95",
```

```
"description": "This door spring is a genuine OEM replacement part for your dishwasher. The spring ensures that your dishwasher door does not fall open too quickly. If this occurs, one or both springs should be replaced. This part consists of one spring. To replace the spring, you will need to pull the dishwasher about six inches to a foot out from the cabinet. Replacing the spring has been rated as an easy repair by our customers.",
```

```
"rating": "87",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close This part works with the following products: Dishwasher. Part# WPW10337934 replaces these: AP6019831, 8268989, 8524473, W10337934, W10462694 Back to Top",
```

```
"review_count": "6",
```

```
"appliance": "dishwasher",
```

```
"compatible_models": [
```

```
"2212413N414",
```

```
"2213092N413",
```

```
"2213099N413",
```

```
"2213479N413",
```

```
"2213809N710",
```

```
"2217383N710",
```

```
"2217389N710",
```

```
"66213273K112",
```

```
"66512093K210",
```

```
"66512413N410",
```

```
"66512413N411",
"66512413N412",
"66512413N413",
"66512723K310",
"66512723K311",
"66513002N510",
"66513002N511",
"66513003N510",
"66513003N511",
"66513004N510",
"66513004N511",
"66513009N510",
"66513009N511",
"66513012K110",
"66513012K111",
"66513012K112",
"66513012K113",
"66513013K110",
"66513013K111",
"66513013K112"
]
},
{
  "part_name": "Door Spring 154430601",
  "part_number": "PS724932",
  "manufacturer": "Kenmore",
```

"price": "43.16",

"description": "Sold individually.",

"rating": "86",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close This part works with the following products: Dishwasher. Part# 154430601 replaces these: AP3219391, 937000, 154430601, 154365701, 154414001 Back to Top",

"review_count": "7",

"appliance": "dishwasher",

"compatible_models": [

"58714202200",

"58714209200",

"58714302200",

"58714302201",

"58714309200",

"58714309201",

"58714852200",

"58714853200",

"58714854200",

"58714859200",

"58715072200",

"58715072201",

"58715073200",

"58715073201",

"58715074200",

"58715074201",

"58715079200",

"58715079201",

```
"58715173400",
"58716072200",
"58716072201",
"58716073200",
"58716073201",
"58716074200",
"58716074201",
"58716079200",
"58716079201",
"CDBE566AB0",
"CDBE566AQ0",
"CDBE566AS0"
]
},
{
  "part_name": "Door Spring WP8270020",
  "part_number": "PS11745526",
  "manufacturer": "Kenmore",
  "price": "33.23",
  "description": "This dishwasher door spring is sold individually. It is recommended if you are replacing one side, to replace both.",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close | Noisy This part works with the following products: Dishwasher. Part# WP8270020 replaces these: AP6012319, 8270020 Back to Top",
  "review_count": "4",
  "appliance": "dishwasher",
```

"compatible_models": [

"2213222N414",

"2213223N414",

"2213229N414",

"2214523N611",

"2214545N711",

"2214715N710",

"2214792N512",

"2214793N512",

"665110739120",

"665110739130",

"665110739140",

"665110739190",

"66512762K312",

"66512762K313",

"66512763K312",

"66512763K313",

"66512769K312",

"66512769K313",

"66512772K312",

"66512772K313",

"66512772K314",

"66512773K313",

"66512773K314",

"66512774K312",

"66512779K312",

"66512779K313",

"66512779K314",

"66512782K310",

"66512782K311",

"66512782K312"

]

},

{

"part_name": "Recess Door Spring WR02X10585",

"part_number": "PS285013",

"manufacturer": "Kenmore",

"price": "9.16",

"description": "This door recess spring or dispenser lever spring in your refrigerator is used to return the ice door to the closed position or the dispenser lever to the home position once released. You will find the spring in the water dispenser assembly, behind the main control panel. If the dispenser lever is malfunctioning or the dispenser ice door is not closing, you may need to replace this door recess spring.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door Sweating | Ice maker won't dispense ice | Door won't open or close This part works with the following products: Refrigerator, Dishwasher. Part# WR02X10585 replaces these: AP3670155, 879075, WR2X10585 Back to Top",

"review_count": "12",

"appliance": "dishwasher",

"compatible_models": [

"40201-0",

"402011",

"40205-0",

"402051",
"40206-0",
"402061",
"402070",
"403110",
"403111",
"405010",
"405011",
"405012",
"405050",
"405051",
"405052",
"405060",
"405061",
"405062",
"4070100",
"4070110",
"4070500",
"4070510",
"4070600",
"4070610",
"4070800",
"4070810",
"4071100",
"4071110",
"4071120",

"4071500"

]

},

{

"part_name": "Door Spring 154430501",

"part_number": "PS815938",

"manufacturer": "Kenmore",

"price": "34.99",

"description": "This door spring is manufactured for a dishwasher door. The door spring applies tension to the dishwasher door so that the door does not drop too quickly when it is opening. If the door drops too quickly, it could cause damage to the dishwasher door or dishwasher door hinges. This spring is sold individually. Check the spring on the opposite side of the dishwasher door, they often wear at the same rate so you may want to replace both springs for exact tension on either side. No tools are required for this repair. This is an OEM replacement part.",

"rating": "96",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close This part works with the following products: Dishwasher. Part# 154430501 replaces these: AP3363442, 1014399, 154226001, 154226002, 154345901, 154345902, 154413301 Back to Top",

"review_count": "9",

"appliance": "dishwasher",

"compatible_models": [

"58714000100",

"58714000101",

"58714000102",

"58714001990",

"58714001991",

"58714001992",

"58714001993",
"58714002990",
"58714002991",
"58714002992",
"58714002993",
"58714003100",
"58714008001",
"58714008002",
"58714008003",
"58714009100",
"58714009101",
"58714009102",
"58714012400",
"58714012401",
"58714012402",
"58714012403",
"58714012404",
"58714012405",
"58714012406A",
"58714012407A",
"58714012408A",
"58714012409B",
"58714012410B",
"58714012411B"

]

},

```
{
```

```
"part_name": "Spring,Hinge 4970ED4004G",
```

```
"part_number": "PS3524564",
```

```
"manufacturer": "LG",
```

```
"price": "17.38",
```

```
"description": "The door spring, used in dishwashers, adds tension to the door through the door hinge to keep it from opening too fast. If you have a door latch failure or your washer door drops too quickly when opened, it is best you replace this part to fix the problem. Refer to the manual provided by the manufacturer for installation instructions and further repair guidance. Unplug your dishwasher from the power source before you begin this repair project as a safety precaution.",
```

```
"rating": "100",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close This part works with the following products: Dishwasher. Part# 4970ED4004G replaces these: AP4997045, 4970ED4004A Back to Top",
```

```
"review_count": "2",
```

```
"appliance": "dishwasher",
```

```
"compatible_models": [
```

```
"14693",
```

```
"14697",
```

```
"39232533",
```

```
"72214697610",
```

```
"D1401TB",
```

```
"D1401TB1",
```

```
"D1412TB",
```

```
"D1414TB",
```

```
"D1425TB",
```

```
"D1426DB1",
```

```
"D1426TB",
"D1426TB1",
"D1436TB",
"D1438DB",
"D1438TB",
"D1471BB",
"D1471BB1",
"D1471DB1",
"D1471DBK",
"D1471TB",
"D1471TB1",
"D1471TBK",
"D1471WB",
"D1471WB1",
"D1472TB",
"D1472TB1",
"D15ASTUL",
"D1608BB",
"D1608TB",
"D1608WB"
]
},
{
  "part_name": "Door Spring 154579101",
  "part_number": "PS1524996",
  "manufacturer": "Kenmore",
```

"price": "43.77",

"description": "Sold individually.",

"rating": "96",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close | Noisy This part works with the following products: Dishwasher. Part# 154579101 replaces these: AP3958752, 1196202 Back to Top",

"review_count": "10",

"appliance": "dishwasher",

"compatible_models": [

"004621710A",

"004621711A",

"58715202800",

"58715202801",

"58715202802",

"58715202803A",

"58715203800",

"58715203801",

"58715203802",

"58715203803A",

"58715313000A",

"58715392100A",

"58715393100A",

"58715399100A",

"605222850A",

"804655850A",

"804655851A",

"905222840A",

"BGHD2433KB0",
"BGHD2433KB1",
"BGHD2433KF0",
"BGHD2433KF1",
"BGHD2433KW0",
"BGHD2433KW1",
"CDB500NB0A",
"CDB500NB1A",
"CDB500NB2A",
"CDB500NB3A",
"CDB500NB4A",
"CDB500NB5B"

]

},

{

"part_name": "Door Spring Kit 00754866",

"part_number": "PS8770519",

"manufacturer": null,

"price": "44.72",

"description": "This kit includes 2 spring and 2 cables. This door spring kit is for dishwashers.\r\n\r\nDoor spring kit applies tension to the dishwasher door through the door hinge to prevent the door from dropping too quickly when you open the dishwasher. The kit may include multiple parts; refer to your parts diagram for a list of parts included.",

"rating": "98",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close This part works with the following products: Dishwasher. Part# 00754866 replaces these: AP5804978, 00623540, 00627230, 00659339, 00751392, 623540, 627230, 659339, 751392, 754866 Back to Top",

"review_count": "21",
"appliance": "dishwasher",
"compatible_models": [
"DF260142",
"DWHD640JFM",
"DWHD640JFP",
"DWHD650JFM",
"DWHD650JFP",
"DWHD651JFM",
"DWHD651JFP",
"SHE53T52UC",
"SHE53T55UC",
"SHE53T56UC",
"SHE53TL2UC",
"SHE65T52UC",
"SHE65T55UC",
"SHE65T56UC",
"SHE68T52UC",
"SHE68T55UC",
"SHE68T56UC",
"SHP53T55UC",
"SHP65T55UC",
"SHX53T55UC",
"SHX5ER55UC",
"SHX65T55UC",
"SHX68T52UC",

"SHX68T55UC",

"SHX68T56UC",

"SHX68TL5UC",

"SHX7ER55UC",

"SPV5ES53UC",

"SPV68U53UC"

]

},

{

"part_name": "Detergent and Rinse Aid Dispenser WPW10224428",

"part_number": "PS11750654",

"manufacturer": "Kenmore",

"price": "76.58",

"description": "This part releases the detergent and rinse aid into the dishwasher. This detergent dispenser is for dishwashers.\r\n\r\nDetergent dispenser holds the dishwasher detergent in a covered compartment.\r\n\r\nUnplug the dishwasher or shut off the house circuit breaker before installing this part. Wear work gloves to protect your hands during this repair.",

"rating": "96",

"troubleshooting_tips": "This part fixes the following symptoms: Will not dispense detergent | Door latch failure | Door won't close | Not cleaning dishes properly This part works with the following products: Dishwasher. Part# WPW10224428 replaces these: AP6017357, 8565814, 8565816, W10195169, W10224428, WPW10224428VP Back to Top",

"review_count": "21",

"appliance": "dishwasher",

"compatible_models": [

"66513222K600",

"66513222K601",
"66513223K600",
"66513223K601",
"66513229K600",
"66513229K601",
"66513452K900",
"66513452K901",
"66513452K902",
"66513453K901",
"66513453K902",
"66513459K900",
"66513459K901",
"66513459K902",
"66513462K900",
"66513462K901",
"66513462K902",
"66513462K903",
"66513463K900",
"66513463K901",
"66513463K902",
"66513463K903",
"66513469K900",
"66513469K901",
"66513469K902",
"66513469K903",
"66513472K900",

"66513472K901",

"66513472K902",

"66513473K900"

]

},

{

"part_name": "Detergent Dispenser 5304506521",

"part_number": "PS11770487",

"manufacturer": "Kenmore",

"price": "70.53",

"description": "This is the replacement detergent dispenser for your refrigerator. It is gray in color and is sold individually. It is approximately 8.5 inches long and 3 inches wide. The detergent dispenser stores the detergent until it is ready to be dispensed. If your dishes are not coming clean, or you notice the detergent is still in the dispenser at the end of the cycle, you may have a damaged or malfunctioning detergent dispenser. This is an OEM part sourced directly from the manufacturer.",

"rating": "87",

"troubleshooting_tips": "This part fixes the following symptoms: Will not dispense detergent | Not cleaning dishes properly | Door latch failure | Leaking This part works with the following products: Dishwasher. Part# 5304506521 replaces these: AP6036339, 154379201, 154379202, 154452703, 154542103, 154860101, 154860102, 5304452518
Back to Top",

"review_count": "6",

"appliance": "dishwasher",

"compatible_models": [

"004621710A",

"004621711A",

"58714012409B",

"58714012410B",

"58714012411B",
"58714012412B",
"58714012413B",
"58714012414B",
"58714012416B",
"58714013410B",
"58714013411B",
"58714013412B",
"58714013413B",
"58714013414B",
"58714013415B",
"58714013416B",
"58714013417B",
"58714014409B",
"58714014410B",
"58714014411B",
"58714014412B",
"58714014413B",
"58714019409B",
"58714019410B",
"58714019411B",
"58714019412B",
"58714019413B",
"58714019414B",
"58714019415B",
"58714019416B"

```
]
},
{
  "part_name": "Detergent Dispenser Assembly WPW10199696",
  "part_number": "PS11750167",
  "manufacturer": "Kenmore",
  "price": "127.86",
  "description": "This part releases the detergent and rinse aid into the dishwasher. Light grey in color. The detergent dispenser attaches to the inner door panel and holds the dishwasher detergent and rinse agent in a covered compartment.",
  "rating": "93",
  "troubleshooting_tips": "This part fixes the following symptoms: Will not dispense detergent | Door latch failure | Not cleaning dishes properly | Leaking This part works with the following products: Dishwasher. Part# WPW10199696 replaces these: AP6016874, 8565815, W10077882, W10199696, W10224429, W10224431 Back to Top",
  "review_count": "28",
  "appliance": "dishwasher",
  "compatible_models": [
    "66513212K901",
    "66513212K902",
    "66513213K900",
    "66513213K901",
    "66513213K902",
    "66513219K901",
    "66513219K902",
    "66513242K900",
    "66513242K901",
```

```
"66513243K900",
"66513243K901",
"66513249K900",
"66513249K901",
"66513752K600",
"66513752K601",
"66513752K602",
"66513752K603",
"66513753K600",
"66513753K601",
"66513753K602",
"66513753K603",
"66513754K600",
"66513754K601",
"66513754K602",
"66513754K603",
"66513759K600",
"66513759K601",
"66513759K602",
"66513759K603",
"66513762K600"
]
},
{
  "part_name": "Detergent Dispenser W10861000",
  "part_number": "PS11731570",
```

"manufacturer": null,

"price": "96.36",

"description": "Detergent dispenser W10861000 is an original equipment manufacturer (OEM) part that fits some Whirlpool, KitchenAid, Maytag and Amana dishwashers.\r\n\r\nDetergent dispenser W10861000 attaches to the inner door panel and holds the dishwasher detergent and rinse aid in covered compartments.\r\n\r\nThis dishwasher detergent dispenser measures approximately 5 inches wide and 4.5 inches high.",

"rating": "89",

"troubleshooting_tips": "This part fixes the following symptoms: Will not dispense detergent | Door latch failure | Not cleaning dishes properly This part works with the following products: Dishwasher. Part# W10861000 replaces these: AP5999391, W10620296, W10620298, W10620299, W10861000VP Back to Top",

"review_count": "19",

"appliance": "dishwasher",

"compatible_models": [

"2213229N414",

"ADB1700ADB2",

"ADB1700ADB3",

"ADB1700ADB4",

"ADB1700ADS2",

"ADB1700ADS3",

"ADB1700ADS4",

"ADB1700ADW2",

"ADB1700ADW3",

"ADB1700ADW4",

"JDB9200CWP2",

"JDB9200CWS2",

```
"JDB9200CWS3",
"JDB9800CWP2",
"JDB9800CWP3",
"JDB9800CWS2",
"KDFE104DBL2",
"KDFE104DBL3",
"KDFE104DBL4",
"KDFE104DBL5",
"KDFE104DSS2",
"KDFE104DSS3",
"KDFE104DSS4",
"KDFE104DSS5",
"KDFE104DWH2",
"KDFE104DWH3",
"KDFE104DWH4",
"KDFE104DWH5",
"KDFE104HBL0",
"KDFE104HBL1"
]
},
{
  "part_name": "Rinse Aid Cap WPW10524920",
  "part_number": "PS11755939",
  "manufacturer": null,
  "price": "31.01",
```


"description": "This is a replacement cap for the detergent/rinse aid dispenser. If the rinse aid cap is damaged or missing, you may notice too much rinse aid in the dishwasher. The cap simply screws in to the dispenser, so if your cap is damaged you can simply screw it out, then screw in the new one. The rinse aid cap is approximately 2 inches in diameter and is sold individually. This is an OEM part, directly from the manufacturer.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Not drying dishes properly | Leaking | Not cleaning dishes properly This part works with the following products: Dishwasher. Part# WPW10524920 replaces these: AP6022605, W10482848, W10524920 Back to Top",

"review_count": "29",

"appliance": "dishwasher",

"compatible_models": [

"KDFE454CSS0",

"KDFE454CSS1",

"KDFE454CSS2",

"KDFE454CSS3",

"KDTE554CSS0",

"KDTE554CSS1",

"KUDC10FBBL0",

"KUDC10FBSS0",

"KUDC10FBWH0",

"KUDC10FXBL6",

"KUDC10FXBL7",

"KUDC10FXSS6",

"KUDC10FXSS7",

"KUDC10FXWH6",

"KUDC10FXWH7",

"KUDC10IXBL8",

"KUDC10IXBL9",

"KUDC10IXSS8",

"KUDC10IXSS9",

"KUDC10IXWH8",

"KUDC10IXWH9",

"KUDE20FBBL0",

"KUDE20FBBL1",

"KUDE20FBSS0",

"KUDE20FBSS1",

"KUDE20FBWH0",

"KUDE20FBWH1",

"KUDE20IXSSA",

"KUDE40FXBL6",

"KUDE40FXBT6"

]

},

{

"part_name": "Tub Cap W10795980",

"part_number": "PS11703426",

"manufacturer": "Kenmore",

"price": "15.48",

"description": "The plastic button covers the sharp ends of screws along the edge of the dishwasher tub. Sold individually.",

"rating": "60",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# W10795980 replaces these: AP5982383, 8270119, W10082838, W10813122, WPW10082838 Back to Top",

"review_count": "1",

"appliance": "dishwasher",

"compatible_models": [

"2213223N414",

"2213229N414",

"2214523N611",

"2214715N710",

"2214792N512",

"665110739120",

"665110739130",

"665110739140",

"665110739190",

"66512762K312",

"66512762K313",

"66512763K312",

"66512763K313",

"66512769K312",

"66512769K313",

"66512772K312",

"66512772K313",

"66512773K313",

"66512774K312",

"66512774K313",

"66512776K311",

```
"66512776K312",
"66512776K314",
"66512779K312",
"66512779K313",
"66512782K310",
"66512782K311",
"66512782K312",
"66512783K311",
"66512783K312"
]
},
{
  "part_name": "LID 00611322",
  "part_number": "PS8727344",
  "manufacturer": "Kenmore",
  "price": "18.25",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part fixes the following symptoms: Not draining This part works with the following products: Dishwasher. Part# 00611322 replaces these: AP4355303, 00628305, 611322, 628305 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "63013003012",
    "63013003015",
    "63013003016",
```

"63013003017",
"63013003018",
"63013023010",
"63013023011",
"63013023015",
"63013023016",
"63013023017",
"63013023018",
"63013902010",
"63013902011",
"63013903010",
"63013903011",
"63013909010",
"63013909011",
"63013909012",
"63013912010",
"63013912011",
"63013913010",
"63013913011",
"63013919010",
"63013919011",
"63013919012",
"63013993010",
"63013993012",
"63013993015",
"63013993016",

```
"63013993017"
]
},
{
  "part_name": "Rinse Aid Cap WPW10077881",
  "part_number": "PS11748135",
  "manufacturer": null,
  "price": "17.73",
  "description": "This part holds the rinse aid liquid in the dispenser until the timer
activates the rinse cycle.",
  "rating": "91",
  "troubleshooting_tips": "This part fixes the following symptoms: Leaking | Will not
dispense detergent | Not cleaning dishes properly | Not drying dishes properly This part
works with the following products: Dishwasher. Part# WPW10077881 replaces these:
AP6014865, W10077881 Back to Top",
  "review_count": "29",
  "appliance": "dishwasher",
  "compatible_models": [
    "KUDA03CTBL0",
    "KUDA03CTBL1",
    "KUDA03CTBL2",
    "KUDA03CTBL3",
    "KUDA03CTBS0",
    "KUDA03CTBS1",
    "KUDA03CTBS2",
    "KUDA03CTBS3",
    "KUDA03CTWH0",
```

```
"KUDA03CTWH1",
"KUDA03CTWH2",
"KUDA03CTWH3",
"KUDB03CTBL0",
"KUDB03CTBL1",
"KUDB03CTBL2",
"KUDB03CTBS0",
"KUDB03CTBS1",
"KUDB03CTBS2",
"KUDC03FTSS0",
"KUDC03FTSS2",
"KUDC03FVBL3",
"KUDC03FVBL4",
"KUDC03FVBL5",
"KUDC03FVSS0",
"KUDC03FVSS2",
"KUDC03FVSS3",
"KUDC03FVSS4",
"KUDC03FVSS5",
"KUDC03FVWH3",
"KUDC03FVWH4"
]
},
{
  "part_name": "Rinse-Aid Dispenser Cap WP8558307",
  "part_number": "PS11746426",
```

"manufacturer": "Kenmore",

"price": "27.56",

"description": "The rinse aid cap (sometimes referred to as the dispenser cap), covers the rinse aid dispenser on the dishwasher door. If your dishwasher will not dispense detergent, or it is leaking detergent, there could be an issue with the rinse aid cap. Check the cap and its gasket for any damage or melting. If the cap has melted or it is not sealing the dispenser properly, the part should be replaced right away. This rinse aid cap comes with the gasket, so you should discard the existing gasket and rinse aid cap at the same time. The repair is relatively straightforward, and requires no tools.",

"rating": "91",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Will not dispense detergent | Not cleaning dishes properly | Not drying dishes properly This part works with the following products: Dishwasher. Part# WP8558307 replaces these: AP6013204, 8193984, 8539095, 8558307, 8558310, WP8558307VP Back to Top",

"review_count": "46",

"appliance": "dishwasher",

"compatible_models": [

"66513212K901",

"66513212K902",

"66513213K900",

"66513213K901",

"66513213K902",

"66513219K901",

"66513219K902",

"66513222K600",

"66513222K601",

"66513223K600",

"66513223K601",

"66513229K600",


```
"66513229K601",
"66513242K900",
"66513242K901",
"66513243K900",
"66513243K901",
"66513249K900",
"66513249K901",
"66513452K900",
"66513452K901",
"66513452K902",
"66513453K901",
"66513453K902",
"66513459K900",
"66513459K901",
"66513459K902",
"66513462K900",
"66513462K901",
"66513462K902"
]
},
{
  "part_name": "Stop Clip 5304506510",
  "part_number": "PS11770481",
  "manufacturer": "Kenmore",
  "price": "7.28",
```

"description": "This rail end cap, or dishrack stop clip, is a genuine OEM replacement part for your dishwasher. This part keeps the rack in your dishwasher from sliding out. This is a very easy repair, to complete it you only need a flat blade screwdriver. Use the screwdriver to pry the locking tab open on the cap, located at the front of your upper dishrack. Pull off the end cap and lock the new one into place.",

"rating": "60",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 5304506510 replaces these: AP6036334, 5304440996 Back to Top",

"review_count": "4",

"appliance": "dishwasher",

"compatible_models": [

"004621710A",

"004621711A",

"58714012409B",

"58714012410B",

"58714012411B",

"58714012412B",

"58714012413B",

"58714012414B",

"58714012416B",

"58714013410B",

"58714013411B",

"58714013412B",

"58714013413B",

"58714013414B",

"58714013415B",

"58714013416B",

"58714013417B",

"58714014409B",

"58714014410B",

"58714014411B",

"58714014412B",

"58714014413B",

"58714019409B",

"58714019410B",

"58714019411B",

"58714019412B",

"58714019413B",

"58714019414B",

"58714019415B",

"58714019416B"

]

},

{

"part_name": "SWITCH 00620775",

"part_number": "PS8728608",

"manufacturer": null,

"price": "35.72",

"description": "",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start This part works with the following products: Dishwasher. Part# 00620775 replaces these: AP5326240, 620775 Back to Top",

"review_count": "1",

"appliance": "dishwasher",

"compatible_models": [

"DF260142",

"DI260410",

"DWHD440MFM",

"DWHD440MFP",

"DWHD440MPR",

"DWHD640JFM",

"DWHD640JFP",

"DWHD640JPR",

"DWHD650GFP",

"DWHD650JFM",

"DWHD650JFP",

"DWHD650JPR",

"SGE53U52UC",

"SGE53U55UC",

"SGE53U56UC",

"SGE63E06UC",

"SGE63E15UC",

"SGE68U55UC",

"SGV63E03UC",

"SGV68U53UC",

"SGX68U55UC",

"SGX68U55UC-D5",

"SHE3AR72UC",

"SHE3AR75UC",

"SHE3AR76UC",

"SHE3ARF2UC",

"SHE3ARF5UC",

"SHE3ARF6UC",

"SHE53T52UC",

"SHE53T55UC"

]

},

{

"part_name": "Dishwasher Switch Assembly 5304517587",

"part_number": "PS12585690",

"manufacturer": null,

"price": "76.52",

"description": "This switch assembly is a genuine OEM replacement part used in dishwashers. It controls the various functions of the dishwasher. It includes multiple switches arranged on a control panel, allowing users to select different wash cycles, adjust settings such as temperature or delay start, and activate special features like heated dry or sanitizing options. These switches are activated by pressing buttons on the touchpad which provides users with a convenient and easy-to-use interface to customize their dishwashing experience. The switch assembly may fail due to malfunctioning switches or faulty wiring, resulting in difficulty selecting or adjusting settings, or the appliance failing to start or complete a cycle properly.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start This part works with the following products: Dishwasher. Part# 5304517587 replaces these: AP6802340 Back to Top",

"review_count": "1",

"appliance": "dishwasher",

"compatible_models": [

```
"004621710A",
"004621711A",
"804655850A",
"804655851A",
"FGID2466QB7A",
"FGID2466QD2A",
"FGID2466QF7A",
"FGID2466QF8A",
"FGID2466QF9A",
"FGID2466QW7A",
"FGID2468UD0A",
"FGID2468UD1A",
"FGID2468UD2A",
"FGID2468UF0A",
"FGID2468UF1A",
"FGID2468UF2A",
"FGIP2468UD0A",
"FGIP2468UD1A",
"FGIP2468UD2A",
"FGIP2468UF0A",
"FGIP2468UF1A",
"FGIP2468UF2A"
]
},
{
  "part_name": "Float Switch 154773201",
```

"part_number": "PS3492842",

"manufacturer": "Kenmore",

"price": "48.00",

"description": "Water that fills your dishwasher lifts the float. When it reaches a certain level, the float triggers the float switch to shut off, thereby shutting off the flow of water into the dishwasher.",

"rating": "60",

"troubleshooting_tips": "This part fixes the following symptoms: Will not fill with water | Leaking | Not draining This part works with the following products: Dishwasher. Part# 154773201 replaces these: AP4982393, 1864244, 154209801, 154386601, 154408701
Back to Top",

"review_count": "2",

"appliance": "dishwasher",

"compatible_models": [

"004621710A",

"004621711A",

"58714000100",

"58714000101",

"58714000102",

"58714001990",

"58714001991",

"58714001992",

"58714001993",

"58714002990",

"58714002991",

"58714002992",

"58714002993",

```
"58714003100",
"58714008001",
"58714008002",
"58714008003",
"58714009100",
"58714009101",
"58714009102",
"58714012400",
"58714012401",
"58714012402",
"58714012403",
"58714012404",
"58714012405",
"58714012406A",
"58714012407A",
"58714012408A",
"58714012409B"
]
},
{
  "part_name": "Dishwasher User Interface Control Button Assembly 5304518467",
  "part_number": "PS12585991",
  "manufacturer": null,
  "price": "94.22",
  "description": "User interface control button assembly makes contact with the user
interface to activate cycle selections.",
```


"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start This part works with the following products: Dishwasher. Part# 5304518467 replaces these: AP6809115 Back to Top",

"review_count": "1",

"appliance": "dishwasher",

"compatible_models": [

"FFID2426TB0A",

"FFID2426TB1A",

"FFID2426TB2A",

"FFID2426TB3A",

"FFID2426TD2A",

"FFID2426TD3A",

"FFID2426TD4A",

"FFID2426TD5A",

"FFID2426TS2A",

"FFID2426TS3A",

"FFID2426TS4A",

"FFID2426TS5A",

"FFID2426TW0A",

"FFID2426TW1A",

"FFID2426TW2A",

"FFID2426TW3A",

"LFID2426TF2A",

"LFID2426TF3A",

"LFID2426TF4A",

"LFID2426TF5A"

```
]
},
{
  "part_name": "Switch Interlock WD21X10224",
  "part_number": "PS1021382",
  "manufacturer": null,
  "price": "18.54",
  "description": "This switch interlock is found on your dishwasher door, and it must be actuated for the dishwasher to start. If your dishwasher door does not close properly, or if the machine will not start, you may have a problem with your switch interlock. This part is sold individually and is an OEM part, built specifically by the manufacturer.",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Will Not Start | Door latch failure This part works with the following products: Dishwasher. Part# WD21X10224 replaces these: AP3872949, 1168295 Back to Top",
  "review_count": "8",
  "appliance": "dishwasher",
  "compatible_models": [
    "4070100",
    "4070110",
    "4070500",
    "4070510",
    "4070600",
    "4070610",
    "4070800",
    "4070810",
    "4071100",
```

```
"4071110",
"4071120",
"4071500",
"4071510",
"4071520",
"4071600",
"4071610",
"4071620",
"EDW5000L00BB",
"EDW5000L00CC",
"EDW5000L00WW",
"EDW5000L15BB",
"EDW5000L15CC",
"EDW5000L15WW",
"EDW5060L00SS",
"EDW5060L15SS",
"EDW5100N00BB",
"EDW5100N00CC",
"EDW5100N00WW",
"EDW5100N10BB",
"EDW5100N10CC"
]
},
{
  "part_name": "Overfill Control Switch WPW10195039",
  "part_number": "PS11750031",
```

"manufacturer": "Kenmore",

"price": "47.54",

"description": "This part is also known as a float switch. This float switch, when activated, stops the flow of water into the dishwasher.",

"rating": "90",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Will not fill with water This part works with the following products: Dishwasher, Dryer. Part# WPW10195039 replaces these: AP6016738, W10195039, W10734532 Back to Top",

"review_count": "6",

"appliance": "dishwasher",

"compatible_models": [

"2212413N414",

"2213092N413",

"2213099N413",

"2213222N414",

"2213223N414",

"2213229N414",

"2213479N413",

"2213809N710",

"2214545N711",

"2214715N710",

"2214792N512",

"2214793N512",

"2217383N710",

"2217389N710",

"66213032K112",

"66213273K112",

"66512093K210",
"66512413N410",
"66512413N411",
"66512413N412",
"66512413N413",
"66512723K310",
"66512723K311",
"66512762K312",
"66512763K312",
"66512763K313",
"66512769K312",
"66512769K313",
"66512772K311",
"66512772K312"

]

},

{

"part_name": "Interlock Switch WD21X10261",

"part_number": "PS1481922",

"manufacturer": "Kenmore",

"price": "27.42",

"description": "The interlock switch may also be referred to as a belt switch. This part is a simple on/off mechanism that prohibits the appliance from operating when the door is open. This is a part for your dryer. The interlock switch senses the door is shut and the dryer can begin. This part might need to be replaced if your dryer is not starting or is in process while the door is open. The black rectangular part of the switch is approximately 2 inches long and a 1/2-inch wide with two gold plates on either end. This is a genuine OEM part that is sourced right from the manufacturer.",

"rating": "93",

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start | Door latch failure | Won't Start This part works with the following products: Dishwasher, Dryer, Washer Dryer Combo. Part# WD21X10261 replaces these: AP3994765, 1263984, WD21X0557, WD21X557 Back to Top",

"review_count": "18",

"appliance": "dishwasher",

"compatible_models": [

"1200L02",

"18385",

"1858",

"2661532110",

"2661532210",

"2661532211",

"2661532212",

"2661532311",

"2661532312",

"2661532412",

"2661532413",

"2661532513",

"26715321",

"2671532110",

"2671532210",

"2671532211",

"2671532212",

"2671532311",

"2671532312",

"2671532412",

"2671532413",

"3631401190",

"3631401191",

"3631401590",

"3631401591",

"3631401592",

"3631401890",

"3631401891",

"3631401892",

"3631402190"

]

},

{

"part_name": "Drain Solenoid and Bracket Assembly WD21X10268",

"part_number": "PS1481923",

"manufacturer": "Kenmore",

"price": "44.59",

"description": "This valve opens in order for the water to drain out of the dishwasher.",

"rating": "86",

"troubleshooting_tips": "This part fixes the following symptoms: Not draining | Leaking | Will not fill with water This part works with the following products: Dishwasher. Part# WD21X10268 replaces these: AP3994907, 1263990, 165D5478P002, WD21X10071 Back to Top",

"review_count": "11",

"appliance": "dishwasher",

"compatible_models": [

"36314031000",
"36314032000",
"36314038000",
"36314039000",
"36314071794",
"36314072795",
"36314074794",
"36314075794",
"36314081993",
"36314151000",
"36314152000",
"36314158000",
"36314159000",
"36314191992",
"36314191993",
"36314192993",
"36314194993",
"36314195993",
"36314382000",
"36314387000",
"36314389000",
"36314391993",
"36314395993",
"36314398993",
"36314471794",
"36314475794",


```
"36314478795",
"36314572000",
"36314573000",
"36314577000"
]
},
{
  "part_name": "Dishwasher Door Switch DD81-02132A",
  "part_number": "PS12394435",
  "manufacturer": null,
  "price": "71.67",
  "description": "This door switch is for dishwashers.\r\n\r\nThe door switch detects when the door is closed so the dishwasher can start.\r\n\r\nUnplug the dishwasher or shut off the house circuit breaker before installing this part. Wear work gloves to protect your hands.",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Door latch failure This part works with the following products: Dishwasher. Part# DD81-02132A replaces these: AP6287051, DD81-01629A Back to Top",
  "review_count": "6",
  "appliance": "dishwasher",
  "compatible_models": [
    "DW80F600UTB",
    "DW80F600UTS",
    "DW80F600UTSAA01",
    "DW80F600UTW",
    "DW80F800UWS",
```

"DW80J3020UB",
"DW80J3020US",
"DW80J3020UW",
"DW80K5050UB",
"DW80K5050UG",
"DW80K5050US",
"DW80K5050UW",
"DW80K7050UG",
"DW80K7050US",
"DW80R5060UG",
"DW80R5060US",
"DW80R5061UG",
"DW80R5061US",
"DW80R5061UT"

]

},

{

"part_name": "Flood Switch WD21X10519",

"part_number": "PS8690623",

"manufacturer": null,

"price": "53.88",

"description": "This is a flood switch assembly for your washer. The flood switch controls the hot and cold water filling your washer tub to ensure the proper amount of water. You may need to replace this part if your washer is overfilling or underfilling with water. It is about 5.5 inches in length, and mostly black in color with a green tip.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Not drying dishes properly | Will not fill with water | Not cleaning dishes properly | Not draining This part works with the following products: Dishwasher. Part# WD21X10519 replaces these: AP5781465, WD21X10492, WD21X20204 Back to Top",

"review_count": "57",

"appliance": "dishwasher",

"compatible_models": [

"ADT521PGF0BS",

"ADT521PGF0WS",

"ADT521PGF2BS",

"ADT521PGF2WS",

"ADT521PGF4BS",

"ADT521PGF4WS",

"ADT521PGF6BS",

"ADT521PGF6WS",

"ADT521PGJ0BS",

"ADT521PGJ0WS",

"ADT521PGJ2BS",

"ADT521PGJ2WS",

"ADT521PGJBS",

"ADT521PGJWS",

"CDT725SSF0SS",

"CDT725SSF2SS",

"CDT725SSF4SS",

"CDT725SSF6SS",

"CDT725SSF7SS",

"CDT765SSF0SS",

"CDT765SSF1SS",
"CDT765SSF7SS",
"DDT575SGF0BB",
"DDT575SGF0WW",
"DDT575SGF2BB",
"DDT575SGF2WW",
"DDT575SGF4BB",
"DDT575SGF4WW",
"DDT575SGF5BB",
"DDT575SGF5WW"

]

},

{

"part_name": "Handle WPW10321839",

"part_number": "PS11752787",

"manufacturer": null,

"price": "70.93",

"description": "",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure This part works with the following products: Dishwasher, Washer Dryer Combo, Washer. Part# WPW10321839 replaces these: W10321839 Back to Top",

"review_count": "1",

"appliance": "dishwasher",

"compatible_models": [

"7WDF530PAYM0",

"7WDF530PAYM1",

"7WDF530PAYM2",
"7WDF530PAYM3",
"IUD7500BS0",
"IUD7500BS1",
"IUD7500BS2",
"MHN30PDAGW0",
"MHN30PDAWW0",
"MHN30PDAXW0",
"MHN30PNAGW0",
"MHN30PRAWW0",
"MHP30PRAWW0",
"MLE20PDAGW0",
"MLE20PDAYW0",
"MLE20PDAZW0",
"MLE20PNAGWO",
"MLE20PRAYW0",
"MLE20PRAZW0",
"MLG20PDAGW0",
"MLG20PDAWW0",
"MLG20PRAWW0",
"WDF530PAYB0",
"WDF530PAYB1",
"WDF530PAYB2",
"WDF530PAYB3",
"WDF530PAYM0",
"WDF530PAYM1",

"WDF530PAYM2",

"WDF530PAYM3"

]

},

{

"part_name": "Door Handle WP9743903",

"part_number": "PS11747089",

"manufacturer": null,

"price": "69.11",

"description": "This is a door handle used for dishwashers, located on the front panel of the dishwasher. *Please Note: The handle is now only available in black and is sold separately. If your door handle will not close, open, start, or there is a door latch failure, then it is best to replace it to solve the issues mentioned above. For installation instructions and accurate guidance, refer to the manual provided by the manufacturer. As a safety precaution, remember to unplug your appliance from the power source.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure This part works with the following products: Dishwasher. Part# WP9743903 replaces these: AP6013862, 9743188, 9743189, 9743190, 9743903, 9743904, 9743905, 9743906 Back to Top",

"review_count": "4",

"appliance": "dishwasher",

"compatible_models": [

"KUDG25SHAL0",

"KUDG25SHAL1",

"KUDG25SHBL0",

"KUDG25SHBL1",

"KUDG25SHBT0",

"KUDG25SHBT1",
"KUDG25SHWH0",
"KUDG25SHWH1",
"KUDI24SEAL0",
"KUDI24SEAL1",
"KUDI24SEAL2",
"KUDI24SEAL3",
"KUDI24SEAL4",
"KUDI24SEAL5",
"KUDI24SEBL0",
"KUDI24SEBL1",
"KUDI24SEBL2",
"KUDI24SEBL3",
"KUDI24SEBL4",
"KUDI24SEBL5",
"KUDI24SEWH0",
"KUDI24SEWH1",
"KUDI24SEWH2",
"KUDI24SEWH3",
"KUDI24SEWH4",
"KUDI24SEWH5",
"KUDM24SEAL0",
"KUDM24SEAL1",
"KUDM24SEAL2",
"KUDM24SEAL3"

]

```
},
```

```
{
```

```
  "part_name": "HANDLE-STRIP 00489674",
```

```
  "part_number": "PS8722221",
```

```
  "manufacturer": null,
```

```
  "price": "34.69",
```

```
  "description": "",
```

```
  "rating": "60",
```

```
  "troubleshooting_tips": "This part fixes the following symptoms: Door latch failure This  
part works with the following products: Dishwasher. Part# 00489674 replaces these:  
AP3858398, 489674 Back to Top",
```

```
  "review_count": "4",
```

```
  "appliance": "dishwasher",
```

```
  "compatible_models": [
```

```
    "SGO45M02SK",
```

```
    "SGO45N08EU",
```

```
    "SGS43B32EE",
```

```
    "SGS43B42EE",
```

```
    "SGS43B52EE",
```

```
    "SGS43B52II",
```

```
    "SGS43B58II",
```

```
    "SGS43B72EE",
```

```
    "SGS43B82EE",
```

```
    "SGS43B92EP",
```

```
    "SGS43C12",
```

```
    "SGS43E02GB",
```

```
    "SGS43E08GB",
```



```
"SGS45A02GB",
"SGS45A08GB",
"SGS45E02GB",
"SGS45E08GB",
"SGS45E68GB",
"SGS45M02EU",
"SGS45M02II",
"SGS45M06II",
"SGS45M18AR",
"SGS45M18II",
"SGS45M32EE",
"SGS45M38EU",
"SGS45M38II",
"SGS45M42EE",
"SGS45M42II",
"SGS45M48EU",
"SGS45M48II"
]
},
{
  "part_name": "Door Handle Actuator WD13X10045",
  "part_number": "PS2337860",
  "manufacturer": null,
  "price": "39.29",
  "description": "This is a handle actuator for your dishwasher. It is made of black plastic,
and is sold individually. The handle actuator is found in the control panel, and it releases
the door latch when you lift the handle. If your current handle actuator is cracked or
```

broken, you may not be able to open your dishwasher door, or the door will not close properly. The dishwasher also may not be able to start, and if this is the case, you will need to replace this part.",

"rating": "92",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Will Not Start | Door won't close This part works with the following products: Dishwasher. Part# WD13X10045 replaces these: AP4355961, 1469070, WD13X10008 Back to Top",

"review_count": "7",

"appliance": "dishwasher",

"compatible_models": [

"40201-0",

"402011",

"40205-0",

"402051",

"40206-0",

"402061",

"402070",

"403110",

"403111",

"405010",

"405011",

"405012",

"405050",

"405051",

"405052",

"405060",

"405061",

"405062",
"4070100",
"4070110",
"4070500",
"4070510",
"4070600",
"4070610",
"4070800",
"4070810",
"4071100",
"4071110",
"4071120",
"4071500"

]

},

{

"part_name": "Dishwasher Door Handle WD09X21321",

"part_number": "PS11736562",

"manufacturer": null,

"price": "77.08",

"description": "Screws NOT included.",

"rating": "96",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WD09X21321 replaces these: WD09X10101 Back to Top",

"review_count": "5",

"appliance": "dishwasher",

"compatible_models": [

"CDT725SSF0SS",

"DDT575SMF0ES",

"DDT575SMF2ES",

"DDT575SMF4ES",

"DDT575SMF5ES",

"DDT575SMF6ES",

"DDT575SMF7ES",

"DDT575SMF8ES",

"DDT575SSF0SS",

"DDT575SSF2SS",

"DDT575SSF4SS",

"DDT575SSF5SS",

"DDT575SSF6SS",

"DDT575SSF7SS",

"DDT575SSF8SS",

"DDT595SMJ0ES",

"DDT595SMJ2ES",

"DDT595SMJ4ES",

"DDT595SMJ5ES",

"DDT595SSJ0SS",

"DDT595SSJ2SS",

"DDT595SSJ4SS",

"DDT595SSJ5SS",

"GDT530PSD0SS",

"GDT530PSD1SS",

```
"GDT530PSD2SS",
"GDT530PSD4SS",
"GDT530PSD6SS",
"GDT535PSJ0SS",
"GDT535PSJ2SS"
]
},
{
  "part_name": "Door Handle WP8269117",
  "part_number": "PS11745495",
  "manufacturer": null,
  "price": "72.89",
  "description": "NOTE: This part is no longer available in white or biscuit. HANDLE only.",
  "rating": "94",
  "troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close | Will Not Start This part works with the following products: Dishwasher. Part# WP8269117 replaces these: AP6012288, 8269117, 8269167, 8269168, 8269169, 8270115 Back to Top",
  "review_count": "25",
  "appliance": "dishwasher",
  "compatible_models": [
    "KUDC01TMBL0",
    "KUDC01TMBL1",
    "KUDC01TMBL6",
    "KUDC01TMWH1",
    "KUDC01TMWH6",
    "KUDC01TMWHO",
```

```
"KUDC02IRBL0",  
"KUDC02IRBL1",  
"KUDC02IRBL2",  
"KUDC02IRBL3",  
"KUDC02IRBL4",  
"KUDC02IRBS1",  
"KUDC02IRBS2",  
"KUDC02IRBS3",  
"KUDC02IRBS4",  
"KUDC02IRWH0",  
"KUDC02IRWH1",  
"KUDC02IRWH2",  
"KUDC02IRWH3",  
"KUDC02IRWH4",  
"KUDC03ITBL0",  
"KUDC03ITBL1",  
"KUDC03ITBL2",  
"KUDC03ITBL3",  
"KUDC03ITBS0",  
"KUDC03ITBS1",  
"KUDC03ITBS2",  
"KUDC03ITBS3",  
"KUDC03IVBL0",  
"KUDC03IVBL1"  
]  
},
```

```
{
  "part_name": "Door Latch with Switches - NO Handle WPW10275768",
  "part_number": "PS11751688",
  "manufacturer": null,
  "price": "56.22",
  "description": "This door latch, used in dishwashers, is located at the top of the door and locks the door shut when the dishwasher is working. If the door will not close or is damaged, changing the latch could be the solution. For this repair, remove all screws from the inner panel, then lift up the inner door panel and hold the door apart. Next, access the latch and pull wires from the switches. Refer to the manual provided by the manufacturer for further instructions and guidance. Remember to unplug the dishwasher from the power source or shut off the house circuit breaker before beginning this installation project.",
  "rating": "86",
  "troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close | Will Not Start | Leaking This part works with the following products: Dishwasher. Part# WPW10275768 replaces these: AP6018386, 99002580, 99003347, W10275768 Back to Top",
  "review_count": "20",
  "appliance": "dishwasher",
  "compatible_models": [
    "ADB1200AWB",
    "ADB1200AWQ",
    "ADB1200AWS",
    "ADB1200AWW",
    "ADB1500AWB",
    "ADB1500AWB0",
    "ADB1500AWB10",
    "ADB1500AWB3",
    "ADB1500AWB37",
```

```
"ADB1500AWB41",
"ADB1500AWB46",
"ADB1500AWQ",
"ADB1500AWQ0",
"ADB1500AWQ10",
"ADB1500AWQ3",
"ADB1500AWQ37",
"ADB1500AWQ41",
"ADB1500AWQ46",
"ADB1500AWS",
"ADB1500AWS0",
"ADB1500AWS10",
"ADB1500AWS3",
"ADB1500AWS37",
"ADB1500AWS41",
"ADB1500AWS46",
"ADB1500AWW",
"ADB1500AWW0",
"ADB1500AWW10",
"ADB1500AWW3",
"ADB1500AWW37"
]
},
{
  "part_name": "HANDLE-CAP SHAPED 00615352",
  "part_number": "PS8727824",
```


"manufacturer": null,

"price": "13.03",

"description": "",

"rating": "95",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure This part works with the following products: Dishwasher. Part# 00615352 replaces these: AP4369140, 00184592, 184592, 615352 Back to Top",

"review_count": "4",

"appliance": "dishwasher",

"compatible_models": [

"HWD275UC",

"HWD305UC",

"SGZ2055UC",

"SHU9955UC",

"SHU9955UC-12",

"SHX2AR55UC",

"SHX2ARL5UC",

"SHX33A05UC",

"SHX33A05UC-14",

"SHX33A05UC-14 (FD8211)",

"SHX33A05UC-21",

"SHX33M05UC",

"SHX33M05UC-46",

"SHX33R55UC",

"SHX33R55UC/64",

"SHX33RF5UC",

"SHX33RL5UC",

```
"SHX3AM05UC",  
"SHX3AM05UC01",  
"SHX3AR55UC",  
"SHX3AR55UC/06",  
"SHX3AR55UC/07",  
"SHX3AR75UC",  
"SHX3AR75UC/06",  
"SHX3AR75UC/07",  
"SHX43C05UC",  
"SHX43E05UC",  
"SHX43E05UC14",  
"SHX43M05UC",  
"SHX43M05UC-48"  
]  
,  
{  
  "part_name": "HANDLE-CAP SHAPED 00628998",  
  "part_number": "PS8729301",  
  "manufacturer": null,  
  "price": "8.06",
```

"description": "This door handle end cap is supplied directly by the manufacturer for use with dishwashers. It is a genuine OEM part that is designed to fit just like the original piece. The end cap is made of highly durable plastic, and it is responsible for securing the end of the handle on the dishwasher door. It protects the handle from scratches, dents, and general wear and tear, which can occur over time. It also contributes to the appearance of the dishwasher by concealing any exposed screws and providing a finished look to the handles. When replacing the end caps, you will need to first remove the door panel. Each end cap is sold individually.",

"rating": "90",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure This part works with the following products: Dishwasher. Part# 00628998 replaces these: AP5690748, 628998 Back to Top",

"review_count": "4",

"appliance": "dishwasher",

"compatible_models": [

"SGX68U55UC",

"SGX68U55UC-D5",

"SHX2AR55UC",

"SHX2ARL5UC-15",

"SHX3AR55UC",

"SHX3AR75UC",

"SHX4AT55UC",

"SHX4ATF5UC",

"SHX53T55UC",

"SHX5AV55UC",

"SHX5AV56UC",

"SHX5AVF5UC",

"SHX65T55UC",

"SHX68T55UC",

"SHX68TL5UC",

"SHX7ER55UC",

"SHX7PT55UC",

"SHX863WB5N",

"SHX863WD5N",

"SHX878WD5N",

"SHX88PW55N",

"SHX88PZ65N",

"SHX89PW55N",

"SHX8PT55UC",

"SHX9PT55UC",

"SHX9PT75UC",

"SHXM4AY55N",

"SHXM63W55N",

"SHXM63WS5N",

"SHXM65W55N"

]

},

{

"part_name": "Dishwasher Door Handle And Latch Assembly with Switch
WPW10130695",

"part_number": "PS11748729",

"manufacturer": null,

"price": "49.63",

"description": "This door latch (Dishwasher Door Latch Assembly, Door Latch Assembly, Latch Assembly) is a simple on/off mechanism that prohibits the dishwasher from operating when the door is open. It is located on the door of your dishwasher, and is mounted on the inner door panel. The door latch can break from material fatigue. If the door is often slammed or opened quickly, the latch may break prematurely. If the door won't open or the door switches won't activate, you will need to replace this part. This latch measures 5 1/2 inches wide, 4 1/2 inches high, 2 1/2 inches deep, is constructed out of plastic and comes in black. The kit includes the black handle, latch, and 2 switches.",

"rating": "96",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Will Not Start | Door won't close | Leaking This part works with the following products:

Dishwasher. Part# WPW10130695 replaces these: AP6015450, 99002577, 99002578, 99002579, W10130694, W10130695, W10130696, WPW10130694, WPW10130695VP, WPW10130696, WPW10130696VP Back to Top",

"review_count": "681",

"appliance": "dishwasher",

"compatible_models": [

"ADB1500AWB1",

"ADB1500AWB2",

"ADB1500AWQ1",

"ADB1500AWQ2",

"ADB1500AWS1",

"ADB1500AWS2",

"ADB1500AWW1",

"ADB1500AWW2",

"CDU650AWB",

"CDU650AWW",

"JDB1050AWB",

"JDB1050AWQ",

"JDB1050AWS",

"JDB1050AWW",

"JDB1060AWB",

"JDB1060AWQ",

"JDB1060AWS",

"JDB1060AWW",

"JDB1080AWB",

"JDB1080AWQ",

"JDB1080AWS",

```
"JDB1080AWW",
"JDB4000AWB",
"JDB4000AWQ",
"JDB4000AWS",
"JDB4000AWW",
"MDB4650AWB",
"MDB4650AWS",
"MDB4650AWW",
"MDB4651AWB"
]
},
{
  "part_name": "THERMOSTAT 5304482472",
  "part_number": "PS3496223",
  "manufacturer": "Kenmore",
  "price": "17.60",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#
5304482472 replaces these: AP5178525 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "58712332510A",
    "58712332F01B",
    "58712333510A",
```

"58712333F01B",
"58712339510A",
"58712339F01B",
"58714652110",
"58714652200A",
"58714652201B",
"58714659110",
"58714659200A",
"58714659201B",
"58714662110",
"58714662200A",
"58714662201B",
"58714663110",
"58714663200A",
"58714663201B",
"58714669110",
"58714669200A",
"58714669201B",
"EIDW1805KS0A",
"EIDW1805KS1B",
"FDB2410HIB2A",
"FDB2410HIB3B",
"FDB2410HIC2A",
"FDB2410HIC3B",
"FDB2410HIS2A",
"FDB2410HIS3B",

```
"FFBD1821MB0A"
]
},
{
  "part_name": "THERMOSTAT 304105",
  "part_number": "PS335598",
  "manufacturer": "Kenmore",
  "price": "21.15",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher, Dryer.
Part# 304105 replaces these: 304105 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "19985",
    "6651588580",
    "6651588582",
    "6651588583",
    "6651588584",
    "6651596080",
    "6651596580",
    "6651596581",
    "6651688580",
    "6651688581",
    "6651688582",
```



```
"6651688583",
"6651688584",
"6651690190",
"6651690191",
"6651690192",
"6651690590",
"6651690591",
"6651690592",
"6651696580",
"6651696581",
"6651696582",
"DE309",
"DE407",
"DE408",
"DE409",
"DG309",
"DG407",
"DG408",
"DG409"
]
},
{
  "part_name": "THERMOSTAT 5304461728",
  "part_number": "PS1992843",
  "manufacturer": "Kenmore",
  "price": "22.15",
```

```
"description": "",
"rating": null,
"troubleshooting_tips": "This part works with the following products: Dishwasher. Back
to Top",
"review_count": null,
"appliance": "dishwasher",
"compatible_models": [
  "58714402400",
  "58714403400",
  "58714409400",
  "58714412400",
  "58714419400",
  "FDB2410HIB0",
  "FDB2410HIB1",
  "FDB2410HIC0",
  "FDB2410HIC1",
  "FDB2410HIS0",
  "FDB2410HIS1",
  "FMB330RGB0",
  "FMB330RGC0",
  "FMB330RGS0",
  "FMP330RGB0",
  "FMP330RGS0"
],
{
```

"part_name": "THERMOSTAT WD01X10567",
"part_number": "PS5135665",
"manufacturer": null,
"price": "21.70",
"description": "",
"rating": null,
"troubleshooting_tips": "This part works with the following products: Dishwasher. Back to Top",
"review_count": null,
"appliance": "dishwasher",
"compatible_models": [
"GLC5604V00BB",
"GLD2850V00CS",
"GLD4550V00CS",
"GLD4560V00SS",
"GLD4604V00BB",
"GLD4604V00WW",
"GLD4644V00SA",
"GLD4664V00SS",
"GLD5604V00BB",
"GLD5604V00CC",
"GLD5604V00WW",
"GLD5606V00BB",
"GLD5606V00CC",
"GLD5606V00WW",
"GLD5654V00CS",

"GLD5660V00SS",
"GLD5664V00SS",
"GLD5666V00SS",
"GLD5666V15SS",
"GLD5706V00BB",
"GLD5706V00CC",
"GLD5706V00WW",
"GLD5708V00BB",
"GLD5708V00WW",
"GLD5766V00SS",
"GLD5768V00SS",
"GLD5808V00BB",
"GLD5808V00WW",
"GLD5868V00SS",
"GLD7768V00SS"

]

},

{

"part_name": "THERMOSTAT 154227811",

"part_number": "PS8746670",

"manufacturer": "Kenmore",

"price": "23.39",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dishwasher. Back to Top",

```
"review_count": null,  
"appliance": "dishwasher",  
"compatible_models": [  
  "58714012409B",  
  "58714012410B",  
  "58714012411B",  
  "58714012412B",  
  "58714012413B",  
  "58714012414B",  
  "58714012416B",  
  "58714013410B",  
  "58714013411B",  
  "58714013412B",  
  "58714013413B",  
  "58714013414B",  
  "58714013415B",  
  "58714013416B",  
  "58714013417B",  
  "58714014409B",  
  "58714014410B",  
  "58714014411B",  
  "58714014412B",  
  "58714014413B",  
  "58714019409B",  
  "58714019410B",  
  "58714019411B",
```

```
"58714019412B",
"58714019413B",
"58714019414B",
"58714019415B",
"58714019416B",
"FBD2400KB10B",
"FBD2400KB11B"
]
},
{
  "part_name": "Limit Thermostat WP99001852",
  "part_number": "PS11747621",
  "manufacturer": null,
  "price": "41.32",
  "description": "This part is used to sense and maintain the heating element temperature
in the dishwasher.",
  "rating": null,
  "troubleshooting_tips": "This part fixes the following symptoms: Not drying dishes
properly This part works with the following products: Dishwasher. Part# WP99001852
replaces these: 99001852 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "ADW662EAB",
    "ADW662EAB-PADW662EAB0",
    "ADW662EAC",
    "ADW662EAC-PADW662EAC0",
```

"ADW662EAS",
"ADW662EAW",
"ADW662EAW-PADW662EAW0",
"ADW862EAB",
"ADW862EAC",
"ADW862EAS",
"ADW862EAW",
"CDB3100AWE",
"CDB3100AWT",
"CDB3100AWX",
"CDB6100AWE",
"CDB6100AWN",
"CDB6100AWX",
"CDC610B",
"CDU510B",
"CDU510V",
"CDU610B",
"CDU610N",
"CDU610V",
"CDU810B",
"CDU810V",
"DDW2470AWP",
"DDW261RAB",
"DDW261RAB-PDDW261RAB0",
"DDW261RAW",
"DDW261RAW-PDDW261RAW0"

```
]
},
{
  "part_name": "High Limit Thermostat 154290204",
  "part_number": "PS420575",
  "manufacturer": "Kenmore",
  "price": "51.03",
  "description": "This resettable hi-limit thermostat acts as a safety mechanism that keeps the dishwasher from overheating. This part will cut out if the internal temperature reaches 200 degrees Fahrenheit. It will reset when the temperature drops to 100 degrees Fahrenheit - the differential of 100 degrees.",
  "rating": "50",
  "troubleshooting_tips": "This part fixes the following symptoms: Not drying dishes properly | Not cleaning dishes properly This part works with the following products: Dishwasher. Part# 154290204 replaces these: AP2109201, 12758, 154290201, 154290202, 154290203 Back to Top",
  "review_count": "2",
  "appliance": "dishwasher",
  "compatible_models": [
    "58714000100",
    "58714000101",
    "58714000102",
    "58714001990",
    "58714001991",
    "58714001992",
    "58714001993",
    "58714002990",
    "58714002991",
```



```
"58714002992",  
"58714002993",  
"58714003100",  
"58714008001",  
"58714008002",  
"58714008003",  
"58714009100",  
"58714009101",  
"58714009102",  
"58714012400",  
"58714012401",  
"58714012402",  
"58714012403",  
"58714012404",  
"58714012405",  
"58714012406A",  
"58714013400",  
"58714013401",  
"58714013402",  
"58714013403",  
"58714013404"  
]  
,  
{  
  "part_name": "Cycling Thermostat - L150-25F WPY304474",  
  "part_number": "PS11757517",
```

"manufacturer": "Kenmore",

"price": "48.07",

"description": "This thermostat controls the internal drying temperature. \nCycling thermostats continually cycle the heating element off and on to maintain a constant inner temperature. This particular cycling thermostat has a limit of 150 degrees Fahrenheit and a differential of 25 degrees. Meaning that with this thermostat, the heating element will cut out at 150 degrees and cycle back on once the internal temperature drops by 25 degrees.",

"rating": null,

"troubleshooting_tips": "This part fixes the following symptoms: Too hot This part works with the following products: Dryer, Dishwasher. Part# WPY304474 replaces these: AP6024167, 304474, Y304474 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"6651570992",

"DE110",

"DE210",

"DE408",

"DE409",

"DE410",

"DE412",

"DE510",

"DE512",

"DE590",

"DE610",

"DE612",

"DE710",

"DE810",

```
"DG110",
"DG210",
"DG408",
"DG409",
"DG410",
"DG412",
"DG510",
"DG512",
"DG590",
"DG610",
"DG612",
"DG710",
"DG810",
"DU9000XR0",
"DU9000XR1",
"DU9000XR2"
]
},
{
  "part_name": "Thermostat WPW10195091",
  "part_number": "PS11750035",
  "manufacturer": "Kenmore",
  "price": "44.96",
```

"description": "This genuine OEM thermostat is sourced directly from the manufacturer to ensure compatibility with your dishwasher model. The thermostat monitors and regulates the temperature of the dishwasher heating element. It is responsible for ensuring that the water temperature reaches the optimal level for effective cleaning while also

helping to prevent overheating and potential damage to the internal components of the dishwasher.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Not drying dishes properly | Not cleaning dishes properly | Will Not Start This part works with the following products: Dishwasher. Part# WPW10195091 replaces these: AP6016742, W10195091, W10339563 Back to Top",

"review_count": "2",

"appliance": "dishwasher",

"compatible_models": [

"2213222N414",

"2213223N414",

"2213229N414",

"2214523N611",

"2214545N711",

"2214715N710",

"2214792N512",

"2214793N512",

"66512762K312",

"66512762K313",

"66512763K312",

"66512763K313",

"66512769K312",

"66512769K313",

"66512772K313",

"66512772K314",

"66512773K313",

"66512773K314",

"66512774K312",

"66512774K313",

"66512776K311",

"66512776K314",

"66512779K312",

"66512779K313",

"66512779K314",

"66512782K310",

"66512782K311",

"66512782K312",

"66512782K313",

"66512783K311"

]

},

{

"part_name": "High Limit Thermostat WP661566",

"part_number": "PS11743423",

"manufacturer": "Kenmore",

"price": "20.69",

"description": "This part acts as as safety mechanism that keeps the dryer from overheating. Once the dryer temperature reaches a certain point, this part will shut down power to the heating element.",

"rating": "98",

"troubleshooting_tips": "This part fixes the following symptoms: Not drying dishes properly | Will Not Start | Not cleaning dishes properly This part works with the following

products: Dishwasher. Part# WP661566 replaces these: AP6010246, 3369777, 3370783, 3371618, 4171694, 661566, W10339474, WP661566VP Back to Top",

"review_count": "9",

"appliance": "dishwasher",

"compatible_models": [

"110773811",

"110773812",

"110773813",

"110773881",

"110773882",

"110773883",

"2212413N414",

"2213092N413",

"2213099N413",

"2213479N413",

"2213809N710",

"2217383N710",

"2217389N710",

"65715755791",

"66213032K112",

"66213273K112",

"66512093K210",

"66512413N410",

"66512413N411",

"66512413N412",

"66512413N413",

"66512723K310",

"66512723K311",

"66513002N510",

"66513002N511",

"66513003N510",

"66513003N511",

"66513004N510",

"66513004N511",

"66513009N510"

]

},

{

"part_name": "Circulation Pump and Motor Assembly W10782773",

"part_number": "PS11699805",

"manufacturer": "Kenmore",

"price": "207.38",

"description": "**** This part no longer includes the Chopper Assembly as per the Manufacturer ***\r\nThe part functions by spinning the impeller of the circulation pump, which is used to move the water through the spray arms during the wash cycle.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Not cleaning dishes properly | Will Not Start | Leaking This part works with the following products: Dishwasher. Part# W10782773 replaces these: AP5962285, 8193772, 8268413, 8268422, 8534884, 8535147, 8535148, 8535149, 8535150, 8535761, 8535762, 8545578, 8564074, 8564075, W10239405, W10780878 Back to Top",

"review_count": "10",

"appliance": "dishwasher",

"compatible_models": [

"665110739120",
"665110739130",
"665110739140",
"665110739190",
"66514353300",
"66514353301",
"66515872000",
"66515874000",
"66515879000",
"66515882000",
"66515884000",
"66515887000",
"66515889000",
"66515892100",
"66515894100",
"66515899100",
"66515912000",
"66515912001",
"66515914000",
"66515914001",
"66515919000",
"66515919001",
"66515922000",
"66515922001",
"66515923000",
"66515923001",


```
"66515924000",
"66515924001",
"66515929000",
"66515929001"
]
},
{
  "part_name": "Motor and Drain Pump WH23X10028",
  "part_number": "PS1766031",
  "manufacturer": "Kenmore",
  "price": "238.72",
  "description": "This pump helps expel water from the washing machine and is activated after the spin speed is maintained for a specific period of time. This pump has sound isolation mounting washers and a filter.",
  "rating": "96",
  "troubleshooting_tips": "This part fixes the following symptoms: Will not drain This part works with the following products: Dishwasher, Washer. Part# WH23X10028 replaces these: AP4324598, 1394137, WH23X10028, WD02X10099, WD02X10106, WD2X10099, WH23X10026, WH23X10037 Back to Top",
  "review_count": "13",
  "appliance": "dishwasher",
  "compatible_models": [
    "36314181200",
    "36314181202",
    "36315222100",
    "36315229100",
    "36315322100",
```

"36315324100",
"36315329100",
"36316222100",
"36316229100",
"402011",
"402051",
"402061",
"403111",
"405010",
"405011",
"405012",
"405050",
"405051",
"405052",
"405060",
"405061",
"405062",
"4070100",
"4070110",
"4070500",
"4070510",
"4070600",
"4070610",
"4070800",
"4070810"

]

```
},
{
  "part_name": "Dishwasher Circulation Motor & Pump Kit with Harness 154859101",
  "part_number": "PS3501031",
  "manufacturer": "Kenmore",
  "price": "179.58",
  "description": "This part has been redesigned by the manufacturer and may appear different, but will function the same. This kit helps propel the water through the spray arms.",
  "rating": "94",
  "troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Leaking | Noisy | Will Not Start This part works with the following products: Dishwasher. Part# 154859101 replaces these: AP5272389, 1940277, 154859101, 154369501, 154395402, 154395403, 154405501, 154418301, 154418302, 154520501, 154523501, 154536101, 154539901, 154574701, 154588402, 154588801 Back to Top",
  "review_count": "3",
  "appliance": "dishwasher",
  "compatible_models": [
    "58714000100",
    "58714000101",
    "58714000102",
    "58714001991",
    "58714001992",
    "58714001993",
    "58714002991",
    "58714002992",
    "58714002993",
    "58714003100",
```

```
"58714008001",
"58714008002",
"58714008003",
"58714009100",
"58714009101",
"58714009102",
"58714112401",
"58714113401",
"58714114401",
"58714119401",
"58714131101",
"58714131102",
"58714132101",
"58714132102",
"58714134101",
"58714134102",
"58714139101",
"58714139102",
"58714153400",
"58714153401"
]
},
{
  "part_name": "Diverter Motor with Wire Harness W10155344",
  "part_number": "PS2328555",
  "manufacturer": "Kenmore",
```

"price": "89.33",

"description": "NOTE: This part has been updated by the manufacture and the shaft seal is now incorporated into the sump housing. The seal for diverter motor shaft only available with the pump sump housing.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Not cleaning dishes properly This part works with the following products: Dishwasher. Part# W10155344 replaces these: AP4324941, 8579252, W10056349, W10134015, W10155344, W10208691 Back to Top",

"review_count": "1",

"appliance": "dishwasher",

"compatible_models": [

"66513122K700",

"66513122K701",

"66513122K702",

"66513122K703",

"66513123K700",

"66513123K701",

"66513123K702",

"66513123K703",

"66513124K700",

"66513124K701",

"66513124K702",

"66513124K703",

"66513129K700",

"66513129K701",

"66513129K702",

"66513129K703",
"66513132K700",
"66513132K701",
"66513133K700",
"66513133K701",
"66513139K700",
"66513139K701",
"66513152K700",
"66513152K701",
"66513152K702",
"66513153K700",
"66513153K701",
"66513153K702",
"66513154K700",
"66513154K701"

]

},

{

"part_name": "Drain Pump 154580301",

"part_number": "PS1765174",

"manufacturer": "Kenmore",

"price": "85.30",

"description": "The pump ejects the water from the unit.",

"rating": "80",

"troubleshooting_tips": "This part fixes the following symptoms: Not draining | Noisy |
Leaking This part works with the following products: Dishwasher. Part# 154580301
replaces these: AP4019644, 1257094, 154580301, 154491301 Back to Top",

```
"review_count": "8",  
"appliance": "dishwasher",  
"compatible_models": [  
  "58714102800",  
  "58715102800",  
  "58715102801",  
  "58715103800",  
  "58715103801",  
  "58715104800",  
  "58715104801",  
  "58715109800",  
  "58715109801",  
  "58715202800",  
  "58715202801",  
  "58715202802",  
  "58715203800",  
  "58715203801",  
  "58715203802",  
  "58715252400",  
  "58715252401",  
  "58715252402",  
  "58715253400",  
  "58715253401",  
  "58715253402",  
  "58715254400",  
  "58715254401",
```

"58715254402",

"58715259400",

"58715259401",

"58715259402",

"58716102800",

"58716102801",

"58716103800"

]

},

{

"part_name": "Pump and Motor Assembly W11025157",

"part_number": "PS11770231",

"manufacturer": "Kenmore",

"price": "227.60",

"description": "This pump and motor assembly is for dishwashers.\r\n\r\nPump and motor assembly pumps water through the spray arms during the dishwashing cycle.\r\n\r\nShut off the house circuit breaker for the dishwasher before installing this part. Wear work gloves to protect your hands.",

"rating": null,

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher. Part# W11025157 replaces these: W10837401, W11184516 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"2213809N710",

"2217383N710",

"2217389N710",
"66513002N511",
"66513003N511",
"66513004N511",
"66513009N511",
"66513802N710",
"66513803N710",
"66513804N710",
"66513809N710",
"66514312N413",
"66514313N413",
"66514319N413",
"66514422N511",
"66514423N511",
"66514429N511",
"66514502N020",
"66514503N020",
"66514509N020",
"66515112K218",
"66515113K218",
"66515114K218",
"66515119K218",
"66517152K217",
"66517159K217",
"66517382N710",
"66517383N710",

```
"66517389N710",
"66517482N710"
]
},
{
  "part_name": "Motor and Pump Assembly 5304519906",
  "part_number": "PS12712308",
  "manufacturer": null,
  "price": "182.70",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher. Part# 5304519906 replaces these: AP6840161 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "605222850A",
    "804621670A",
    "804621671A",
    "905222840A",
    "FDPC4221AB0A",
    "FDPC4221AS0A",
    "FDPC4221AW0A",
    "FFCD2413UB1A",
    "FFCD2413UB2A",
    "FFCD2413UB3A",
```

```
"FFCD2413UB4A",
"FFCD2413US1A",
"FFCD2413US2A",
"FFCD2413US3A",
"FFCD2413US4A",
"FFCD2413UW1A",
"FFCD2413UW2A",
"FFCD2413UW3A",
"FFCD2413UW4A",
"FFCD2418UB3A",
"FFCD2418US3A",
"FFCD2418UW3A",
"FFID2426TB1A",
"FFID2426TB2A",
"FFID2426TB3A",
"FFID2426TD3A",
"FFID2426TD4A",
"FFID2426TD5A",
"FFID2426TS3A",
"FFID2426TS4A"
]
},
{
  "part_name": "Diverter Motor - 120V 60Hz 4681ED3001D",
  "part_number": "PS3579323",
  "manufacturer": "LG",
```

"price": "40.39",

"description": "This diverter motor, or stepper motor, controls the movement of the spray arms in your dishwasher. It directs water between the drain pump and the spray arms by turning a check valve inside the pump, managing the flow of water to these spray arms. This diverter motor runs on 120 volts and 60 Hz. When this motor fails, the dishwasher will not wash or drain properly. Please keep in mind that this genuine OEM replacement part is sold separately from the spray arms.",

"rating": "90",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Noisy This part works with the following products: Dishwasher. Part# 4681ED3001D replaces these: AP5243567, 4681ED3001B Back to Top",

"review_count": "6",

"appliance": "dishwasher",

"compatible_models": [

"13383",

"13387",

"14305",

"14307",

"14355",

"14357",

"14673",

"14677",

"14693",

"14697",

"39232533",

"72213387910",

"72214305910",

"72214307910",

```
"72214357910",
"72214673710",
"72214697610",
"ADFD5448AT",
"D1401TB",
"D1401TB1",
"D1412TB",
"D1414TB",
"D1425TB",
"D1426DB1",
"D1426TB",
"D1426TB1",
"D1435BB",
"D1435TB",
"D1435WB",
"D1436TB"
]
},
{
  "part_name": "Pump Motor Kit 154844301",
  "part_number": "PS3497737",
  "manufacturer": "Kenmore",
  "price": "163.71",
  "description": "This kit includes the motor and o-rings.",
  "rating": "95",
```

"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Not cleaning dishes properly | Leaking | Will Not Start This part works with the following products: Dishwasher. Part# 154844301 replaces these: AP5272221, 1940268, 154488001, 154588701, 154594201, 154648101, 154700101, 154792801, 154794401 Back to Top",

"review_count": "11",

"appliance": "dishwasher",

"compatible_models": [

"58714022200A",

"58714023200A",

"58714024200A",

"58714028200A",

"58714029200A",

"58714102800",

"58714112400",

"58714112401",

"58714112402",

"58714113400",

"58714113401",

"58714113402",

"58714114400",

"58714114401",

"58714114402",

"58714119400",

"58714119401",

"58714119402",

"58714183403",

"58714183404",

"58714184403",

"58714184404",

"58715102800",

"58715102801",

"58715103800",

"58715103801",

"58715104800",

"58715104801",

"58715109800",

"58715109801"

]

},

{

"part_name": "Motor W10537869",

"part_number": "PS5136127",

"manufacturer": "Kenmore",

"price": "109.32",

"description": "Also know as a diverter valve. This diverter motor is for dishwashers.\r\n\r\nDiverter motor controls the flow of water to the spray arms.\r\n\r\nUnplug the dishwasher and shut off the water supply before installing this part. Wear work gloves to protect your hands.",

"rating": "90",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Not cleaning dishes properly This part works with the following products: Dishwasher. Part# W10537869 replaces these: AP5650272, W10195076, W10476222, W10537869VP, W10849439 Back to Top",

"review_count": "21",

"appliance": "dishwasher",

"compatible_models": [

"2212413N414",

"2213092N413",

"2213099N413",

"2213222N414",

"2213223N414",

"2213229N414",

"2213479N413",

"2214523N611",

"2214545N711",

"2214715N710",

"2214792N512",

"2214793N512",

"66213032K112",

"66213273K112",

"66512093K210",

"66512413N410",

"66512413N411",

"66512413N412",

"66512413N413",

"66512723K310",

"66512723K311",

"66512762K312",

"66512763K312",

"66512763K313",

"66512769K312",


```
"66512769K313",
"66512772K312",
"66512772K313",
"66512772K314",
"66512773K313"
]
},
{
  "part_name": "SHELF 5304482487",
  "part_number": "PS3496238",
  "manufacturer": "Kenmore",
  "price": "24.70",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 5304482487 replaces these: AP5178540 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "58712332510A",
    "58712332F01B",
    "58712333510A",
    "58712333F01B",
    "58712339510A",
    "58712339F01B",
    "FDB2410HIB2A",
```

```
"FDB2410HIB3B",
"FDB2410HIC2A",
"FDB2410HIC3B",
"FDB2410HIS2A",
"FDB2410HIS3B"
]
},
{
  "part_name": "SHELF 5304480733",
  "part_number": "PS3419936",
  "manufacturer": "Kenmore",
  "price": "29.55",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher, Refrigerator. Part# 5304480733 replaces these: AP4701001 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "58715412100A",
    "58715413100A",
    "FGHD2455LB0",
    "FGHD2455LB1A",
    "FGHD2455LF0",
    "FGHD2455LF1A",
    "FGHD2455LW0",
```

```
"FGHD2455LW1A"
]
},
{
  "part_name": "Shelf WP8268828",
  "part_number": "PS11745470",
  "manufacturer": "Kenmore",
  "price": "77.21",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#
WP8268828 replaces these: 3369907, 3370474, 3371264, 3371266, 8268828 Back to
Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "66213032K112",
    "66513032K110",
    "66513032K111",
    "66513032K112",
    "66513032K113",
    "66513032K114",
    "66513032K115",
    "66513032K116",
    "66513033K110",
    "66513033K111",
    "66513033K112",
```

```
"66513033K113",
"66513033K114",
"66513033K115",
"66513033K116",
"66513039K110",
"66513039K111",
"66513039K112",
"66513039K113",
"66513039K114",
"66513039K115",
"66513039K116",
"66513592K600",
"66513593K600",
"66513594K600",
"66513599K600",
"66513692K600",
"66513699K600",
"66515032K110",
"66515032K112"
]
},
{
  "part_name": "TRAY MJS63631802",
  "part_number": "PS12082162",
  "manufacturer": "LG",
  "price": "34.63",
```

```
"description": "",
"rating": null,
"troubleshooting_tips": "This part works with the following products: Dishwasher, Range.
Back to Top",
"review_count": null,
"appliance": "dishwasher",
"compatible_models": [
  "LUDP8908SN",
  "LUDP8996SN",
  "LUDP8997SN",
  "SKSDW2401S"
]
},
{
  "part_name": "TRAY MJS63631801",
  "part_number": "PS12082161",
  "manufacturer": "LG",
  "price": "34.63",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#
MJS63631801 replaces these: MJS63631803 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "14305",
    "14307",
```

"14355",
"14357",
"14673",
"14677",
"72214305910",
"72214307910",
"72214357910",
"72214673710",
"79551832414",
"LDP5676BD",
"LDP6797BB",
"LDP6797BD",
"LDP6797BM",
"LDP6797SS",
"LDP6797ST",
"LDP6797WW",
"LDP6810BD",
"LDP6810SS",
"LDP7708BD",
"LDP7708ST",
"LDP7808BD",
"LDP7808SS",
"LDPN6761T",
"LDPS6844AS",
"LDT7797BD",
"LDT7797BM",

```
"LDT7797ST",
"LDT7808BD"
]
},
{
  "part_name": "SHELF W10630204",
  "part_number": "PS10062144",
  "manufacturer": null,
  "price": "55.78",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "JDB9800CWP1",
    "JDB9800CWP2",
    "JDB9800CWP3",
    "JDB9800CWS1",
    "JDB9800CWS2",
    "JDB9800CWS3",
    "JDB9800CWX2",
    "JDTSS245GX0",
    "JDTSS246GL0",
    "JDTSS246GM0",
```

```
"JDTSS246GP0",
"JDTSS246GS0",
"JDTSS247HS0",
"MDB7949SDE0",
"MDB7949SDE1",
"MDB7949SDE2",
"MDB7949SDE3",
"MDB7949SDH0",
"MDB7949SDH1",
"MDB7949SDH2",
"MDB7949SDH3",
"MDB7949SDM0",
"MDB7949SDM1",
"MDB7949SDM2",
"MDB7949SDM3",
"MDB8969SDE0",
"MDB8969SDE1",
"MDB8969SDE2",
"MDB8969SDE3",
"MDB8969SDH0"
]
},
{
  "part_name": "SHELF 808124102",
  "part_number": "PS9494200",
  "manufacturer": null,
```



```
"price": "138.45",
"description": "",
"rating": null,
"troubleshooting_tips": "This part works with the following products: Dishwasher. Back
to Top",
"review_count": null,
"appliance": "dishwasher",
"compatible_models": [
  "905045720A",
  "FDSH4501AS0A",
  "FDSH4501AS1A",
  "FDSH4501AS2A",
  "FDSH4501AS3A",
  "FDSH450LAF0A",
  "FDSH450LAF1A",
  "FDSH450LAF2A",
  "FDSH450LAF3A",
  "FFID2459VS0A",
  "FFID2459VS1A",
  "FFID2459VS2A",
  "FFID2459VS3A",
  "FGCD2456QB0A",
  "FGCD2456QB0B",
  "FGCD2456QB1B",
  "FGCD2456QF0A",
  "FGCD2456QF0B",
```

"FGCD2456QF1B",
"FGCD2456QF4B",
"FGCD2456QW0A",
"FGCD2456QW0B",
"FGCD2456QW1B",
"FGID2474QB0A",
"FGID2474QB0B",
"FGID2474QB1B",
"FGID2474QB3B",
"FGID2474QB4B",
"FGID2474QB5B",
"FGID2474QB6B"

]

},

{

"part_name": "TRAY 807104203",

"part_number": "PS9494136",

"manufacturer": null,

"price": "161.63",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dishwasher. Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"905045720A",
"E24ID74QPS0A",
"E24ID74QPS1A",
"E24ID74QPS3A",
"E24ID74QPS4A",
"E24ID75SPS0A",
"E24ID75SPS1A",
"E24ID75SPS2A",
"E24ID75SPS3A",
"EDSH4944AS0A",
"EI24CD35RS2A",
"EI24CD35RS3A",
"EI24CD35RS4A",
"EI24ID30QB0A",
"EI24ID30QB0B",
"EI24ID30QB3B",
"EI24ID30QS0A",
"EI24ID30QS0B",
"EI24ID30QS3B",
"EI24ID30QS4B",
"EI24ID30QS5B",
"EI24ID30QW0A",
"EI24ID30QW0B",
"EI24ID30QW3B",
"EI24ID50QS0A",
"EI24ID50QS0B",

```
"EI24ID50QS1A",
"EI24ID50QS1B",
"EI24ID50QS4B",
"EI24ID50QS5B"
]
},
{
  "part_name": "Tray MJS38945601",
  "part_number": "PS3535959",
  "manufacturer": "LG",
  "price": "34.63",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Back  
to Top",
  "review_count": "1",
  "appliance": "dishwasher",
  "compatible_models": [
    "14693",
    "39232533",
    "72214697610",
    "D1454CFN",
    "LDF7061ST",
    "LDF7561ST",
    "LDF7774BB",
    "LDF7774BD",
```

```
"LDF7774ST",
"LDF7774WW",
"LDF8574ST",
"LDF8874ST",
"LDF9810ST",
"LDF9932ST",
"LDS5560ST",
"LDS5774ST",
"LDT9965BD",
"LSDF995ST",
"LSDF9962ST",
"LSDF9969BD"
]
},
{
  "part_name": "Upper Dishrack with Wheels WD28X10399",
  "part_number": "PS8690632",
  "manufacturer": null,
  "price": "231.05",
  "description": "This rack comes with the attached rollers",
  "rating": "97",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WD28X10399 replaces these: AP5781495, WD28X10164, WD28X10167, WD28X10214, WD28X10287, WD28X10336 Back to Top",
  "review_count": "6",
  "appliance": "dishwasher",
  "compatible_models": [
```

"4070100",
"4070110",
"4070500",
"4070510",
"4070600",
"4070800",
"4070810",
"4071100",
"4071110",
"4071120",
"4071500",
"4071510",
"4071520",
"4071600",
"4071610",
"4071620",
"EDW5000L00BB",
"EDW5000L00CC",
"EDW5000L00WW",
"EDW5000L15BB",
"EDW5000L15CC",
"EDW5000L15WW",
"EDW5060L00SS",
"EDW5060L15SS",
"EDW5100N00BB",
"EDW5100N00CC",

```
"EDW5100N00WW",
"EDW5100N10BB",
"EDW5100N10CC",
"EDW5100N10WW"
]
},
{
  "part_name": "Turbidity Sensor 154473901",
  "part_number": "PS816014",
  "manufacturer": "Kenmore",
  "price": "161.85",
  "description": "The sensor measures level of soil in the water and the thermistor is used
to regulate water temperature when certain cycles or options are selected.",
  "rating": null,
  "troubleshooting_tips": "This part fixes the following symptoms: Will Not Start This part
works with the following products: Dishwasher. Part# 154473901 replaces these:
AP3580342, 1014458, 7154473901 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "58715202800",
    "58715202801",
    "58715202802",
    "58715203800",
    "58715203801",
    "58715203802",
    "EDW7505HPS0",
```

```
"EDW7505HPS0A",  
"EDW7505HPS1B",  
"EDW7505HSS0",  
"EDW7505HSS0A",  
"EDW7505HSS1B",  
"EIDW5905JB0A",  
"EIDW5905JS0A",  
"EIDW5905JW0A",  
"EIDW6105GB0",  
"EIDW6105GB1",  
"EIDW6105GB1A",  
"EIDW6105GB2B",  
"EIDW6105GS0",  
"EIDW6105GS1",  
"EIDW6105GS1A",  
"EIDW6105GS2B",  
"EIDW6105GW0",  
"EIDW6105GW1",  
"EIDW6105GW1A",  
"EIDW6105GW2B",  
"EIDW6305GB0",  
"EIDW6305GB1",  
"EIDW6305GB1A"  
]  
,  
{
```


"part_name": "SENSOR TURBIDITY Assembly WD21X10494",
"part_number": "PS7783361",
"manufacturer": null,
"price": "25.57",
"description": "",
"rating": null,
"troubleshooting_tips": "This part works with the following products: Dishwasher. Back to Top",
"review_count": null,
"appliance": "dishwasher",
"compatible_models": [
"ADT521PGF0BS",
"ADT521PGF0WS",
"ADT521PGF2BS",
"ADT521PGF2WS",
"ADT521PGJBS",
"ADT521PGJWS",
"CDT725SSF0SS",
"CDT725SSF2SS",
"CDT725SSF4SS",
"CDT725SSF6SS",
"CDT725SSF7SS",
"CDT765SSF0SS",
"CDT765SSF1SS",
"CDT765SSF7SS",
"DDT575SGF0BB",

"DDT575SGF0WW",
"DDT575SGF2BB",
"DDT575SGF2WW",
"DDT575SMF0ES",
"DDT575SMF2ES",
"DDT575SSF0SS",
"DDT575SSF2SS",
"GDF520PGD0BB",
"GDF520PGD0CC",
"GDF520PGD0WW",
"GDF520PGD1BB",
"GDF520PGD1CC",
"GDF520PGD1WW",
"GDF520PGD2BB",
"GDF520PGD2CC"

]

},

{

"part_name": "SENSOR 00611574",

"part_number": "PS8727394",

"manufacturer": "Kenmore",

"price": "29.72",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 00611574 replaces these: AP4483013, 611574 Back to Top",

```
"review_count": null,  
"appliance": "dishwasher",  
"compatible_models": [  
  "63013003012",  
  "63013003015",  
  "63013003016",  
  "63013003017",  
  "63013003018",  
  "63013023010",  
  "63013023011",  
  "63013023015",  
  "63013023016",  
  "63013023017",  
  "63013023018",  
  "63013993010",  
  "63013993012",  
  "63013993015",  
  "63013993016",  
  "63013993017",  
  "63013993018",  
  "DF240161",  
  "DF241161",  
  "DF241761",  
  "DF260141",  
  "DF260142",  
  "DF260161",
```

```
"DF260161F",
"DF260162",
"DF260760",
"DF260761",
"DF261161",
"DF261161F",
"DF261161S"
]
},
{
  "part_name": "Turbidity Sensor 00165279",
  "part_number": "PS8697053",
  "manufacturer": "Kenmore",
  "price": "53.09",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 00165279 replaces these: AP2802364, 165279 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "63013952010",
    "63013952011",
    "63013953010",
    "63013953011",
    "63013959010",
```

"63013959011",
"63016302400",
"63016302401",
"63016302402",
"63016302403",
"63016302404",
"63016302405",
"63016302406",
"63016303400",
"63016303401",
"63016303402",
"63016303403",
"63016303404",
"63016303405",
"63016303406",
"63016304400",
"63016304401",
"63016304402",
"63016304403",
"63016304404",
"63016304405",
"63016304406",
"63016309400",
"63016309401",
"63016309402"

]

```
},  
{  
  "part_name": "Dishwasher Thermistor WP8269208",  
  "part_number": "PS11745500",  
  "manufacturer": "Kenmore",  
  "price": "117.38",  
  "description": "This part is used to regulate water temperature when certain cycles or  
options are selected. The thermistor is part of the sensor mounted in the tub.",  
  "rating": null,  
  "troubleshooting_tips": "This part fixes the following symptoms: Will Not Start | Not  
cleaning dishes properly This part works with the following products: Dishwasher. Part#  
WP8269208 replaces these: AP6012293, 8269208 Back to Top",  
  "review_count": null,  
  "appliance": "dishwasher",  
  "compatible_models": [  
    "66514353300",  
    "66515872000",  
    "66515874000",  
    "66515879000",  
    "66515882000",  
    "66515884000",  
    "66515887000",  
    "66515889000",  
    "66515892100",  
    "66515894100",  
    "66515899100",  
    "66515912000",
```

```
"66515914000",
"66515919000",
"66516012402",
"66516013402",
"66516014402",
"66516019402",
"66516052401",
"66516052402",
"66516053400",
"66516053401",
"66516053402",
"66516054400",
"66516054401",
"66516054402",
"66516059401",
"66516059402",
"66516262400",
"66516262402"
]
},
{
  "part_name": "Turbidity Sensor 154762601",
  "part_number": "PS2363559",
  "manufacturer": "Kenmore",
  "price": "61.70",
  "description": ""
```

"rating": null,

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# 154762601 replaces these: AP4432768
Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"004621710A",

"004621711A",

"58715202803A",

"58715203803A",

"58715313000A",

"58715382100A",

"58715382100B",

"58715383100A",

"58715383100B",

"58715389100A",

"58715389100B",

"58715392100A",

"58715393100A",

"58715399100A",

"605222850A",

"804655850A",

"804655851A",

"905222840A",

"BBBD2432KB0",

"BBBD2432KF0",

"BBBD2432KW0",
"BGBD2432KB0",
"BGBD2432KF0",
"BGBD2432KW0",
"BGHD2433KB0",
"BGHD2433KB1",
"BGHD2433KF0",
"BGHD2433KF1",
"BGHD2433KW0",
"BGHD2433KW1"

]

},

{

"part_name": "SENSOR W11084121",

"part_number": "PS12070543",

"manufacturer": "Kenmore",

"price": "53.92",

"description": "",

"rating": null,

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher. Part# W11084121 replaces these: AP6048025, W10723295 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"2212413N414",

"2213092N413",

"2213099N413",
"2213222N414",
"2213223N414",
"2213229N414",
"2213479N413",
"2213809N710",
"2214523N611",
"2214715N710",
"2214792N512",
"2214793N512",
"2217383N710",
"2217389N710",
"66512413N412",
"66512413N413",
"66513002N510",
"66513002N511",
"66513003N510",
"66513003N511",
"66513004N510",
"66513004N511",
"66513009N510",
"66513009N511",
"66513073K217",
"66513092N412",
"66513092N413",
"66513093N412",

```
"66513093N413",
"66513099N412"
]
},
{
  "part_name": "SENSOR 00611323",
  "part_number": "PS8727345",
  "manufacturer": "Kenmore",
  "price": "46.40",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part fixes the following symptoms: Not draining | Not
cleaning dishes properly This part works with the following products: Dishwasher. Part#
00611323 replaces these: AP4482988, 00611567, 00611568, 611323, 611567, 611568
Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "63013003012",
    "63013003015",
    "63013003016",
    "63013003017",
    "63013003018",
    "63013023010",
    "63013023011",
    "63013023015",
    "63013023016",
```

```
"63013023017",
"63013023018",
"63013902010",
"63013902011",
"63013903010",
"63013903011",
"63013909010",
"63013909011",
"63013909012",
"63013912010",
"63013912011",
"63013913010",
"63013913011",
"63013919010",
"63013919011",
"63013919012",
"63013993010",
"63013993012",
"63013993015",
"63013993016",
"63013993017"
]
},
{
  "part_name": "SENSOR 00611312",
  "part_number": "PS8727335",
```

"manufacturer": "Kenmore",

"price": "33.16",

"description": "",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Will Not Start | Door won't close This part works with the following products: Dishwasher. Part# 00611312 replaces these: AP4482981, 00611660, 00611661, 00618716, 611312, 611660, 611661, 618716 Back to Top",

"review_count": "1",

"appliance": "dishwasher",

"compatible_models": [

"63013003012",

"63013003015",

"63013003016",

"63013003017",

"63013003018",

"63013023010",

"63013023011",

"63013023015",

"63013023016",

"63013023017",

"63013023018",

"63013902010",

"63013902011",

"63013903010",

"63013903011",

"63013909010",

"63013909011",
"63013909012",
"63013912010",
"63013912011",
"63013913010",
"63013913011",
"63013919010",
"63013919011",
"63013919012",
"63013993010",
"63013993012",
"63013993015",
"63013993016",
"63013993017"

]

},

{

"part_name": "Turbidity Sensor WPW10705575",

"part_number": "PS11757214",

"manufacturer": "Kenmore",

"price": "33.70",

"description": "Measures level of soil in the water.",

"rating": "92",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Not draining | Will Not Start | Leaking This part works with the following products: Dishwasher. Part# WPW10705575 replaces these: AP6023867, 8563432, 8574079,

W10055980, W10082647, W10134016, W10134017, W10134058, W10253602,
W10705575 Back to Top",

"review_count": "5",

"appliance": "dishwasher",

"compatible_models": [

"66213032K112",

"66213273K112",

"66512093K210",

"66512413N410",

"66512413N411",

"66512723K310",

"66512723K311",

"66512762K312",

"66512763K312",

"66512763K313",

"66512769K312",

"66512769K313",

"66512772K312",

"66512772K313",

"66512772K314",

"66512773K313",

"66512774K312",

"66512774K313",

"66512776K311",

"66512776K312",

"66512776K314",

"66512779K312",

"66512779K313",

"66512779K314",

"66512782K310",

"66512782K312",

"66512782K313",

"66512783K311",

"66512783K312",

"66512783K313"

]

},

{

"part_name": "Shield WPW10343251",

"part_number": "PS11753266",

"manufacturer": "Kenmore",

"price": "7.82",

"description": "",

"rating": null,

"troubleshooting_tips": "This part fixes the following symptoms: Not drying dishes properly This part works with the following products: Dishwasher. Part# WPW10343251 replaces these: AP6019955, W10343251 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"66213032K112",

"66213273K112",

"66512093K210",

"66512782K310",
"66513012K110",
"66513012K111",
"66513012K112",
"66513012K113",
"66513013K110",
"66513013K111",
"66513013K112",
"66513013K113",
"66513014K110",
"66513014K111",
"66513014K112",
"66513014K113",
"66513019K110",
"66513019K111",
"66513019K112",
"66513019K113",
"66513023K110",
"66513023K111",
"66513023K112",
"66513023K113",
"66513032K110",
"66513032K111",
"66513032K112",
"66513032K113",
"66513032K114",

"66513033K110"

]

},

{

"part_name": "Dishwasher Control Panel Overlay WD34X21700",

"part_number": "PS11736595",

"manufacturer": null,

"price": "38.37",

"description": "This part is the replacement console cover for your dishwasher. The console cover is a long piece of black plastic that fits over top of your dishwasher console. The console cover has text written on it that lets you know which buttons on your dishwasher control which settings. The main reason you would want to replace the console cover is if it is cracked, missing, or if the text has become illegible. This part is sold individually and is an authentic OEM part.",

"rating": "78",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WD34X21700 replaces these: AP6004388 Back to Top",

"review_count": "7",

"appliance": "dishwasher",

"compatible_models": [

"GDT625PSJ0SS",

"GDT625PSJ2SS",

"GDT625PSJ4SS",

"GDT625PSJ5SS",

"GDT625PSJ6SS",

"GDT635HSJ0SS",

"GDT635HSJ2SS",

"GDT635HSJ4SS",

```
"GDT635HSJ5SS",
"GDT635HSJ6SS"
]
},
{
  "part_name": "Dishwasher Control Panel 00683958",
  "part_number": "PS8734595",
  "manufacturer": null,
  "price": "137.25",
  "description": "This control panel is for dishwashers.\r\n\r\nControl panel houses the selection buttons and display for the dishwasher.\r\n\r\nUnplug the dishwasher or shut off the house circuit breaker before installing this part. Wear work gloves to protect your hands.",
  "rating": null,
  "troubleshooting_tips": "This part fixes the following symptoms: Door latch failure This part works with the following products: Dishwasher. Part# 00683958 replaces these: AP4483917, 683958 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "SHE43P05UC",
    "SHE43P05UC-56",
    "SHE43P05UC/58",
    "SHE43P05UC/59",
    "SHE43P05UC/60",
    "SHE43P15UC",
    "SHE43P15UC/56",
```

```
"SHE43P15UC/59",
"SHE43P15UC/60",
"SHE43P25UC"
]
},
{
  "part_name": "CONSOLE CVR GRAPHIC Assembly WD34X22262",
  "part_number": "PS11729212",
  "manufacturer": null,
  "price": "33.11",
  "description": "",
  "rating": "74",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#
WD34X22262 replaces these: AP5993396, WD34X11832 Back to Top",
  "review_count": "3",
  "appliance": "dishwasher",
  "compatible_models": [
    "GDT545PFJ6DS",
    "GDT545PSJ0SS",
    "GDT545PSJ2SS",
    "GDT545PSJ4SS",
    "GDT545PSJ5SS",
    "GDT545PSJ6SS",
    "GDT550HSD0SS",
    "GDT550HSD1SS",
    "GDT550HSD2SS",
```

```
"GDT550HSD4SS",  
"GDT550HSD6SS"  
]  
,  
{  
  "part_name": "Dishwasher Control Panel Button Set 00600072",  
  "part_number": "PS8725630",  
  "manufacturer": null,  
  "price": "47.13",  
  "description": "This control panel button set is for dishwashers. Control panel button set  
makes contact with the switch to activate cycle or option settings.",  
  "rating": "100",  
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#  
00600072 replaces these: AP3859103, 600072 Back to Top",  
  "review_count": "1",  
  "appliance": "dishwasher",  
  "compatible_models": [  
    "SHE43F16UC",  
    "SHE43F16UC/56",  
    "SHE43F16UC/58",  
    "SHE43F16UC/59",  
    "SHE43F16UC/60",  
    "SHE43P06UC",  
    "SHE43P06UC/56",  
    "SHE43P06UC/58",  
    "SHE43P06UC/59",  
    "SHE43P16UC",
```

"SHE43P16UC/56",
"SHE43P26UC",
"SHE45M06UC",
"SHE45M06UC/46",
"SHE45M06UC/48",
"SHE45M06UC/50",
"SHE45M06UC/52",
"SHE45M06UC/53",
"SHE45M06UC/56",
"SHE46C06UC",
"SHE46C06UC/17",
"SHE46C06UC/22",
"SHE46C06UC/33",
"SHE46C06UC/36",
"SHE46C06UC/38",
"SHE46C06UC/40",
"SHE46C06UC/43",
"SHE46C06UC/46",
"SHE46C06UC/47",
"SHE46C06UC/48"

]

},

{

"part_name": "Door Latch Knob WD9X351",
"part_number": "PS264113",
"manufacturer": "Kenmore",

"price": "12.27",

"description": "This knob is attached to the dishwasher door latch mechanism.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure This part works with the following products: Dishwasher. Part# WD9X351 replaces these: AP2038969, 274379, WD09X0351 Back to Top",

"review_count": "3",

"appliance": "dishwasher",

"compatible_models": [

"36314031000",

"36314031001",

"36314038000",

"36314038001",

"36314039000",

"36314039001",

"36314072790",

"36314072791",

"36314072792",

"36314072793",

"36314072794",

"36314072795",

"36314074790",

"36314074791",

"36314074792",

"36314074793",

"36314074794",

"36314075790",

```
"36314075791",
"36314075792",
"36314075793",
"36314075794",
"36314151000",
"36314152000",
"36314158000",
"36314159000",
"36314172790",
"36314172791",
"36314172792",
"36314174790"
]
},
{
  "part_name": "Timer Knob WD09X10025",
  "part_number": "PS258821",
  "manufacturer": null,
  "price": "11.76",
  "description": "This part is the replacement timer knob for your dishwasher. It is made of white plastic with a gray indicator line, and it is approximately 2 inches long and 1 inch wide. The timer knob turns on the shaft and allows you to choose the correct setting for your dishwasher. The main reason you would be replacing this knob, is if the old one is broken or stripped, and it will not turn the shaft. To replace this knob, carefully remove it from the shaft, and replace it with the new one. This part is sold individually and is an OEM part sourced directly from the manufacturer.",
  "rating": "98",
```


"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start This part works with the following products: Dishwasher. Part# WD09X10025 replaces these: AP3425315, 876887, WD9X10025 Back to Top",

"review_count": "8",

"appliance": "dishwasher",

"compatible_models": [

"403410",

"403411",

"403610",

"403611",

"423410",

"423411",

"ADW1000K00WW",

"BSD3204G00WW",

"BSD3204G01WW",

"BSD3204J00WW",

"GHD1106F00WW",

"GHD1106F01WW",

"GHDA350N00WW",

"GHDA350N10WW",

"GHDA350N20WW",

"GHDD306L00WW",

"GHDD306N00WW",

"GHDD396L00WW",

"GSC3200G00WW",

"GSC3200G01WW",

"GSC3200J01WW",

```
"GSC3230F00WW",
"GSC3304F01WW",
"GSC3304F02WW",
"GSC3304F03WW",
"GSC3404G00WW",
"GSC3404J00WW",
"GSC3404J01WW",
"GSC3500D00WW",
"GSC3500D35WW"
]
},
{
  "part_name": "BUTTON 00600071",
  "part_number": "PS8725629",
  "manufacturer": null,
  "price": "45.37",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#
00600071 replaces these: AP3859064, 600071 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "SGO45N08EU",
    "SGS45M18AR",
    "SGS45M38EU",
```

"SGS45M48II",
"SGS45M58EU",
"SGS45N18EU",
"SGS46M78AU",
"SGS55M08MX",
"SGS55M68EU",
"SGS65M08AU",
"SGS65M08TR",
"SHE43F15UC",
"SHE43F15UC/56",
"SHE43F15UC/59",
"SHE43F15UC/60",
"SHE43P05UC",
"SHE43P05UC-56",
"SHE43P05UC/58",
"SHE43P05UC/59",
"SHE43P05UC/60",
"SHE43P15UC",
"SHE43P15UC/56",
"SHE43P15UC/59",
"SHE43P15UC/60",
"SHE43P25UC",
"SHE45M05UC",
"SHE45M05UC/46",
"SHE45M05UC/47",
"SHE45M05UC/48",

```
"SHE45M05UC/50"
]
},
{
  "part_name": "KNOB LATCH HANDLE White WD9X352",
  "part_number": "PS264114",
  "manufacturer": "Kenmore",
  "price": "12.38",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WD9X352 replaces these: AP2038970, 274380, WD09X0352 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "36314032000",
    "36314032001",
    "36314071790",
    "36314071791",
    "36314071792",
    "36314071793",
    "36314071794",
    "36314151000",
    "36314152000",
    "36314158000",
    "36314159000",
```

```
"36314171790",
"36314171791",
"36314171792",
"36314191990",
"36314191991",
"36314191993",
"36314232100",
"36314252100",
"36314371790",
"36314371791",
"36314371792",
"36314382000",
"36314391990",
"36314391991",
"36314391992",
"36314391993",
"36314471790",
"36314471791",
"36314471792"
]
},
{
  "part_name": "Timer Knob WD09X10024",
  "part_number": "PS258820",
  "manufacturer": null,
  "price": "7.69",
```

"description": "",

"rating": "80",

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start This part works with the following products: Dishwasher. Part# WD09X10024 replaces these: AP3419567, 824328, WD9X10024 Back to Top",

"review_count": "4",

"appliance": "dishwasher",

"compatible_models": [

"BSD3204G00BB",

"BSD3204G01BB",

"BSD3204J00BB",

"GHDA350N00BB",

"GHDA350N10BB",

"GHDA350N20BB",

"GHDA356N00SS",

"GHDA356N10SS",

"GHDA356N20SS",

"GHDD306L00SB",

"GHDD306N00SB",

"GSC3200F00BL",

"GSC3200F01BL",

"GSC3200G00BB",

"GSC3200G01BB",

"GSC3200J01BB",

"GSC3304F00BB",

"GSC3304F01AB",

"GSC3304F01BB",

```
"GSC3304F01WB",
"GSC3304F02BB",
"GSC3304F02WB",
"GSC3304F03WB",
"GSC3500D00BB",
"GSC3500D35BB",
"GSC3500D45BB",
"GSC3500D50BB",
"GSC3500D51BB",
"GSC3500D55BB",
"GSC3500N00BB"
]
},
{
  "part_name": "Rinse Aid Fill Cap WD12X10284",
  "part_number": "PS2351824",
  "manufacturer": "Kenmore",
  "price": "18.39",
  "description": "This part helps keep the rinse aid the dispenser until its needed.",
  "rating": "84",
  "troubleshooting_tips": "This part fixes the following symptoms: Will not dispense detergent | Not cleaning dishes properly | Leaking | Not drying dishes properly This part works with the following products: Dishwasher. Part# WD12X10284 replaces these: AP4390010, 1472897, WD03X0654, WD12M0076, WD12M76, WD12X0119, WD12X0179, WD12X0234, WD12X0259, WD12X0261, WD12X0319, WD12X0323, WD12X0392, WD12X0400, WD12X0409, WD12X10024, WD12X10037, WD12X119, WD12X179, WD12X234 ... Show more , WD12X259, WD12X261, WD12X319, WD12X323, WD12X392, WD12X400, WD12X409, WD12X5040, WD3X654 Show less Back to Top",
```

"review_count": "11",
"appliance": "dishwasher",
"compatible_models": [
 "1200L02",
 "18385",
 "18585",
 "18885",
 "18985",
 "3000B10",
 "3000W10",
 "3631401190",
 "3631401191",
 "3631401590",
 "3631401591",
 "3631401592",
 "3631401890",
 "3631401891",
 "3631401892",
 "3631402190",
 "3631402191",
 "3631402192",
 "3631402590",
 "3631402591",
 "3631402592",
 "3631402890",
 "3631402891",


```
"3631402892",
"36314031000",
"36314031001",
"36314032000",
"36314032001",
"36314038000",
"36314038001"
]
},
{
  "part_name": "Rinse Aid Cap WD12X10122",
  "part_number": "PS958932",
  "manufacturer": null,
  "price": "16.42",
  "description": "This part holds the rinse aid liquid in the dispenser until the timer
activates the rinse cycle.",
  "rating": "87",
  "troubleshooting_tips": "This part fixes the following symptoms: Will not dispense
detergent | Leaking | Not cleaning dishes properly This part works with the following
products: Dishwasher. Part# WD12X10122 replaces these: AP3777967, 1057401,
WD12X10102, WD12X10200 Back to Top",
  "review_count": "21",
  "appliance": "dishwasher",
  "compatible_models": [
    "402011",
    "402051",
    "402061",
```

"402070",
"403110",
"403111",
"405010",
"405011",
"405012",
"405050",
"405051",
"405052",
"405060",
"405061",
"405062",
"CDW9380N00SS",
"CDW9380N20SS",
"CDWT280V00SS",
"CDWT280V05SS",
"CDWT280V50SS",
"CDWT980R10SS",
"CDWT980R30SS",
"CDWT980V00SS",
"CDWT980V05SS",
"CDWT980V50SS",
"EDW4000G02BB",
"EDW4000G02CC",
"EDW4000G02WW",
"EDW4000G03BB",

```
"EDW4000G03CC"
]
},
{
  "part_name": "Rinse Aid Cap WPW10524919",
  "part_number": "PS11755938",
  "manufacturer": null,
  "price": "18.66",
  "description": "This part holds the rinse aid liquid in the dispenser until the timer
activates the rinse cycle.",
  "rating": "99",
  "troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes
properly This part works with the following products: Dishwasher. Part# WPW10524919
replaces these: AP6022604, W10524919, W10524923 Back to Top",
  "review_count": "15",
  "appliance": "dishwasher",
  "compatible_models": [
    "ADB1100AWB5",
    "ADB1100AWS5",
    "ADB1100AWW5",
    "ADB1400PYB5",
    "ADB1400PYS5",
    "ADB1400PYW5",
    "ADB1700ADB1",
    "ADB1700ADS1",
    "ADB1700ADW1",
    "BLB14DRANA1",
```

```
"BLB14DRANA2",
"IDT870SAGX0",
"IDT930SAGX0",
"IUD3100BW3",
"IUD3100BW4",
"IUD3100BW5",
"IUD6100BB3",
"IUD7555DS0",
"IUD7555DS1",
"IUD8010DS0",
"IUD8010DS1",
"IUD8555DX0",
"IUD8555DX1",
"IUD8555DX2",
"IUD8555DX3",
"IUD8555DX4",
"JDB8000AWB2",
"JDB8000AWB3",
"JDB8000AWC1",
"JDB8000AWC2"
]
},
{
  "part_name": "Rinse Aid Cap 154388801",
  "part_number": "PS421128",
  "manufacturer": "Kenmore",
```

"price": "19.95",

"description": "This is a replacement cap for the detergent/rinse aid dispenser. If the rinse aid cap is damaged or missing, you may notice too much rinse aid in the dishwasher. The cap simply screws into the dispenser, so if your cap is damaged you can simply screw it out, then screw in the new one. The rinse aid cap is approximately 2 inches in diameter and is sold individually. This is an OEM part, directly from the manufacturer.",

"rating": "93",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Will not dispense detergent | Not cleaning dishes properly | Not drying dishes properly This part works with the following products: Dishwasher. Part# 154388801 replaces these: AP2109579, 890363, 154388802 Back to Top",

"review_count": "13",

"appliance": "dishwasher",

"compatible_models": [

"58714000100",

"58714000101",

"58714000102",

"58714001991",

"58714001992",

"58714001993",

"58714002991",

"58714002992",

"58714002993",

"58714003100",

"58714008001",

"58714008002",

"58714008003",

"58714009100",

```
"58714009101",  
"58714009102",  
"58714012400",  
"58714012401",  
"58714012402",  
"58714012403",  
"58714012404",  
"58714012405",  
"58714012406A",  
"58714012407A",  
"58714012408A",  
"58714013400",  
"58714013401",  
"58714013402",  
"58714013403",  
"58714013404"  
]  
,  
{  
  "part_name": "DOOR 5304506908",  
  "part_number": "PS11770558",  
  "manufacturer": null,  
  "price": "106.85",  
  "description": "",  
  "rating": null,
```

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 5304506908 replaces these: AP6038474, 5304517204 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"CDBEH600SB0A",

"CDBEH600SB2A",

"FFBD2412SB0A",

"FFBD2412SB2A",

"FFCD2413UB0A",

"FFCD2413UB1A",

"FFCD2413UB2A",

"FFCD2413UB3A",

"FFCD2413UB4A",

"FFCD2413US0A",

"FFCD2413US1A",

"FFCD2413US2A",

"FFCD2413US3A",

"FFCD2413US4A",

"FFCD2413UW0A",

"FFCD2413UW1A",

"FFCD2413UW2A",

"FFCD2413UW3A",

"FFCD2413UW4A",

"FFCD2418UB0A",

"FFCD2418UB1A",

```
"FFCD2418UB2A",
"FFCD2418UB3A",
"FFCD2418US2A",
"FFCD2418US3A",
"FFCD2418UW2A",
"FFCD2418UW3A"
]
},
{
  "part_name": "Exterior Door Panel with Name Plate - Stainless WPW10629473",
  "part_number": "PS11756853",
  "manufacturer": null,
  "price": "220.18",
  "description": "This door outer panel is for dishwashers and protects the wiring and components inside the dishwasher door and provides a decorative finish for the front of the dishwasher.",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WPW10629473 replaces these: AP6023509, W10629473 Back to Top",
  "review_count": "2",
  "appliance": "dishwasher",
  "compatible_models": [
    "WDF520PADB0",
    "WDF520PADB2",
    "WDF520PADB3",
    "WDF520PADB5",
    "WDF520PADB6",
```


"WDF520PADB7",
"WDF520PADB8",
"WDF520PADM0",
"WDF520PADM2",
"WDF520PADM3",
"WDF520PADM5",
"WDF520PADM6",
"WDF520PADM7",
"WDF520PADM8",
"WDF520PADM9",
"WDF520PADW0",
"WDF520PADW2",
"WDF520PADW3",
"WDF520PADW5",
"WDF520PADW6",
"WDF520PADW7",
"WDF520PADW8",
"WDF520PADW9",
"WDF540PADB0",
"WDF540PADB1",
"WDF540PADB2",
"WDF540PADB3",
"WDF540PADM0",
"WDF540PADM1",
"WDF540PADM2"

]

```
},  
{  
  "part_name": "DOOR 5304506911",  
  "part_number": "PS11770561",  
  "manufacturer": null,  
  "price": "129.24",  
  "description": "",  
  "rating": null,  
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#  
5304506911 replaces these: 5304506910, 5304506912, 5304517205 Back to Top",  
  "review_count": null,  
  "appliance": "dishwasher",  
  "compatible_models": [  
    "CDBEH600SS0A",  
    "CDBEH600SS2A",  
    "FFBD2412SM0A",  
    "FFBD2412SM2A",  
    "FFBD2412SS0A",  
    "FFBD2412SS2A",  
    "FFCD2413UB0A",  
    "FFCD2413UB1A",  
    "FFCD2413UB2A",  
    "FFCD2413UB3A",  
    "FFCD2413UB4A",  
    "FFCD2413US0A",  
    "FFCD2413US1A",
```

```
"FFCD2413US2A",
"FFCD2413US3A",
"FFCD2413US4A",
"FFCD2413UW0A",
"FFCD2413UW1A",
"FFCD2413UW2A",
"FFCD2413UW3A",
"FFCD2413UW4A",
"FFCD2418UB2A",
"FFCD2418UB3A",
"FFCD2418US0A",
"FFCD2418US1A",
"FFCD2418US2A",
"FFCD2418US3A",
"FFCD2418UW2A",
"FFCD2418UW3A",
"LFBD2412SF0A"
]
},
{
  "part_name": "Door Panel Insert WP3369769",
  "part_number": "PS11741289",
  "manufacturer": "Kenmore",
  "price": "47.39",
  "description": "This panel is reversible, black on one side, white on the other side.",
  "rating": "100",
```

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WP3369769 replaces these: AP6008156, 3369516, 3369606, 3369769, 3370524, 8274853, 99989666, WP8274853 Back to Top",

"review_count": "5",

"appliance": "dishwasher",

"compatible_models": [

"110723120",

"6651514590",

"6651514591",

"6651514593",

"6651514594",

"6651544590",

"6651544591",

"6651544593",

"6651544594",

"66515592790",

"66515592791",

"66515595790",

"66515595791",

"66515595792",

"66515595793",

"6651561590",

"6651561591",

"66515625690",

"66515625691",

"66515625692",

"6651563590",

"6651563591",
"66515641891",
"66515645891",
"6651564990",
"6651564991",
"6651564992",
"6651564993",
"6651565590",
"6651565591"

]

},

{

"part_name": "Door Spring Kit 901111",

"part_number": "PS2097003",

"manufacturer": "Kenmore",

"price": "43.09",

"description": "Sold individually.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close This part works with the following products: Dishwasher. Part# 901111 replaces these: AP4110653, 1397, 7-57016, 757016, 9-1111, 901111, K35-604, Y757016
Back to Top",

"review_count": "2",

"appliance": "dishwasher",

"compatible_models": [

"1949",

"19495",

"1959",
"19595",
"1988",
"19885",
"1999",
"19995",
"DP450",
"DP450-C",
"DP451",
"DP470",
"DP476",
"DU401",
"DU450",
"DU450-C",
"DU451",
"DU470",
"DU470-C",
"DU476",
"DU486",
"DU490",
"DU490-C",
"DU491",
"DU496",
"DU588",
"DU588W",
"DU598",

```
"DU599B",
"DU599W"
]
},
{
  "part_name": "ATTACH STRIP Right Hand WD01X22836",
  "part_number": "PS11771956",
  "manufacturer": null,
  "price": "13.91",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part fixes the following symptoms: Door won't close This part works with the following products: Dishwasher. Part# WD01X22836 replaces these: WD01X10633 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "CDT706P2M4S1",
    "CDT706P2M5S1",
    "CDT725SSF0SS",
    "CDT725SSF2SS",
    "CDT725SSF4SS",
    "CDT725SSF6SS",
    "CDT725SSF7SS",
    "CDT765SSF0SS",
    "CDT765SSF1SS",
    "CDT765SSF7SS",
```

```
"CDT800P2N0S1",
"CDT800P2N2S1",
"CDT800P2N3S1",
"CDT800P2N4S1",
"CDT800P2N5S1",
"CDT805M5N0S5",
"CDT805M5N2S5",
"CDT805M5N4S5",
"CDT805P2N0S1",
"CDT805P2N1S1",
"CDT805P2N2S1",
"CDT805P2N4S1",
"CDT805P2N5S1",
"CDT805P2N8S1",
"CDT835SMJ0DS",
"CDT835SMJ2DS",
"CDT835SMJ4DS",
"CDT835SMJ5DS",
"CDT835SSJ0SS",
"CDT835SSJ2SS"
]
},
{
  "part_name": "ATTACH STRIP WD01X10634",
  "part_number": "PS8756120",
  "manufacturer": null,
```


"price": "8.06",

"description": "",

"rating": null,

"troubleshooting_tips": "This part fixes the following symptoms: Door won't close This part works with the following products: Dishwasher. Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"CDT706P2M4S1",

"CDT706P2M5S1",

"CDT725SSF0SS",

"CDT725SSF2SS",

"CDT725SSF4SS",

"CDT725SSF6SS",

"CDT725SSF7SS",

"CDT765SSF0SS",

"CDT765SSF1SS",

"CDT765SSF7SS",

"CDT800P2N0S1",

"CDT800P2N2S1",

"CDT800P2N3S1",

"CDT800P2N4S1",

"CDT800P2N5S1",

"CDT805M5N0S5",

"CDT805M5N2S5",

"CDT805M5N3S5",

"CDT805M5N4S5",
"CDT805P2N0S1",
"CDT805P2N1S1",
"CDT805P2N2S1",
"CDT805P2N3S1",
"CDT805P2N4S1",
"CDT805P2N5S1",
"CDT805P2N8S1",
"CDT835SMJ0DS",
"CDT835SMJ2DS",
"CDT835SMJ4DS",
"CDT835SMJ5DS"

]

},

{

"part_name": "Door Switches and Holder Assembly 99002254",

"part_number": "PS2099645",

"manufacturer": null,

"price": "78.12",

"description": "This part senses when the dishwasher door is closed so the cycle can start, and prevents it from starting if the door is not closed. If the dishwasher will not start or will not close, you may need to replace the door switches and holder assembly, also known as the door latch assembly. The dishwasher will not start if this part is defective. It includes two switches and the holder, this part does not include the handle or screws. Tools needed are T20 torx driver, needle nose pliers, and 1/4 inch nut driver. This is a genuine OEM part that is sourced directly from the manufacturer.",

"rating": "92",

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start | Door latch failure | Door won't close This part works with the following products: Dishwasher. Part# 99002254 replaces these: AP4113223, 780069, 9-3086, 903086, 99001077, 99002254 Back to Top",

"review_count": "17",

"appliance": "dishwasher",

"compatible_models": [

"CDC400B",

"CDC450B",

"CDC5J",

"CDU20J",

"CDU250B",

"CDU250V",

"CDU2J",

"CDU2J3",

"CDU400B",

"CDU450B",

"CDU5J",

"CDU5JV",

"CDU600B",

"CDU600V",

"CDU8000B",

"CDU8000V",

"CDU8J",

"DC4000B",

"DC4500B",

"DC5J",

```
"DU2000B",
"DU2000B-C",
"DU2000V",
"DU2000V-C",
"DU2000W",
"DU20J",
"DU20J-CAN",
"DU20JV",
"DU2100B",
"DU2500B"
]
},
{
  "part_name": "Door Cable and Eyelet WD7X14",
  "part_number": "PS263918",
  "manufacturer": "Kenmore",
  "price": "25.94",
  "description": "This part is sold individually. It is recommended that both sides are
changed when replacing one.",
  "rating": "95",
  "troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door
won't close This part works with the following products: Dishwasher. Part# WD7X14
replaces these: AP2038829, 2291, WD07X0013, WD07X0014, WD7X13 Back to Top",
  "review_count": "14",
  "appliance": "dishwasher",
  "compatible_models": [
    "18385",
```

"361402891",
"3631401190",
"3631401191",
"3631401590",
"3631401591",
"3631401592",
"3631401890",
"3631401891",
"3631401892",
"3631402190",
"3631402191",
"3631402192",
"3631402590",
"3631402591",
"3631402592",
"3631402890",
"3631402891",
"3631402892",
"3631404193",
"3631404194",
"3631404196",
"3631404593",
"3631404594",
"3631404595",
"3631404596",
"3631404893",

"3631404894",

"3631404895",

"3631404896"

]

},

{

"part_name": "Door Catch Kit 279570",

"part_number": "PS334230",

"manufacturer": "Kenmore",

"price": "5.04",

"description": "This part replaces your appliances latch (Door Latch Kit, Door Catch, Dryer Door Latch Kit). On your appliance you will find both a strike and a catch. The strike is mounted on the body of the dryer, while the catch is mounted on the dryer door. These two parts work together to keep your dryer door closed. The catch holds the door strike to keep the door closed during the drying cycle. If the door does not latch closed, you won't be able to start a drying cycle. If this part is malfunctioning, you may not be able to open or close your door. In some instances, it may seem like your door is closing, but if it is not latching properly you won't be able to start your drying cycle. You should replace this part as soon as it's malfunctioning. Your dryer may run even though the latch is malfunctioning, but it is unsafe if the dryer continues to run while the door is open. This replacement part features 1 door latch kit which includes 2 strikes, 3 catches, and a set of instructions. This model is constructed of plastic and metal, and comes in white/silver.",

"rating": "96",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't close | Door Pops Open | Lid or door won't close This part works with the following products: Dryer, Washer Dryer Combo, Dishwasher, Laundry Accessories. Part# 279570 replaces these: AP3094183, 3493, 279570, 14205029, 14205577, 14210022, 2003, 236876, 23687600, 236877, 23687700, 241282, 241286, 241890, 26000279570, 261847, 263067, 279280, 279337, 279469 ... Show more , 279570VP, 291949, 3390239, 3392538, 3398175, 342295, 347813, 4165234, 51651001, 51655001, 690081, 690082, 693717, 694343, 696144, 8208, 830751, 834767, 834813, 834943, 834944, FSP279570 Show less Back to Top",

```
"review_count": "125",  
"appliance": "dishwasher",  
"compatible_models": [  
  "106508802",  
  "10686294140",  
  "10686294340",  
  "10686294540",  
  "10686294740",  
  "10686294840",  
  "10687884100",  
  "10687884300",  
  "10687884600",  
  "10688419100",  
  "10688419300",  
  "10697502820",  
  "110088732791",  
  "1101820299",  
  "110508802",  
  "11060012000",  
  "11060012001",  
  "11060012002",  
  "11060022010",  
  "11060052990",  
  "11060052991",  
  "11060056990",  
  "11060056991",
```

```
"1106007299",
"11060072990",
"11060072991",
"1106007713",
"1106007714",
"1106007715",
"1106007716"
]
},
{
  "part_name": "BEARING 00632374",
  "part_number": "PS10057899",
  "manufacturer": null,
  "price": "22.98",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 00632374 replaces these: AP5950415, 632374 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "SHE9PT55UC",
    "SHEM78WH5N",
    "SHEM78WH5N-32",
    "SHV9PT53UC",
    "SHX9PT55UC",
```



```
"SHX9PT75UC"
]
},
{
  "part_name": "Dishwasher Tine Row Pivot Clip 00611473",
  "part_number": "PS8727385",
  "manufacturer": "Kenmore",
  "price": "28.09",
  "description": "This tine row pivot clip is for dishwashers. Tine row pivot clip attaches the
tine row to the dishrack and allows the tine row to pivot up and down.",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#
00611473 replaces these: AP4483010, 611473 Back to Top",
  "review_count": "1",
  "appliance": "dishwasher",
  "compatible_models": [
    "63013003012",
    "63013003015",
    "63013003016",
    "63013003017",
    "63013003018",
    "63013023010",
    "63013023011",
    "63013023015",
    "63013023016",
    "63013023017",
    "63013023018",
```

```
"63013993010",
"63013993012",
"63013993015",
"63013993016",
"63013993017",
"63013993018",
"DF240140",
"DF240161",
"DF241161",
"DF241761",
"DF260161",
"DF260161F",
"DF260162",
"DF260760",
"DF260761",
"DF261161",
"DF261161F",
"DF261161S",
"DF261162"
]
},
{
  "part_name": "BEARING 154686401",
  "part_number": "PS2342486",
  "manufacturer": "Kenmore",
  "price": "10.60",
```

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 154686401 replaces these: AP4363358 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"004621710A",

"004621711A",

"58714012405",

"58714012406A",

"58714012407A",

"58714012408A",

"58714012409B",

"58714012410B",

"58714012411B",

"58714012412B",

"58714012413B",

"58714012414B",

"58714012416B",

"58714013406",

"58714013407A",

"58714013408A",

"58714013409A",

"58714013410B",

"58714013411B",

```
"58714013412B",
"58714013413B",
"58714013414B",
"58714013415B",
"58714013416B",
"58714013417B",
"58714014405",
"58714014406A",
"58714014407A",
"58714014408A",
"58714014409B"
]
},
{
  "part_name": "BEARING SPRAY ARM WD01X10340",
  "part_number": "PS1765970",
  "manufacturer": null,
  "price": "16.47",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WD01X10340 replaces these: AP4300601, 1263896 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "ADW1100N00BB",
```

"ADW1100N00WW",
"ADW1100N10BB",
"ADW1100N10WW",
"ADW1100N15BB",
"ADW1100N15WW",
"ADW1100N20BB",
"ADW1100N20WW",
"ADW1100N30BB",
"ADW1100N35BB",
"ADW1100N35WW",
"ADW1100NB",
"ADW1100NW",
"GFSD234P00BB",
"GFSD234P00SB",
"GFSD234P00WW",
"GFSD551P00BB",
"GFSD551P00SB",
"GFSD551P00WW",
"GHDA350N00BB",
"GHDA350N00WW",
"GHDA350N10BB",
"GHDA350N10WW",
"GHDA350N20BB",
"GHDA350N20WW",
"GHDA356N00SS",
"GHDA356N10SS",

```
"GHDA356N20SS",
"GHSD307P00SB",
"GHSD307P00WW"
]
},
{
  "part_name": "Dishwasher Tine Row Clip 00611472",
  "part_number": "PS8727384",
  "manufacturer": "Kenmore",
  "price": "35.42",
  "description": "This tine row clip is for dishwashers. Tine row clip holds the tine row in position.",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 00611472 replaces these: AP4483009, 611472 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "63013003012",
    "63013003015",
    "63013003016",
    "63013003017",
    "63013003018",
    "63013023010",
    "63013023011",
    "63013023015",
    "63013023016",
```

```
"63013023017",
"63013023018",
"63013993010",
"63013993012",
"63013993015",
"63013993016",
"63013993017",
"63013993018",
"DF240140",
"DF240161",
"DF241161",
"DF241761",
"DF260161",
"DF260161F",
"DF260162",
"DF260760",
"DF260761",
"DF261161",
"DF261161F",
"DF261161S",
"DF261162"
]
},
{
  "part_name": "Bearing, Spring, (2) WP3373234",
  "part_number": "PS11741317",
```

"manufacturer": "Kenmore",

"price": "6.90",

"description": "Sold Individually. This is what your door spring would hook into and it prevents the metal spring from rubbing against the metal on the side of the door.",

"rating": null,

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure This part works with the following products: Dishwasher. Part# WP3373234 replaces these: 3373234 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"110723120",

"110773811",

"110773812",

"110773813",

"110773881",

"110773882",

"110773883",

"66513402K900",

"66513402K901",

"66513409K900",

"66513409K901",

"66513442K900",

"66513442K901",

"66513443K900",

"66513443K901",

"66513444K900",

"66513444K901",
"66513449K900",
"66513449K901",
"66513492K600",
"66513499K600",
"66513592K600",
"66513593K600",
"66513594K600",
"66513599K600",
"66513692K600",
"66513699K600",
"66514212K900",
"66514212K901",
"66514213K900"

]

},

{

"part_name": "Dishwasher Door Hinge Lever Bearing 00165296",

"part_number": "PS8697061",

"manufacturer": "Kenmore",

"price": "22.37",

"description": "This door hinge lever bearing is for dishwashers. Door hinge lever bearing allows the door hinge lever to move smoothly.",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 00165296 replaces these: AP2821583, 00170830, 00421781, 00488250, 00580333, 165296, 170830, 421781, 488250, 580333 Back to Top",

```
"review_count": "1",  
"appliance": "dishwasher",  
"compatible_models": [  
  "63013003012",  
  "63013003015",  
  "63013003016",  
  "63013003017",  
  "63013003018",  
  "63013023010",  
  "63013023011",  
  "63013023015",  
  "63013023016",  
  "63013023017",  
  "63013023018",  
  "63013902010",  
  "63013902011",  
  "63013903010",  
  "63013903011",  
  "63013909010",  
  "63013909011",  
  "63013909012",  
  "63013912010",  
  "63013912011",  
  "63013913010",  
  "63013913011",  
  "63013919010",
```

"63013919011",

"63013952010",

"63013952011",

"63013953010",

"63013953011",

"63013959010",

"63013959011"

]

},

{

"part_name": "Upper Spray Arm Bearing WD01X10410",

"part_number": "PS2353863",

"manufacturer": null,

"price": "12.24",

"description": "This is the upper spray arm bearing for your dishwasher. The spray arm fits onto the spray arm bearing, which allows it to spin during the cycle. If your dishwasher is not cleaning dishes properly, or is making a lot of noise during operation, it could be the result of a damaged spray arm bearing. This part is made of white plastic and is approximately 1 inch long and 1/2 inch wide. This part is sold individually and is a genuine OEM part from the manufacturer.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Noisy This part works with the following products: Dishwasher. Part# WD01X10410 replaces these: AP4412557, WD01X10102, WD01X10209, WD1X10102
Back to Top",

"review_count": "3",

"appliance": "dishwasher",

"compatible_models": [

"40201-0",
"402011",
"40205-0",
"402051",
"40206-0",
"402061",
"402070",
"403110",
"403111",
"405010",
"405011",
"405012",
"405050",
"405051",
"405052",
"405060",
"405061",
"405062",
"4070100",
"4070110",
"4070500",
"4070510",
"4070600",
"4070610",
"4070800",
"4070810",

```
"4071100",
"4071110",
"4071120",
"4071500"
]
},
{
  "part_name": "Spray Arm Seal WP8268433",
  "part_number": "PS11745444",
  "manufacturer": "Kenmore",
  "price": "13.69",
  "description": "This seal is located between the spray arm and the water feed tube.",
  "rating": "84",
  "troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Leaking | Noisy This part works with the following products: Dishwasher. Part# WP8268433 replaces these: AP6012237, 8268433 Back to Top",
  "review_count": "6",
  "appliance": "dishwasher",
  "compatible_models": [
    "665110739120",
    "665110739130",
    "665110739140",
    "665110739190",
    "66513102K900",
    "66513102K901",
    "66513102K902",
    "66513103K900",
```

```
"66513103K901",  
"66513103K902",  
"66513104K900",  
"66513104K901",  
"66513104K902",  
"66513109K900",  
"66513109K901",  
"66513109K902",  
"66513112K700",  
"66513112K701",  
"66513112K702",  
"66513113K700",  
"66513113K701",  
"66513113K702",  
"66513114K700",  
"66513114K701",  
"66513114K702",  
"66513119K700",  
"66513119K701",  
"66513119K702",  
"66513212K901",  
"66513212K902"  
]  
,  
{  
  "part_name": "Wash Arm Bearing 807035801",
```

"part_number": "PS9492561",

"manufacturer": null,

"price": "21.56",

"description": "This part is the replacement wash arm bearing for your dishwasher. It is made of black plastic and is approximately 1 1/4 inches in diameter. The wash arm bearing allows the wash arm to rotate when the dishwasher is operating. A broken bearing can make the wash arm difficult to rotate, and when this occurs, your dishes may not be washed properly. This part is sold individually and is an authentic OEM part sourced directly from the manufacturer.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher. Part# 807035801 replaces these: AP5805701 Back to Top",

"review_count": "1",

"appliance": "dishwasher",

"compatible_models": [

"905045720A",

"E24ID74QPS0A",

"E24ID74QPS1A",

"E24ID74QPS3A",

"E24ID74QPS4A",

"E24ID75SPS0A",

"E24ID75SPS1A",

"E24ID75SPS2A",

"E24ID75SPS3A",

"EDSH4944AS0A",

"EI24CD35RS2A",

"EI24CD35RS3A",

```
"EI24CD35RS4A",
"EI24ID30QB0A",
"EI24ID30QB0B",
"EI24ID30QB3B",
"EI24ID30QS0A",
"EI24ID30QS0B",
"EI24ID30QS3B",
"EI24ID30QS4B",
"EI24ID30QS5B",
"EI24ID30QW0A",
"EI24ID30QW0B",
"EI24ID30QW3B",
"EI24ID50QS0A",
"EI24ID50QS0B",
"EI24ID50QS1A",
"EI24ID50QS1B",
"EI24ID50QS4B",
"EI24ID50QS5B"
]
},
{
  "part_name": "COVER VENT WD12X10127",
  "part_number": "PS958937",
  "manufacturer": null,
  "price": "16.21",
  "description": ""
```


"rating": null,

"troubleshooting_tips": "This part works with the following products: Dishwasher. Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"CDW9380N00SS",

"CDW9380N20SS",

"CDWT280V00SS",

"CDWT280V05SS",

"CDWT280V50SS",

"CDWT980R10SS",

"CDWT980R30SS",

"CDWT980V00SS",

"CDWT980V05SS",

"CDWT980V50SS",

"EDWF800P00BB",

"EDWF800P00WW",

"EDWF860P00SS",

"GDWF100R10BB",

"GDWF100R10WW",

"GDWF100R30BB",

"GDWF100R30WW",

"GDWF100V40BB",

"GDWF100V40WW",

"GDWF100V50BB",

```
"GDWF100V50WW",
"GDWF100V55BB",
"GDWF100V55WW",
"GDWF100V70WW",
"GDWF106V00WW",
"GDWF150V40ES",
"GDWF150V50ES",
"GDWF150V55ES",
"GDWF160R10SS",
"GDWF160R30SS"
]
},
{
  "part_name": "Toe Kick Panel with Screws - Black 5304475610",
  "part_number": "PS2379455",
  "manufacturer": "Kenmore",
  "price": "71.76",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 5304475610 replaces these: AP4508562 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "58715413100A",
    "58715423100A",
```

"EIDW5705PB0A",
"EIDW5705PS0A",
"EIDW5705PW0A",
"FGHD2455LB0",
"FGHD2455LB1A",
"FGHD2455LF0",
"FGHD2455LF1A",
"FGHD2472PB0",
"FGHD2472PF0",
"FGHD2472PF1A",
"FGHD2472PW0",
"FGHD2491LB0",
"FGHD2491LW0",
"FPHD2491KF0"

]

},

{

"part_name": "KICKPLATE A02025002",

"part_number": "PS10066379",

"manufacturer": null,

"price": "189.58",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# A02025002 replaces these: 14002025002, 807110202, 807110302, 807110303, A02025001, A02065603 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"E24ID74QPS0A",

"E24ID74QPS1A",

"E24ID74QPS3A",

"E24ID74QPS4A",

"EI24CD35RS2A",

"EI24CD35RS3A",

"EI24CD35RS4A",

"EI24ID30QB0A",

"EI24ID30QB0B",

"EI24ID30QB3B",

"EI24ID30QS0A",

"EI24ID30QS0B",

"EI24ID30QS3B",

"EI24ID30QS4B",

"EI24ID30QS5B",

"EI24ID30QW0A",

"EI24ID30QW0B",

"EI24ID30QW3B",

"EI24ID50QS0A",

"EI24ID50QS0B",

"EI24ID50QS1A",

"EI24ID50QS1B",

"EI24ID50QS4B",

"EI24ID50QS5B",

```
"EW24ID70QT0A",
"EW24ID70QT3A",
"EW24ID70QT4A",
"EW24ID80QS0A",
"EW24ID80QS1A",
"EW24ID80QS2A"
]
},
{
  "part_name": "Toe Kick Panel - Black WD27X10068",
  "part_number": "PS260957",
  "manufacturer": "Kenmore",
  "price": "62.92",
  "description": "",
  "rating": "20",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WD27X10068 replaces these: AP3190792, 912046, WD27X10197 Back to Top",
  "review_count": "2",
  "appliance": "dishwasher",
  "compatible_models": [
    "361402891",
    "36314239100",
    "36314259100",
    "36314475792",
    "36314589100",
    "36314773100",
```

"36314779100",
"36315129100",
"36315219100",
"36315229100",
"36315319100",
"36315329100",
"36316129100",
"36316219100",
"36316229100",
"ADW1000K00BB",
"ADW1100N00BB",
"ADW1100N10BB",
"ADW1100N15BB",
"ADW1100N20BB",
"ADW1100N30BB",
"ADW1100N30WW",
"ADW1100N35BB",
"BSD3204G00BB",
"BSD3204G01BB",
"BSD3204J00BB",
"DDW550B-45",
"DDW550B-48",
"DDW550B-55",
"DDW650B-45"
]
},

```
{
  "part_name": "Access Panel - White WPW10526115",
  "part_number": "PS11755985",
  "manufacturer": null,
  "price": "82.60",
  "description": "",
  "rating": "20",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#
WPW10526115 replaces these: W10368716, W10369030, W10526115 Back to Top",
  "review_count": "1",
  "appliance": "dishwasher",
  "compatible_models": [
    "7GU2300XTVQ2",
    "7GU2300XTVQ3",
    "7GU2300XTVS2",
    "7GU2300XTVS3",
    "GU2275XTVB2",
    "GU2275XTVB3",
    "GU2275XTVQ2",
    "GU2275XTVQ3",
    "GU2275XTVY2",
    "GU2275XTVY3",
    "GU2300XTVB2",
    "GU2300XTVB3",
    "GU2300XTVQ2",
    "GU2300XTVQ3",
```

```
"GU2300XTVS2",
"GU2300XTVS3",
"GU2300XTVT2",
"GU2300XTVT3",
"JDB3200AWB4",
"JDB3200AWB5",
"JDB3200AWS4",
"JDB3200AWS5",
"JDB3200AWW4",
"JDB3200AWW5",
"JDB3650AWF4",
"JDB3650AWF5",
"JDB3650AWR4",
"JDB3650AWR5",
"JDB3650AWY4",
"JDB3650AWY5"
]
},
{
  "part_name": "Toeplate - White 154745501",
  "part_number": "PS3653438",
  "manufacturer": "Kenmore",
  "price": "26.68",
  "description": "",
  "rating": null,
```


"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 154745501 replaces these: AP5628604, 154322901, 154589401 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"58714000100",

"58714001990",

"58714001991",

"58714001992",

"58714001993",

"58714002990",

"58714002991",

"58714002992",

"58714002993",

"58714008001",

"58714009100",

"58714012400",

"58714012401",

"58714012402",

"58714012403",

"58714012404",

"58714012405",

"58714012406A",

"58714012407A",

"58714012408A",

"58714012409B",

```
"58714012410B",
"58714012411B",
"58714012412B",
"58714012413B",
"58714012414B",
"58714012416B",
"58714013411B",
"58714013416B",
"58714013417B"
]
},
{
  "part_name": "Kickplate - Black W10871196",
  "part_number": "PS11769017",
  "manufacturer": "Kenmore",
  "price": "97.13",
  "description": "New Black Single Metal Access Panel Replacement Kit. Replaces old two part toe kick plates. Reuse insulation off old panel or see Recommended Parts.",
  "rating": "87",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# W10871196 replaces these: 8268999, 8269003, 8270026, 8558252, 8573286, W10177629, W10205336, W10586590, W10737729, W10780487, W10799405, W10827633, W11024697, WP8573286, WPW10205336, WPW10586590 Back to Top",
  "review_count": "3",
  "appliance": "dishwasher",
  "compatible_models": [
    "665110739120",
```

"665110739130",
"665110739140",
"665110739190",
"66512782K310",
"66512782K311",
"66512782K312",
"66512782K313",
"66512783K311",
"66512783K312",
"66512783K313",
"66512789K311",
"66512789K312",
"66512789K313",
"66512793K311",
"66512803K311",
"66512833K311",
"66513012K110",
"66513012K111",
"66513013K110",
"66513013K111",
"66513014K110",
"66513014K111",
"66513019K110",
"66513019K111",
"66513023K110",
"66513023K111",

"66513032K110",

"66513032K111",

"66513033K110"

]

},

{

"part_name": "Inlet/Outlet Bezel WP99003605",

"part_number": "PS11747779",

"manufacturer": "Kenmore",

"price": "21.88",

"description": "This is an inlet/outlet bezel, also known as the air duct bezel, is for your dishwasher. It covers the vent openings in the dishwasher and prevents the dishwasher from leaking. It is gray in color and is approximately 4 inches in diameter. If the bezel is damaged, or the tabs holding in place are broken, you may need to replace it. Many of our customers have described this repair as easy. This is an authentic OEM part sourced directly from the manufacturer.",

"rating": "93",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Not cleaning dishes properly This part works with the following products: Dishwasher. Part# WP99003605 replaces these: AP6014539, 6-919693, 99003605 Back to Top",

"review_count": "11",

"appliance": "dishwasher",

"compatible_models": [

"46513322600",

"46513323600",

"46513329600",

"46513333600",

"46513339600",

"46513342600",
"46513343600",
"46513349600",
"665133225",
"66513322K605",
"665133235",
"66513323K605",
"665133295",
"66513329K605",
"665133335",
"66513333K605",
"665133395",
"66513339K605",
"665133425",
"665133426",
"66513342K605",
"66513342K606",
"665133435",
"665133436",
"66513343K605",
"66513343K606",
"665133495",
"665133496",
"66513349K605",
"66513349K606"

]

```
},
```

```
{
```

```
"part_name": "Kickplate Grille - Black 5304501484",
```

```
"part_number": "PS11704182",
```

```
"manufacturer": "Kenmore",
```

```
"price": "42.00",
```

```
"description": "This part is the replacement kickplate grille or toe panel for your dishwasher. It is black in color and is approximately 7 inches by 24 inches. The kickplate grille is a decorative panel that covers up the opening at the bottom of your dishwasher. If your kickplate is damaged or missing, this is the part that will replace it. To replace the kickplate grille, simply unscrew it from the bottom of your dishwasher, then line up the new kickplate with the locator pins and screw it back into place. This part is an OEM part from the manufacturer and is sold individually.",
```

```
"rating": "100",
```

```
"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 5304501484 replaces these: AP5981864, 154224702, 154323003, 154323006, 154323007, 154370703, 154397203, 154589503, 154854903, 154871203 Back to Top",
```

```
"review_count": "1",
```

```
"appliance": "dishwasher",
```

```
"compatible_models": [
```

```
"004621710A",
```

```
"004621711A",
```

```
"58714000100",
```

```
"58714001991",
```

```
"58714002991",
```

```
"58714003100",
```

```
"58714008001",
```

```
"58714009100",
```

"58714009101",
"58714009102",
"58714012410B",
"58714012416B",
"58714013400",
"58714013401",
"58714013402",
"58714013403",
"58714013404",
"58714013405",
"58714013406",
"58714013407A",
"58714013409A",
"58714013410B",
"58714013411B",
"58714013412B",
"58714013413B",
"58714013414B",
"58714013415B",
"58714013416B",
"58714013417B",
"58714014410B"

]

},

{

"part_name": "Kickplate Grille - Black 154745503",

"part_number": "PS3633191",

"manufacturer": "Kenmore",

"price": "13.42",

"description": "This kickplate grille is attached to the bottom of the dishwasher.",

"rating": "94",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 154745503 replaces these: AP5590026, 154227002, 154322903, 154589403, 159224702
Back to Top",

"review_count": "3",

"appliance": "dishwasher",

"compatible_models": [

"004621710A",

"004621711A",

"58714000100",

"58714001991",

"58714002991",

"58714003100",

"58714008001",

"58714009100",

"58714009101",

"58714009102",

"58714012410B",

"58714012416B",

"58714013400",

"58714013401",

"58714013402",

"58714013403",

"58714013404",
"58714013405",
"58714013406",
"58714013407A",
"58714013408A",
"58714013409A",
"58714013410B",
"58714013411B",
"58714013412B",
"58714013413B",
"58714013414B",
"58714013415B",
"58714013416B",
"58714013417B"

]

},

{

"part_name": "Crisper Drawer Cover Support - Left Side 5303201639",

"part_number": "PS454341",

"manufacturer": null,

"price": "58.99",

"description": "It is 'L' shaped and is intended for the left side of the refrigerator, with the short leg in the front nearest to the door.",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator, Dishwasher. Part# 5303201639 replaces these: AP2137283, 528, 08001044, 194064, 3201639, 5301229525, 8001044, G173113, K1229499, K1229525 Back to Top",

```
"review_count": null,  
"appliance": "dishwasher",  
"compatible_models": [  
  "DW3350A1",  
  "DW3350F1",  
  "DW3350H1",  
  "DW3350L1",  
  "DW3350W1",  
  "FPCE22V3FA0",  
  "FPCE22V3FA1",  
  "FPCE22V3FF0",  
  "FPCE22V3FF1",  
  "FPCE22V3FH0",  
  "FPCE22V3FH1",  
  "FPCE22V3FL0",  
  "FPCE22V3FL1",  
  "FPCE22V3FW0",  
  "FPCE22V3FW1",  
  "FPCE22V3PL0",  
  "FPCE22V3PL1",  
  "FPCE22V3PW0",  
  "FPCE22V3PW1",  
  "FPCE22VWFA0",  
  "FPCE22VWFA1",  
  "FPCE22VWFA2",  
  "FPCE22VWFA3",
```

```
"FPCE22VWFF0",
"FPCE22VWFF1",
"FPCE22VWFF2",
"FPCE22VWFF3",
"FPCE22VWFH0",
"FPCE22VWFH1",
"FPCE22VWFH2"
]
},
{
  "part_name": "SLIDE 154572201",
  "part_number": "PS1524972",
  "manufacturer": "Kenmore",
  "price": "40.24",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Back
to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "58715202800",
    "58715202801",
    "58715203800",
    "58715203801",
    "BGHD2433KB0",
```

"BGHD2433KF0",
"BGHD2433KW0",
"DGBD2432KB0",
"DGBD2432KF0",
"DGBD2432KW0",
"DGHD2433KF0",
"FDB4315LFB0",
"FDB4315LFB1",
"FDB4315LFB2",
"FDB4315LFB3",
"FDB4315LFC0",
"FDB4315LFC1",
"FDB4315LFC2",
"FDB4315LFC3",
"FDB4315LFS0",
"FDB4315LFS1",
"FDB4315LFS2",
"FDB4315LFS3",
"FDBB4365FB0",
"FDBB4365FB1",
"FDBB4365FB2",
"FDBB4365FB3",
"FDBB4365FC0",
"FDBB4365FC1",
"FDBB4365FC2"

]

```
},  
{  
  "part_name": "SLIDE- Right Hand WP99003760",  
  "part_number": "PS11747792",  
  "manufacturer": "Kenmore",  
  "price": "249.26",  
  "description": "",  
  "rating": null,  
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#  
WP99003760 replaces these: 6-919541, 99003760 Back to Top",  
  "review_count": null,  
  "appliance": "dishwasher",  
  "compatible_models": [  
    "46513322600",  
    "46513323600",  
    "46513329600",  
    "46513333600",  
    "46513339600",  
    "46513342600",  
    "46513343600",  
    "46513349600",  
    "DK524N1ABL0",  
    "DK524N1ASS0",  
    "DK524Q1ABL0",  
    "DK524Q1ASS0",  
    "DK724N1ASS0",
```

```
"DK724Q1ASS0",
"JDD4000AWS2",
"JDD4000AWS3",
"JDD4000AWX2",
"JDD4000AWX3",
"KUDD03DTBL0",
"KUDD03DTBL10",
"KUDD03DTBL2",
"KUDD03DTBL3",
"KUDD03DTPA0",
"KUDD03DTPA1",
"KUDD03DTPA10",
"KUDD03DTPA2",
"KUDD03DTSS0",
"KUDD03DTSS10",
"KUDD03DTSS2",
"KUDD03DTSS3"
]
},
{
  "part_name": "SLIDE- Left Hand WP99003759",
  "part_number": "PS11747791",
  "manufacturer": "Kenmore",
  "price": "172.00",
  "description": "",
  "rating": "100",
```

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WP99003759 replaces these: 6-919540, 99003759 Back to Top",

"review_count": "1",

"appliance": "dishwasher",

"compatible_models": [

"46513322600",

"46513323600",

"46513329600",

"46513333600",

"46513339600",

"46513342600",

"46513343600",

"46513349600",

"DK524N1ABL0",

"DK524N1ASS0",

"DK524Q1ABL0",

"DK524Q1ASS0",

"DK724N1ASS0",

"DK724Q1ASS0",

"JDD4000AWS2",

"JDD4000AWS3",

"JDD4000AWX2",

"JDD4000AWX3",

"KUDD03DTBL0",

"KUDD03DTBL10",

"KUDD03DTBL2",

```
"KUDD03DTBL3",
"KUDD03DTPA0",
"KUDD03DTPA1",
"KUDD03DTPA10",
"KUDD03DTPA2",
"KUDD03DTSS0",
"KUDD03DTSS10",
"KUDD03DTSS2",
"KUDD03DTSS3"
]
},
{
  "part_name": "Upper Rack Track Assembly - Left & Right Side W10404344",
  "part_number": "PS3495236",
  "manufacturer": null,
  "price": "206.85",
  "description": "This includes both sides. The dishrack glides back and forth on this track as it's mounted to the side of the tub.",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# W10404344 replaces these: AP5183453, 1937097, 8270130, 8531302, 8531559, 8531630 Back to Top",
  "review_count": "4",
  "appliance": "dishwasher",
  "compatible_models": [
    "KUDM01FKBL0",
    "KUDM01FKBL1",
```


"KUDM01FKBT0",
"KUDM01FKBT1",
"KUDM01FKSS0",
"KUDM01FKSS1",
"KUDM01FKWH0",
"KUDM01FKWH1",
"KUDM01TJBL0",
"KUDM01TJBL1",
"KUDM01TJBS0",
"KUDM01TJBS1",
"KUDM01TJBT0",
"KUDM01TJBT1",
"KUDM01TJWH0",
"KUDM01TJWH1",
"KUDP01DLBL0",
"KUDP01DLBL1",
"KUDP01DLBL2",
"KUDP01DLBL3",
"KUDP01DLBL5",
"KUDP01DLBL6",
"KUDP01DLBL7",
"KUDP01DLBS0",
"KUDP01DLBS1",
"KUDP01DLBS2",
"KUDP01DLBS3",
"KUDP01DLBS5",

```
"KUDP01DLBS6",
"KUDP01DLBS7"
]
},
{
  "part_name": "Upper Dishrack Inner Rail WD30X10021",
  "part_number": "PS959486",
  "manufacturer": null,
  "price": "62.76",
  "description": "This slide is mounted to each side of the upper cabinet wall. The dishrack wheels roll inside this track, which guides the upper rack.",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WD30X10021 replaces these: AP3422221, 1057531 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "CDW9380N00SS",
    "CDW9380N20SS",
    "CDWT980R10SS",
    "CDWT980R30SS",
    "EDWF800P00BB",
    "EDWF800P00WW",
    "EDWF860P00SS",
    "GDWF100R10BB",
    "GDWF100R10WW",
    "GDWF100R30BB",
```

```
"GDWF100R30WW",
"GDWF160R10SS",
"GDWF160R30SS",
"GDWT100R00BB",
"GDWT100R00WW",
"GDWT100R05BB",
"GDWT100R05WW",
"GDWT100R10BB",
"GDWT100R10WW",
"GDWT100R30BB",
"GDWT100R30WW",
"GDWT160R00SS",
"GDWT160R05SS",
"GDWT160R10SS",
"GDWT160R30SS",
"GDWT200R10BB",
"GDWT200R10WW",
"GDWT200R30BB",
"GDWT200R30WW",
"GDWT260R10SS"
]
},
{
  "part_name": "Dishrack Roller Bracket, Upper WP8564899",
  "part_number": "PS11746565",
  "manufacturer": null,
```

"price": "62.57",

"description": "Sold individually. This dishrack roller bracket is for dishwashers. Dishrack roller bracket fits on the dishrack and attaches the roller wheels to the dishrack.",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WP8564899 replaces these: AP6013339, 8564898, 8564899 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"JDB8700AWP0",

"JDB8700AWP1",

"JDB8700AWP2",

"JDB8700AWP3",

"JDB8700AWS0",

"JDB8700AWS1",

"JDB8700AWS2",

"JDB8700AWS3",

"JDB8700AWS4",

"JDB9800CWP1",

"JDB9800CWP2",

"JDB9800CWP3",

"JDB9800CWS1",

"JDB9800CWS2",

"JDB9800CWS3",

"JDB9800CWX2",

"JDTSS245GX0",

"JDTSS246GL0",

"JDTSS246GM0",

"JDTSS246GP0",

"JDTSS246GS0",

"KDHE704DSS0",

"KDTE204DBL0",

"KDTE204DBL1",

"KDTE204DSS0",

"KDTE204DSS1",

"KDTE204DWH0",

"KDTE204DWH1",

"KDTE334DBL0",

"KDTE334DSS0"

]

},

{

"part_name": "Upper Rack Slide WD30X98",

"part_number": "PS261576",

"manufacturer": "Kenmore",

"price": "70.69",

"description": "This slide is mounted to each side of the upper cabinet wall. The dishrack wheels roll inside this track, which guides the upper rack.",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WD30X98 replaces these: AP2040347, 272573, WD30X98, WD30X0093, WD30X0097, WD30X0098 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"1200L02",

"18081",

"18385",

"1858",

"18585",

"18885",

"18985",

"3000B10",

"3000W10",

"3631401190",

"3631401191",

"3631401590",

"3631401591",

"3631401592",

"3631401890",

"3631401891",

"3631401892",

"3631402190",

"3631402192",

"3631402590",

"3631402591",

"3631402592",

"3631402890",

"3631402891",

"3631402892",

"36314031000",

"36314031001",

"36314032000",

"36314032001",

"36314038000"

]

},

{

"part_name": "Upper Dishrack Slide 154597801",

"part_number": "PS1525080",

"manufacturer": "Kenmore",

"price": "49.57",

"description": "This is an upper dishrack slide for your dishwasher. It is mounted to each side of the upper cabinet wall. The dishrack wheels roll inside this track, which guides the upper rack. The mounting screws are not included in this purchase and can be found in the related parts section below. You should purchase a new dishrack slide if your current one has been warped or damaged over time.",

"rating": "20",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 154597801 replaces these: AP4019645, 1258729, 154232701 Back to Top",

"review_count": "1",

"appliance": "dishwasher",

"compatible_models": [

"004621710A",

"004621711A",

"58714000100",

"58714000101",

"58714000102",
"58714001990",
"58714001991",
"58714001992",
"58714001993",
"58714002990",
"58714002991",
"58714002992",
"58714002993",
"58714003100",
"58714008001",
"58714008002",
"58714008003",
"58714009100",
"58714009101",
"58714009102",
"58714012400",
"58714012401",
"58714012402",
"58714012403",
"58714012404",
"58714012405",
"58714012406A",
"58714012407A",
"58714012408A",
"58714012409B"


```
]
},
{
  "part_name": "Control Panel - Black W10811155",
  "part_number": "PS11723007",
  "manufacturer": null,
  "price": "114.95",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Will Not Start This part works with the following products: Dishwasher. Part# W10811155 replaces these: W10240112, W10254846, W10751533 Back to Top",
  "review_count": "4",
  "appliance": "dishwasher",
  "compatible_models": [
    "MDB7609AWB0",
    "MDB7609AWB1",
    "MDB7609AWB2",
    "MDB7609AWB3",
    "MDB7609AWS0",
    "MDB7609AWS1",
    "MDB7609AWS2",
    "MDB7609AWS3",
    "MDB7609AWW0",
    "MDB7609AWW1",
    "MDB7609AWW2",
    "MDB7609AWW3",
```

"MDBH979AWB1",
"MDBH979AWB2",
"MDBH979AWB3",
"MDBH979AWB4",
"MDBH979AWS1",
"MDBH979AWS2",
"MDBH979AWS3",
"MDBH979AWS4",
"MDBH979AWW1",
"MDBH979AWW2",
"MDBH979AWW3",
"MDBH979AWW4"

]

},

{

"part_name": "Electronic Control Board 5304514670",

"part_number": "PS12365809",

"manufacturer": "Kenmore",

"price": "148.81",

"description": "Electronic control board manages the functions of the dishwasher such as washing, draining and drying",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start This part works with the following products: Dishwasher. Part# 5304514670 replaces these: AP6327227, 154543602, 154636102, 154752901, 154757002, 154815601, 154886102, 154886103, 5304500203, 5304504782, 5304506317, 807151001, A01555601 Back to Top",

```
"review_count": "6",  
"appliance": "dishwasher",  
"compatible_models": [  
  "58715202800",  
  "58715202801",  
  "58715202802",  
  "58715203800",  
  "58715203801",  
  "58715203802",  
  "BGHD2433KB0",  
  "BGHD2433KB1",  
  "BGHD2433KF0",  
  "BGHD2433KF1",  
  "BGHD2433KW0",  
  "BGHD2433KW1",  
  "DGHD2433KF0",  
  "DGHD2433KF1",  
  "FDB4050LHB0",  
  "FDB4050LHB1",  
  "FDB4050LHC0",  
  "FDB4050LHC1",  
  "FDB4050LHS0",  
  "FDB4050LHS1",  
  "FDB4315LFB0",  
  "FDB4315LFB1",  
  "FDB4315LFB2",
```

"FDB4315LFB3",

"FDB4315LFC0",

"FDB4315LFC1",

"FDB4315LFC2",

"FDB4315LFC3",

"FDB4315LFS0",

"FDB4315LFS1"

]

},

{

"part_name": "Control Panel and Touchpad - White W10811149",

"part_number": "PS11723001",

"manufacturer": null,

"price": "113.98",

"description": "NOTE: Electrical control board is NOT included.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start This part works with the following products: Dishwasher. Part# W10811149 replaces these: AP5985196, W10356460, W10356467, W10751526 Back to Top",

"review_count": "7",

"appliance": "dishwasher",

"compatible_models": [

"MDB7749AWB0",

"MDB7749AWB1",

"MDB7749AWB2",

"MDB7749AWM1",

"MDB7749AWM2",

"MDB7749AWQ1",
"MDB7749AWQ2",
"MDB7749AWS0",
"MDB7749AWS1",
"MDB7749AWW0",
"MDB7749AWW1",
"MDB7749AWW2"

]

},

{

"part_name": "Control Panel- Stainless WPW10475780",

"part_number": "PS11755345",

"manufacturer": null,

"price": "210.82",

"description": "",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start This part works with the following products: Dishwasher. Part# WPW10475780 replaces these: AP6022016, W10329536, W10475780 Back to Top",

"review_count": "1",

"appliance": "dishwasher",

"compatible_models": [

"MDB8959SAB0",

"MDB8959SAB1",

"MDB8959SAS0",

"MDB8959SAS1",

"MDB8959SAW0",

"MDB8959SAW1",
"MDB8959SBB0",
"MDB8959SBB1",
"MDB8959SBB2",
"MDB8959SBB3",
"MDB8959SBS0",
"MDB8959SBS1",
"MDB8959SBS2",
"MDB8959SBS3",
"MDB8959SBW0",
"MDB8959SBW1",
"MDB8959SBW2",
"MDB8959SBW3"

]

},

{

"part_name": "Electronic Control Board WPW10084141",

"part_number": "PS11748220",

"manufacturer": "Kenmore",

"price": "422.25",

"description": "This board is located in the control panel of the dishwasher.Thermal fuse is NOT included.",

"rating": null,

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start | Will not dispense detergent | Not cleaning dishes properly This part works with the following products: Dishwasher. Part# WPW10084141 replaces these: AP6014950, 8559824, 8559825, 8562996, 8562996R, 8562997, 8562997R, 8575276, 8575276R, 8575277,

8575277R, W10039760, W10039770, W10076350, W10076360, W10084141,
W10084141R Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"66513112K700",

"66513112K701",

"66513112K702",

"66513113K701",

"66513113K702",

"66513114K700",

"66513114K702",

"66513119K701",

"66513119K702",

"66513222K600",

"66513222K601",

"66513223K600",

"66513223K601",

"66513229K600",

"66513229K601",

"66513412K700",

"66513412K701",

"66513412K702",

"66513413K701",

"66513413K702",

"66513419K700",

"66513419K702",

"66513482K900",

"66513483K900",

"66513484K900",

"66513489K900",

"66513672K600",

"66513672K601",

"66513672K602",

"66513673K600"

]

},

{

"part_name": "Noise Filter Assembly 6201EC1006T",

"part_number": "PS3528920",

"manufacturer": "LG",

"price": "73.58",

"description": "",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start This part works with the following products: Washer, Dishwasher, Washer Dryer Combo, Dryer. Part# 6201EC1006T replaces these: 5251356, 2226388, 6201EC1006A, 6201EC1006E, 6201EC1006H, 6201EC1006L, 6201EC1006Q, 6201EC1006U, 6201EC1006W, 6201EC1006Z, 6201EN1005A Back to Top",

"review_count": "2",

"appliance": "dishwasher",

"compatible_models": [

"14693",

"39232533",
"40272",
"40318",
"40441",
"41538",
"41549",
"42198",
"42199",
"45429",
"48231009799",
"48231010108",
"498610",
"72214697610",
"79640021900",
"79640272800",
"79640272900",
"79640311900",
"79640318900",
"79640441900",
"79640448900",
"79640512900",
"79640518900",
"79641022900",
"79641028900",
"79641029900",
"79641372210",

```
"79641372211",
"79641379210",
"79641532110"
]
},
{
  "part_name": "Electronic Control Board 807022404",
  "part_number": "PS11758324",
  "manufacturer": null,
  "price": "103.83",
  "description": "",
  "rating": "90",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 807022404 replaces these: 807022402, 807022403 Back to Top",
  "review_count": "2",
  "appliance": "dishwasher",
  "compatible_models": [
    "FGID2474QB0A",
    "FGID2474QB0B",
    "FGID2474QB1B",
    "FGID2474QB3B",
    "FGID2474QB4B",
    "FGID2474QB5B",
    "FGID2474QB6B",
    "FGID2474QB7B",
    "FGID2474QF0A",
```

"FGID2474QF0B",
"FGID2474QF1B",
"FGID2474QF2B",
"FGID2474QF3B",
"FGID2474QF4B",
"FGID2474QF5B",
"FGID2474QF6B",
"FGID2474QF7B",
"FGID2474QW0A",
"FGID2474QW0B",
"FGID2474QW1B",
"FGID2474QW2B",
"FGID2474QW3B",
"FGID2474QW4B",
"FGID2474QW5B",
"FGID2474QW6B",
"FGID2474QW7B",
"FGID2477RF1A",
"FGID2477RF3A",
"FGID2477RF4A",
"FGID2477RF5A"

]

},

{

"part_name": "BOARD,CONTROL 5304520582",

"part_number": "PS12712360",

```
"manufacturer": null,

"price": "155.64",

"description": "",

"rating": null,

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start This part works with the following products: Dishwasher. Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

    "004621710A",

    "004621711A",

    "804655850A",

    "804655851A",

    "FGID2466QB7A",

    "FGID2466QD2A",

    "FGID2466QF7A",

    "FGID2466QF8A",

    "FGID2466QF9A",

    "FGID2466QW7A"

]

},

{

    "part_name": "BOARD,CONTROL FIA A11147301",

    "part_number": "PS16661027",

    "manufacturer": null,

    "price": "163.18",
```

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# A11147301 replaces these: 5304518470 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"FFID2426TB0A",

"FFID2426TB1A",

"FFID2426TB2A",

"FFID2426TB3A",

"FFID2426TD2A",

"FFID2426TD3A",

"FFID2426TD4A",

"FFID2426TD5A",

"FFID2426TS2A",

"FFID2426TS3A",

"FFID2426TS4A",

"FFID2426TW0A",

"FFID2426TW1A",

"FFID2426TW2A",

"FFID2426TW3A",

"LFID2426TF2A",

"LFID2426TF3A",

"LFID2426TF4A",

"LFID2426TF5A"

```
]
},
{
  "part_name": "Dishwasher Timer WD21X10474",
  "part_number": "PS4704218",
  "manufacturer": null,
  "price": "110.55",
  "description": "The timer manages the various dishwasher functions such as filling,
washing, draining and drying.",
  "rating": "84",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#
WD21X10474 replaces these: AP5646373 Back to Top",
  "review_count": "5",
  "appliance": "dishwasher",
  "compatible_models": [
    "GSD2100V35BB",
    "GSD2100V35CC",
    "GSD2100V35WW",
    "GSD2100V45BB",
    "GSD2100V45CC",
    "GSD2100V45WW",
    "GSD2100V50BB",
    "GSD2100V50CC",
    "GSD2100V50WW",
    "GSD2100V55BB",
    "GSD2100V55CC",
    "GSD2100V55WW",
```

```
"GSD2100V65BB",
"GSD2100V65CC",
"GSD2100V65WW",
"GSD2100V70CC",
"GSD2100V70WW",
"GSD2101V35BB",
"GSD2101V35WW",
"GSD2101V45BB",
"GSD2101V45WW",
"GSD2101V50BB",
"GSD2101V50WW",
"GSD2101V55BB",
"GSD2101V55WW",
"HDA2100H35BB",
"HDA2100H35CC",
"HDA2100H35WW",
"HDA2100H45BB",
"HDA2100H45CC"
]
},
{
  "part_name": "INSULATION 5304501485",
  "part_number": "PS11704183",
  "manufacturer": null,
  "price": "126.50",
  "description": ""
```

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 5304501485 replaces these: AP5983077, 154580601, 154828701, 807460801 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"004621710A",

"004621711A",

"804655850A",

"804655851A",

"CDBEH600SB0A",

"CDBEH600SB2A",

"CDBEH600SS0A",

"CDBEH600SS2A",

"CDBEH600SW0A",

"CDBEH600SW2A",

"CDBEH950SB1A",

"CDBEH950SS1A",

"CDBEH950SW1A",

"CDBEH960TD0A",

"CDBEH960TS0A",

"DGCD2444SA0A",

"DGCD2444SA1A",

"DGCD2444SA2A",

"DGCD2444SD0A",

"FFBD2412SB0A",


```
"FFBD2412SB2A",
"FFBD2412SM0A",
"FFBD2412SM2A",
"FFBD2412SQ0A",
"FFBD2412SQ2A",
"FFBD2412SS0A",
"FFBD2412SS2A",
"FFBD2412SW0A",
"FFBD2412SW2A",
"FFCD2418UB0A"
]
},
{
  "part_name": "INSULATION 154253201",
  "part_number": "PS420505",
  "manufacturer": "Kenmore",
  "price": "135.00",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Back  
to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "004621710A",
    "004621711A",
```

"58714003100",
"58714302200",
"58714302201",
"58714309200",
"58714309201",
"58715072200",
"58715072201",
"58715073200",
"58715073201",
"58715074200",
"58715074201",
"58715079200",
"58715079201",
"58715313000A",
"58715372100A",
"58715372100B",
"58715373100A",
"58715373100B",
"58715378100A",
"58715378100B",
"58715379100A",
"58715379100B",
"58715382100A",
"58715382100B",
"58715383100A",
"58715383100B",

```
"58715389100A",
"58715389100B"
]
},
{
  "part_name": "PAD-INS WPW10746770",
  "part_number": "PS11757367",
  "manufacturer": "Kenmore",
  "price": "30.77",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#
WPW10746770 replaces these: 8268582, 8268587, W10195368, W10266857,
W10746770, WPW10195368 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "66512772K312",
    "66512772K313",
    "66512772K314",
    "66512773K313",
    "66512773K314",
    "66512774K312",
    "66512774K313",
    "66512776K311",
    "66512776K312",
    "66512776K314",
```

```
"66512779K312",
"66512779K313",
"66512779K314",
"66512782K310",
"66512782K311",
"66512782K312",
"66512782K313",
"66512783K311",
"66512783K312",
"66512783K313",
"66512789K311",
"66512789K312",
"66512789K313",
"66512813K313",
"66513012K112",
"66513012K113",
"66513013K112",
"66513013K113",
"66513014K112",
"66513014K113"
]
},
{
  "part_name": "Insulation Pad WPW10223013",
  "part_number": "PS11750638",
  "manufacturer": null,
```

"price": "55.11",

"description": "",

"rating": "90",

"troubleshooting_tips": "This part fixes the following symptoms: Noisy This part works with the following products: Dishwasher. Part# WPW10223013 replaces these: 9-12456, 9-12655, 9-12748, 912456, 912655, 912748, 99001198, 99001691, 99001692, 99002156, 99002191, 99002405, 99002406, 99002407, 99002695, 99002849, 99003127, W10223013, Y912748 Back to Top",

"review_count": "2",

"appliance": "dishwasher",

"compatible_models": [

"ADB2200AWB",

"ADB2200AWQ",

"ADB2200AWS",

"ADB2200AWW",

"ADB2500AWB1",

"ADB2500AWB2",

"ADB2500AWB3",

"ADB2500AWB37",

"ADB2500AWB40",

"ADB2500AWB46",

"ADB2500AWQ1",

"ADB2500AWQ2",

"ADB2500AWQ3",

"ADB2500AWQ37",

"ADB2500AWQ40",

"ADB2500AWQ46",

"ADB2500AWS1",
"ADB2500AWS2",
"ADB2500AWS3",
"ADB2500AWS37",
"ADB2500AWS40",
"ADB2500AWS46",
"ADB2500AWW1",
"ADB2500AWW2",
"ADB2500AWW3",
"ADB2500AWW37",
"ADB2500AWW40",
"ADB2500AWW46",
"ADB3500AWB",
"ADB3500AWB0"

]

},

{

"part_name": "Front Panel Insulation WPW10073520",

"part_number": "PS11748109",

"manufacturer": "Kenmore",

"price": "50.42",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WPW10073520 replaces these: 8268580, 8542577, W10073520 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"2212413N414",

"2213092N413",

"2213099N413",

"2213222N414",

"2213223N414",

"2213229N414",

"2213479N413",

"2213809N710",

"2217383N710",

"2217389N710",

"66213013K112",

"66213014K112",

"66213019K112",

"66213023K112",

"66213032K112",

"66213033K112",

"66213043K112",

"66213044K112",

"66213049K112",

"66213273K112",

"66213279K112",

"66213282K112",

"66213289K112",

"66213292K112",

```
"66512093K210",
"66512413N410",
"66512413N411",
"66512413N412",
"66512413N413",
"66512723K310"
]
},
{
  "part_name": "VENT PAD WD1X1467",
  "part_number": "PS259749",
  "manufacturer": "Kenmore",
  "price": "11.31",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WD1X1467 replaces these: AP2038428, 270277, WD01X1467 Back to Top",
  "review_count": "2",
  "appliance": "dishwasher",
  "compatible_models": [
    "36314061790",
    "400210",
    "400211",
    "400212",
    "400410",
    "400610",
```



```
"400611",  
"403410",  
"403411",  
"403610",  
"403611",  
"40461119",  
"40471119",  
"40471129",  
"404713",  
"404714",  
"40561119",  
"40561129",  
"405613",  
"405614",  
"41040118",  
"41040119",  
"41040128",  
"41040138",  
"410410",  
"41461119",  
"41471119",  
"41471129",  
"414713",  
"414714"  
]  
},
```

```
{  
  "part_name": "Dishwasher Tub Sound Shield W10877094",  
  "part_number": "PS11738163",  
  "manufacturer": "Kenmore",  
  "price": "110.39",  
  "description": "The tub sound shield insulates the tub to reduce noise.",  
  "rating": "100",  
  "troubleshooting_tips": "This part fixes the following symptoms: Noisy This part works  
with the following products: Dishwasher. Part# W10877094 replaces these: AP6004901,  
8268585, 8268586, 8531027, 8531028, 8531401, 8542576, 8573239, 8573241,  
W10796452, W10866980 Back to Top",  
  "review_count": "2",  
  "appliance": "dishwasher",  
  "compatible_models": [  
    "2214715N710",  
    "2214792N512",  
    "2214793N512",  
    "66512793K312",  
    "66512793K313",  
    "66512803K312",  
    "66512833K311",  
    "66512833K312",  
    "66513012K112",  
    "66513012K113",  
    "66513013K112",  
    "66513013K113",  
    "66513014K112",  
  ]  
}
```

```
"66513014K113",
"66513019K112",
"66513019K113",
"66513023K112",
"66513023K113",
"66513073K210",
"66513073K211",
"66513073K212",
"66513152K700",
"66513152K701",
"66513152K702",
"66513153K700",
"66513153K701",
"66513153K702",
"66513154K700",
"66513154K701",
"66513154K702"
]
},
{
  "part_name": "Tub Insulation 154641601",
  "part_number": "PS1990923",
  "manufacturer": "Kenmore",
  "price": "30.82",
  "description": "",
  "rating": null,
```

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 154641601 replaces these: AP4301097, 154238301, 154238302, 154238303, 154238304, 154238305, 154238306, 154249401, 154447102, 154456901, 154457001, 154457002, 154544701, 154635001, 154753301, 154859001, 5300809710, 5303208369 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"58714000100",

"58714000101",

"58714000102",

"58714001990",

"58714001991",

"58714001992",

"58714001993",

"58714002990",

"58714002991",

"58714002992",

"58714002993",

"58714003100",

"58714008001",

"58714008002",

"58714008003",

"58714009100",

"58714009101",

"58714009102",

"58714012400",

"58714012401",
"58714012402",
"58714012403",
"58714012404",
"58714012405",
"58714012406A",
"58714012407A",
"58714012408A",
"58714012409B",
"58714012410B",
"58714012411B"

]

},

{

"part_name": "Tub Sound Shield - Insulation W11086533",

"part_number": "PS12070612",

"manufacturer": "Kenmore",

"price": "26.18",

"description": "",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Noisy This part works with the following products: Dishwasher, Refrigerator. Part# W11086533 replaces these: 20082433, 20083521, 300865, 302804, 303457, 303483, 303779, 304663, 304786, 3367043, 3369329, 3374765, 3375549, 3375550, 3381229, 3381230, 8055334, 8055335, 8268583, 8271509 ... Show more , 8318252, 8531029, 8531031, 8531032, 8573240, 8573242, 8573243, 9742661, 9743172, 9743789, W10796453, W10866978, WP8573240, WP8573242 Show less Back to Top",

"review_count": "2",

"appliance": "dishwasher",

"compatible_models": [

"110723120",

"110773811",

"110773812",

"110773813",

"110773881",

"110773882",

"110773883",

"19385",

"19585",

"19985",

"2212413N414",

"2213222N414",

"2213223N414",

"2213229N414",

"2213479N413",

"2214523N611",

"2214545N711",

"56413485100",

"5648650100",

"5648650110",

"5648650180",

"5648650190",

"5648651100",

"5648651110",

```
"5648651180",
"5648651190",
"5648660100",
"5648660101",
"5648660110",
"5648660111"
]
},
{
  "part_name": "SHIELD W10831329",
  "part_number": "PS11730934",
  "manufacturer": "Kenmore",
  "price": "38.42",
  "description": "Shield",
  "rating": "67",
  "troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# W10831329 replaces these: 8194024, 8268581, 8268584, 8542578, 8545574, 8545575, W10056273, W10056310, W10073540, W10073550, W10084477, W10084568, W10189681, W10195629, W10275524, W10275525, W10300769, W10350437, W10385107, W10518815 ... Show more , W10519755, W10526104, W10526105, W11162100, W11172908, WPW10300769, WPW10526104 Show less Back to Top",
  "review_count": "3",
  "appliance": "dishwasher",
  "compatible_models": [
    "2212413N414",
    "2213092N413",
    "2213099N413",
```

"2213479N413",
"66213013K112",
"66213014K112",
"66213019K112",
"66213292K112",
"66512413N413",
"66512772K311",
"66512772K312",
"66512772K313",
"66512772K314",
"66512773K311",
"66512773K312",
"66512773K313",
"66512773K314",
"66512774K311",
"66512774K312",
"66512774K313",
"66512776K311",
"66512776K312",
"66512776K314",
"66512779K311",
"66512779K312",
"66512779K313",
"66512779K314",
"66512782K310",
"66512782K311",


```
"66512782K312"
]
},
{
  "part_name": "FOOT 00617585",
  "part_number": "PS8728141",
  "manufacturer": "Kenmore",
  "price": "7.59",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#
00617585 replaces these: AP4434723, 617585 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "63013902010",
    "63013902011",
    "63013903010",
    "63013903011",
    "63013909010",
    "63013909011",
    "63013912010",
    "63013912011",
    "63013913010",
    "63013913011",
    "63013919010",
```

```
"63013919011",
"63013952010",
"63013952011",
"63013953010",
"63013953011",
"63013959010",
"63013959011",
"63016302404",
"63016302405",
"63016302406",
"63016303404",
"63016303405",
"63016303406",
"63016304404",
"63016304405",
"63016304406",
"63016309404",
"63016309405",
"63017303404"
]
},
{
  "part_name": "Caster Wheel WP903297",
  "part_number": "PS11746836",
  "manufacturer": null,
  "price": "13.69",
```

"description": "This dishwasher caster wheel is four inches long. It is a two inch black wheel with a white shaft. This wheel is used with portable dishwashers.",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WP903297 replaces these: AP6013609, 9-3297, 903297 Back to Top",

"review_count": "2",

"appliance": "dishwasher",

"compatible_models": [

"CDC400B",

"CDC450B",

"CDC5J",

"CDC610B",

"DC4000B",

"DC4500B",

"DC5J",

"DWC4910AAW",

"DWC6402AAE",

"DWC6402ABE",

"DWC7302AAB",

"DWC7302ABB",

"DWC7400AAW",

"DWC7400ABW",

"DWC7602AAB",

"DWC7602AAE",

"DWC7602ABB",

"DWC7602ABE",

"DWC8240AAW",

"DWC8240ABW",
"DWC8330AAW",
"DWCA500AAW",
"MCD4100AWE",
"MCD4100AWX",
"MDC4000AWE",
"MDC4000AWX",
"MDC4100AWE",
"MDC4100AWX",
"MDC4650AWB",
"MDC4650AWB0"

]

},

{

"part_name": "LEG MFA63022901",

"part_number": "PS12081891",

"manufacturer": "LG",

"price": "8.28",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# MFA63022901 replaces these: AP6237117 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"13383",

"13387",
"14305",
"14307",
"14355",
"14357",
"14673",
"14677",
"72213387910",
"72214305910",
"72214307910",
"72214357910",
"72214673710",
"79551832414",
"LDB4548ST",
"LDF5545BB",
"LDF5545BD",
"LDF5545SS",
"LDF5545ST",
"LDF5545WW",
"LDF5678BD",
"LDF5678SS",
"LDF5678ST",
"LDFN3432T",
"LDFN343LS",
"LDFN4542B",
"LDFN4542D",

```
"LDFN4542S",
"LDFN4542W",
"LDP5676BD"
]
},
{
  "part_name": "Leveling Leg 5304506540",
  "part_number": "PS11770497",
  "manufacturer": "Kenmore",
  "price": "10.60",
  "description": "Sold individually.",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 5304506540 replaces these: AP6036344, 154571101, 7154571101 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "004621710A",
    "004621711A",
    "58714012401",
    "58714012402",
    "58714012403",
    "58714012404",
    "58714012405",
    "58714012406A",
    "58714012407A",
```

"58714012408A",
"58714012409B",
"58714012410B",
"58714012411B",
"58714012412B",
"58714012413B",
"58714012414B",
"58714012416B",
"58714013402",
"58714013403",
"58714013404",
"58714013405",
"58714013406",
"58714013407A",
"58714013408A",
"58714013409A",
"58714013410B",
"58714013411B",
"58714013412B",
"58714013413B",
"58714013414B"

]

},

{

"part_name": "Leveling Leg 8193716",

"part_number": "PS557020",

"manufacturer": "Kenmore",

"price": "50.01",

"description": "Leveling leg Now includes two different sizes. Use the one for your model. If you need two legs you will need to purchase a QTY of two of this kit.",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dishwasher, Ice Maker, Refrigerator. Part# 8193716 replaces these: AP3138177, 920086, 302849, 3374849, 3376439, 3385424, 8193716, 8524584, W10304228, W10400109, W10619352, W10619353 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"1064689482991",

"10689482700",

"10689482990",

"10689482991",

"10689482992",

"10689482993",

"10689482994",

"10689482995",

"10689482996",

"10689482998",

"10689483992",

"10689483993",

"10689483994",

"10689483995",

"10689483996",

"10689485990",
"10689485991",
"10689485992",
"10689489990",
"10689489991",
"10689489992",
"10689489993",
"10689489994",
"10689489995",
"10689489996",
"10689489997",
"10689553102",
"10689582701",
"10689582702",
"10689582704"

]

},

{

"part_name": "CASTER (4 PACK) WP8559933",

"part_number": "PS11746474",

"manufacturer": "Kenmore",

"price": "55.05",

"description": "This includes all 4 casters.",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WP8559933 replaces these: 8559932, 8559933 Back to Top",

```
"review_count": "3",  
"appliance": "dishwasher",  
"compatible_models": [  
  "66517152K210",  
  "66517152K211",  
  "66517152K212",  
  "66517152K213",  
  "66517152K214",  
  "66517152K215",  
  "66517152K216",  
  "66517152K217",  
  "66517159K210",  
  "66517159K211",  
  "66517159K212",  
  "66517159K213",  
  "66517159K214",  
  "66517159K215",  
  "66517159K216",  
  "66517159K217",  
  "66517432002",  
  "66517439002",  
  "66517459001",  
  "66517482N710",  
  "66517489N710",  
  "66517669400",  
  "66517679400",
```

"66517702K600",

"66517709K600",

"66517722001",

"66517722002",

"66517722K900",

"66517729001",

"66517729002"

]

},

{

"part_name": "Adjustable Leveling Screw WE1M642",

"part_number": "PS1021358",

"manufacturer": "Kenmore",

"price": "16.49",

"description": "The adjustable leveling screws on the bottom of your dryer can be screwed in or out to lower or raise the leg level. If one of the leveling screws is stripped, damaged, or missing, you may not be able to create a level base for your dryer. The leveling screw has a hexagon-shaped gray plastic foot, with a screw that is approximately 1 inch in length. To replace a damaged screw, simply turn the old screw to the left, until it can be removed. Then, simply screw the new leveling screw into place on the bottom of the dryer, making sure it is the same height as the other 3 leveling screws.",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Dryer, Dishwasher. Part# WE1M642 replaces these: AP3885801, 1174111, WE01M0311, WE01M0368, WE02X0162, WE02X0193, WE02X0229, WE02X0355, WE1M311, WE1M368, WE2X162, WE2X193, WE2X229, WE2X355 Back to Top",

"review_count": "2",

"appliance": "dishwasher",

"compatible_models": [

"363DDE8109VML",
"363DDE8200GAL",
"363DDE8509RCMAA",
"363DDE8509RCMWW",
"363DDE9200GAL",
"363DDE9600RCMAA",
"61140418",
"61140419",
"61148418",
"61148419",
"62140418",
"62140419",
"62148418",
"62148419",
"62150419",
"62150429",
"62150439",
"62160T3WB",
"62160T5WB",
"62170419",
"62180419",
"62188419",
"62190419",
"62190429",
"62190439",
"62190449",

```
"62190459",
"62190479",
"62198419",
"62198429"
]
},
{
  "part_name": "Leveling Screw WD12X23057",
  "part_number": "PS11762951",
  "manufacturer": null,
  "price": "8.06",
  "description": "This is a genuine GE dishwasher leveling screw. It operates as a leg on the bottom of your dishwasher, and can be screwed in and out to raise and lower the height of the dishwasher. It is made of metal and is and OEM part.",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WD12X23057 replaces these: AP6032534, WD12X10417 Back to Top",
  "review_count": "2",
  "appliance": "dishwasher",
  "compatible_models": [
    "ADT521PGF0BS",
    "ADT521PGF0WS",
    "ADT521PGF2BS",
    "ADT521PGF2WS",
    "ADT521PGF4BS",
    "ADT521PGF4WS",
    "ADT521PGF6BS",
```

```
"ADT521PGF6WS",  
"ADT521PGJ0BS",  
"ADT521PGJ0WS",  
"ADT521PGJ2BS",  
"ADT521PGJ2WS",  
"ADT521PGJBS",  
"ADT521PGJWS",  
"CDT706P2M4S1",  
"CDT706P2M5S1",  
"CDT725SSF0SS",  
"CDT725SSF2SS",  
"CDT725SSF4SS",  
"CDT725SSF6SS",  
"CDT725SSF7SS",  
"CDT765SSF0SS",  
"CDT765SSF1SS",  
"CDT765SSF7SS",  
"CDT800P2N0S1",  
"CDT800P2N4S1",  
"CDT800P2N5S1",  
"CDT805M5N0S5",  
"CDT805M5N4S5",  
"CDT805P2N0S1"  
]  
,  
{
```

"part_name": "Vent Assembly (Also Order Item 6) WP8572611",

"part_number": "PS11746657",

"manufacturer": "Kenmore",

"price": "120.69",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WP8572611 replaces these: 8270151, 8531759, 8572611 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"66513132K700",

"66513132K701",

"66513133K700",

"66513133K701",

"66513139K700",

"66513139K701",

"66513152K700",

"66513152K701",

"66513152K702",

"66513153K700",

"66513153K701",

"66513153K702",

"66513154K700",

"66513154K701",

"66513154K702",

"66513159K700",
"66513159K701",
"66513159K702",
"66513163K700",
"66513163K701",
"66513163K702",
"66513163K703",
"66513169K700",
"66513169K701",
"66513169K702",
"66513169K703",
"66513173K700",
"66513173K701",
"66513173K702",
"66513173K703"

]

},

{

"part_name": "DEFLECTOR W10259618",

"part_number": "PS2367184",

"manufacturer": null,

"price": "37.87",

"description": "Deflectors are located in the lower front corners of the dishwasher tub. They allow water to be deflected away from the corners eliminating the “surging” effect of water behind the inner door.",

"rating": null,

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# W10259618 replaces these: AP4481270, 99003029 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"ADB3500AWB",

"ADB3500AWB0",

"ADB3500AWB1",

"ADB3500AWB36",

"ADB3500AWB41",

"ADB3500AWB44",

"ADB3500AWB45",

"ADB3500AWQ",

"ADB3500AWQ36",

"ADB3500AWS",

"ADB3500AWS0",

"ADB3500AWS1",

"ADB3500AWS36",

"ADB3500AWS41",

"ADB3500AWS44",

"ADB3500AWS45",

"ADB3500AWW",

"ADB3500AWW0",

"ADB3500AWW1",

"ADB3500AWW36",

"ADB3500AWW41",

"ADB3500AWW44",

"ADB3500AWW45",

"JDB1080AWB0",

"JDB1080AWB1",

"JDB1080AWS0",

"JDB1080AWS1",

"JDB1080AWW0",

"JDB1080AWW1",

"JDB1095AWB0"

]

},

{

"part_name": "Vent Assembly (Includes Item 6 WP3379674",

"part_number": "PS11741358",

"manufacturer": "Kenmore",

"price": "49.23",

"description": "",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# WP3379674 replaces these: 3379674 Back to Top",

"review_count": "2",

"appliance": "dishwasher",

"compatible_models": [

"110773811",

"110773812",

"110773813",

"110773881",
"110773882",
"110773883",
"65715755791",
"66513402K900",
"66513402K901",
"66513409K900",
"66513409K901",
"66513442K900",
"66513442K901",
"66513443K900",
"66513443K901",
"66513444K900",
"66513444K901",
"66513449K900",
"66513449K901",
"66513492K600",
"66513499K600",
"66513592K600",
"66513593K600",
"66513594K600",
"66513599K600",
"66513692K600",
"66513699K600",
"66515522000",
"66515524000",

```
"66515529000"
]
},
{
  "part_name": "DUCT A00060305",
  "part_number": "PS10065015",
  "manufacturer": null,
  "price": "140.74",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#
A00060305 replaces these: AP5955560, A00060301 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "905045720A",
    "FDSH4501AS0A",
    "FDSH4501AS1A",
    "FDSH4501AS2A",
    "FDSH4501AS3A",
    "FDSH450LAF0A",
    "FDSH450LAF1A",
    "FDSH450LAF2A",
    "FDSH450LAF3A",
    "FFID2459VS0A",
    "FFID2459VS1A",
```

```
"FFID2459VS2A",
"FFID2459VS3A",
"FGCD2456QB0A",
"FGCD2456QB0B",
"FGCD2456QB1B",
"FGCD2456QF0A",
"FGCD2456QF0B",
"FGCD2456QF1B",
"FGCD2456QF4B",
"FGCD2456QW0A",
"FGCD2456QW0B",
"FGCD2456QW1B",
"FGID2474QB0A",
"FGID2474QB0B",
"FGID2474QB1B",
"FGID2474QB3B",
"FGID2474QB4B",
"FGID2474QB5B",
"FGID2474QB6B"
]
},
{
  "part_name": "Door Vent - White WD12X10026",
  "part_number": "PS259045",
  "manufacturer": "Kenmore",
  "price": "17.08",
```

```
"description": "",
"rating": null,
"troubleshooting_tips": "This part works with the following products: Dishwasher. Part#
WD12X10026 replaces these: AP2039248, 824329, WD12X0328, WD12X328 Back to Top",
"review_count": null,
"appliance": "dishwasher",
"compatible_models": [
  "1200L02",
  "18385",
  "1858",
  "18585",
  "18885",
  "18985",
  "3000B10",
  "3000W10",
  "361402891",
  "3631401190",
  "3631401191",
  "3631401590",
  "3631401591",
  "3631401592",
  "3631401890",
  "3631401891",
  "3631401892",
  "3631402190",
  "3631402191",
```

```
"3631402192",
"3631402590",
"3631402591",
"3631402592",
"3631402890",
"3631402891",
"3631402892",
"36314031000",
"36314031001",
"36314032000",
"36314032001"
]
},
{
  "part_name": "Vent WPW10329609",
  "part_number": "PS11752990",
  "manufacturer": "Kenmore",
  "price": "68.40",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WPW10329609 replaces these: W10329609 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "66514502N020",
```

"66514503N020",
"66514509N020",
"7WDF530PAYM0",
"7WDF530PAYM1",
"7WDF530PAYM2",
"7WDF530PAYM3",
"7WDF530PAYM4",
"7WDF530PAYM5",
"7WDF530PAYM6",
"7WDF530PAYM7",
"ADB1400AMB0",
"ADB1400AMS0",
"ADB1400AMW0",
"IUD7070DS0",
"IUD7070DS1",
"IUD7070DS2",
"IUD7070DS3",
"MDB4709PAB0",
"MDB4709PAB1",
"MDB4709PAB2",
"MDB4709PAB3",
"MDB4709PAB4",
"MDB4709PAM0",
"MDB4709PAM1",
"MDB4709PAM2",
"MDB4709PAM3",


```
"MDB4709PAM4",
"MDB4709PAQ0",
"MDB4709PAQ1"
]
},
{
  "part_name": "Vent WPW10428211",
  "part_number": "PS11754644",
  "manufacturer": "Kenmore",
  "price": "106.39",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#
WPW10428211 replaces these: W10274928, W10329927, W10428211 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "2212413N414",
    "2213092N413",
    "2213099N413",
    "2213479N413",
    "66213032K112",
    "66213043K112",
    "66213273K112",
    "66512093K210",
    "66512413N410",
```

"66512413N411",
"66512413N412",
"66512413N413",
"66512723K310",
"66512723K311",
"66513032K110",
"66513032K111",
"66513032K112",
"66513032K113",
"66513032K114",
"66513032K115",
"66513032K116",
"66513033K110",
"66513033K111",
"66513033K112",
"66513033K113",
"66513033K114",
"66513033K115",
"66513033K116",
"66513039K110",
"66513039K111"

]

},

{

"part_name": "Vent WPW10469574",

"part_number": "PS11755274",

"manufacturer": "Kenmore",

"price": "75.68",

"description": "",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WPW10469574 replaces these: W10195024, W10195034, W10375833, W10462768, W10469574, WPW10469574VP Back to Top",

"review_count": "1",

"appliance": "dishwasher",

"compatible_models": [

"66512782K310",

"66512782K311",

"66512782K312",

"66512782K313",

"66512783K311",

"66512783K312",

"66512783K313",

"66512789K311",

"66512789K312",

"66512789K313",

"66512793K312",

"66512793K313",

"66512803K312",

"66512833K311",

"66512833K312",

"66513355N020",

"66513402N410",

"66513402N411",

"66513402N412",

"66513402N413",

"66513403N410",

"66513403N411",

"66513403N412",

"66513403N413",

"66513409N410",

"66513409N411",

"66513409N412",

"66513409N413",

"66513692N410",

"66513692N411"

]

},

{

"part_name": "Air Inlet WP8268937",

"part_number": "PS11745487",

"manufacturer": "Kenmore",

"price": "47.56",

"description": "This part is located at the bottom of the door. It helps to circulate air during the drying process.",

"rating": "70",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# WP8268937 replaces these: AP6012280, 8268937, 8269266 Back to Top",

"review_count": "2",

"appliance": "dishwasher",

"compatible_models": [

"665110739120",

"665110739130",

"665110739140",

"665110739190",

"66513212K901",

"66513212K902",

"66513213K900",

"66513213K901",

"66513213K902",

"66513219K901",

"66513219K902",

"66513242K900",

"66513242K901",

"66513243K900",

"66513243K901",

"66513249K900",

"66513249K901",

"66513752K600",

"66513752K601",

"66513752K602",

"66513752K603",

"66513753K600",

"66513753K601",

"66513753K602",

```
"66513753K603",
"66513754K600",
"66513754K601",
"66513754K602",
"66513754K603",
"66513759K600"
]
},
{
  "part_name": "Air Inlet WPW10077883",
  "part_number": "PS11748136",
  "manufacturer": "Kenmore",
  "price": "45.99",
  "description": "Also known as an air baffle.",
  "rating": null,
  "troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# WPW10077883 replaces these: AP6014866, W10077883 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "66513102K900",
    "66513102K901",
    "66513102K902",
    "66513103K900",
    "66513103K901",
    "66513103K902",
```

```
"66513104K900",  
"66513104K901",  
"66513104K902",  
"66513109K900",  
"66513109K901",  
"66513109K902",  
"66513112K700",  
"66513112K701",  
"66513112K702",  
"66513113K700",  
"66513113K701",  
"66513113K702",  
"66513114K700",  
"66513114K701",  
"66513114K702",  
"66513119K700",  
"66513119K701",  
"66513119K702",  
"66513122K700",  
"66513122K701",  
"66513122K702",  
"66513122K703",  
"66513123K700",  
"66513123K701"  
]  
},
```

```
{
  "part_name": "Timer WPW10199587",
  "part_number": "PS11750161",
  "manufacturer": null,
  "price": "278.92",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#
WPW10199587 replaces these: W10039480, W10199587 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "7DU850SWSQ0",
    "DU850SWPB3",
    "DU850SWPB4",
    "DU850SWPQ3",
    "DU850SWPQ4",
    "DU850SWPS3",
    "DU850SWPS4",
    "DU850SWPT3",
    "DU850SWPT4",
    "DU850SWPU3",
    "DU850SWPU4",
    "DU895SWPB0",
    "DU895SWPQ0",
    "DU895SWPS0",
```



```
"DU895SWPT0",
"DU895SWPU0",
"IPU25363",
"IPU25364",
"IUD6000RQ3",
"IUD6000RS3",
"IUD6000WQ0",
"IUD6000WQ1",
"IUD6000WS0",
"IUD6000WS1",
"MDB3601BWB0",
"MDB3601BWB1",
"MDB3601BWQ0",
"MDB3601BWQ1",
"MDB3601BWS0",
"MDB3601BWS1"
]
},
{
  "part_name": "TIMER 154858101",
  "part_number": "PS3633218",
  "manufacturer": "Kenmore",
  "price": "202.96",
  "description": "",
  "rating": null,
```

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 154858101 replaces these: 154794201 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"58714012406A",

"58714012407A",

"58714012408A",

"58714013407A",

"58714013408A",

"58714013409A",

"58714014406A",

"58714014407A",

"58714014408A",

"58714019406A",

"58714019407A",

"58714019408A",

"FBD2400KB2A",

"FBD2400KB3A",

"FBD2400KB4A",

"FBD2400KQ2A",

"FBD2400KQ3A",

"FBD2400KQ4A",

"FBD2400KS0A",

"FBD2400KS1A",

"FBD2400KS2A",

```
"FBD2400KW2A",
"FBD2400KW3A",
"FBD2400KW4A",
"TDB210RFB7A",
"TDB210RFS7A",
"WWBD2400HB1A",
"WWBD2400HB2A",
"WWBD2400HW1A",
"WWBD2400HW2A"
]
},
{
  "part_name": "Dishwasher Timer 807387501",
  "part_number": "PS8747114",
  "manufacturer": "Kenmore",
  "price": "197.17",
  "description": "Timer manages the various dishwasher functions such as filling,
washing, draining and drying.",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#
807387501 replaces these: AP5788729 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "58714012409B",
    "58714012410B",
    "58714012411B",
```

"58714012412B",
"58714012413B",
"58714012414B",
"58714012416B",
"58714013410B",
"58714013411B",
"58714013412B",
"58714013413B",
"58714013414B",
"58714013415B",
"58714013416B",
"58714013417B",
"58714014409B",
"58714014410B",
"58714014411B",
"58714014412B",
"58714014413B",
"58714019409B",
"58714019410B",
"58714019411B",
"58714019412B",
"58714019413B",
"58714019414B",
"58714019415B",
"58714019416B",
"FBD2400KB10B",

```
"FBD2400KB11B"
]
},
{
  "part_name": "Dishwasher Timer WD21X10475",
  "part_number": "PS6011663",
  "manufacturer": null,
  "price": "115.33",
  "description": "The timer manages the various dishwasher functions such as filling,
washing, draining and drying.",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#
WD21X10475 replaces these: AP5657127, WD21X10437 Back to Top",
  "review_count": "1",
  "appliance": "dishwasher",
  "compatible_models": [
    "GSC3500V00BB",
    "GSC3500V00WW",
    "GSD2300V00BB",
    "GSD2300V00WW",
    "GSD2300V35BB",
    "GSD2300V35WW",
    "GSD2301V00BB",
    "GSD2301V00WW",
    "GSD2301V35BB",
    "GSD2301V35WW",
    "GSD2340V00SA",
```

"GSD2340V35SA",
"GSD2350V00CS",
"GSD2350V35CS",
"GSD3300V00BB",
"GSD3300V00CC",
"GSD3300V00WW",
"GSD3360V00SS",
"GSM2200V00BB",
"GSM2200V00WW",
"GSM2200V45BB",
"GSM2200V45WW",
"GSM2200V50BB",
"GSM2200V50WW",
"GSM2200V55BB",
"GSM2200V55WW",
"GSM2200V65BB",
"GSM2200V65WW",
"GSM2200V70BB",
"GSM2200V70WW"

]

},

{

"part_name": "Timer WD21X10349",
"part_number": "PS1765982",
"manufacturer": null,
"price": "70.84",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WD21X10349 replaces these: AP4308805, 1472737, WD21X10263 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"GFSD234P00BB",

"GFSD234P00SB",

"GFSD234P00WW",

"GRSC345P00SB",

"GRSC345P00WW",

"GSC3500N00BB",

"GSC3500N00WW",

"GSC3500N10BB",

"GSC3500N10WW",

"GSC3500N15BB",

"GSC3500N15WW",

"GSD2204P00WW",

"GSD2300N00BB",

"GSD2300N00CC",

"GSD2300N00WW",

"GSD2300N10BB",

"GSD2300N10CC",

"GSD2300N10WW",

"GSD2301N00WW",

"GSD2301N10WW",

"GSD2400N00BB",

"GSD2400N00CC",

"GSD2400N00WW",

"GSD2400N10BB",

"GSD2400N10CC",

"GSD2400N10WW",

"GSD2700N00BB",

"GSD2700N00CC",

"GSD2700N00WW",

"GSD2700N10BB"

]

},

{

"part_name": "TRIM W10796651",

"part_number": "PS11703430",

"manufacturer": null,

"price": "85.59",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# W10796651 replaces these: W10642693 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"KDTM804EBS0",


```
"KDTM804EBS1",
"KDTM804EBS2",
"KDTM804ESS0",
"KDTM804ESS1",
"KDTM804ESS2"
]
},
{
  "part_name": "TRIM W10796650",
  "part_number": "PS11703429",
  "manufacturer": null,
  "price": "95.50",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#
W10796650 replaces these: W10642699 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "KDTM804EBS0",
    "KDTM804EBS1",
    "KDTM804EBS2",
    "KDTM804ESS0",
    "KDTM804ESS1",
    "KDTM804ESS2"
  ]
}
```

```
},  
{  
  "part_name": "TRIM TUB FLANGE BLACK WD08X10021",  
  "part_number": "PS258659",  
  "manufacturer": null,  
  "price": "8.06",  
  "description": "",  
  "rating": null,  
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#  
WD08X10021 replaces these: AP3669349, 943376, WD8X10021 Back to Top",  
  "review_count": null,  
  "appliance": "dishwasher",  
  "compatible_models": [  
    "EDW4000G00BB",  
    "EDW4000G02BB",  
    "EDW4000G03BB",  
    "EDW4000G10BB",  
    "EDW4060G00SS",  
    "EDW4060G02SS",  
    "EDW4060G03SS",  
    "EDW4060G10SS",  
    "GHD6711L15BB",  
    "GHD6711L15SS",  
    "GHD6711N00BB",  
    "GHD6711N00SS",  
    "GHD6711N10BB",
```

```
"GHD6711N10SS",
"GHD6711N20BB",
"GHD6711N20SS",
"GLD6500L00BB",
"GLD6500L15BB",
"GLD6560L00SS",
"GLD6560L15SS",
"GLD6611L15BB",
"GLD6611L15SS",
"GLD6611L18BB",
"GLD6611L18SS",
"GLD6611L20BB",
"GLD6611L20SS",
"GLD6611N10BB",
"GLD6611N10SS",
"GLD6800N00BB",
"GLD6800N10BB"
]
},
{
  "part_name": "Access Panel Retainer - Black WP3372412",
  "part_number": "PS11741311",
  "manufacturer": "Kenmore",
  "price": "38.71",
  "description": "",
  "rating": null,
```

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WP3372412 replaces these: 3369511, 3372412 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"66515641891",

"66515645891",

"66515685790",

"66515685791",

"6651571590",

"6651571591",

"6651571592",

"6651571593",

"66515725690",

"66515725691",

"66515725692",

"6651574991",

"6651574992",

"6651574993",

"66515765690",

"66515765691",

"66515765692",

"6651577990",

"6651581590",

"6651581591",

"6651581592",

```
"6651581593",
"66515822692",
"66515825690",
"66515825691",
"66515825692",
"6651584990",
"6651584991",
"6651584992",
"6651584993"
]
},
{
  "part_name": "TRIM DOOR Left Hand WD12X22541",
  "part_number": "PS11762938",
  "manufacturer": null,
  "price": "8.06",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Back  
to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "DDT575SGF2BB",
    "DDT575SGF2WW",
    "DDT575SGF4BB",
```

"DDT575SGF4WW",
"DDT575SGF5BB",
"DDT575SGF5WW",
"DDT575SGF6BB",
"DDT575SGF6WW",
"DDT575SGF7BB",
"DDT575SGF7WW",
"DDT575SGF8BB",
"DDT575SGF8WW",
"DDT575SMF2ES",
"DDT575SMF4ES",
"DDT575SMF5ES",
"DDT575SMF6ES",
"DDT575SMF7ES",
"DDT575SMF8ES",
"DDT575SSF2SS",
"DDT575SSF4SS",
"DDT575SSF5SS",
"DDT575SSF6SS",
"DDT575SSF7SS",
"DDT575SSF8SS",
"GDF540HGD4BB",
"GDF540HGD4WW",
"GDF540HGD6BB",
"GDF540HGD6WW",
"GDF540HMF0ES",

```
"GDF540HMF2ES"
]
},
{
  "part_name": "Lower Corner Edge Trim - Left Side WP99003038",
  "part_number": "PS11747742",
  "manufacturer": "Kenmore",
  "price": "7.60",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# WP99003038 replaces these: 99003038 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "110985000",
    "ADB3500AWB",
    "ADB3500AWB0",
    "ADB3500AWB1",
    "ADB3500AWB36",
    "ADB3500AWB41",
    "ADB3500AWB44",
    "ADB3500AWB45",
    "ADB3500AWQ",
    "ADB3500AWQ36",
    "ADB3500AWS",
```

```
"ADB3500AWS0",
"ADB3500AWS1",
"ADB3500AWS36",
"ADB3500AWS41",
"ADB3500AWS44",
"ADB3500AWS45",
"ADB3500AWW",
"ADB3500AWW0",
"ADB3500AWW1",
"ADB3500AWW36",
"ADB3500AWW41",
"ADB3500AWW44",
"ADB3500AWW45",
"JDB1060AWB",
"JDB1060AWQ",
"JDB1060AWS",
"JDB1060AWW",
"JDB1080AWB",
"JDB1080AWB0"
]
},
{
  "part_name": "Lower Corner Edge Trim - Right Side WP99003039",
  "part_number": "PS11747743",
  "manufacturer": null,
  "price": "7.60",
```


"description": "",

"rating": null,

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# WP99003039 replaces these: 99003039
Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"ADB3500AWB",

"ADB3500AWB0",

"ADB3500AWB1",

"ADB3500AWB36",

"ADB3500AWB41",

"ADB3500AWB44",

"ADB3500AWB45",

"ADB3500AWQ",

"ADB3500AWQ36",

"ADB3500AWS",

"ADB3500AWS0",

"ADB3500AWS1",

"ADB3500AWS36",

"ADB3500AWS41",

"ADB3500AWS44",

"ADB3500AWS45",

"ADB3500AWW",

"ADB3500AWW0",

"ADB3500AWW1",

"ADB3500AWW36",

"ADB3500AWW41",

"ADB3500AWW44",

"ADB3500AWW45",

"JDB1060AWB",

"JDB1060AWQ",

"JDB1060AWS",

"JDB1060AWW",

"JDB1080AWB",

"JDB1080AWB0",

"JDB1080AWB1"

]

},

{

"part_name": "Dishwasher Tub Trim, Lower WP99003041",

"part_number": "PS11747744",

"manufacturer": null,

"price": "67.07",

"description": "The tub trim forms an edge along the outer edge of the tub.",

"rating": null,

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# WP99003041 replaces these: AP6014504, 99003041 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"ADB3500AWB",

"ADB3500AWB0",
"ADB3500AWB1",
"ADB3500AWB36",
"ADB3500AWB41",
"ADB3500AWB44",
"ADB3500AWB45",
"ADB3500AWQ",
"ADB3500AWQ36",
"ADB3500AWS",
"ADB3500AWS0",
"ADB3500AWS1",
"ADB3500AWS36",
"ADB3500AWS41",
"ADB3500AWS44",
"ADB3500AWS45",
"ADB3500AWW",
"ADB3500AWW0",
"ADB3500AWW1",
"ADB3500AWW36",
"ADB3500AWW41",
"ADB3500AWW44",
"ADB3500AWW45",
"DB5710DT",
"JDB1060AWB",
"JDB1060AWQ",
"JDB1060AWS",

```
"JDB1060AWW",
"JDB1080AWB",
"JDB1080AWB0"
]
},
{
  "part_name": "STRIP 00749684",
  "part_number": "PS8747374",
  "manufacturer": "Kenmore",
  "price": "16.25",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#
00749684 replaces these: AP5788043, 00660316, 00660317, 660316, 660317, 749684
Back to Top",
  "review_count": "1",
  "appliance": "dishwasher",
  "compatible_models": [
    "63013903010",
    "63013903011",
    "63013909010",
    "63013909011",
    "63013909012",
    "63013913010",
    "63013913011",
    "63013919010",
    "63013919011",
```

```
"63013919012",
"63013953010",
"63013953011",
"63013959010",
"63013959011",
"63016303406",
"63016304406",
"63016309406",
"63077933010",
"63077933011",
"63077942011",
"63077943011",
"DF251760",
"DWHD410GFM",
"DWHD410GFM-53",
"DWHD410GPR",
"DWHD410GPR-53",
"DWHD410HFM",
"DWHD410HPR",
"DWHD410JFM",
"DWHD410JFP"
]
},
{
  "part_name": "TRIM GASKET WD08X10054",
  "part_number": "PS958905",
```

"manufacturer": null,

"price": "13.70",

"description": "",

"rating": "40",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# WD08X10054 replaces these: AP3794551, 1088471, WD08X10039 Back to Top",

"review_count": "1",

"appliance": "dishwasher",

"compatible_models": [

"CDW9380N00SS",

"CDW9380N20SS",

"CDWT280V00SS",

"CDWT280V05SS",

"CDWT280V50SS",

"CDWT980R10SS",

"CDWT980R30SS",

"CDWT980V00SS",

"CDWT980V05SS",

"CDWT980V50SS",

"GDWF100R10BB",

"GDWF100R10WW",

"GDWF100R30BB",

"GDWF100R30WW",

"GDWF100V40BB",

"GDWF100V40WW",

"GDWF100V50BB",

"GDWF100V50WW",
"GDWF100V55BB",
"GDWF100V55WW",
"GDWF100V70WW",
"GDWF106V00WW",
"GDWF150V40ES",
"GDWF150V50ES",
"GDWF150V55ES",
"GDWF160R10SS",
"GDWF160R30SS",
"GDWF160V00SS",
"GDWF160V10SS",
"GDWF160V40SS"

]

},

{

"part_name": "CONNECTOR W10876590",

"part_number": "PS11738154",

"manufacturer": "Kenmore",

"price": "10.71",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Washer, Washer
Dryer Combo, Dishwasher. Part# W10876590 replaces these: 352089 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"10682872600",

"11010202000",

"11010202001",

"1101050299",

"11010502990",

"11010502991",

"11010852990",

"11010852991",

"11012202100",

"11012502100",

"11012852100",

"11013202200",

"11013212200",

"11014102300",

"11014112300",

"11014202300",

"11014212200",

"11014222300",

"11014502300",

"11014852300",

"11015732400",

"11015842400",

"11015852400",

"11015862400",

"11015864400",


```
"11015942400",
"11015942401",
"11015944400",
"11015944401",
"11015952400"
]
},
{
  "part_name": "HARNS-WIRE W10871221",
  "part_number": "PS11738102",
  "manufacturer": null,
  "price": "163.82",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# W10871221 replaces these: W10434893, W10496097, W10537891, WPW10496097 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "KUDS30CXBL7",
    "KUDS30CXSS7",
    "KUDS30CXWH7",
    "KUDS30FBBL0",
    "KUDS30FBBL1",
    "KUDS30FBSS0",
    "KUDS30FBSS1",
```

```
"KUDS30FBWH0",  
"KUDS30FBWH1",  
"KUDS30FXBL5",  
"KUDS30FXBL8",  
"KUDS30FXBL9",  
"KUDS30FXBLA",  
"KUDS30FXPA4",  
"KUDS30FXPA8",  
"KUDS30FXPA9",  
"KUDS30FXPAA",  
"KUDS30FXSS5",  
"KUDS30FXSS8",  
"KUDS30FXSS9",  
"KUDS30FXSSA",  
"KUDS30FXWH5",  
"KUDS30FXWH8",  
"KUDS30FXWH9",  
"KUDS30FXWHA",  
"KUDS30IBBL0",  
"KUDS30IBBL1",  
"KUDS30IBBT0",  
"KUDS30IBBT1",  
"KUDS30IBSS0"  
]  
,  
{
```

"part_name": "Wiring Harness WPW10413098",

"part_number": "PS11754429",

"manufacturer": "Kenmore",

"price": "174.13",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WPW10413098 replaces these: W10078201, W10224469, W10341070, W10413098 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"66513212K902",

"66513219K901",

"GU3200TXB0",

"GU3200TXB1",

"GU3200TXB2",

"GU3200TXB3",

"GU3200TXB4",

"GU3200TXQ0",

"GU3200TXQ1",

"GU3200TXQ2",

"GU3200TXQ3",

"GU3200TXQ4",

"GU3200XTXY0",

"GU3200XTXY1",

"GU3200XTXY2",

"GU3200XTXY3",
"GU3200XTXY4",
"IUD9500WX0",
"IUD9500WX2",
"IUD9500WX3",
"IUD9500WX4",
"IUD9750WS0",
"IUD9750WS1",
"IUD9750WS2",
"IUD9750WS3",
"IUD9750WS4",
"KUDC03FTSS0",
"KUDC03FTSS2",
"KUDC03FVBL3",
"KUDC03FVBL4"

]

},

{

"part_name": "CONNECTOR W10783730",

"part_number": "PS11703328",

"manufacturer": "Kenmore",

"price": "22.84",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# W10783730 replaces these: W10369575, W10401190, W10756253 Back to Top",

```
"review_count": null,  
"appliance": "dishwasher",  
"compatible_models": [  
  "66213032K112",  
  "66213043K112",  
  "66213049K112",  
  "66213273K112",  
  "66213282K112",  
  "66213289K112",  
  "66512093K210",  
  "66512413N410",  
  "66512413N411",  
  "66512413N412",  
  "66512723K310",  
  "66512723K311",  
  "66513002N510",  
  "66513003N510",  
  "66513004N510",  
  "66513009N510",  
  "66513012K110",  
  "66513012K111",  
  "66513012K112",  
  "66513012K113",  
  "66513013K110",  
  "66513013K111",  
  "66513013K112",
```

```
"66513013K113",
"66513014K110",
"66513014K111",
"66513014K112",
"66513014K113",
"66513019K110",
"66513019K111"
]
},
{
  "part_name": "Ribbon Cable WP8524447",
  "part_number": "PS11746082",
  "manufacturer": "Kenmore",
  "price": "146.56",
  "description": "This part is used to connect the electronic control board and the touchpad control board.",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Will Not Start This part works with the following products: Dishwasher. Part# WP8524447 replaces these: AP6012865, 8524447 Back to Top",
  "review_count": "1",
  "appliance": "dishwasher",
  "compatible_models": [
    "66513173K705",
    "66513173K706",
    "66513192K901",
    "66513193K901",
```

"66513206K901",
"66513772K600",
"66513772K603",
"66513772K604",
"66513773K603",
"66513773K604",
"66513779K600",
"66513792K604",
"66513793K600",
"66513793K601",
"66513793K602",
"66513793K603",
"66513793K604",
"66513794K600",
"66513794K603",
"66513794K604",
"66513799K601",
"66516272400",
"66516272401",
"66516273400",
"66516273402",
"66516274400",
"66516274401",
"66516279400",
"66516279401",
"66516279402"

```
]
},
{
  "part_name": "CONNECTOR W10222056",
  "part_number": "PS2342343",
  "manufacturer": null,
  "price": "38.68",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "GU3100XTVB0",
    "GU3100XTVQ0",
    "GU3100XTVS0"
  ]
},
{
  "part_name": "Turbidity Sensor Wire Harness 154833101",
  "part_number": "PS3495367",
  "manufacturer": null,
  "price": "17.21",
  "description": "",
  "rating": null,
```


"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 154833101 replaces these: 154627001, 7154627001 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"EDW7505HPS0",

"EDW7505HPS0A",

"EDW7505HPS1B",

"EDW7505HSS0",

"EDW7505HSS0A",

"EDW7505HSS1B",

"EIDW5905JB0A",

"EIDW5905JS0A",

"EIDW5905JW0A",

"EIDW6105GB0",

"EIDW6105GB1",

"EIDW6105GB1A",

"EIDW6105GB2B",

"EIDW6105GS0",

"EIDW6105GS1",

"EIDW6105GS1A",

"EIDW6105GS2B",

"EIDW6105GW0",

"EIDW6105GW1",

"EIDW6105GW1A",

"EIDW6105GW2B",

```
"EIDW6305GB0",
"EIDW6305GB1",
"EIDW6305GB1A",
"EIDW6305GB2B",
"EIDW6305GS0",
"EIDW6305GS1",
"EIDW6305GS1A",
"EIDW6305GS2B",
"EIDW6305GW0"
]
},
{
  "part_name": "Dishwasher Wire Harness WPW10195666",
  "part_number": "PS11750079",
  "manufacturer": "Kenmore",
  "price": "13.54",
  "description": "This wire harness is for dishwashers and supplies power to electrical components in the dishwasher.",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WPW10195666 replaces these: W10195666 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "66513932K014",
    "66513932K015",
    "66513942K014",
```

"66513942K015",
"66513942K017",
"66513943K014",
"66513943K015",
"66513944K014",
"66513944K015",
"66513949K014",
"66513949K015",
"BLB14BRANA0",
"JDB8000AWB0",
"JDB8000AWC0",
"JDB8000AWS0",
"JDB8200AWP0",
"JDB8200AWS0",
"JDB8700AWP0",
"JDB8700AWS0",
"KUDC10FXBL5",
"KUDC10FXSS5",
"KUDC10FXWH5",
"KUDC10IXBL6",
"KUDC10IXBL7",
"KUDC10IXSS6",
"KUDC10IXSS7",
"KUDC10IXWH6",
"KUDC10IXWH7",
"KUDE20IXBL6",

```
"KUDE20IXBL8"
]
},
{
  "part_name": "Dishwasher Wire Harness W11028004",
  "part_number": "PS11770295",
  "manufacturer": "Kenmore",
  "price": "14.35",
  "description": "This wire harness is for dishwashers and supplies power to electrical components in the dishwasher.",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# W11028004 replaces these: W10566903 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "2212413N414",
    "2213092N413",
    "2213099N413",
    "2213222N414",
    "2213223N414",
    "2213229N414",
    "2213479N413",
    "66512413N410",
    "66512413N411",
    "66512413N412",
    "66512413N413",
```

"66513092N410",
"66513092N411",
"66513092N412",
"66513092N413",
"66513093N410",
"66513093N411",
"66513093N412",
"66513093N413",
"66513099N410",
"66513099N411",
"66513099N412",
"66513202N410",
"66513202N411",
"66513202N412",
"66513203N410",
"66513203N411",
"66513203N412",
"66513203N413",
"66513204N410"

]

},

{

"part_name": "TERMINAL BOX 00640476",
"part_number": "PS8729475",
"manufacturer": "Kenmore",
"price": "28.09",

"description": "",

"rating": null,

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start This part works with the following products: Dishwasher. Part# 00640476 replaces these: AP3962500, 640476 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"63013902010",

"63013902011",

"63013903010",

"63013903011",

"63013909010",

"63013909011",

"63013909012",

"63013912010",

"63013912011",

"63013913010",

"63013913011",

"63013919010",

"63013919011",

"63013919012",

"63013952010",

"63013952011",

"63013953010",

"63013953011",

"63013959010",

"63013959011",

"63016302403",

"63016302404",

"63016302405",

"63016302406",

"63016303403",

"63016303404",

"63016303405",

"63016303406",

"63016304401",

"63016304403"

]

},

{

"part_name": "DIY Dryer Manual 677818L",

"part_number": "PS993033",

"manufacturer": null,

"price": "40.30",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dryer, Washer, Refrigerator, Dishwasher. Part# 677818L replaces these: AP3873780, 677818, 677818L, 677819, LIT677818 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"110LGR5644EQ0",

"1CWED5200VQ0",
"1CWGD5300SQ0",
"1CWGD5700VW0",
"1CWGD5790SQ0",
"1CWGD5850SW0",
"3DWED5605SQ0",
"3HLER5437JQ0",
"3HLER5437JQ1",
"3HLER5437JQ2",
"3HLER5437JQ3",
"3LA5800XPW1",
"3LE5710XMW3",
"3LER5434BN1",
"3LER5434BQ1",
"3LER5434BW1",
"3LER5434DN0",
"3LER5434DN1",
"3LER5434DQ0",
"3LER5434DQ1",
"3LER5434DW0",
"3LER5434DW1",
"3LER5436EQ0",
"3LER5436EQ1",
"3LG5701XPW0",
"3LG5701XSW0",
"3LG5706XPW0",


```
"3LGR5436EQ0",
"3LGR5436EQ1",
"3RAED3005TQ0"
]
},
{
  "part_name": "BADGE GE Assembly WR04X10181",
  "part_number": "PS6447742",
  "manufacturer": null,
  "price": "10.58",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Refrigerator, Dishwasher, Water Heater, Range. Part# WR04X10181 replaces these: WB49X20204, WB49X20204X, WR04X10221 Back to Top",
  "review_count": "1",
  "appliance": "dishwasher",
  "compatible_models": [
    "CDT725SSF0SS",
    "CDT725SSF2SS",
    "CDT725SSF4SS",
    "CDT725SSF6SS",
    "CDT725SSF7SS",
    "CDT765SSF7SS",
    "CDT835SMJ0DS",
    "CDT835SMJ2DS",
    "CDT835SSJ0SS",
```

"CDT835SSJ2SS",
"CDT865SMJ0DS",
"CDT865SMJ2DS",
"CDT865SSJ0SS",
"CDT865SSJ2SS",
"CFE28TSHBSS",
"CFE28TSHCSS",
"CFE28TSHDSS",
"CFE28TSHESS",
"CFE28TSHFSS",
"CFE28TSHGSS",
"CFE28TSHISS",
"CFE28TSHJSS",
"CFE28TSHKSS",
"CFE28TSHLSS",
"CFE28TSHMSS",
"CFE28TSHNSS",
"CFE28TSHOSS",
"CFE28TSHPSS",
"CFE28UELBDs",
"CFE28UELCDS"

]

},

{

"part_name": "Nameplate - Black WPW10243392",

"part_number": "PS11750931",

"manufacturer": null,

"price": "46.22",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator, Dishwasher, Range, Ice Maker. Part# WPW10243392 replaces these: 8206515, W10046640, W10243392 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"K2TREFFWBL00",

"K2TREFFWMS00",

"K2TREFFWWH00",

"K9TREFFWBL00",

"K9TREFFWMS00",

"K9TREFFWWH00",

"KBFL25ETBL00",

"KBFL25ETBL01",

"KBFL25ETBL11",

"KBFL25ETSS00",

"KBFL25ETSS01",

"KBFL25ETSS11",

"KBFL25ETWH00",

"KBFL25ETWH01",

"KBFL25ETWH11",

"KBFS20ECBL00",

"KBFS20ECMS00",

"KBFS20ECWH00",
"KBFS20ETBL00",
"KBFS20ETBL01",
"KBFS20ETSS00",
"KBFS20ETSS01",
"KBFS20ETWH00",
"KBFS20ETWH01",
"KBFS20EVBL00",
"KBFS20EVBL1",
"KBFS20EVBL10",
"KBFS20EVBL2",
"KBFS20EVBL3",
"KBFS20EVBL4"

]

},

{

"part_name": "NAMEPLATE 241873301",

"part_number": "PS1991437",

"manufacturer": null,

"price": "6.00",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator, Freezer, Dishwasher, Wine and Beverage Cooler. Part# 241873301 replaces these: AP4393687, 154658705, 241873307, 316517500, 316517505, 5304463359, 5304467807, 5304483653, 5304494007, 5304494071, 7154658705, 7241873301, 7241873307, 75304467807 Back to Top",

```
"review_count": null,  
"appliance": "dishwasher",  
"compatible_models": [  
  "CEI30EF3JSA",  
  "CEI30EF3JSB",  
  "CEI30EF3JSC",  
  "CEI30IF4LSB",  
  "CEI30IF4LSC",  
  "E30MH65QPSA",  
  "EI15IM55GS0",  
  "EI23BC30KS1",  
  "EI23BC30KS2",  
  "EI23BC30KS3",  
  "EI23BC30KS4A",  
  "EI23BC30KS5A",  
  "EI23BC30KS7A",  
  "EI23BC30KS8A",  
  "EI23BC30KS9A",  
  "EI23BC32SS0",  
  "EI23BC32SS1",  
  "EI23BC32SS2",  
  "EI23BC32SS3",  
  "EI23BC32SS4",  
  "EI23BC35KS3",  
  "EI23BC35KS4",  
  "EI23BC35KS5",
```

"EI23BC35KS6",

"EI23BC35KS7",

"EI23BC35KS8",

"EI23BC35KS8A",

"EI23BC35KS9A",

"EI23BC35KSAA",

"EI23BC35KSBA"

]

},

{

"part_name": "Nameplate - Stainless Steel WPW10243391",

"part_number": "PS11750930",

"manufacturer": null,

"price": "43.20",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dishwasher, Refrigerator, Range, Wall Oven. Part# WPW10243391 replaces these: W10243391 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"5KRFX9000M00",

"7KSC24C8EY00",

"7KSF26C6YY00",

"KBFS20ECBL00",

"KBFS20ECMS00",

"KBFS20ECWH00",
"KBFS20EVMS11",
"KBFS20EVMS13",
"KBFS20EVMS5",
"KBFS20EVMS6",
"KBFS20EVMS7",
"KBFS20EVMS8",
"KBFS20EVMS9",
"KBFS22ECBL00",
"KBFS22ECMS00",
"KBFS22ECWH00",
"KBFS22EWMS3",
"KBFS22EWMS4",
"KBFS22EWMS5",
"KBFS22EWMS7",
"KBFS22EWMS9",
"KBFS25ECBL00",
"KBFS25ECMS00",
"KBFS25ECWH00",
"KBFS25EWBL2",
"KBFS25EWBL3",
"KBFS25EWBL4",
"KBFS25EWMS10",
"KBFS25EWMS2",
"KBFS25EWMS3"

]

```
},
```

```
{
```

```
"part_name": "RACK SLIDE END CAP WD12X10304",
```

```
"part_number": "PS2370502",
```

```
"manufacturer": "Kenmore",
```

```
"price": "12.61",
```

```
"description": "The Rack Slide End Cap is a white one-inch plastic part which replaces the end cap for your dishwasher rack, preventing your rack from sliding too far. If you find the dish rack is causing the door to not close properly, it may be due to the part being worn out or damaged. All you need to complete this repair is a small flat blade screw driver. Simply pop out the cap with a smaller flat-blade screwdriver and snap the new one into place. If the rear cap needs to be replaced you will need to remove both front caps and slide the rack completely off for full access. It is important to note that this part is sold individually, and more than one may be required, depending on your repair. An inexpensive part, it can be a good idea to purchase several at a time to have on-hand when needed.",
```

```
"rating": "94",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Door won't close | Door latch failure This part works with the following products: Dishwasher. Part# WD12X10304 replaces these: AP4484666, 1556527, WD12X0344, WD12X10238, WD12X344, WD30X93, WD30X97 Back to Top",
```

```
"review_count": "52",
```

```
"appliance": "dishwasher",
```

```
"compatible_models": [
```

```
"1200L02",
```

```
"18385",
```

```
"1858",
```

```
"3000B10",
```

```
"3000W10",
```

```
"361402891",
```



```
"3631401190",  
"3631401191",  
"3631401590",  
"3631401591",  
"3631401592",  
"3631401890",  
"3631401891",  
"3631401892",  
"3631402190",  
"3631402191",  
"3631402192",  
"3631402590",  
"3631402591",  
"3631402592",  
"3631402890",  
"3631402891",  
"3631402892",  
"36314031000",  
"36314031001",  
"36314032000",  
"36314032001",  
"36314038000",  
"36314038001",  
"36314039000"  
]  
},
```

```
{  
  "part_name": "Dishwasher Dish Rack Slide Track - Left Side W11259785",  
  "part_number": "PS12584376",  
  "manufacturer": null,  
  "price": "84.18",  
  "description": "This is the dishrack slide track for the left side of various dishwashers. This track allows your upper dishrack to be supported and slide in and out of the dishwasher to place or remove dishes from the dishrack as necessary. If your left dishrack is currently broken or damaged, it needs to be replaced for your dishrack to be completely supported. Replacing this dishrack slide requires some disassembly of your dishwasher and will require a screwdriver to pull your dishwasher out from underneath your countertop, and remove the securing bolts from the slide track. This OEM dishrack slide track is sold individually and does not include the slide track for the right side of your dishwasher.",  
  "rating": "97",  
  "troubleshooting_tips": "This part fixes the following symptoms: Door won't close | Door latch failure | Noisy This part works with the following products: Dishwasher. Part# W11259785 replaces these: AP6783992, W10311157, W10462359, W10752595, W10781301, W10811586, W10852728, W10914015, W10915185, W11048934, W11192640 Back to Top",  
  "review_count": "34",  
  "appliance": "dishwasher",  
  "compatible_models": [  
    "2214715N710",  
    "66512782K310",  
    "66512782K312",  
    "66512782K313",  
    "66512783K311",  
    "66512783K312",  
    "66512783K313",  
  ]  
}
```

```
"66512789K311",  
"66512789K312",  
"66512789K313",  
"66512793K312",  
"66512793K313",  
"66512803K312",  
"66512833K311",  
"66512833K312",  
"66514712N710",  
"66514713N710",  
"BLB14BRANA0",  
"BLB14DRANA0",  
"BLB14DRANA1",  
"BLB14DRANA2",  
"BLB14DRANA4",  
"BLB14DRANA5",  
"BLB14FRANA0",  
"GLB14BBANA0",  
"GLB14BBANA1",  
"IDT930SAGX0",  
"JDB8200AWP0",  
"JDB8200AWP1",  
"JDB8200AWP2"  
]  
,  
{
```

"part_name": "Dishwasher Dish Rack Slide Track - Right Side W11259786",

"part_number": "PS12584377",

"manufacturer": null,

"price": "71.74",

"description": "This dish rack slide rail is a genuine OEM replacement part that is compatible with various models of dishwasher. It is designed to fit on the right side of the dishwasher. The slide rail or track supports the upper dish rack and allows it to slide in and out of the dishwasher smoothly so that you can easily load and unload your dishes. It is made of stainless steel and can be found mounted to the side of the interior cavity of the dishwasher. If your dish rack is unstable and difficult to pull in and out, you will likely need to replace the slide rail. Mounting hardware is sold separately.",

"rating": "96",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't close | Door latch failure This part works with the following products: Dishwasher. Part# W11259786 replaces these: W10311156, W10462358, W10752596, W10781305, W10811587, W10852729, W10914016, W10915186, W11048936, W11192638 Back to Top",

"review_count": "44",

"appliance": "dishwasher",

"compatible_models": [

"2214715N710",

"66512782K310",

"66512782K312",

"66512782K313",

"66512783K311",

"66512783K312",

"66512783K313",

"66512789K311",

"66512789K312",

"66512789K313",

```
"66512793K312",
"66512793K313",
"66512803K312",
"66512833K311",
"66512833K312",
"66514712N710",
"66514713N710",
"BLB14BRANA0",
"BLB14DRANA0",
"BLB14DRANA1",
"BLB14DRANA2",
"BLB14DRANA4",
"BLB14DRANA5",
"BLB14FRANA0",
"GLB14BBANA0",
"GLB14BBANA1",
"IDT930SAGX0",
"JDB8200AWP0",
"JDB8200AWP1",
"JDB8200AWP2"
]
},
{
  "part_name": "Dishwasher Positioner WPW10195840",
  "part_number": "PS11750093",
  "manufacturer": "Kenmore",
```

"price": "38.21",

"description": "Also known as rack adjuster. Sold individually. \r\nThis is an original part from KitchenAid, Kenmore, Whirlpool, Jenn-Air, and Maytag for use with Dishwashers. The dishrack adjuster arm positioner clip holds the adjuster arm in the right position on the dishrack. The most common reason for replacing the strap is if the rack will not stay in its desired position. This part is sold individually. There are no tools needed to replace the positioner.",

"rating": "60",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't close | Not cleaning dishes properly | Door latch failure This part works with the following products: Dishwasher. Part# WPW10195840 replaces these: AP6016800, W10195840, W10418323
Back to Top",

"review_count": "6",

"appliance": "dishwasher",

"compatible_models": [

"2213222N414",

"2213223N414",

"2213229N414",

"2214523N611",

"2214545N711",

"2214715N710",

"2214792N512",

"2214793N512",

"66213293K112",

"66512762K312",

"66512763K312",

"66512763K313",

"66512769K312",

```
"66512769K313",  
"66512772K312",  
"66512772K313",  
"66512772K314",  
"66512773K313",  
"66512773K314",  
"66512774K312",  
"66512774K313",  
"66512776K312",  
"66512776K314",  
"66512779K312",  
"66512779K313",  
"66512779K314",  
"66512782K310",  
"66512782K312",  
"66512782K313",  
"66512783K311"  
]  
,  
{  
  "part_name": "Tine Pivot WPW10082853",  
  "part_number": "PS11748190",  
  "manufacturer": "Kenmore",  
  "price": "10.67",
```

"description": "The tine pivot clip, also known as the tine row pivot, is used in dishwashers and is located in the upper dishrack. At around 3 inches in length, the clip is used to keep the tine row in place in the dishrack. If your clip is cracked or damaged, it is

best to replace this part. To repair, first lift the release tab and hold the other side to prevent it from falling off. After lifting it off, you can set the new clip on the tine row and lock it up. Refer to the manual provided by the manufacturer for further installation instructions and guidance. Remember to wear work gloves as a safety precaution. This repair was rated as very easy by our customers and should be done in 15 minutes or less.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher. Part# WPW10082853 replaces these: AP6014920, W10082853, WPW10082853VP Back to Top",

"review_count": "28",

"appliance": "dishwasher",

"compatible_models": [

"2214715N710",

"2214792N512",

"2214793N512",

"66512762K312",

"66512763K312",

"66512763K313",

"66512769K312",

"66512769K313",

"66512772K312",

"66512772K313",

"66512772K314",

"66512773K313",

"66512773K314",

"66512774K313",

"66512776K312",

"66512776K314",


```
"66512779K312",
"66512779K313",
"66512779K314",
"66512782K310",
"66512782K312",
"66512782K313",
"66512783K311",
"66512783K312",
"66512783K313",
"66512789K311",
"66512789K312",
"66512789K313",
"66512793K312",
"66512793K313"
]
},
{
  "part_name": "Rack Stop Clip WPW10195622",
  "part_number": "PS11750071",
  "manufacturer": "Kenmore",
  "price": "8.10",
```

"description": "This manufacturer-approved Rack Stop Clip is a gray plastic part which can be installed with a screwdriver. Measuring slightly over an inch in length, it prevents the rack from sliding too far and falling off. If broken or damaged, then the rack will slide too far and this is a sign the part should be replaced. It attaches to the end of the top dishwasher rack. This clip can be used for the left or right side, and is sold individually. It is a good idea to replace both sides at once. To make this repair, start by pulling out the rack, then, using your screwdriver, reach in behind the rack stops and press the clips in. You should be able

to remove the stops from the track from here. Next, you should be able to slide the track back over the rollers and snap the new track stop into place.",

"rating": "92",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't close | Door latch failure | Not cleaning dishes properly This part works with the following products: Dishwasher. Part# WPW10195622 replaces these: AP6016778, W10195622, WPW10195622VP Back to Top",

"review_count": "80",

"appliance": "dishwasher",

"compatible_models": [

"66213293K112",

"66513042K110",

"66513042K111",

"66513042K112",

"66513042K113",

"66513042K114",

"66513042K115",

"66513042K116",

"66513043K110",

"66513043K111",

"66513043K112",

"66513043K113",

"66513043K114",

"66513043K115",

"66513043K116",

"66513044K110",

"66513044K111",

```
"66513044K112",
"66513044K113",
"66513044K114",
"66513044K115",
"66513044K116",
"66513049K110",
"66513049K111",
"66513049K112",
"66513049K113",
"66513049K114",
"66513049K115",
"66513049K116",
"66513252K110"
]
},
{
  "part_name": "Dishwasher Upper Rack Adjuster WPW10546503",
  "part_number": "PS11756150",
  "manufacturer": null,
  "price": "43.81",
```

"description": "This OEM Dishwasher Upper Rack Adjuster is a grayish-black, plastic part which will require a screwdriver to install. It fits onto the dishwasher rack and connects it to the track allowing it to slide in and out. If broken then the rack will no longer slide properly, and the part must be replaced. The installation has been rated as \"easy\" by customers. Before beginning any repair, you should unplug the dishwasher and wear gloves to protect your hands. Check your model number and user manual to see if this part is right for you! Your dishwasher should have a left and right upper rack adjuster, and both are the

same part. These parts are sold individually, so if you are looking to replace both, you will need to order two parts.",

"rating": "95",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't close | Door latch failure | Not cleaning dishes properly | Leaking This part works with the following products: Dishwasher. Part# WPW10546503 replaces these: AP6022813, W10306646, W10418314, W10546502, W10546503, W10911100, WPW10546503VP Back to Top",

"review_count": "121",

"appliance": "dishwasher",

"compatible_models": [

"2214715N710",

"2214792N512",

"2214793N512",

"66512782K310",

"66512782K312",

"66512782K313",

"66512783K311",

"66512783K312",

"66512783K313",

"66512789K311",

"66512789K312",

"66512789K313",

"66514712N710",

"66514713N710",

"66514763N510",

"66514769N510",

"66514792N510",

```
"66514792N512",  
"66514793N510",  
"66514793N511",  
"66514793N512",  
"66514799N510",  
"66514799N511",  
"66514812N611",  
"66514812N612",  
"66514813N610",  
"66514813N611",  
"66514815N612",  
"66514815N613",  
"66514819N610"  
]  
,  
{  
  "part_name": "Rack Track Stop WP8565925",  
  "part_number": "PS11746591",  
  "manufacturer": "Kenmore",  
  "price": "7.70",
```

"description": "The rack track stop on your dishwasher is designed to stop the dish rack at the appropriate place when opening and closing the rack. If your dishwasher is not cleaning your dishes properly, the rack stop may need to be replaced. The replacement part may differ slightly from the broken part, depending on the model. However, the different styles are interchangeable. This product is sold individually and comes in both a white and grey plastic version. Many of our customers found this repair to be very easy and takes less than 30 minutes to complete. Simply snap the old part out and snap the new

part into place. You will not require any tools to complete the job. This is an authentic part approved by the manufacturer.",

"rating": "92",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Not cleaning dishes properly | Door won't close This part works with the following products: Dishwasher. Part# WP8565925 replaces these: AP6013365, 8270105, 8270106, 8524581, 8524582, 8562015, 8565920, 8565925, W10082860, W10082861, W10199682, W10508950, WP8565925VP, WPW10082861, WPW10082861VP, WPW10508950, WPW10508950VP Back to Top",

"review_count": "118",

"appliance": "dishwasher",

"compatible_models": [

"110723120",

"2212413N414",

"2213092N413",

"2213099N413",

"2213222N414",

"2213223N414",

"2213229N414",

"2213479N413",

"2213802N710",

"2213804N710",

"2213809N710",

"2214523N611",

"2214545N711",

"2217383N710",

"2217389N710",

"66213032K112",

"665110739120",

"665110739130",

"665110739140",

"665110739190",

"66512093K210",

"66512413N410",

"66512413N411",

"66512413N412",

"66512413N413",

"66512723K310",

"66512723K311",

"66512762K312",

"66512763K312",

"66512763K313"

]

},

{

"part_name": "RACK ASSEMBLY UPPER 5304535251",

"part_number": "PS17219604",

"manufacturer": "Kenmore",

"price": "125.80",

"description": "The upper dishrack is used to hold your dishes in place while the dishwasher goes through the wash cycles. Over time the dishrack can become damaged, start to rust, or be missing rollers, and the dishrack will need to be replaced. This rack is white in color with light gray rollers and measures approximately 23 Inch x 23 Inch. This is a genuine OEM part.",

"rating": "99",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher. Part# 5304535251 replaces these: 154207603, 154207604, 154207705, 154207706, 154207707, 154308204, 154308205, 154319404, 154319505, 154319506, 154319510, 154319518, 154319519, 154319521, 154319524, 154321101, 154321102, 154321103, 154321104, 154321105 ... Show more , 154321106, 154321107, 154321112, 154321113, 154321201, 154425701, 154426102, 154586201, 154866505, 154866506, 5304498208, 5304498211, 5304498212, 5304505698, 808602002 Show less Back to Top",

"review_count": "22",

"appliance": "dishwasher",

"compatible_models": [

"58714022200A",

"58714023200A",

"58714024200A",

"58714028200A",

"58714029200A",

"58714102800",

"58714112400",

"58714112401",

"58714112402",

"58714113400",

"58714113401",

"58714113402",

"58714114400",

"58714114401",

"58714114402",

"58714119400",

"58714119401",


```
"58714119402",  
"58714131100",  
"58714131101",  
"58714131102",  
"58714132100",  
"58714132101",  
"58714132102",  
"58714134100",  
"58714134101",  
"58714134102",  
"58714139100",  
"58714139101",  
"58714139102"  
]
```

```
},
```

```
{
```

```
"part_name": "RACK ASSEMBLY,LOWER,GREY 5304535768",
```

```
"part_number": "PS17219739",
```

```
"manufacturer": "Kenmore",
```

```
"price": "232.22",
```

```
"description": "This grey lower dish rack assembly comes with eight light-gray rollers for  
easy access. The dish rack is approximately 21 inches wide x 22 inches deep. The dish rack  
holds dishes in place during the dishwashing cycle. If you see rust spots on the dishes, the  
lower rack will not pull out, or the lower rack is visibly rusted or damaged, you will need to  
replace the part. Other common symptoms include: unusual or loud noises coming from  
the unit, or the dishes on the lower rack not being washed properly.",
```

```
"rating": "96",
```

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher. Part# 5304535768 replaces these: 154207803, 154207804, 154207905, 154207906, 154207907, 154224902, 154308304, 154308305, 154308306, 154319604, 154319706, 154319708, 154320901, 154320902, 154320903, 154320904, 154320905, 154320906, 154321001, 154321002 ... Show more , 154425502, 154432601, 154432602, 154432603, 154866702, 5304520633, 5304535252, 808602302, 808602303 Show less Back to Top",

"review_count": "82",

"appliance": "dishwasher",

"compatible_models": [

"58714022200A",

"58714023200A",

"58714024200A",

"58714028200A",

"58714029200A",

"58714102800",

"58714112400",

"58714112401",

"58714112402",

"58714113400",

"58714113401",

"58714113402",

"58714114400",

"58714114401",

"58714114402",

"58714119400",

"58714119401",

"58714119402",

"58714131100",

"58714131101",

"58714131102",

"58714132100",

"58714132101",

"58714132102",

"58714134100",

"58714134101",

"58714134102",

"58714139100",

"58714139101",

"58714139102"

]

},

{

"part_name": "WHEEL&BUSHING ASY, UPPER,BLACK 5304535381",

"part_number": "PS17219660",

"manufacturer": "Kenmore",

"price": "4.99",

"description": "The upper dishrack roller and axel kit comes with two pieces, a wheel and an axle. This kit is made for your dishwasher. Both pieces measure to be roughly one square inch each, they are made entirely of plastic, and are white in color. The purpose of these parts is to allow your dishrack to roll easily on the support rails. This kit is sold individually and contains only one wheel and one axle. Please order the required quantity for your repair. If your dishrack is having trouble rolling in and out you may need replace your rollers and axles.",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 5304535381 replaces these: 154494502, 5300809974, 5303269771, 5303286384, 5304523190, 5304534832 Back to Top",

"review_count": "2",

"appliance": "dishwasher",

"compatible_models": [

"1031-005A",

"1041-002A",

"1071-003A",

"1081-000A",

"58714001990",

"58714002990",

"58714242100",

"58714249990",

"58714249991",

"5871429990",

"5871434969",

"5871501190",

"5871504190",

"5871511590",

"58715202802",

"58715202803A",

"58715203802",

"58715203803A",

"58715313000A",

"58715382100A",

"58715382100B",

"58715383100A",

"58715383100B",

"58715389100A",

"58715389100B",

"58715392100A",

"58715393100A",

"58715399100A",

"5871541590",

"5871541591"

]

},

{

"part_name": "WHEEL & BUSHING ASS 5304532229",

"part_number": "PS16745479",

"manufacturer": "Kenmore",

"price": "6.88",

"description": "The single rack roller kit comes with one axle/clip and one wheel/roller. The rack wheel is designed to allow the rack of your dishwasher to roll in and out. If the rack will not complete this task, or you notice that your dishwasher is not cleaning dishes properly, you may need to replace the rack wheel. The single rack roller kit is made of white plastic, and clips to the dishwasher rack with the included axle/clip. Many of our customers have described this repair as easy, and you will not require any tools to complete it.
\nLower rack roller and bracket assembly, grey. Wheel has been updated. If wheel pictured is not like old one, you may need to replace all wheels.",

"rating": "90",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher. Part# 5304532229 replaces these: 154174501, 154174502, 154174503, 154294801, 3202777, 5304521179
Back to Top",

```
"review_count": "6",  
"appliance": "dishwasher",  
"compatible_models": [  
  "004621710A",  
  "004621711A",  
  "58714000100",  
  "58714000101",  
  "58714000102",  
  "58714001990",  
  "58714001991",  
  "58714001992",  
  "58714001993",  
  "58714002990",  
  "58714002991",  
  "58714002992",  
  "58714002993",  
  "58714003100",  
  "58714008001",  
  "58714008002",  
  "58714008003",  
  "58714009100",  
  "58714009101",  
  "58714009102",  
  "58714012400",  
  "58714012401",  
  "58714012402",
```

"58714012403",
"58714012404",
"58714012405",
"58714012406A",
"58714012409B",
"58714012410B",
"58714012411B"

]

},

{

"part_name": "SPRAY ARM 00745856",

"part_number": "PS8737036",

"manufacturer": null,

"price": "24.85",

"description": "This OEM upper spray arm is sourced directly from the manufacturer for use in various models of dishwasher. It is responsible for spraying water onto the dishes that are placed in the top rack. It is located beneath the top rack and consists of several small openings or nozzles through which water is propelled with high pressure. When the dishwasher is in running, water is pumped through the spray arm, and the force of the water causes it to rotate, ensuring that water is distributed evenly across the dishes for effective cleaning. If the arm become damaged or clogged with debris, you may notice difficulties cleaning your dishes properly, rattling or scraping sounds and reduced overall efficiency.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Door won't close This part works with the following products: Dishwasher. Part# 00745856 replaces these: AP5691325, 745856 Back to Top",

"review_count": "9",

"appliance": "dishwasher",

"compatible_models": [

"DWHD440MFP",

"SHE53T52UC",

"SHE53T55UC",

"SHE53T56UC",

"SHE53TF2UC",

"SHE53TF5UC",

"SHE53TF6UC",

"SHE53TL2UC",

"SHE65T52UC",

"SHE65T55UC",

"SHE65T56UC",

"SHE68T52UC",

"SHE68T55UC",

"SHE68T56UC",

"SHE68TL5UC",

"SHE7PT52UC",

"SHE7PT55UC",

"SHE7PT56UC",

"SHE863WF2N",

"SHE863WF5N",

"SHE863WF6N",

"SHE878WD2N",

"SHE878WD5N",

"SHE878WD6N",

"SHE89PW55N",


```
"SHE8PT55UC",  
"SHEM63W52N",  
"SHEM63W55N",  
"SHEM63W56N",  
"SHEM78W52N"  
]  
},  
{  
  "part_name": "VALVE ACCESS 10023852",  
  "part_number": "PS16746057",  
  "manufacturer": null,  
  "price": "24.00",
```

"description": "This water access valve, also known as a water inlet valve, is an authentic OEM replacement part used in dishwashers. The valve controls the flow of water into the dishwasher. It is responsible for allowing water from the household water supply to enter the dishwasher tub during the wash cycle. The valve is controlled by the electronic control board, which signals it to open or close based on the selected cycle and water level requirements. Once the dishwasher is filled to the appropriate level, the water inlet valve closes to prevent any further water from entering the tub. If the valve is faulty, you will likely experience water leakages, difficulties filling dishwasher, and poor cleaning results. This part is commonly associated with the E15 error code on dishwashers.",

```
"rating": "100",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Will not fill  
with water | Will Not Start This part works with the following products: Dishwasher. Part#  
10023852 replaces these: 00628334, 628334 Back to Top",
```

```
"review_count": "7",
```

```
"appliance": "dishwasher",
```

```
"compatible_models": [  
  "DWHD440MFP",
```

"SHE53T52UC",
"SHE53T55UC",
"SHE53T56UC",
"SHE53TF2UC",
"SHE53TF5UC",
"SHE53TF6UC",
"SHE53TL2UC",
"SHE65T52UC",
"SHE65T55UC",
"SHE65T56UC",
"SHE68T52UC",
"SHE68T55UC",
"SHE68T56UC",
"SHE68TL5UC",
"SHE7PT52UC",
"SHE7PT55UC",
"SHE7PT56UC",
"SHE863WF2N",
"SHE863WF5N",
"SHE863WF6N",
"SHE878WD2N",
"SHE878WD5N",
"SHE878WD6N",
"SHE89PW55N",
"SHE8PT55UC",
"SHEM63W52N",

```
"SHEM63W55N",
"SHEM63W56N",
"SHEM78W52N"
]
},
{
  "part_name": "Lower Dishrack 20000533",
  "part_number": "PS12730058",
  "manufacturer": null,
  "price": "109.10",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 20000533 replaces these: AP6894232, 00689429, 00689997, 00770024, 00770085, 00770689, 00770730, 00775315, 00775824, 00775826, 20000532, 689429, 689997, 770024, 770085, 770689, 770730, 775315, 775824, 775826 Back to Top",
  "review_count": "6",
  "appliance": "dishwasher",
  "compatible_models": [
    "DWHD440MFP",
    "SHE53T52UC",
    "SHE53T55UC",
    "SHE53T56UC",
    "SHE53TF2UC",
    "SHE53TF5UC",
    "SHE53TF6UC",
    "SHE53TL2UC",
```

"SHE65T52UC",

"SHE65T55UC",

"SHE65T56UC",

"SHE68T52UC",

"SHE68T55UC",

"SHE68T56UC",

"SHE68TL5UC",

"SHE7PT52UC",

"SHE7PT55UC",

"SHE7PT56UC",

"SHE863WF2N",

"SHE863WF5N",

"SHE863WF6N",

"SHE878WD2N",

"SHE878WD5N",

"SHE878WD6N",

"SHE8PT55UC",

"SHEM63W52N",

"SHEM63W55N",

"SHEM63W56N",

"SHEM78W52N",

"SHEM78W55N"

]

},

{

"part_name": "Door Gasket - Black 3920DD3005A",

"part_number": "PS3522654",

"manufacturer": "LG",

"price": "53.46",

"description": "This is a door gasket for a dishwasher. It creates a watertight seal between the dishwasher door and tub to prevent leaking while the appliance is in use. The gasket is approximately 76 inches long and is black in color. The gasket could become dry and brittle over time which can cause a leak, forcing you to replace it. After removing the old door gasket, clean the empty crevice to ensure a proper seal when you install the replacement gasket. To install the replacement gasket after cleaning the area, simply push the new part into place around the door.",

"rating": "96",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# 3920DD3005A replaces these: AP4437203, 3920DD3003A, 3920DD3005A, 3920DD3005B Back to Top",

"review_count": "10",

"appliance": "dishwasher",

"compatible_models": [

"14693",

"14697",

"72214697610",

"D1401TB",

"D1401TB1",

"D1412TB",

"D1414TB",

"D1425TB",

"D1426DB1",

"D1426TB",

"D1426TB1",

```
"D1435BB",
"D1435TB",
"D1435WB",
"D1436TB",
"D1438DB",
"D1438TB",
"D1454CFN",
"D1470BB",
"D1470TB",
"D1470TBR",
"D1470WB",
"D1471BB",
"D1471BB1",
"D1471DB1",
"D1471DBK",
"D1471TB",
"D1471TB1",
"D1471TBK",
"D1471WB"
]
},
{
  "part_name": "Roller with Axle 4581DD3002A",
  "part_number": "PS3523050",
  "manufacturer": "LG",
  "price": "11.75",
```

"description": "The rack roller and axle in your dishwasher allows the dish rack to slide in and out effectively.If you notice that your dish rack is not performing this function, or if one or more of your rack rollers are damaged, you should consider replacing it. The roller attaches to the dish rack with the axle, both are included in this part. This part is gray in color, and measures 1 inch in diameter. With the axle, this part is approximately 1-1/2 inches wide. To access the rack roller and axle, you will need to remove the top dish rack from your dishwasher.",

"rating": "64",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 4581DD3002A replaces these: AP4437685, 1266813, 4581DD3002A, 4581DD3002A, 4581DD9001A, 4581DD9001B Back to Top",

"review_count": "10",

"appliance": "dishwasher",

"compatible_models": [

"14693",

"14697",

"39232533",

"72214697610",

"D1425TB",

"D1426DB1",

"D1426TB",

"D1426TB1",

"D1436TB",

"D1438DB",

"D1438TB",

"D1454CFN",

"D1470TBR",

"D1471BB1",

"D1471DB1",
"D1471DBK",
"D1471TB1",
"D1471TBK",
"D1471WB1",
"D1472TB",
"D1475TUR1",
"D15ASTUL",
"D1607BB",
"D1607TB",
"D1607WB",
"D1608BB",
"D1608TB",
"D1608WB",
"LD-6090BB",
"LD-6090BB1"

]

},

{

"part_name": "NOZZLE ASSEMBLY AGB73093001",

"part_number": "PS7788355",

"manufacturer": "LG",

"price": "41.76",

"description": "This nozzle assembly, commonly referred to as a sprayer head or spray arm, is an authentic replacement part supplied directly by LG for use in LG dishwashers. The nozzle assembly can be found at the bottom of the dishwasher tub. It is responsible for spraying water onto the dishes and utensils inside the dishwasher using a series of nozzles

that release pressure water. Over time, the sprayer head may become clogged due to a build of debris and soap residue, or it may also be damaged by a falling item. If the sprayer head is faulty, you will likely notice that your dishes are not cleaned properly after a cycle, and they have spots of leftover soap residue. It is important to replace the sprayer head to keep your dishwasher running efficiently.",

"rating": "96",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher. Part# AGB73093001 replaces these: AP5676135, AGB73093101 Back to Top",

"review_count": "23",

"appliance": "dishwasher",

"compatible_models": [

"14693",

"39232533",

"72214697610",

"LDF7061ST",

"LDF7551BB",

"LDF7551ST",

"LDF7551WW",

"LDF7561ST",

"LDF7774BB",

"LDF7774BD",

"LDF7774ST",

"LDF7774WW",

"LDF8072ST",

"LDF8764ST",

"LDF8874ST",

"LDS5040ST",

```
"LDS5774ST",
"LDT9965BD",
"LSDF9962ST",
"LSDF9969BD"
]
},
{
  "part_name": "HOLDER MEG64438901",
  "part_number": "PS12081830",
  "manufacturer": "LG",
  "price": "8.79",
  "description": "This is a dishrack holder designed for various models of LG dishwashers.
The purpose of this holder is to secure various parts within the dishwasher, such as the
cutlery basket. This holder measures approximately 1 inch long and 0.4 inches wide, is
made of plastic, and features two hooks that attach themselves to the frame of the rack.
This genuine OEM holder comes as an individual part, so if you require multiple holders,
consider that before ordering.",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Back
to Top",
  "review_count": "2",
  "appliance": "dishwasher",
  "compatible_models": [
    "ADFD5448AT",
    "LDB4548ST",
    "LDF5545BB",
    "LDF5545BD",
    "LDF5545SS",
```

"LDF5545ST",
"LDF5545WW",
"LDF5678BD",
"LDF5678SS",
"LDF5678ST",
"LDFN3432T",
"LDFN343LS",
"LDFN4542B",
"LDFN4542D",
"LDFN4542S",
"LDFN4542W",
"LDP5676BD",
"LDP6797BB",
"LDP6797BD",
"LDP6797BM",
"LDP6797SS",
"LDP6797ST",
"LDP6797WW",
"LDP6809BD",
"LDP6809BM",
"LDP6809SS",
"LDP6810BD",
"LDP6810SS",
"LDP7808BD",
"LDPN6761T"

]

```
},
```

```
{
```

```
  "part_name": "ROLLER ASSEMBLY 4581DD3003C",
```

```
  "part_number": "PS12075858",
```

```
  "manufacturer": "LG",
```

```
  "price": "9.30",
```

```
  "description": "The dishwasher roller assembly connects to the dishrack, and is located in the lower level of the dishwasher. It allows the dishrack to easily slide in and out. If the lower rack keeps falling off the track in your dishwasher, makes noises, the door will not close, or the dishes are not getting clean, then it is best to replace it for more security. A flat blade screw driver is the only tool needed for this installation. Open the lower dishwasher rack and remove retaining tabs from both ends of the rack and slide it out. Locate the older roll assembly, remove it and replace the rollers. Remember to put the tabs on each side back before sliding it back in. Make sure the dishwasher is off before starting this installation project.",
```

```
  "rating": "100",
```

```
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 4581DD3003C replaces these: 4580DD4001A, 4581DD3003B Back to Top",
```

```
  "review_count": "1",
```

```
  "appliance": "dishwasher",
```

```
  "compatible_models": [
```

```
    "13383",
```

```
    "13387",
```

```
    "14305",
```

```
    "14307",
```

```
    "14355",
```

```
    "14357",
```

```
    "14673",
```

```
    "14677",
```

```
"72213387910",  
"72214305910",  
"72214307910",  
"72214357910",  
"72214673710",  
"72214697610",  
"ADFD5448AT",  
"LDB4548ST",  
"LDF5545BB",  
"LDF5545BD",  
"LDF5545SS",  
"LDF5545ST",  
"LDF5545WW",  
"LDF5678BD",  
"LDF5678SS",  
"LDF5678ST",  
"LDF8812ST",  
"LDF9810ST",  
"LDFN3432T",  
"LDFN343LS",  
"LDFN4542B",  
"LDFN4542D"  
]  
,  
{  
  "part_name": "HOLDER MEG64438801",
```

"part_number": "PS12081829",

"manufacturer": "LG",

"price": "8.79",

"description": "This holder, also known as a mounting bracket, is responsible for securing the dish rack in place inside your dishwasher during cleaning. It is a genuine OEM replacement part sourced directly from LG to ensure a perfect fit for your dishwasher. It is gray in color and measures 1 inch by 1 inch. If the holder is lost or broken, your dish racks may become dislodged or unstable and cause damage inside the dishwasher. Each holder is sold individually.",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# MEG64438801 replaces these: AP6237065 Back to Top",

"review_count": "4",

"appliance": "dishwasher",

"compatible_models": [

"ADFD5448AT",

"LDB4548ST",

"LDF5545BB",

"LDF5545BD",

"LDF5545SS",

"LDF5545ST",

"LDF5545WW",

"LDF5678BD",

"LDF5678SS",

"LDF5678ST",

"LDFN3432T",

"LDFN343LS",

"LDFN4542B",

```
"LDFN4542D",
"LDFN4542S",
"LDFN4542W",
"LDP5676BD",
"LDP6797BB",
"LDP6797BD",
"LDP6797BM",
"LDP6797SS",
"LDP6797ST",
"LDP6797WW",
"LDP6809BD",
"LDP6809BM",
"LDP6809SS",
"LDP6810BD",
"LDP6810SS",
"LDP7708BD",
"LDP7708ST"
]
},
{
  "part_name": "CUTLERY BASKET 00675794",
  "part_number": "PS8733632",
  "manufacturer": null,
  "price": "39.50",
  "description": "",
  "rating": "94",
```

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 00675794 replaces these: AP4483661, 00704855, 11027062, 675794, 704855 Back to Top",

"review_count": "3",

"appliance": "dishwasher",

"compatible_models": [

"DF251760",

"DWHD410GFM",

"DWHD410GFM-53",

"DWHD410GPR",

"DWHD410GPR-53",

"DWHD410HFM",

"DWHD410HPR",

"DWHD440MFM",

"DWHD440MFP",

"DWHD440MPR",

"DWHD630GCM",

"DWHD630GCP",

"DWHD630GPR",

"SHE3AR52UC",

"SHE3AR52UC/06",

"SHE3AR52UC/07",

"SHE3AR55UC",

"SHE3AR55UC/06",

"SHE3AR55UC/07",

"SHE3AR56UC",

"SHE3AR56UC/06",

"SHE3AR56UC/07",

"SHE3AR72UC",

"SHE3AR72UC/06",

"SHE3AR72UC/07",

"SHE3AR75UC",

"SHE3AR75UC/06",

"SHE3AR75UC/07",

"SHE3AR76UC",

"SHE3AR76UC/06"

]

},

{

"part_name": "Lower Rack Wheel with Clip 00165314",

"part_number": "PS8697067",

"manufacturer": "Kenmore",

"price": "18.54",

"description": "This dishrack wheel is designed for use on the lower rack of your dishwasher, it allows the rack to roll in and out of your appliance with ease. This roller wheel includes the locking clip required for installation. The roller wheel attaches directly to the rack, you simply snap it into place on the frame of the rack, it does not include the axel. Due to how the roller wheels wear out we recommend replacing them in pairs. The diameter of the wheel is approximately one and a half inches. The roller wheel and clip are made of plastic.",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 00165314 replaces these: AP2802428, 00420198, 165314, 420198 Back to Top",

"review_count": "10",

"appliance": "dishwasher",

"compatible_models": [

"63016302400",

"63016302401",

"63016302402",

"63016302403",

"63016302404",

"63016302405",

"63016302406",

"63016303400",

"63016303401",

"63016303402",

"63016303403",

"63016303404",

"63016303405",

"63016303406",

"63016304400",

"63016304401",

"63016304402",

"63016304403",

"63016304404",

"63016304405",

"63016304406",

"63016309400",

"63016309401",

"63016309402",

"63016309403",

```
"63016309404",  
"63016309405",  
"63016309406",  
"63017303400",  
"63017303401"
```

```
]
```

```
},
```

```
{
```

```
"part_name": "Door Seal 00494772",
```

```
"part_number": "PS8723143",
```

```
"manufacturer": "Kenmore",
```

```
"price": "31.07",
```

```
"description": "This seal is also referred to as a door gasket, and it is designed for use on dishwashers. It is installed on the door of the appliance, and it seals the space between the tub of the dishwasher and the door. This seal works for prevent water from escaping during the wash cycle. Over time the seal might wear out, or it might get damaged, when that happens you will start to notice leaks. If water is leaking from the door of your dishwasher during operation it may be time for you to replace the door gasket on your appliance. This door seal is made of rubber, and it is black in color.",
```

```
"rating": "96",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# 00494772 replaces these: AP3768902, 494772 Back to Top",
```

```
"review_count": "5",
```

```
"appliance": "dishwasher",
```

```
"compatible_models": [  
  "63013952010",  
  "63013952011",
```

"63013953010",
"63013953011",
"63013959010",
"63013959011",
"63016302400",
"63016302401",
"63016302402",
"63016302403",
"63016302404",
"63016302405",
"63016302406",
"63016303400",
"63016303401",
"63016303402",
"63016303403",
"63016303404",
"63016303405",
"63016303406",
"63016304400",
"63016304401",
"63016304402",
"63016304403",
"63016304404",
"63016304405",
"63016304406",
"63016309400",

```
"63016309401",  
"63016309402"  
]  
,  
{  
  "part_name": "Lower Dishrack 00249276",  
  "part_number": "PS8701740",  
  "manufacturer": "Kenmore",  
  "price": "263.96",  
  "description": "",  
  "rating": "94",  
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#  
00249276 replaces these: AP4511159, 00186892, 00187062, 00213967, 00214560,  
00215913, 00216087, 00239132, 00241112, 00248822, 00434333, 00434336,  
00434644, 00434647, 00434649, 00440805, 00440806, 00442766, 00446654,  
00448593 ... Show more , 00490350, 00660293, 00665311, 00665898, 00850007,  
186892, 187062, 213967, 214560, 215913, 216087, 239132, 241112, 248822, 249276,  
434333, 434336, 434644, 434647, 434649, 440805, 440806, 442766, 446654, 448593,  
490350, 660293, 665311, 665898, 850007 Show less Back to Top",  
  "review_count": "9",  
  "appliance": "dishwasher",  
  "compatible_models": [  
    "63016302400",  
    "63016302401",  
    "63016302402",  
    "63016302403",  
    "63016302404",  
    "63016302405",
```

"63016302406",
"63016303400",
"63016303401",
"63016303402",
"63016303403",
"63016303404",
"63016303405",
"63016303406",
"63016304400",
"63016304401",
"63016304402",
"63016304403",
"63016304404",
"63016304405",
"63016304406",
"63016309400",
"63016309401",
"63016309402",
"63016309403",
"63016309404",
"63016309405",
"63016309406",
"63017303400",
"63017303401"

]

},

```
{  
  "part_name": "Adjustable Tine Row Clip 00611981",  
  "part_number": "PS8727471",  
  "manufacturer": "Kenmore",  
  "price": "6.08",  
  "description": "This part is a replacement tine row clip for your dishwasher. The tine row clip is adjustable, and it fits onto your dishrack to holds the tines into place. If your dishrack tine rows will not stay in position, you could have one or more broken tine clips. To replace a tine row clip, simply snap the old tine row clip out, and replace it with the new clip. This part is made of gray plastic and is approximately one inch long and half an inch wide. This part is sold individually, so it is a good idea to check all of your tine row clips to determine if more than one are broken.",  
  "rating": "100",  
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 00611981 replaces these: AP4397877, 611981 Back to Top",  
  "review_count": "2",  
  "appliance": "dishwasher",  
  "compatible_models": [  
    "63013952010",  
    "63013952011",  
    "63013953010",  
    "63013953011",  
    "63013959010",  
    "63013959011",  
    "DF251760",  
    "DF260141",  
    "DF260142",  
    "DI260410",
```

"DWHD410GFM",
"DWHD410GFM-53",
"DWHD410GPR",
"DWHD410GPR-53",
"DWHD410HFM",
"DWHD410HPR",
"DWHD410JFM",
"DWHD410JFP",
"DWHD410JPR",
"DWHD440MFP",
"DWHD630GCM",
"DWHD630GCP",
"DWHD630GPR",
"DWHD630IFM",
"DWHD630IFP",
"DWHD630IPR",
"S45KMK12UC",
"S45KMK12UC-60",
"S45KMK15UC",
"S45KMK15UC-60"

]

},

{

"part_name": "Middle Spray Arm WPW10498900",
"part_number": "PS11755664",
"manufacturer": "Kenmore",

"price": "54.17",

"description": "This is a replacement middle spray arm in your dishwasher. You will find your middle spray arm mounted on the bottom of the middle dish rack. The upper spray arm rotates and sprays water during the operating cycle. If your dishes are not coming out of the dishwasher clean, you may have a malfunctioning middle spray arm. Debris and hard water buildup in your dishwasher can cause the middle spray arm to clog. To replace the spray arm, simply turn the arm counter clockwise to release it from the dish rack. Screw in the new spray arm to complete the repair. This part is sold individually.",

"rating": "99",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Leaking This part works with the following products: Dishwasher, Washer Dryer Combo, Washer. Part# WPW10498900 replaces these: AP6022331, W10342777, W10342790, W10342791, W10376692, W10376693, W10498900, W10850340, WPW10376693 Back to Top",

"review_count": "17",

"appliance": "dishwasher",

"compatible_models": [

"2212413N414",

"2213092N413",

"2213099N413",

"2213222N414",

"2213223N414",

"2213229N414",

"2213809N710",

"2214523N611",

"2214545N711",

"2217383N710",

"2217389N710",

"66213032K112",

```
"66213273K112",
"66213293K112",
"66213299K112",
"66512093K210",
"66512413N410",
"66512413N411",
"66512413N412",
"66512413N413",
"66512723K310",
"66512723K311",
"66512782K310",
"66512782K312",
"66512782K313",
"66512783K311",
"66512783K312",
"66512783K313",
"66512789K311",
"66512789K312"
]
},
{
  "part_name": "GASKET W11498831",
  "part_number": "PS16221222",
  "manufacturer": "Kenmore",
  "price": "28.68",
```

"description": "This door gasket is a genuine OEM replacement part that is specially designed for your dishwasher. The gasket is located around the frame of the dishwasher. It is a rubber seal that helps prevent water from leaking out of the dishwasher during the wash cycle. It also helps to absorb the noise and vibrations created while the dishwasher is running. Over time the gasket may wear down, tear, or fall off due to exposure to heat and chemicals. If the gasket can no longer create a watertight seal, it is best to replace it promptly to keep your dishwasher running efficiently and to prevent potential accidents.",

"rating": "99",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# W11498831 replaces these: W10524469, W11425053, WPW10524469 Back to Top",

"review_count": "14",

"appliance": "dishwasher",

"compatible_models": [

"2213092N413",

"2213099N413",

"2213479N413",

"2213809N710",

"2214502N020",

"2217383N710",

"2217389N710",

"66512093K210",

"66512413N410",

"66512413N411",

"66512413N412",

"66512413N413",

"66512723K310",

"66512723K311",

```
"66513002N510",
"66513002N511",
"66513003N510",
"66513003N511",
"66513004N510",
"66513004N511",
"66513009N510",
"66513009N511",
"66513032K114",
"66513032K115",
"66513032K116",
"66513033K114",
"66513033K115",
"66513033K116",
"66513039K114",
"66513039K115"
]
},
{
  "part_name": "RACK ASSEMBLY UPPER 5304535250",
  "part_number": "PS17219603",
  "manufacturer": "Kenmore",
  "price": "122.49",
  "description": "This is an OEM upper dishrack, which works with dishwashers.",
  "rating": "74",
```

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 5304535250 replaces these: 154461101, 154494404, 154494406, 154638901, 154807901, 5304498205, 808602202 Back to Top",

"review_count": "3",

"appliance": "dishwasher",

"compatible_models": [

"004621710A",

"004621711A",

"58715202800",

"58715202801",

"58715202802",

"58715202803A",

"58715203800",

"58715203801",

"58715203802",

"58715203803A",

"58715313000A",

"58715382100A",

"58715382100B",

"58715383100A",

"58715383100B",

"58715389100A",

"58715389100B",

"58715392100A",

"58715393100A",

"58715399100A",

"804655850A",

"804655851A",
"BGHD2433KB0",
"BGHD2433KB1",
"BGHD2433KF0",
"BGHD2433KF1",
"BGHD2433KW0",
"BGHD2433KW1",
"DGBD2432KB0",
"DGBD2432KB1"

]

},

{

"part_name": "LATCH DOOR 5304535183",
"part_number": "PS17219598",
"manufacturer": "Kenmore",
"price": "26.96",
"description": "This is an OEM latch, which works with dishwashers.",
"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close | Will Not Start This part works with the following products: Dishwasher. Part# 5304535183 replaces these: 5304460923, 5304482428 Back to Top",

"review_count": "1",
"appliance": "dishwasher",
"compatible_models": [
"58712332510A",
"58712332F01B",
"58712333510A",

"58712333F01B",
"58712339510A",
"58712339F01B",
"58714402400",
"58714403400",
"58714409400",
"58714412400",
"58714419400",
"58714652110",
"58714652200A",
"58714652201B",
"58714659110",
"58714659200A",
"58714659201B",
"58714662110",
"58714662200A",
"58714662201B",
"58714663110",
"58714663200A",
"58714663201B",
"58714669110",
"58714669200A",
"58714669201B",
"58714683110",
"EIDW1805KS0A",
"EIDW1805KS1B",

```
"FDB2410HIB0"
]
},
{
  "part_name": "Fold-Down Tine Row - Left Side 154740304",
  "part_number": "PS8689159",
  "manufacturer": "Kenmore",
  "price": "25.90",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 154740304 replaces these: 154480403, 154598602, 154740302, 154740303 Back to Top",
  "review_count": "2",
  "appliance": "dishwasher",
  "compatible_models": [
    "58715202800",
    "58715202801",
    "58715202802",
    "58715202803A",
    "58715203800",
    "58715203801",
    "58715203802",
    "58715203803A",
    "58715313000A",
    "58715372100A",
    "58715372100B",
```


"58715373100A",
"58715373100B",
"58715378100A",
"58715378100B",
"58715379100A",
"58715379100B",
"58715382100A",
"58715382100B",
"58715383100A",
"58715383100B",
"58715389100A",
"58715389100B",
"58715392100A",
"58715393100A",
"58715399100A",
"BBBD2432KB0",
"BBBD2432KF0",
"BBBD2432KW0",
"BGBD2432KB0"

]

},

{

"part_name": "SPRING & CABLE ASSE 5304530071",
"part_number": "PS16620843",
"manufacturer": "Kenmore",
"price": "17.98",

"description": "",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Door latch failure | Door won't close This part works with the following products: Dishwasher. Part# 5304530071 replaces these: 5304475581, 5304475582 Back to Top",

"review_count": "3",

"appliance": "dishwasher",

"compatible_models": [

"58715412100A",

"58715413100A",

"58715423100A",

"EIDW5705PB0A",

"EIDW5705PS0A",

"EIDW5705PW0A",

"FGHD2455LB0",

"FGHD2455LB1A",

"FGHD2455LF0",

"FGHD2455LF1A",

"FGHD2455LW0",

"FGHD2455LW1A",

"FGHD2472PB0",

"FGHD2472PF0",

"FGHD2472PF1A",

"FGHD2472PW0",

"FGHD2491LB0",

"FGHD2491LW0",

"FPHD2491KF0"

```
]
},
{
  "part_name": "Tine Bracket 154428403",
  "part_number": "PS2330942",
  "manufacturer": "Kenmore",
  "price": "9.02",
  "description": "This is a bracket, but it may also be known as a dishrack row clip, or simply a tine clip, and it is used in conjunction with your dishwasher. The purpose of this part is to fasten to the rack and the tine row. This will give the tine the stability it needs to hold your glasses and bowls by firmly attaching to the rack. You will not need any tools to make this repair. This piece is sold individually, measures to be about 2 inches by 1 inch, and is gray in color.",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 154428403 replaces these: 154428401, 154428404, 7154428403, 7154428404 Back to Top",
  "review_count": "3",
  "appliance": "dishwasher",
  "compatible_models": [
    "58715072200",
    "58715072201",
    "58715073200",
    "58715073201",
    "58715074200",
    "58715074201",
    "58715079200",
    "58715079201",
```

```
"58716072200",
"58716072201",
"58716073200",
"58716073201",
"58716074200",
"58716074201",
"58716079200",
"58716079201",
"EDW7505HPS0",
"EDW7505HPS0A",
"EDW7505HPS1B",
"EDW7505HSS0",
"EDW7505HSS0A",
"EDW7505HSS1B",
"EIDW5905JB0A",
"EIDW5905JS0A",
"EIDW5905JW0A",
"EIDW6105GB0",
"EIDW6105GB1",
"EIDW6105GB1A",
"EIDW6105GB2B",
"EIDW6105GS0"
]
},
{
  "part_name": "FENCE 5304506535",
```

"part_number": "PS11770496",

"manufacturer": "Kenmore",

"price": "19.27",

"description": "This is an authentic upper rack tine (right side), which works with dishwashers.",

"rating": "94",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 5304506535 replaces these: AP6038449, 154480503, 154598402, 154740402, 154740403, 154740404 Back to Top",

"review_count": "9",

"appliance": "dishwasher",

"compatible_models": [

"004621710A",

"004621711A",

"58715202800",

"58715202801",

"58715202802",

"58715202803A",

"58715203800",

"58715203801",

"58715203802",

"58715203803A",

"58715313000A",

"58715372100A",

"58715372100B",

"58715373100A",

"58715373100B",

```
"58715378100A",
"58715378100B",
"58715379100A",
"58715379100B",
"58715382100A",
"58715382100B",
"58715383100A",
"58715383100B",
"58715389100A",
"58715389100B",
"58715392100A",
"58715393100A",
"58715399100A",
"804655850A",
"804655851A"
]
},
{
  "part_name": "Silverware Basket 5304535382",
  "part_number": "PS17219661",
  "manufacturer": "Kenmore",
  "price": "36.42",
```

"description": "The silverware basket, used for dishwashers, is in the bottom dishrack. The lower dishrack basket is used to hold eating utensils such as spoons, forks, and knives, and other small tools. If the basket in the dishwasher is worn out or the basket is broken, replacing it can be a solution. No tools for this replacement are required, as it is an easy process. If you need further guidance refer to the instructions provided by the

manufacturer. For safety precautions make sure to unplug the dishwasher and wear gloves.",

"rating": "90",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Leaking This part works with the following products: Dishwasher. Part# 5304535382 replaces these: 154253901, 154254001, 154254401, 154295201, 154423901, 154423902, 154423906, 154423908, 154424001, 154424002, 154424005, 154424101, 154424102, 154424202, 154424302, 154556101, 154556102, 154747801, 154747802, 154747901 ... Show more , 154747902, 154748001, 154748002, 154748101, 154748102, 154749502, 154749503, 154749601, 5304452614, 5304475626, 5304475627, 5304475628, 5304475630, 5304475631, 5304506522, 5304506523, 5304507404, 5304521739 Show less Back to Top",

"review_count": "30",

"appliance": "dishwasher",

"compatible_models": [

"004621710A",

"004621711A",

"58714022200A",

"58714023200A",

"58714024200A",

"58714028200A",

"58714029200A",

"58714102800",

"58714131100",

"58714131101",

"58714131102",

"58714132100",

"58714132101",

"58714132102",

```
"58714134100",  
"58714134101",  
"58714134102",  
"58714139100",  
"58714139101",  
"58714139102",  
"58714153400",  
"58714153401",  
"58714153402",  
"58714154400",  
"58714154401",  
"58714183400",  
"58714183401",  
"58714183402",  
"58714183403",  
"58714183404"  
]  
,  
{  
  "part_name": "RACK ASSEMBLY LOWER SILVER 5304535253",  
  "part_number": "PS17219606",  
  "manufacturer": "Kenmore",  
  "price": "135.40",
```

"description": "This lower dishrack assembly comes with 8 rollers enabling it to roll in and out with ease. The dishrack is approximately 22 inches long x 20 inches wide. The dishrack holds dishes in place during the dishwashing cycle. If you see rust spots on the dishes, the lower rack will not pull out, or the lower rack is visibly rusted or damaged, the

part should be replaced. Other common symptoms include: unusual or loud noises coming from the unit, or the dishes on the lower rack not being washed properly. This part is also known as a dish rack or a dishwasher rack.",

"rating": "87",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 5304535253 replaces these: 154432604, 154462701, 154639001, 154808001, 154866803, 154866902, 154887103, 808602402 Back to Top",

"review_count": "16",

"appliance": "dishwasher",

"compatible_models": [

"004621710A",

"004621711A",

"58715202800",

"58715202801",

"58715202802",

"58715202803A",

"58715203800",

"58715203801",

"58715203802",

"58715203803A",

"58715313000A",

"58715392100A",

"58715393100A",

"58715399100A",

"804655850A",

"804655851A",

"BGHD2433KB0",

"BGHD2433KB1",
"BGHD2433KF0",
"BGHD2433KF1",
"BGHD2433KW0",
"BGHD2433KW1",
"DGHD2433KF0",
"DGHD2433KF1",
"EIDW5905JB0A",
"EIDW5905JS0A",
"EIDW5905JW0A",
"FDB2410LDB0",
"FDB2410LDB1",
"FDB2410LDB2"

]

},

{

"part_name": "FOLD DOWN FENCE WI CLIPS 5304534829",

"part_number": "PS17219470",

"manufacturer": "Kenmore",

"price": "24.13",

"description": "Sold individually.",

"rating": "94",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 5304534829 replaces these: 154425503, 154721402, 154721403, 154721404, 5304507394 Back to Top",

"review_count": "15",

"appliance": "dishwasher",

"compatible_models": [

"004621710A",

"004621711A",

"58715202800",

"58715202801",

"58715202802",

"58715202803A",

"58715203800",

"58715203801",

"58715203802",

"58715203803A",

"58715313000A",

"58715392100A",

"58715393100A",

"58715399100A",

"804655850A",

"804655851A",

"BGHD2433KB0",

"BGHD2433KB1",

"BGHD2433KF0",

"BGHD2433KF1",

"BGHD2433KW0",

"BGHD2433KW1",

"DGHD2433KF0",

"DGHD2433KF1",

"EIDW5905JB0A",

```
"EIDW5905JS0A",
"EIDW5905JW0A",
"FDB2410LDB0",
"FDB2410LDB1",
"FDB2410LDB2"
]
},
{
  "part_name": "Rotor Assembly (Upper) DD97-00509A",
  "part_number": "PS12085764",
  "manufacturer": null,
  "price": "62.10",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# DD97-00509A replaces these: 113279 Back to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "DW60M9990AP",
    "DW80M9550UG",
    "DW80M9550US",
    "DW80M9960UG",
    "DW80M9990UM",
    "DW80M9990US",
    "DW80R7060UG",
```

```
"DW80R7060US",
"DW80R7061UG",
"DW80R7061US",
"DW80R9950QN",
"DW80R9950UG",
"DW80R9950US",
"DW80R9950UT"
]
},
{
  "part_name": "Dishrack Roller Wheel DD61-00222A",
  "part_number": "PS4222377",
  "manufacturer": null,
  "price": "10.64",
  "description": "",
  "rating": "40",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Back to Top",
  "review_count": "1",
  "appliance": "dishwasher",
  "compatible_models": [
    "DMR57LFB",
    "DMR57LFB/XAA-0000",
    "DMR57LFBXAA",
    "DMR57LFS",
    "DMR57LFS/XAA-0000",
```

"DMR57LFSXAA",
"DMR57LFW",
"DMR57LFW/XAA-0000",
"DMR57LFWXAA",
"DMR77LHB",
"DMR77LHBXAA",
"DMR77LHS",
"DMR77LHS/XAA-0000",
"DMR77LHSXAA",
"DMR77LHW",
"DMR77LHW/XAA-0000",
"DMR77LHWXAA",
"DMR78AHB",
"DMR78AHB/XAA-0000",
"DMR78AHBXAA",
"DMR78AHS",
"DMR78AHS/XAA-0000",
"DMR78AHSXAA",
"DMR78AHW",
"DMR78AHW/XAA-0000",
"DMR78AHWXAA",
"DMT300RFB",
"DMT300RFB/XAA",
"DMT300RFS",
"DMT300RFS/XAA"

]

```
},
```

```
{
```

```
"part_name": "Door Guide Cap DD67-00113B",
```

```
"part_number": "PS12721288",
```

```
"manufacturer": null,
```

```
"price": "4.66",
```

```
"description": "This dishwasher door cap guide is a genuine OEM replacement designed for Samsung WaterWall dishwashers. The door cap guide serves an aesthetic purpose by hiding mounting screws or other hardware on the dishwasher cabinet. It also protects the hardware from moisture, debris, or hard impacts. It is normal for the cap to become damaged or worn down over time due to normal mechanical stress, aging, or accidents. Over time the cap may crack or break, the adhesive backing may wear down or the cover may be unable to stay securely in place. You will need to replace the door cap or the mounting hardware on the exterior panel will be exposed. Simply pull off the faulty cap and snap the new one into place.",
```

```
"rating": null,
```

```
"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# DD67-00113B replaces these: AP6884906, 113236, 114370, DD67-00074A Back to Top",
```

```
"review_count": null,
```

```
"appliance": "dishwasher",
```

```
"compatible_models": [
```

```
"DW60M9990AP",
```

```
"DW80B6060UG",
```

```
"DW80B6060US",
```

```
"DW80B6061UG",
```

```
"DW80B6061US",
```

```
"DW80B7070AP",
```

```
"DW80B7070UG",
```

```
"DW80B7070US",
```

"DW80B7071UG",
"DW80B7071US",
"DW80H9930MO",
"DW80H9930US",
"DW80H9940US",
"DW80H9950US",
"DW80H9970MO",
"DW80H9970US",
"DW80J7550UG",
"DW80J7550US",
"DW80J7550UW",
"DW80J9945MO",
"DW80J9945US",
"DW80M9550UG",
"DW80M9550UGAA",
"DW80M9550US",
"DW80M9550USAA",
"DW80M9960UG",
"DW80M9960US",
"DW80M9990UM",
"DW80M9990US",
"DW80R7060UG"

]

},

{

"part_name": "Nozzle Assembly Top DD82-01309A",


```
"part_number": "PS12085666",
"manufacturer": null,
"price": "41.75",
"description": "",
"rating": "92",
"troubleshooting_tips": "This part works with the following products: Dishwasher. Back
to Top",
"review_count": "9",
"appliance": "dishwasher",
"compatible_models": [
  "DW80K7050UG",
  "DW80K7050US"
]
},
{
  "part_name": "Middle Spray Arm DD82-01339A",
  "part_number": "PS12085675",
  "manufacturer": null,
  "price": "82.44",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Back
to Top",
  "review_count": "3",
  "appliance": "dishwasher",
  "compatible_models": [
    "DW80K7050UG",
```

```
"DW80K7050US",
"DW80R5060UG",
"DW80R5060US",
"DW80R5061UG",
"DW80R5061US",
"DW80R5061UT"
]
},
{
  "part_name": "Lower Rack Roller with Mounting Clip DD66-00023A",
  "part_number": "PS4222532",
  "manufacturer": null,
  "price": "20.21",
  "description": "",
  "rating": "98",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# DD66-00023A replaces these: AP4342187 Back to Top",
  "review_count": "7",
  "appliance": "dishwasher",
  "compatible_models": [
    "DMR57LFB",
    "DMR57LFB/XAA-0000",
    "DMR57LFBXAA",
    "DMR57LFS",
    "DMR57LFS/XAA-0000",
    "DMR57LFSXAA",
```

```
"DMR57LFW",  
"DMR57LFW/XAA-0000",  
"DMR57LFWXAA",  
"DMR77LHB",  
"DMR77LHBXAA",  
"DMR77LHS",  
"DMR77LHS/XAA-0000",  
"DMR77LHSXAA",  
"DMR77LHW",  
"DMR77LHW/XAA-0000",  
"DMR77LHWXAA",  
"DMR78AHB",  
"DMR78AHB/XAA-0000",  
"DMR78AHBXAA",  
"DMR78AHS",  
"DMR78AHS/XAA-0000",  
"DMR78AHSXAA",  
"DMR78AHW",  
"DMR78AHW/XAA-0000",  
"DMR78AHWXAA",  
"DMT300RFB",  
"DMT300RFB/XAA",  
"DMT300RFS",  
"DMT300RFS/XAA"  
]  
},
```

```
{  
  "part_name": "Installation Bracket DD61-00465A",  
  "part_number": "PS10058975",  
  "manufacturer": null,  
  "price": "5.85",  
  "description": "This genuine OEM installation bracket, or mounting bracket, anchors the  
appliance to the surrounding cabinets, so that it stays in place and does not shift during  
operation. They hold the unit under the countertop. Keep in mind that this replacement part  
is sold individually, so check how many you will need for your installation.",  
  "rating": null,  
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#  
DD61-00465A replaces these: 113163 Back to Top",  
  "review_count": null,  
  "appliance": "dishwasher",  
  "compatible_models": [  
    "DW60M9990AP",  
    "DW80B6060UG",  
    "DW80B6060US",  
    "DW80B6061UG",  
    "DW80B6061US",  
    "DW80B7070AP",  
    "DW80B7070UG",  
    "DW80B7070US",  
    "DW80B7071UG",  
    "DW80B7071US",  
    "DW80H9930MO",  
    "DW80H9930US",  
  ]  
}
```

```
"DW80H9940US",
"DW80H9950US",
"DW80H9970MO",
"DW80H9970US",
"DW80J7550UG",
"DW80J7550US",
"DW80J7550UW",
"DW80J9945MO",
"DW80J9945US",
"DW80M9550UG",
"DW80M9550UGAA",
"DW80M9550US",
"DW80M9550USAA",
"DW80M9960UG",
"DW80M9960US",
"DW80M9990UM",
"DW80M9990US",
"DW80R7060UG"
]
},
{
  "part_name": "Affresh Cleaner W10282479",
  "part_number": "PS2367638",
  "manufacturer": "Kenmore",
  "price": "19.09",
```

"description": "There are 6 tablets in each package and it is suggested to use every month. These keep the dishwasher fresh by dissolving and removing odor.",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dishwasher, Food Waste Disposer. Part# W10282479 replaces these: AP4482632, 11090, 14202928, 14211394, 18001017, 18001020, 18001059, 4319102, 8171408, 8171408RM, W10209294 Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"17560101",

"17560102",

"17560110",

"17560111",

"17560111X",

"17560115",

"17560120",

"17560121",

"17560122",

"17560130",

"17560131",

"17560135",

"17560200",

"17560300",

"17560350",

"17560351X",

"175605090",

"175605140",
"175605150",
"175605160",
"175605520",
"17560552CE",
"175605530",
"17560563",
"17560572",
"17565223",
"17565280",
"17565360",
"17565370",
"17565380"

]

},

{

"part_name": "Upper Spray Arm Nut W10877037",

"part_number": "PS11738161",

"manufacturer": null,

"price": "11.09",

"description": "This upper spray arm nut is three inches long. It attaches to the spray arm to help hold it in place. It is all white in color and is made of plastic.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher. Part# W10877037 replaces these: AP6004899, 99001587 Back to Top",

"review_count": "3",

"appliance": "dishwasher",

"compatible_models": [

"CDB6100AWE",

"CDB6100AWN",

"CDB6100AWX",

"CDC400B",

"CDC450B",

"CDC610B",

"CDU250B",

"CDU250V",

"CDU400B",

"CDU450B",

"CDU450V",

"CDU510B",

"CDU510V",

"CDU600B",

"CDU600V",

"CDU610B",

"CDU610N",

"CDU610V",

"CDU8000B",

"CDU8000V",

"CDU810B",

"CDU810V",

"DC4000B",

"DC4500B",


```
"DDW261RAB",
"DDW261RAB-PDDW261RAB0",
"DDW261RAW",
"DDW261RAW-PDDW261RAW0",
"DU2500B",
"DU2500V"
]
},
{
  "part_name": "Upper Spray Arm Assembly WP99001586",
  "part_number": "PS11747612",
  "manufacturer": null,
  "price": "11.05",
  "description": "The upper spray arm helps distribute water from the top of the dishwasher tub.",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher. Part# WP99001586 replaces these: AP6014374, 99001586 Back to Top",
  "review_count": "6",
  "appliance": "dishwasher",
  "compatible_models": [
    "CDB6100AWE",
    "CDB6100AWN",
    "CDB6100AWX",
    "CDC400B",
    "CDC450B",
```

"CDC610B",
"CDU250B",
"CDU250V",
"CDU400B",
"CDU450B",
"CDU450V",
"CDU510B",
"CDU510V",
"CDU600B",
"CDU600V",
"CDU610B",
"CDU610N",
"CDU610V",
"CDU8000B",
"CDU8000V",
"CDU810B",
"CDU810V",
"DC4000B",
"DC4500B",
"DDW261RAB",
"DDW261RAB-PDDW261RAB0",
"DDW261RAW",
"DDW261RAW-PDDW261RAW0",
"DU2500B",
"DU2500V"

]

},

{

"part_name": "Hose Clamp WP596669",

"part_number": "PS11743008",

"manufacturer": "Kenmore",

"price": "11.77",

"description": "This hose clamp is used in a wide variety of household appliances. Most often it is found in washers, dishwashers, refrigerators, freezers, dehumidifiers, garbage disposals, or air conditioners. This clamp is used to securely attach a hose to another part of your appliance, which helps prevent leaks from those connections. Depending on the appliance, it can attach hoses to drain pumps, water inlet valves, pressure switches, and injector nozzles. We recommend you refer to model-specific diagrams for appropriate uses and exact placement. This hose clamp is made of metal, and is sold individually. To access and replace this part you will need a nut driver, pliers, and screwdrivers. Before you begin any repair work, make sure you have unplugged your appliance, and shut off the water supply if applicable.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Washer, Dishwasher, Refrigerator, Washer Dryer Combo. Part# WP596669 replaces these: AP6009835, 01-37-687, 113200024, 113200152, 113200392, 14206537, 16314, 2-11639, 2-14739, 2-1575, 2-16169, 2-2515, 2-985, 200985, 201575, 202515, 21002253, 211639, 214739, 216169 ... Show more , 22002509, 22003018, 22003072, 22003073, 22003905, 2200954, 22294, 23001257, 23001506, 25-6049, 25-7796, 25-7867, 251830, 25988, 272794, 272796, 272844, 272845, 272846, 272847, 274337, 27643, 287859, 288446, 301958, 34001161, 34001207, 34001208, 34001224, 34941, 353366, 353367, 356436, 357821, 36801, 370450, 370451, 370452, 371501, 371503, 371505, 371506, 388000, 39282, 3955674, 4-0059, 4-0168, 4-0179, 4-10296, 4-10377, 4-179, 400059, 400168, 400179, 40054901, 410296, 410377, 4171914, 478572, 487728, 488157, 489257, 563972, 568692, 569097, 596110, 596471, 596508, 596669, 6-911856, 6-919982, 6-920322, 601105, 616148, 644261, 648470, 650369, 65036900, 650373, 660632, 660635, 67001408, 7-57247, 710082, 715453, 757247, 797369, 798017, 8055019, 8181537, 8181538, 8194172, 8318451, 8318490, 8318491, 8318492, 8318493, 8318494, 8318495, 8526324, 8526325, 8533946, 8541009, 866812, 866823, 9-0433, 9-0440, 9-11856, 900433, 900440, 911856, 9602-3, 965242, 965321,

9724996, 9724997, 98292, 983190, 98334, 98465, 98659, 99003634, 99003635, DC61-00219C, DC65-00008A, P113200024, P113200152, P113200392, R0601506, R0601540, R9800234, W10096851, W10096852, W10116736, W10117298, W10117299, W10156124, W10286344, W10286346, W10286356, W10286357, Y22003072, Y2200954, Y22294, Y757247 Show less Back to Top",

"review_count": "1",

"appliance": "dishwasher",

"compatible_models": [

"101906620",

"106625480",

"106625481",

"106625482",

"106625490",

"106625491",

"106626480",

"106626490",

"106627481",

"106627483",

"106627484",

"106627491",

"106627493",

"106627494",

"106628480",

"106628481",

"106628490",

"106628491",

"106628530",

```
"106628531",  
"106629480",  
"106629490",  
"106629590",  
"106635170",  
"106635171",  
"106638170",  
"106638200",  
"106639200",  
"106639201",  
"106639202"
```

```
]
```

```
},
```

```
{
```

```
"part_name": "White Dishrack Roller WP903093",
```

```
"part_number": "PS11746834",
```

```
"manufacturer": null,
```

```
"price": "17.17",
```

```
"description": "This upper dishwasher dishrack roller, also known as a dishrack wheel, allows you to roll the dishwasher rack easily on the support rails. If your dishwasher rack is disconnected or the rack is broken, then replacing this part might be the solution. The first step in this repair is to remove the upper dishrack from the track, the next step is to remove the defective rack roller and replace it with the new one by sliding it onto the shaft and locking it in. No tools are required for this replacement and customers rate this project as easy. The roller is entirely made from plastic and is just over an inch in diameter.",
```

```
"rating": "74",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher. Part# WP903093"
```

replaces these: AP6013607, 9-12683, 9-12684, 9-3093, 903093, 912683, 912684 Back to Top",

"review_count": "6",

"appliance": "dishwasher",

"compatible_models": [

"ADW662EAB",

"ADW662EAB-PADW662EAB0",

"ADW662EAC",

"ADW662EAC-PADW662EAC0",

"ADW662EAS",

"ADW662EAW",

"ADW662EAW-PADW662EAW0",

"ADW862EAB",

"ADW862EAC",

"ADW862EAS",

"ADW862EAW",

"CDB3100AWE",

"CDB3100AWT",

"CDB3100AWX",

"CDB6100AWE",

"CDB6100AWN",

"CDB6100AWX",

"CDC400B",

"CDC450B",

"CDC5J",

"CDC610B",

"CDU20J",
"CDU250B",
"CDU250V",
"CDU2J",
"CDU2J3",
"CDU400B",
"CDU450B",
"CDU450V",
"CDU510B"

]

},

{

"part_name": "Inner Door Foam Insulation Strip WPW10117748",

"part_number": "PS11748543",

"manufacturer": null,

"price": "36.18",

"description": "This genuine inner door foam insulation strip, sometimes known as bottom seal foam, is used to create a waterproof seal that helps prevent leaking from the door area of the dishwasher. The existing insulation strip may leave a sticky residue or leftover disintegrated strip that must be scraped off before installing the new strip. Residue can be scraped off with a putty knife. Be sure to remove all residue and clean surrounding areas of the dishwasher build. It is strongly recommended to check other sealant parts on the dishwasher door such as the door gasket and dispenser grommet to ensure the leaking issue is fully solved.",

"rating": "85",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# WPW10117748 replaces these: AP6015268, 9-3233, 903233, W10117748 Back to Top",

"review_count": "4",

"appliance": "dishwasher",

"compatible_models": [

"ADB1200AWB",

"ADB1200AWQ",

"ADB1200AWS",

"ADB1200AWW",

"ADB1500AWB",

"ADB1500AWB0",

"ADB1500AWB1",

"ADB1500AWB2",

"ADB1500AWB3",

"ADB1500AWB37",

"ADB1500AWB41",

"ADB1500AWB46",

"ADB1500AWQ",

"ADB1500AWQ0",

"ADB1500AWQ1",

"ADB1500AWQ2",

"ADB1500AWQ3",

"ADB1500AWQ37",

"ADB1500AWQ41",

"ADB1500AWQ46",

"ADB1500AWS",

"ADB1500AWS0",

"ADB1500AWS1",

"ADB1500AWS2",


```

"ADB1500AWS3",
"ADB1500AWS37",
"ADB1500AWS41",
"ADB1500AWS46",
"ADB1500AWW",
"ADB1500AWW0"
]
},
{
  "part_name": "Door Gasket WP902894",
  "part_number": "PS11746830",
  "manufacturer": null,
  "price": "69.71",
  "description": "This dishwasher door gasket, or door seal, allows the dishwasher door to
have an airtight seal when closing the door. No tools are required for this installation,
simply remove the existing gasket and press the replacement gasket into the channel
around the door. It is recommended to clean the channel while the gasket is removed. This
part may need to be replaced if the existing one is cracked, broken, or hardened, possibly
causing water to leak through the door while it is running. This part is sold individually, and
is sourced from the original manufacturer.",
  "rating": "92",
  "troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works
with the following products: Dishwasher. Part# WP902894 replaces these: AP6013603,
902894, 99001072, 99002006, WP902894VP Back to Top",
  "review_count": "44",
  "appliance": "dishwasher",
  "compatible_models": [
    "ADW662EAB",

```

"ADW662EAB-PADW662EAB0",
"ADW662EAC",
"ADW662EAC-PADW662EAC0",
"ADW662EAS",
"ADW662EAW",
"ADW662EAW-PADW662EAW0",
"ADW862EAB",
"ADW862EAC",
"ADW862EAS",
"ADW862EAW",
"CDB3100AWE",
"CDB3100AWT",
"CDB3100AWX",
"CDB6100AWE",
"CDB6100AWN",
"CDB6100AWX",
"CDC400B",
"CDC450B",
"CDC5J",
"CDC610B",
"CDU20J",
"CDU250B",
"CDU250V",
"CDU2J",
"CDU2J3",
"CDU400B",

```
"CDU450B",  
"CDU450V",  
"CDU510B"  
]  
},  
{
```

```
"part_name": "Element Grommet 5300806833",
```

```
"part_number": "PS451462",
```

```
"manufacturer": null,
```

```
"price": "5.86",
```

```
"description": "This grommet is used in a number of household appliances. Most often it  
is used in the dishwasher as part of the assembly that mounts and holds the heating  
element in place. This replacement part is made out of rubber, which helps create a seal  
between the element and the appliance. This grommet is sold individually. If you are  
replacing the heating element, or the brass nut that holds it in place, we recommend you  
replace the grommet at the same time. Before you begin any repair work on your  
dishwasher, make sure you have unplugged it and shut off the water supply.",
```

```
"rating": null,
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works  
with the following products: Dishwasher, Cooktop, Air Conditioner. Part# 5300806833  
replaces these: AP2135215, 611359, 08014806, 0806833, 3014682, 3351028, 40570,  
5300007101, 5303351028, 7-5831, 705831, 8-6833, 8014806, 806833, 89593-1,  
G148568, G159894, K1082080, K1093193, K1093359 ... Show more , S000007101,  
WS7101 Show less Back to Top",
```

```
"review_count": null,
```

```
"appliance": "dishwasher",
```

```
"compatible_models": [  
"5871430591",  
"5871433590",
```

"5871444990",
"5871509181",
"5871710591",
"5871733590",
"5871744590",
"61-1127-10-00",
"61-1137-10-00",
"61-1147-00-10",
"61-1157-10-00",
"8505L00",
"8505L20",
"8508H30",
"8515L00",
"8515L10",
"8515L20",
"8517L00",
"8518L30",
"8518L40",
"8565L00",
"8565L10",
"8565L20",
"8565L30",
"8565L40",
"8566H30",
"8575L00",
"8575L10",

```
"8575L20",  
"8575L30"  
]  
},  
{  
  "part_name": "Faucet Adapter Coupling 5304490369",  
  "part_number": "PS7321390",  
  "manufacturer": "Kenmore",  
  "price": "47.25",
```

"description": "A faucet adapter coupling allows the user to connect their dishwasher to their kitchen faucet, and this coupling acts as a bridge between the faucet and intake hose for its various compatible dishwashers. This coupling features a plastic end with a mainly metal construction and a threaded section near that plastic end to screw into the faucet, whereas the other end connects to an intake hose that feeds into the dishwasher. This faucet adapter coupling is sold as an individual OEM part without any other hoses or connectors but does come with smaller components inside, such as O-rings and a spout adapter. If you notice water leaking from the connector area of this adapter on your dishwasher, it is likely that the adapter has some form of O-ring deterioration, thread wear, or mineral buildup and needs to be replaced. To replace this adapter, make sure your dishwasher and sink are off, and then simply thread this adapter onto the end of your faucet and connect the non-threaded end into the hose.",

```
"rating": "100",
```

"troubleshooting_tips": "This part works with the following products: Dishwasher, Air Conditioner. Part# 5304490369 replaces these: AP5669904, 00633599, 06592041, 07527100, 08000565, 08000646, 08000674, 08001089, 0800782, 40037-1, 5300800782, 5300803149, 5300803391, 5300803393, 5300806670, 5303271584, 5303304813, 5304474646, 5308000565, 5308000646 ... Show more , 5308001089, 633599, 6592041, 7527100, 8-0782, 80-0782, 8000565, 8000646, 8000674, 8001089, 800782, 803149, 803393, 83-0310, C000080101, C000092878, C000098063, C000098543, C000098544, C98063, G148392, G148404, K1082336, K1082568, WC98063, WC98543 Show less Back to Top",

```
"review_count": "4",
```

"appliance": "dishwasher",

"compatible_models": [

"5871710590",

"5871710591",

"5871717581",

"5871717583",

"5871717585",

"5871717586",

"58717242100",

"58717245990",

"58717245991",

"58717248400",

"58717248401",

"58717252200",

"58717252201",

"58717252202",

"58717259200",

"58717259201",

"58717259202",

"5871730590",

"5871733590",

"5871734569",

"58717345691",

"58717345790",

"5871736580",

"5871737580",

"5871737581",

"5871737583",

"5871738580",

"5871738581",

"5871740590",

"5871744580"

]

},

{

"part_name": "Clamp WP696392",

"part_number": "PS11743796",

"manufacturer": "Kenmore",

"price": "7.28",

"description": "This screw-type clamp, also known as a hose clamp, is made of metal and is used within various models of washers to secure the tub-to-pump hose and tub/drum of the washer. Without this clamp, the hose is vulnerable to leaking and disconnecting from the tub during the wash cycle of the washer, which can present a serious safety hazard for the machine and your home. Clamps can wear out and lose their tension due to excessive vibrations, mechanical damage, and normal wear and tear, all things present within a washing machine. To replace this clamp, you will first need to turn off your washer and you will need access to the lower portion of the washer chassis, which may require one or multiple screwdrivers and wrenches. Once you have access, use your screwdriver to loosen this clamp, which can then be removed and replaced with the new clamp, which will need to be tightened securely. Then you can simply reassemble the rest of the washer you originally disassembled.",

"rating": null,

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Washer, Dishwasher, Washer Dryer Combo, Dryer. Part# WP696392 replaces these: 14202480, 14202568, 2-0753, 200753, 22002053, 2235-0001, 2235-0002, 2235-0006, 2235-0007, 2235-0008, 23001025, 23001258, 24001353, 251971304015, 696392, 7-93043, 7-93045, 793043, 793045, 8181734 ... Show more ,

8540008, R0901504, R0901505, R0901506, R0901512, W10273037, W10712805,
WD01X0987, WD01X1319, Y793045 Show less Back to Top",

"review_count": null,

"appliance": "dishwasher",

"compatible_models": [

"1102647751K",

"11041932510",

"11041942710",

"11041952710",

"11042822200",

"11042822201",

"11042822202",

"11042822203",

"11042824200",

"11042824201",

"11042824202",

"11042824203",

"11042826200",

"11042826201",

"11042832200",

"11042832201",

"11042834200",

"11042834201",

"11042836200",

"11042836201",

"11042922200",

"11042922201",

"11042922202",

"11042922203",

"11042924200",

"11042924201",

"11042924202",

"11042924203",

"11042926200",

"11042926201"

]

},

{

"part_name": "Heat Resistant Adhesive W10841140",

"part_number": "PS11728058",

"manufacturer": "Kenmore",

"price": "23.81",

"description": "This is a heat-resistant adhesive for your appliance. The heat resistance allows you to stick parts such as grate feet, gaskets, and felt seals in hot areas, such as a cooktop, without compromising the integrity of the adhesive. It is white in color, and the tube is approximately 7.5 inches long.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Microwave, Washer, Dishwasher, Range. Part# W10841140 replaces these: AP5988848, 0055200, 05080015, 05600006, 058700, 07020012, 07020028, 0807509, 14212552, 14213557, 1430323, 17001001, 17199-3, 307576, 3147868, 33-1205, 350499, 56685-2, 58700, 618287 ... Show more , 618970, 674718, 674877, 674899, 675652, 7-0838, 7-15875, 7-57113, 7-8930, 700838, 702-0012, 702-0028, 708930, 715875, 757113, 788066, 788306, 8-7509, 807509, 8201588, 8201711, 834595, 869005, 89674, 89675, 92218P01, 92219P01, M0275597, M0275598, M13D1,

M13D2, M13D8, WP675652, Y0055200, Y05080015, Y05600006, Y058700, Y07020012, Y07020028, Y0807509, Y700838, Y708930, Y757113 Show less Back to Top",

"review_count": "1",

"appliance": "dishwasher",

"compatible_models": [

"001",

"05000",

"05501",

"05540SS",

"08000",

"08001",

"08500",

"08501",

"1010000",

"1011000",

"1015000",

"1018000",

"10200",

"1020000",

"1021000",

"1022000",

"1035000",

"1041000",

"1050000",

"1051000",

"110773811",

```
"110773813",
"110773881",
"110773883",
"1110000",
"1110001",
"1110002",
"11100A",
"1110101",
"1110A"
]
},
{
  "part_name": "Hose Clamp WP285655",
  "part_number": "PS11740613",
  "manufacturer": "Kenmore",
  "price": "11.09",
```

"description": "The hose clamp is used to hold the water hose in place which will prevent the hose from leaking water. Sometimes the clamp may lose its ability to latch on, causing a leaking washer. For the installation, you will need a flat head screw driver to replace the clamp and a drill to access the screws to remove the front of the washer. Be careful if you do not have specific clamp pliers as the clamp could fly off. Once the front of the washer has been removed, take a quick look for water damage or any obvious signs of where the leak is coming from. If it is not obvious, run water to test.",

"rating": "60",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Washer, Dishwasher, Washer Dryer Combo, Refrigerator. Part# WP285655 replaces these: AP6007497, 01500081, 01500148, 01500206, 01500208, 01500214, 0808186, 113200354, 113200366, 14001075, 14001076, 14219080, 14220070, 14224489, 17225, 2-0461, 2-0908, 2-0909, 2-1011, 2-10597 ... Show more ,

2-11641, 2-14875, 2-2574, 2-461, 2-4680, 2-908, 2-909, 200461, 200908, 200909, 201011, 20211, 202574, 20391, 204680, 21001875, 21002254, 210597, 211641, 21276, 214875, 22001640, 22001820, 22001984, 22002054, 22002838, 22002853, 22003295, 22003596, 22003897, 22003933, 22004375, 23001259, 24001438, 25-6068, 25-7080, 25-7797, 25-7881, 27001024, 27001223, 27151, 27153, 272803, 272849, 272851, 272852, 272853, 272854, 272858, 27644, 285655, 287323, 288003, 288004, 288094, 29176, 29439, 326031815, 326038497, 326049294, 33748, 34-0534, 34001315, 34894, 353093, 353097, 35370, 35384, 36802, 370445, 370446, 370447, 370449, 371498, 371500, 4-10297, 40109101, 410297, 4159784, 4160500, 42011233, 42011267, 42048095, 42048116, 42048119, 42048125, 4340211, 4355207, 451200, 451201, 451202, 451203, 451204, 500901, 500984, 503277, 503294, 505535, 52754, 596592, 596595, 596616, 596727, 61001162, 614.4098, 619584, 650010, 65001000, 650297, 65029700, 650438, 65043800, 650439, 650453, 65045300, 650510, 65051000, 650597, 65059700, 65349, 660626, 660628, 7-57388, 7-57442, 712138, 719649, 719650, 719933, 757388, 757442, 8-8186, 80-8186, 808186, 8181753, 8182375, 8182425, 8182768, 8182906, 8317496, 8317946, 8318497, 9-10068, 910068, 9411984, 9414925, 9420906, 965289, 96739, 96991, 98014, A3326001, A3326003, DC65-00009A, M0103004, P113200366, R0000457, R0213577, R0601505, R0601515, R0601516, R0601517, R0601518, R0601519, R0601541, R0601549, R0601551, R9800067, W10112110, W10142630, W10151157, W10156063, W10245724, W10421047, W10527162, W10736530, W11375994, WP22001984, Y01500081, Y01500148, Y01500206, Y01500208, Y01500214, Y0808186, Y22001820, Y6144098, Y757388 Show less Back to Top",

"review_count": "2",

"appliance": "dishwasher",

"compatible_models": [

"101963580",

"101963581",

"101963582",

"10682872600",

"110088732791",

"11010202000",

"11010202001",

```
"1101050299",  
"11010502990",  
"11010502991",  
"11010852990",  
"11010852991",  
"11012202100",  
"11012502100",  
"11012852100",  
"11013202200",  
"11013212200",  
"11014102300",  
"11014112300",  
"11014202300",  
"11014212200",  
"11014222300",  
"11014502300",  
"11014852300",  
"11015732400",  
"11015842400",  
"11015852400",  
"11015862400",  
"11015864400",  
"11015942400"  
]  
,  
{
```

"part_name": "Faucet Adapter WPW10254672",

"part_number": "PS11751238",

"manufacturer": "Kenmore",

"price": "54.41",

"description": "The faucet adapter for your portable dishwasher or washing machine attaches to the faucet and allows you to connect the machine to the tap. Before you install the faucet adapter on your taps, be sure that it fits the coupler on your dishwasher or washer. As per the factory, this is used for faucets with inside or outside threads. For female connection (outside) just remove the washers. This adapter is approximately 1 inch in length, and slightly less than one inch in diameter. This adapter comes with two different thicknesses of rubber washer. You will not need to use both so be sure to determine which thickness works best for your tap before installing it.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Will not fill with water This part works with the following products: Dishwasher, Washer, Air Conditioner. Part# WPW10254672 replaces these: AP6017937, 0803149, 0803391, 110552, 115356, 14205693, 20057331, 20082085, 20082444, 20084016, 20103199, 21014, 300446, 326039784, 3374592, 39898-1, 40006-1, 40420-1, 4107541, 4160080 ... Show more , 4160963, 4161359, 4170538, 4170540, 4170541, 4170551, 4170552, 4340088, 4340099, 4355128, 7-57004, 711445, 712709, 712721, 712781, 713750, 718045, 757004, 8-3149, 8-3391, 80-3149, 80-3391, 803149, 803391, 80582, 83-0311, 9-0084, 9-0159, 9-84, 900084, 900159, W10254672, Y0803149, Y0803391, Y757004 Show less Back to Top",

"review_count": "22",

"appliance": "dishwasher",

"compatible_models": [

"1102644182",

"1102644722",

"1102870090",

"1102970093",

"1103733107",

"11042182200",
"11042182201",
"11042722200",
"11042722201",
"11044182400",
"11044182401",
"11044722400",
"11044722401",
"11048182790",
"11048182791",
"11048184790",
"11048184791",
"11048722790",
"11048722791",
"11048724790",
"11048724791",
"11049182990",
"11049182991",
"11049182992",
"11049722990",
"11049722991",
"11049722992",
"1106603300",
"1106603301",
"1106733100"

]

```
},
```

```
{
```

```
"part_name": "Single Drum Glide Felt Pad WP500121",
```

```
"part_number": "PS11742773",
```

```
"manufacturer": null,
```

```
"price": "8.00",
```

```
"description": "This dryer drum glide pad is an inch long. It is made of a felt material and is used for gas and electric clothes dryers. The dryer drum glide provides a soft surface for the front of the drum glide and allows the drum to move effortlessly. If you notice that your dryer is making loud squeaking noises, it might be due to the drum glide pad being worn down or torn apart. Make sure to unplug your dryer before performing this repair. To access this part, you will need to open up the top of the dryer. The front panel and the bulk head will also need to come off.",
```

```
"rating": "100",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Marks left on clothes This part works with the following products: Dryer, Washer Dryer Combo. Part# WP500121 replaces these: AP6009605, 5-0121, 500121, 56058, R0604507 Back to Top",
```

```
"review_count": "3",
```

```
"appliance": "dishwasher",
```

```
"compatible_models": [
```

```
"1106702901",
```

```
"1106702910",
```

```
"ADE7005AKW",
```

```
"ADE7005AYW",
```

```
"ADE9005AGW",
```

```
"ADG7005AWW",
```

```
"AEM197",
```

```
"AEM377",
```



```
"AEM397",  
"AEM407L",  
"AEM407L2",  
"AEM407W",  
"AEM407W2",  
"AEM427L2",  
"AEM427W",  
"AEM427W2",  
"AEM477L2",  
"AEM477W",  
"AEM477W2",  
"AEM497L",  
"AEM497L2",  
"AEM497W",  
"AEM497W2",  
"AEM677L2",  
"AEM677W",  
"AEM677W2",  
"AEM697L",  
"AEM697L2",  
"AEM697W",  
"AEM697W2"  
]  
,  
{  
  "part_name": "Idler Pulley Wheel with Bearing WPY54414",
```

"part_number": "PS11757553",

"manufacturer": null,

"price": "22.26",

"description": "The idler pulley wheel helps the belt to rotate the drum in your dryer. If your dryer will not start, will not tumble, or is noisy during operation, the idler pulley wheel may need to be replaced. This part is located beneath the drum of the dryer, so the drum will need to be removed before you can access the idler pulley wheel. It is also recommended to remove the blower housing and motor from the dryer itself, for easier access to the idler pulley wheel. It is connected by a set of two 5/16 screws. This two-inch-wide idler pulley wheel is beige or black in color and is made of plastic. This pulley wheel comes with its own metallic bearing in its center. Be sure to shut off power to the dryer before beginning this repair.",

"rating": "93",

"troubleshooting_tips": "This part fixes the following symptoms: Noisy This part works with the following products: Dryer, Washer Dryer Combo. Part# WPY54414 replaces these: AP6024203, 14218926, 54414, R0609504, WPY54414VP, Y54414 Back to Top",

"review_count": "20",

"appliance": "dishwasher",

"compatible_models": [

"7493-LEM437",

"AE3213",

"AE3413",

"AE4113",

"AE4213",

"AE4413",

"AE5113",

"AE5213",

"AE5413",

"AE7133",

```
"AE7233",
"AE9133",
"AE9233",
"AE9433",
"AEE933",
"AEE953",
"AEM197",
"AEM333",
"AEM353",
"AEM377",
"AEM397",
"AEM407L",
"AEM407L2",
"AEM407L2-PAEM402L2",
"AEM407W",
"AEM407W2",
"AEM407W2-PAEM402W2",
"AEM427L2",
"AEM427L2-PAEM427L2",
"AEM427W"
]
},
{
  "part_name": "Thrust Washer WP233520",
  "part_number": "PS11740482",
  "manufacturer": "Kenmore",
```

"price": "7.95",

"description": "This genuine OEM washer has a 3/4 inch outside diameter. This thrust washer can be used on most makes and models of dryers. A complete list of compatible dryers is available below. The washer is found on dryers around the drum support rollers and idler pulleys, and helps prevent the rollers and pulleys from bumping up against the brackets they are installed on. Your thrust washer could be defective if you notice your dryer wont tumble, rotate, or turn; or there is a load squealing or whining noise when the dryer tumbles. The repair is a relatively easy job. You will require a putty knife, 5/16 inch nut driver, and E-Ring pliers. Remember to disconnect the power to your dryer before you begin the repair.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Will not agitate | Burning smell | Spins slowly This part works with the following products: Dryer, Washer, Washer Dryer Combo. Part# WP233520 replaces these: AP6007368, 16318, 16707, 233520, 501733, 51068, 52549, R0600526, WP52549 Back to Top",

"review_count": "2",

"appliance": "dishwasher",

"compatible_models": [

"10687884100",

"10687884300",

"10687884600",

"10697502820",

"11051730",

"11055594",

"1105807410",

"1105808010",

"1105808700",

"1105808800",

"1105808810",

```
"1105808850",
"1105808860",
"1105817820",
"1105817830",
"1105818810",
"1105818820",
"1105907000",
"1105907100",
"1105907400",
"1105907500",
"1105907501",
"1105907600",
"1105907610",
"1105907700",
"1105907710",
"1105907720",
"1105907721",
"1105907730",
"1105907800"
]
},
{
  "part_name": "Dryer Idler Assembly WP37001287",
  "part_number": "PS11741930",
  "manufacturer": null,
  "price": "35.66",
```

"description": "The spring for this part is sold separately.\r\n\r\nThis idler assembly is for dryers.\r\n\r\nIdler assembly includes the idler arm and the idler pulley that maintains tension on the drive belt, allowing the belt to turn.\r\n\r\nDisconnect the power before installing this part. Wear work gloves to protect your hands.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Drum Not Spinning This part works with the following products: Dryer. Part# WP37001287 replaces these: AP6008789, 37001287, 5-0269, 500269, 500269P, WP37001287VP Back to Top",

"review_count": "20",

"appliance": "dishwasher",

"compatible_models": [

"7493-LEM437",

"ADE7005AKW",

"ADE7005AYW",

"ADE9005AGW",

"ADG7005AWW",

"AEM197",

"AEM377",

"AEM397",

"AEM407L",

"AEM407L2",

"AEM407L2-PAEM402L2",

"AEM407W",

"AEM407W2",

"AEM407W2-PAEM402W2",

"AEM427L2",

"AEM427L2-PAEM427L2",

```
"AEM427W",
"AEM427W2",
"AEM427W2-PAEM427W2",
"AEM477L2",
"AEM477L2-PAEM477L2",
"AEM477W",
"AEM477W2",
"AEM477W2-PAEM477W2",
"AEM497L",
"AEM497L2",
"AEM497L2-PAEM497L2",
"AEM497W",
"AEM497W2",
"AEM497W2-PAEM497W2"
]
},
{
  "part_name": "Drum Glide WP37001298",
  "part_number": "PS11741931",
  "manufacturer": null,
  "price": "14.16",
```

"description": "If your dryer is noisy, will not tumble, or is leaving marks on your clothes, you may need to replace the drum glide. The drum glide is installed on the front bulkhead either at the top or the bottom, regardless of the brand of dryer. To gain access to the drum glide, you will have to open the cabinet on the dryer. This drum glide is sold individually but it is important to note that they should be replaced in pairs. Before beginning this repair, it is important to disconnect the dryer from the power source. The tools required for this repair are a putty knife and a 5/16 nut driver.",

"rating": "98",

"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Marks left on clothes This part works with the following products: Dryer. Part# WP37001298 replaces these: AP6008790, 37001298, 40116501, 40116502, 5-1553, 5-1676, 5-3452, 501553, 501676, 503452, WP37001298VP, Y501676 Back to Top",

"review_count": "10",

"appliance": "dishwasher",

"compatible_models": [

"ADE7005AKW",

"ADE7005AYW",

"ADE9005AGW",

"ADG7005AWW",

"AEM197",

"AEM377",

"AEM397",

"AEM407L",

"AEM407L2",

"AEM407L2-PAEM402L2",

"AEM407W",

"AEM407W2",

"AEM407W2-PAEM402W2",

"AEM427L2",

"AEM427L2-PAEM427L2",

"AEM427W",

"AEM427W2",

"AEM427W2-PAEM427W2",

"AEM477L2",

"AEM477L2-PAEM477L2",
"AEM477W",
"AEM477W2",
"AEM477W2-PAEM477W2",
"AEM497L",
"AEM497L2",
"AEM497L2-PAEM497L2",
"AEM497W",
"AEM497W2",
"AEM497W2-PAEM497W2",
"AEM677L2"

]

},

{

"part_name": "Dryer Radiant Flame Sensor WP338906",

"part_number": "PS11741429",

"manufacturer": "Kenmore",

"price": "47.87",

"description": "If your gas dryer is not heating up or igniting, then replacing the flame sensor, located in the burner assembly, could solve it. This part senses heat from the igniter to monitor if it is hot enough to ignite gas to light the burner. Once the igniter is hot enough it will open the valve and allow gas to flow. This is a safety mechanism to prevent dangerous levels of gas from building up. To repair, the main top of the dryer should be lifted, as well as the front panel to access the component. This flame sensor assembly is made of both plastic and metal.",

"rating": "90",

"troubleshooting_tips": "This part fixes the following symptoms: Not Heating This part works with the following products: Dryer, Washer Dryer Combo, Refrigerator. Part#

WP338906 replaces these: AP6008294, 14205529, 14210083, 14218928, 3-3377, 303377, 338906, 35001096, 56231, 63-5013, DC32-00008A, DE353, K35-194, R0611503, WP338906VP, Y303377, Y56231 Back to Top",

"review_count": "12",

"appliance": "dishwasher",

"compatible_models": [

"10687884100",

"10687884300",

"10687884600",

"10697502820",

"1103401795",

"1103401796",

"1103402855",

"1103402856",

"1106507821",

"1106507830",

"1106507831",

"1106517741",

"1106517744",

"1106517746",

"1106807613",

"1106807615",

"1106807703",

"1106807705",

"1106807811",

"1106807822",

"1106807830",

```
"1106817231",  
"1106817241",  
"1106907100",  
"1106907101",  
"1106907200",  
"1106907201",  
"1106907600",  
"1106907610",  
"1106907613"
```

```
]
```

```
},
```

```
{
```

```
"part_name": "Drum Support Roller WP37001042",
```

```
"part_number": "PS11741913",
```

```
"manufacturer": null,
```

```
"price": "20.93",
```

```
"description": "This drum support roller is used for square-ported model clothes dryers. This part is sold individually; however, rollers tend to wear at the same rate, so it is suggested that both should be replaced at the same time. It has a metallic bearing in its center. The drum support roller holds the drum in place while it rotates on the support wheels. You may have a faulty or damaged roller if your dryer will not start or tumble, takes too long to dry clothes, or starts making loud noises. Customers have ranked this repair as easy and should take 15-30 minutes to complete.",
```

```
"rating": "96",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Noisy This part works with the following products: Dryer. Part# WP37001042 replaces these: AP6008773, 14218934, 37001042, 5-0214, 500214, 500214P, WP37001042VP Back to Top",
```

```
"review_count": "13",
```

"appliance": "dishwasher",
"compatible_models": [
"106M12A-F",
"106M12P-F",
"106M12S-F",
"ADE7005AKW",
"ADE7005AYW",
"ADE9005AGW",
"ADG7005AWW",
"AEM197",
"AEM377",
"AEM397",
"AEM407L",
"AEM407L2",
"AEM407L2-PAEM402L2",
"AEM407W",
"AEM407W2",
"AEM407W2-PAEM402W2",
"AEM427L2",
"AEM427L2-PAEM427L2",
"AEM427W",
"AEM427W2",
"AEM427W2-PAEM427W2",
"AEM477L2",
"AEM477L2-PAEM477L2",
"AEM477W",

```
"AEM477W2",
"AEM477W2-PAEM477W2",
"AEM497L",
"AEM497L2",
"AEM497L2-PAEM497L2",
"AEM497W"
]
},
{
  "part_name": "Affresh Washing Machine Cleaner - 3 pack W10135699",
  "part_number": "PS1960673",
  "manufacturer": "Kenmore",
  "price": "12.58",
  "description": "This front load washer cleaner removes odor-causing residue. Use it once a month and it will keep your machine fresh and clean. Package comes with 3 tablets.",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Washer, Washer Dryer Combo. Part# W10135699 replaces these: AP4308494, 14211394, 18001017, 18001080, 4319102, 77109, AFFRESH, GLISTEN, TJ106, TJ122, TJ129, W10135699, W10135699A, W10913950 Back to Top",
  "review_count": "2",
  "appliance": "dishwasher",
  "compatible_models": [
    "10682872600",
    "1101050299",
    "11020022012",
```

"11020022014",
"11020102310",
"11020222510",
"11020222511",
"11020232711",
"11020242510",
"11020362810",
"11020362811",
"11020362812",
"11020372711",
"1102071299",
"1102086299",
"1102087299",
"11021102012",
"11021102013",
"11021112020",
"11021112021",
"11021112022",
"11021182012",
"11021182013",
"11021252111",
"11021292012",
"11021292013",
"11021302010",
"11021302011",
"11021302013",

"11021352111"

]

},

{

"part_name": "M Series New Style Coil Kit 279834",

"part_number": "PS334310",

"manufacturer": "Kenmore",

"price": "30.86",

"description": "When the igniter reaches a high enough temperature, these coils (Coil Valve, Dryer Gas Valve Coil Kit, Dryer Valve Coil Kit, Gas Valve Solenoid) work together to open the gas valve and allow the gas to enter the burner. This is a safety mechanism to ensure that there are no unsafe buildups of gas inside your appliance. The coils are attached to the dryer gas valve. If the dryer does not heat or heats intermittently, the coil may not be opening the gas valve. Both coils must be operational for the valve to open. No continuity would indicate a defective coil, but they can be intermittent and fail when they get hot. Both coils should be replaced when one of them is broken. This part can break as a result of material fatigue from normal use. This part measures approximately 1 inch in diameter and 1 inch in height, and is constructed of plastic and metal. It comes in black/beige. This part features a 3-terminal boost/hold coil and a 2-terminal secondary coil",

"rating": "96",

"troubleshooting_tips": "This part fixes the following symptoms: Not Heating | Noisy This part works with the following products: Dryer, Washer Dryer Combo. Part# 279834 replaces these: AP3094251, 3479, 279834, 12001349, 14201336, 14201452, 14202750, 14205025, 14210032, 14210725, 14210908, 279834, 279834BULK, 279834VP, 3-6105, 3-6106, 306105, 306106, 58804A, 58804B ... Show more , 63-6614, 63-6615, 694539, 694540, F91-3889, F91-3890, K35-288, K35-355, K35-450, R0610003, R0610050, SCA700, WP279834 Show less Back to Top",

"review_count": "149",

"appliance": "dishwasher",

"compatible_models": [

"10687884100",
"10687884300",
"10687884600",
"1103387617",
"1103397617",
"1103398423",
"1103401771",
"1103401795",
"1103401796",
"1103401797",
"1103401798",
"1103401799",
"1103402243",
"1103402844",
"1103402851",
"1103402855",
"1103402856",
"1104319351",
"1104319410",
"110694670",
"110694671",
"110695502",
"110697436",
"11070012000",
"11070012001",
"11070012002",

"11070022010",

"11070052990",

"11070052991",

"11070056990"

]

},

{

"part_name": "Multi Rib Belt WP40111201",

"part_number": "PS11742271",

"manufacturer": null,

"price": "9.43",

"description": "This dryer drum drive belt attaches to the motor pulley and works the drum as the motor rotates. The belt has a length of 93- 3/6 inches, and wraps all the way around the dryer drum, around a tension pulley, and then around the drive motor pulley. Replacing the rib belt could solve symptoms such as a screeching noise when the dryer tumbles, a broken belt (dryer will not tumble if its broken), no heat or not enough heat, or the dryer will not start. The tools needed for this repair are a nut driver and a putty knife. Remember to unplug the dryer before installing the part and protect your hands by wearing gloves.",

"rating": "95",

"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Drum Not Spinning This part works with the following products: Dryer. Part# WP40111201 replaces these: AP6009126, 14218936, 40051501, 40051502, 40111201, 59174, R0606549, WP40111201VP Back to Top",

"review_count": "103",

"appliance": "dishwasher",

"compatible_models": [

"4260",

"7493-LEM437",

"ADE7005AKW",
"ADE7005AYW",
"ADE9005AGW",
"ADG7005AWW",
"AE3213",
"AE3413",
"AE4113",
"AE4213",
"AE4413",
"AE5113",
"AE5213",
"AE5413",
"AE7133",
"AE7233",
"AE9133",
"AE9233",
"AE9433",
"AEE933",
"AEE953",
"AEM197",
"AEM333",
"AEM353",
"AEM377",
"AEM397",
"AEM407L",
"AEM407L2",

```
"AEM407L2-PAEM402L2",  
"AEM407W"  
]  
,  
{  
  "part_name": "Upper Rack Adjuster Kit - White Wheels, Left and Right Sides  
W10712395",  
  "part_number": "PS10065979",  
  "manufacturer": "Kenmore",  
  "price": "47.79",  
  "description": "This authentic Dishwasher Upper Rack Adjuster Kit with white wheels is a  
kit made up of primarily plastic and metal components, which will require a screwdriver to  
install. This kit comes with all the necessary parts for a dishwasher rack adjuster. It fits  
onto the dishwasher rack and connects it to the track allowing it to slide in and out. If  
broken then the rack will no longer slide properly, and the part must be replaced. In many  
cases, our customers have reported the top rack of their dishwasher hanging down or  
sagging due to the adjuster kit, particularly if the wheels, have broken or failed. If you are  
having problems in this area, this kit will help get your dishwasher back up and running.  
Check your model number and user manual to see if this part is right for you. The parts for  
this kit come as a package and are not generally sold individually.",  
  "rating": "94",  
  "troubleshooting_tips": "This part fixes the following symptoms: Door won't close | Door  
latch failure | Not cleaning dishes properly | Noisy This part works with the following  
products: Dishwasher. Part# W10712395 replaces these: AP5957560, W10250159,  
W10350375, W10712395VP Back to Top",  
  "review_count": "611",  
  "appliance": "dishwasher",  
  "compatible_models": [  
    "2213222N414",  
    "2213223N414",
```

"2213229N414",
"2214523N611",
"2214545N711",
"66512762K312",
"66512763K312",
"66512763K313",
"66512769K312",
"66512769K313",
"66512772K312",
"66512772K313",
"66512772K314",
"66512773K313",
"66512773K314",
"66512774K312",
"66512774K313",
"66512776K312",
"66512776K314",
"66512779K312",
"66512779K313",
"66512779K314",
"66512813K313",
"66513202N410",
"66513202N411",
"66513202N413",
"66513203N410",
"66513203N411",

```
"66513203N413",
"66513204N410"
]
},
{
  "part_name": "Upper Rack Wheel and Mount Assembly WP8270019",
  "part_number": "PS11745525",
  "manufacturer": "Kenmore",
  "price": "11.29",
  "description": "Sold Individually.",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher, Refrigerator. Part# WP8270019 replaces these: AP6012318, 8270019 Back to Top",
  "review_count": "12",
  "appliance": "dishwasher",
  "compatible_models": [
    "665110739120",
    "665110739130",
    "665110739140",
    "665110739190",
    "66513212K901",
    "66513212K902",
    "66513213K900",
    "66513213K901",
    "66513213K902",
    "66513219K901",
```

```
"66513219K902",
"66513242K900",
"66513242K901",
"66513243K900",
"66513243K901",
"66513249K900",
"66513249K901",
"66513752K600",
"66513752K601",
"66513752K602",
"66513752K603",
"66513753K600",
"66513753K601",
"66513753K602",
"66513753K603",
"66513754K600",
"66513754K601",
"66513754K602",
"66513754K603",
"66513759K600"
]
},
{
  "part_name": "Rack Adjuster WPW10204131",
  "part_number": "PS11750255",
  "manufacturer": "Kenmore",
```

"price": "11.09",

"description": "This OEM dishrack roller and adjuster is found in your dishwasher. They work together to support and facilitate the smooth movement of your dishrack. The dishrack rollers are small wheels located on the sides of the dishrack and allow it to slide in and out effortlessly. Meanwhile, the dishrack adjuster is used to adjust the height via the selector at the back of this component. Over time, the rollers wear out. You may experience resistance or difficulty when sliding the dishrack in or out. If left unreplaced, your rollers or adjuster may break, causing dishes to tilt, collide, or fall over during the wash cycle. When removing a roller and adjuster from your appliance, you will need to pull out the dishrack partway. Detach the assembly by depressing the tabs on the two end stops before lifting them up. Keep in mind that the roller and adjuster are sold together, but the dishrack itself is sold separately.",

"rating": "94",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WPW10204131 replaces these: AP6016961, 3373365, 3380395, 3380860, 8051116, 8268848, 8268852, W10204114, W10204131, WPW10204114 Back to Top",

"review_count": "33",

"appliance": "dishwasher",

"compatible_models": [

"110723120",

"65715755791",

"66513402K900",

"66513402K901",

"66513409K900",

"66513409K901",

"66513442K900",

"66513442K901",

"66513443K900",

"66513443K901",

"66513444K900",

```
"66513444K901",
"66513449K900",
"66513449K901",
"66513492K600",
"66513499K600",
"66514212K900",
"66514212K901",
"66514213K900",
"66514213K901",
"66514214K900",
"66514214K901",
"66514219K900",
"66514219K901",
"66515522000",
"66515524000",
"66515529000",
"66515641891",
"66515645891",
"66515662990"
]
},
{
  "part_name": "Upper Rack Wheel with Mount WP8268655",
  "part_number": "PS11745451",
  "manufacturer": "Kenmore",
  "price": "29.36",
```


"description": "This is a replacement upper dish rack wheel with mount for your dishwasher. The mount supports the dish rack, and the wheel allows the rack to slide out easily. To replace this part, remove the rack stops and pull out the upper dish rack. This wheel mount pops off, and the new one can be snapped into place.",

"rating": "98",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't close | Not cleaning dishes properly | Noisy | Door latch failure This part works with the following products: Dishwasher. Part# WP8268655 replaces these: AP6012244, 8268655, WP8268655VP Back to Top",

"review_count": "59",

"appliance": "dishwasher",

"compatible_models": [

"665110739120",

"665110739130",

"665110739140",

"665110739190",

"66513482K900",

"66513482K901",

"66513482K902",

"66513482K903",

"66513483K900",

"66513483K901",

"66513483K902",

"66513483K903",

"66513484K900",

"66513484K901",

"66513484K902",

"66513484K903",

"66513489K900",
"66513489K901",
"66513489K902",
"66513489K903",
"66513892K800",
"66513892K801",
"66513892K802",
"66513893K800",
"66513893K801",
"66513893K802",
"66513899K800",
"66513899K801",
"66513899K802",
"66514353300"

]

},

{

"part_name": "Dishwasher Upper Dish Rack Wheel Mount WP8268743",

"part_number": "PS11745459",

"manufacturer": "Kenmore",

"price": "29.88",

"description": "This upper dish rack wheel mount can be used on either side of your dish rack. It is sold individually. The part includes the wheel and support, which attaches to the dish rack and allows it to slide in and out easily.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't close | Noisy | Not cleaning dishes properly | Door latch failure This part works with the following

products: Dishwasher. Part# WP8268743 replaces these: AP6012252, 8268743, WP8268743VP Back to Top",

"review_count": "63",

"appliance": "dishwasher",

"compatible_models": [

"2213479N413",

"66513212K901",

"66513212K902",

"66513213K900",

"66513213K901",

"66513213K902",

"66513219K901",

"66513219K902",

"66513472N410",

"66513472N411",

"66513472N412",

"66513472N413",

"66513473N410",

"66513473N411",

"66513473N412",

"66513473N413",

"66513479N410",

"66513479N411",

"66513479N412",

"66513479N413",

"7GU3200XTSS0",

```
"7GU3200XTSS1",  
"GU2200XTSB1",  
"GU2200XTSB2",  
"GU2200XTSB3",  
"GU2200XTSQ1",  
"GU2200XTSQ2",  
"GU2200XTSQ3",  
"GU2200XTSS1",  
"GU2200XTSS2"
```

```
]
```

```
},
```

```
{
```

```
"part_name": "Lower Rack Wheel Kit - 8 Pack WD35X21038",
```

```
"part_number": "PS11726733",
```

```
"manufacturer": "Kenmore",
```

```
"price": "36.85",
```

```
"description": "This lower rack wheel kit includes 8 wheels and 8 axles that allow the lower dishwasher rack to slide in and out smoothly. If your dishwasher door will not close, is noisy when operating, or the dishes are not cleaning properly, you might need to replace one or more of the wheels. Each wheel and axle are made of plastic, and fit into one another so they can be clipped on to the lower dishwasher rack. Many of our customers found this repair to be quick and easy, and the only tool you should need to complete the repair is a pair of pliers.",
```

```
"rating": "94",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Noisy | Door won't close This part works with the following products: Dishwasher. Part# WD35X21038 replaces these: AP5986365, WD12X0272, WD12X0427, WD12X0441, WD12X10074, WD12X10076, WD12X10077, WD12X10078, WD12X10079, WD12X10080, WD12X10081, WD12X10082, WD12X10083, WD12X10084, WD12X10085, WD12X10086,
```

WD12X10087, WD12X10088, WD12X10089, WD12X10090 ... Show more , WD12X10091, WD12X10092, WD12X10093, WD12X10094, WD12X10095, WD12X10096, WD12X10097, WD12X10098, WD12X10100, WD12X10265, WD12X10267, WD12X272, WD12X427, WD12X441 Show less Back to Top",

"review_count": "157",

"appliance": "dishwasher",

"compatible_models": [

"1200L02",

"18385",

"1858",

"3000B10",

"3000W10",

"361402891",

"3631401190",

"3631401191",

"3631401590",

"3631401591",

"3631401592",

"3631401890",

"3631401891",

"3631401892",

"3631402190",

"3631402191",

"3631402192",

"3631402590",

"3631402591",

"3631402592",

"3631402890",
"3631402891",
"3631402892",
"36314031000",
"36314031001",
"36314032000",
"36314032001",
"36314038000",
"36314038001",
"36314039000"

]

},

{

"part_name": "Rack Roller Wheel 00611666",

"part_number": "PS8727423",

"manufacturer": "Kenmore",

"price": "10.28",

"description": "This wheel is a dishwasher rack wheel designed for the upper rack of your appliance. The roller wheel is approximately 1.25 inches in diameters and includes the brushing you need for installation. It simply clips right on to the rack frame. After the wheel are attached to the side of the dishrack and are placed into the slides on either side of the appliance. Dishrack roller wheels allow the upper rack in a dishwasher to glide in and out of the appliance with ease. Due to the fact the roller wheel is made of plastic they tend to wear out after a period of time, also they can break. We do recommend you replace these rack wheels in pairs as they often wear out at the same rate. These wheels are sold individually.",

"rating": "93",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 00611666 replaces these: AP4355370, 611666 Back to Top",

```
"review_count": "11",  
"appliance": "dishwasher",  
"compatible_models": [  
  "63013902010",  
  "63013902011",  
  "63013903010",  
  "63013903011",  
  "63013909010",  
  "63013909011",  
  "63013909012",  
  "63013912010",  
  "63013912011",  
  "63013913010",  
  "63013913011",  
  "63013919010",  
  "63013919011",  
  "63077932010",  
  "63077932011",  
  "63077933010",  
  "63077933011",  
  "63077942011",  
  "63077943011",  
  "7701-7912)",  
  "7705-7912)",  
  "7712-8002)",  
  "7905-7912)",
```

"7908-8002)",

"8001-8003)",

"8002-8003)",

"8006)",

"8105)",

"DW244UB",

"DW244UW"

]

},

{

"part_name": "Dishrack Adjuster and Wheel Assembly WPW10571738",

"part_number": "PS11756470",

"manufacturer": null,

"price": "28.88",

"description": "This dishrack adjuster and wheel assembly is for dishwashers and lets you adjust the dishrack height and attaches the track wheels to the dishrack.",

"rating": "95",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher. Part# WPW10571738 replaces these: W10571738 Back to Top",

"review_count": "12",

"appliance": "dishwasher",

"compatible_models": [

"MDB4949SDE0",

"MDB4949SDE1",

"MDB4949SDE2",

"MDB4949SDE3",

"MDB4949SDH0",
"MDB4949SDH1",
"MDB4949SDH2",
"MDB4949SDH3",
"MDB4949SDM0",
"MDB4949SDM1",
"MDB4949SDM2",
"MDB4949SDM3",
"MDB4949SDZ0",
"MDB4949SHB0",
"MDB4949SHB1",
"MDB4949SHW0",
"MDB4949SHW1",
"MDB4949SHZ0",
"MDB4949SHZ1",
"MDB5969SDE0",
"MDB5969SDE1",
"MDB5969SDE2",
"MDB5969SDH0",
"MDB5969SDH1",
"MDB5969SDH2",
"MDB5969SDM0",
"MDB5969SDM1",
"MDB5969SDM2"

]

},

```
{  
  "part_name": "Dishrack Roller - Grey 00611475",  
  "part_number": "PS8727387",  
  "manufacturer": "Kenmore",  
  "price": "11.11",  
  "description": "This is a replacement dishrack roller or wheel for your dishwasher. It is made of gray plastic, measures a little over an inch in diameter, and is sold individually. This roller is designed for the lower dishrack of your dishwasher. On one side of the roller is a clip that allows it to be attached to the dishrack. The dishrack roller allows you to slide the dishrack in and out of the dishwasher efficiently. If one of the rollers is broken or missing, it can cause the dishrack to become difficult to slide in and out. To replace the roller, simply snap it off the dishrack, and snap the new one into place. This is a genuine OEM part.",  
  "rating": "95",  
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# 00611475 replaces these: AP4339780, 611475 Back to Top",  
  "review_count": "25",  
  "appliance": "dishwasher",  
  "compatible_models": [  
    "63013003012",  
    "63013003015",  
    "63013003016",  
    "63013003017",  
    "63013003018",  
    "63013023010",  
    "63013023011",  
    "63013023015",  
    "63013023016",
```

```
"63013023017",
"63013023018",
"63013993010",
"63013993012",
"63013993015",
"63013993016",
"63013993017",
"63013993018",
"DF240161",
"DF241161",
"DF241761",
"DF260141",
"DF260142",
"DF260161",
"DF260161F",
"DF260162",
"DF260760",
"DF260761",
"DF261161",
"DF261161F",
"DF261161S"
]
},
{
  "part_name": "Lower Dishrack Wheel Assembly WPW10195417",
  "part_number": "PS11750057",
```

"manufacturer": "Kenmore",

"price": "36.70",

"description": "This gray plastic lower dishrack roller is a part for your dishwasher. It attaches to the bottom of the lower dishrack, allowing it to move in and out smoothly. If the lower dishrack stops moving in and out easily or preventing you from being able to shut the dishwasher door, inspect the dishrack roller for damage. The assembly includes 2 rollers and the bracket that attaches to the dishrack (parts are not sold separately). This assembly is sold individually, so you will need 4 assemblies to replace them all in your appliance. For this easy repair, start by removing the lower dishrack from the appliance and set it on the counter. Use a screwdriver to pry off the old roller assembly from the lower tabs. Align the new part on the dishrack by snapping it in place.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't close | Door latch failure This part works with the following products: Dishwasher. Part# WPW10195417 replaces these: AP6016764, W10195417, WPW10195417VP Back to Top",

"review_count": "111",

"appliance": "dishwasher",

"compatible_models": [

"2214715N710",

"2214792N512",

"2214793N512",

"66512762K312",

"66512762K313",

"66512763K312",

"66512763K313",

"66512769K312",

"66512769K313",

"66512772K312",

"66512772K313",

```
"66512772K314",
"66512773K313",
"66512773K314",
"66512774K312",
"66512774K313",
"66512776K312",
"66512776K314",
"66512779K312",
"66512779K313",
"66512779K314",
"66512782K310",
"66512782K312",
"66512782K313",
"66512783K311",
"66512783K312",
"66512783K313",
"66512789K311",
"66512789K312",
"66512789K313"
]
},
{
  "part_name": "Lower Dishrack Wheel W10195416",
  "part_number": "PS3406971",
  "manufacturer": "Kenmore",
  "price": "46.00",
```

"description": "This OEM gray Dishwasher Lower Dishrack Wheel Assembly is a plastic kit that allows the rack to slide in and out of the dishwasher easily. If it breaks or becomes damaged, sliding will feel difficult. This can happen due to normal wear and tear, and the part should be replaced if this occurs. Check your model number and user manual to make sure this part is correct. It attaches directly to the dishrack. To repair, open the dishwasher door and pull out the lower dishrack. Next, push the tab from both sides and it should pop out. To install the new wheel assembly, place it on the rack and make sure the caps overlap the wire from the inside before you clip it in place by pushing the wheel. It measures roughly 3x6 inches.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Door won't close | Noisy | Door latch failure This part works with the following products: Dishwasher. Part# W10195416 replaces these: W10195416V, W10195416VP
Back to Top",

"review_count": "333",

"appliance": "dishwasher",

"compatible_models": [

"2213222N414",

"2213223N414",

"2213229N414",

"2214523N611",

"2214545N711",

"66213292K112",

"66213299K112",

"66513222N410",

"66513222N411",

"66513222N412",

"66513222N413",

"66513223N410",

```
"66513223N411",
"66513223N412",
"66513223N413",
"66513223N414",
"66513229N410",
"66513229N411",
"66513229N412",
"66513229N413",
"66513229N414",
"66513252K110",
"66513252K111",
"66513252K112",
"66513252K113",
"66513252K114",
"66513252K115",
"66513253K110",
"66513255K110",
"66513255K111"
]
},
{
  "part_name": "Dishwasher Door Gasket with Strike - Black W10542314",
  "part_number": "PS5136129",
  "manufacturer": "Kenmore",
  "price": "62.19",
```

"description": "This one-piece door gasket provides a water tight seal between the tub and the door, to keep water from leaking out of your dishwasher. If your dishwasher is leaking, tears, or there are gaps in your gasket, you may need to replace the door gasket. This black door gasket is made of rubber, includes a new latch strike plate for the door latch, and is a genuine OEM part.",

"rating": "93",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Not cleaning dishes properly | Door latch failure | Door won't close This part works with the following products: Dishwasher. Part# W10542314 replaces these: AP5650274, 2409202, W10542314, 8268888, W10284090, W10300589, W10350162, W10542314VP Back to Top",

"review_count": "62",

"appliance": "dishwasher",

"compatible_models": [

"66213032K112",

"66213273K112",

"66513012K110",

"66513012K111",

"66513012K112",

"66513012K113",

"66513013K110",

"66513013K111",

"66513013K112",

"66513013K113",

"66513014K110",

"66513014K111",

"66513014K112",

"66513014K113",


```
"66513019K110",
"66513019K111",
"66513019K112",
"66513019K113",
"66513023K110",
"66513023K111",
"66513023K112",
"66513023K113",
"66513032K110",
"66513032K111",
"66513032K112",
"66513032K113",
"66513033K110",
"66513033K111",
"66513033K112",
"66513033K113"
]
},
{
  "part_name": "GASKET TUB Stainless Steel WD08X22095",
  "part_number": "PS11721490",
  "manufacturer": null,
  "price": "17.00",
  "description": "",
  "rating": "93",
```

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# WD08X22095 replaces these: AP5986342, WD08X20591, WD08X20675 Back to Top",

"review_count": "8",

"appliance": "dishwasher",

"compatible_models": [

"CDT706P2M4S1",

"CDT706P2M5S1",

"CDT725SSF2SS",

"CDT725SSF4SS",

"CDT725SSF6SS",

"CDT725SSF7SS",

"CDT765SSF0SS",

"CDT765SSF1SS",

"CDT765SSF7SS",

"CDT800P2N0S1",

"CDT800P2N2S1",

"CDT800P2N3S1",

"CDT800P2N4S1",

"CDT800P2N5S1",

"CDT805M5N0S5",

"CDT805M5N2S5",

"CDT805M5N3S5",

"CDT805M5N4S5",

"CDT805P2N0S1",

"CDT805P2N1S1",

"CDT805P2N2S1",

"CDT805P2N3S1",
"CDT805P2N4S1",
"CDT805P2N5S1",
"CDT805P2N8S1",
"CDT835SMJ0DS",
"CDT835SMJ2DS",
"CDT835SMJ4DS",
"CDT835SMJ5DS",
"CDT835SSJ0SS"

]

},

{

"part_name": "Splash Shield Kit 154701001",

"part_number": "PS2203346",

"manufacturer": "Kenmore",

"price": "39.42",

"description": "This splash shield kit is used in dishwashers and is attached to the lower front corners of the tub. The splash shield is used to prevent water from spraying past the door seal. If your dishwasher is leaking from the corners of the door gasket, replace this part. For this repair, the only tool needed is a flathead screwdriver. The measurements of this part are: 1.50 inches in length, 0.50 inches in width, 1.70 inches in height. It weighs 0.10 pounds. Remember to unplug your appliance from the power source as a safety precaution.",

"rating": "98",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# 154701001 replaces these: AP4338941, 1465007, 154685101 Back to Top",

"review_count": "9",

"appliance": "dishwasher",

"compatible_models": [

"58714012405",

"58714012406A",

"58714012407A",

"58714012408A",

"58714012409B",

"58714012410B",

"58714013406",

"58714013407A",

"58714013408A",

"58714013409A",

"58714013410B",

"58714013411B",

"58714014405",

"58714014406A",

"58714014407A",

"58714014408A",

"58714014409B",

"58714014410B",

"58714019405",

"58714019406A",

"58714019407A",

"58714019408A",

"58714019409B",

"58714019410B",

"58714022200A",

"58714023200A",

"58714024200A",

"58714028200A",

"58714029200A",

"58714102800"

]

},

{

"part_name": "Seal WPW10497235",

"part_number": "PS11755651",

"manufacturer": "Kenmore",

"price": "11.13",

"description": "This part is the replacement door seal for your dishwasher. It is approximately 22 inches long and 2 inches wide. This door seal is made of gray plastic and is found at the bottom the dishwasher. The door seal is designed to seal the gap between the dishwasher tub and outer edge of the door. This helps to prevent leaks when your dishwasher is running. A leaking dishwasher is a good indication that the door seal is damaged. This seal is sold individually and is an OEM part sourced directly from the manufacturer.",

"rating": "80",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# WPW10497235 replaces these: AP6022318, W10195543, W10497235 Back to Top",

"review_count": "17",

"appliance": "dishwasher",

"compatible_models": [

"66512762K312",

"66512763K312",
"66512763K313",
"66512769K312",
"66512769K313",
"66512772K311",
"66512772K312",
"66512772K313",
"66512773K311",
"66512773K312",
"66512773K313",
"66512774K311",
"66512774K312",
"66512774K313",
"66512776K311",
"66512776K312",
"66512776K314",
"66512779K311",
"66512779K312",
"66512779K313",
"66512782K310",
"66512782K311",
"66512782K312",
"66512783K311",
"66512783K312",
"66512789K311",
"66512789K312",

```
"66512793K312",  
"66512803K312",  
"66512813K313"  
]  
,  
{  
  "part_name": "Dishwasher Tub Gasket WD08X23476",  
  "part_number": "PS11774412",  
  "manufacturer": null,  
  "price": "21.57",
```

"description": "The tub gasket, also known as the door gasket runs along the perimeter of your dishwasher basin and creates a seal that prevents water from leaking out when the tub is full. If you notice water on the floor after you run your dishwasher, it may be an indication that the gasket is loose or damaged. If your door gasket is damaged, it will need to be replaced. To replace the gasket, simply pull the old gasket out of the groove it rests in, and press the new gasket into place. This part is made of black rubber and is sold individually.",

```
"rating": "97",
```

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# WD08X23476 replaces these: AP6041569, WD08X10088, WD08X20674, WD08X22094 Back to Top",

```
"review_count": "31",
```

```
"appliance": "dishwasher",
```

```
"compatible_models": [  
  "ADT521PGF0BS",  
  "ADT521PGF0WS",  
  "ADT521PGF2BS",  
  "ADT521PGF2WS",  
]
```

"ADT521PGF4BS",
"ADT521PGF4WS",
"ADT521PGF6BS",
"ADT521PGF6WS",
"ADT521PGJ0BS",
"ADT521PGJ0WS",
"ADT521PGJ2BS",
"ADT521PGJ2WS",
"ADT521PGJBS",
"ADT521PGJWS",
"CDT725SSF0SS",
"DDT575SGF0BB",
"DDT575SGF0WW",
"DDT575SMF0ES",
"DDT575SSF0SS",
"GDF450PGR0BB",
"GDF450PGR0WW",
"GDF450PGR1BB",
"GDF450PGR1WW",
"GDF450PGR3BB",
"GDF450PGR3WW",
"GDF450PGRABB",
"GDF450PGRAWW",
"GDF450PSR0SS",
"GDF450PSR1SS",
"GDF450PSR3SS"


```
]
},
{
  "part_name": "Dishwasher Door Seal W11177741",
  "part_number": "PS12348515",
  "manufacturer": "Kenmore",
  "price": "67.47",
  "description": "Door seal seals the gap between the opening to the dishwasher tub and the outer edge of the door.",
  "rating": "94",
  "troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# W11177741 replaces these: AP6285721, W10300924, W10300924V, W10300924VP, W10660528 Back to Top",
  "review_count": "34",
  "appliance": "dishwasher",
  "compatible_models": [
    "2213222N414",
    "2213223N414",
    "2214523N611",
    "2214545N711",
    "2214715N710",
    "2214792N512",
    "2214793N512",
    "66512762K312",
    "66512762K313",
    "66512763K312",
    "66512763K313",
```

"66512769K312",
"66512769K313",
"66512772K312",
"66512772K313",
"66512772K314",
"66512773K313",
"66512773K314",
"66512774K312",
"66512774K313",
"66512776K311",
"66512776K312",
"66512776K314",
"66512779K312",
"66512779K313",
"66512779K314",
"66512782K310",
"66512782K311",
"66512782K312",
"66512782K313"

]

},

{

"part_name": "Dishwasher Door Bottom Seal 5304500204",
"part_number": "PS11703834",
"manufacturer": "Kenmore",
"price": "32.27",

"description": "This door seal is for dishwashers.\r\n\r\nDoor seal seals the gap between the opening to the dishwasher tub and the outer edge of the door.\r\n\r\nAfter installing the door seal, shut the dishwasher door and leave the door closed for several hours to properly seat the new door seal.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# 5304500204 replaces these: AP5962194
Back to Top",

"review_count": "19",

"appliance": "dishwasher",

"compatible_models": [

"004621710A",

"004621711A",

"58714012411B",

"58714012412B",

"58714012413B",

"58714012414B",

"58714012416B",

"58714013412B",

"58714013413B",

"58714013414B",

"58714013415B",

"58714013416B",

"58714013417B",

"58714014411B",

"58714014412B",

"58714014413B",

```
"58714019411B",
"58714019412B",
"58714019413B",
"58714019414B",
"58714019415B",
"58714019416B",
"804621670A",
"804621671A",
"804655850A",
"804655851A",
"CDB350NB10B",
"CDB350NB4A",
"CDB350NB5A",
"CDB350NB6B"
]
},
{
  "part_name": "Gasket WD08X21894",
  "part_number": "PS11700870",
  "manufacturer": null,
  "price": "8.54",
  "description": "This part is a replacement gasket for your dishwasher. The gasket creates a seal at the bottom of the dishwasher tub, so water does not leak out while the dishwasher is running. If you notice water leaking out onto the floor, you should inspect the gasket for damages and replace as necessary. The gasket is gray in color and is approximately 22 inches long. It is made of plastic and is sold individually. This is a genuine OEM part sourced directly from the manufacturer.",
```

"rating": "93",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# WD08X21894 replaces these: AP5980286, WD08X10090 Back to Top",

"review_count": "28",

"appliance": "dishwasher",

"compatible_models": [

"ADT521PGF0BS",

"ADT521PGF0WS",

"ADT521PGF2BS",

"ADT521PGF2WS",

"ADT521PGF4BS",

"ADT521PGF4WS",

"ADT521PGF6BS",

"ADT521PGF6WS",

"ADT521PGJ0BS",

"ADT521PGJ0WS",

"ADT521PGJ2BS",

"ADT521PGJ2WS",

"ADT521PGJBS",

"ADT521PGJWS",

"GDF450PGR1BB",

"GDF450PGR1WW",

"GDF450PGR3BB",

"GDF450PGR3WW",

"GDF450PGRABB",

"GDF450PGRAWW",

```
"GDF450PSR1SS",  
"GDF450PSR3SS",  
"GDF450PSRASS",  
"GDF460PGT3BB",  
"GDF460PGT3WW",  
"GDF460PST3SS",  
"GDF510PGD0BB",  
"GDF510PGD0WW",  
"GDF510PGD1BB",  
"GDF510PGD1WW"
```

```
]
```

```
},
```

```
{
```

```
"part_name": "Dishwasher Tub Gasket - Gray 154827601",
```

```
"part_number": "PS8260227",
```

```
"manufacturer": "Kenmore",
```

```
"price": "32.35",
```

```
"description": "This grey OEM dishwasher tub gasket is a 73\" grey rubber part that  
creates a seal around the dishwasher to prevent any water leakage during a cycle. If it's  
damaged or broken, you'll start seeing water leaking out. If broken, it should be replaced.  
Refer to your model number and user manual to ensure this part is right for you. When  
making this repair, open the dishwasher door and take out the lower dish tray for better  
access. Pull out the old gasket, and clean the channel with a rag. Push the new gasket into  
place into the notch on the door, which you should see upon close inspection, using a flat-  
head screwdriver for assistance if necessary. We do not recommend cutting any additional  
length off on the tub gasket if any is present during your repair.",
```

```
"rating": "95",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Door won't  
close | Not cleaning dishes properly This part works with the following products:
```

Dishwasher. Part# 154827601 replaces these: AP5690109, 2705419, 154827601, 154211801, 154219501, 154561001, 154561002, 154782401, 154845301 [Back to Top](#)",

"review_count": "42",

"appliance": "dishwasher",

"compatible_models": [

"004621710A",

"004621711A",

"58714000100",

"58714000101",

"58714000102",

"58714001991",

"58714001992",

"58714001993",

"58714002990",

"58714002991",

"58714002992",

"58714002993",

"58714003100",

"58714008001",

"58714008002",

"58714008003",

"58714009100",

"58714009101",

"58714009102",

"58714012400",

"58714012401",

"58714012402",
"58714012403",
"58714012404",
"58714012405",
"58714012406A",
"58714012407A",
"58714012408A",
"58714012409B",
"58714012410B"

]

},

{

"part_name": "Dishwasher Bottom Door Gasket 809006501",

"part_number": "PS9495545",

"manufacturer": "Kenmore",

"price": "21.06",

"description": "This dishwasher door gasket (Bottom Gasket, Gasket, Door Seal, Dishwasher Door Lower Seal) helps prevent water from leaking out of the bottom edge of your dishwasher door by creating a watertight seal. This part is attached to the bottom of your dishwasher inner door panel. It is frequently exposed to water and detergent during its lifetime. The water and chemicals can eventually wear down the gasket and compromise the integrity of the seal. If the gasket is malfunctioning, the integrity of the door seal will be effected. You will notice leaking through the bottom of your dishwasher door. If your dishwasher is leaking water from the bottom of the door, first inspect the seal for food particles near the bottom and sides, and remove the buildup, as it can stop the door from closing properly and keeping a tight seal; if not, you may need to replace the bottom door gasket. Check the door gasket for tears, cuts, or wear. This part is sold individually and measures 22.5 inches by 1.25 inches. It is constructed of plastic, and comes in yellow/grey. Includes one lower door gasket.",

"rating": "95",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Not cleaning dishes properly | Door won't close | Door latch failure This part works with the following products: Dishwasher. Part# 809006501 replaces these: AP5809675, 154297601, 154297602, 154297603, 154576501, 154588201, 154759101 Back to Top",

"review_count": "182",

"appliance": "dishwasher",

"compatible_models": [

"58714000100",

"58714000101",

"58714000102",

"58714001990",

"58714001991",

"58714001992",

"58714001993",

"58714002990",

"58714002991",

"58714002992",

"58714002993",

"58714003100",

"58714008001",

"58714008002",

"58714008003",

"58714009100",

"58714009101",

"58714009102",

"58714012400",

"58714012401",

```
"58714012402",
"58714012403",
"58714012404",
"58714012405",
"58714012406A",
"58714012407A",
"58714012408A",
"58714012409B",
"58714012410B",
"58714013400"
]
},
{
  "part_name": "RACK ASSEMBLY LOWER GREY 5304535379",
  "part_number": "PS17219658",
  "manufacturer": null,
  "price": "112.94",
  "description": "This dishrack is for dishwashers. The dishrack holds the dishes in place during the dishwashing cycle.",
  "rating": "95",
  "troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher. Part# 5304535379 replaces these: 154331605, 154331606, 154336009, 154336020, 5304491809, 5304517200 Back to Top",
  "review_count": "17",
  "appliance": "dishwasher",
  "compatible_models": [
```

"804621670A",
"804621671A",
"CDB350NB0A",
"CDB350NB10B",
"CDB350NW0A",
"CDB350NW10B",
"CDB400KB0",
"CDB400KB0A",
"CDB400KB1B",
"CDB400KW0",
"CDB400KW0A",
"CDB400KW1B",
"CDB500CGB0",
"CDB500CGB1",
"CDB500CGB2",
"CDB500CGB3",
"CDB500CGC0",
"CDB500CGC1",
"CDB500CGC2",
"CDB500CGC3",
"CDB500CGS0",
"CDB500CGS1",
"CDB500CGS2",
"CDB500CGS3",
"FDB1450CHB0",
"FDB1450CHB1",

```
"FDB1450CHB2",
"FDB1450CHB4",
"FDB1450CHB4A",
"FDB1450CHC0"
]
},
{
  "part_name": "RACK ASSEMBLY UPPER GREY 5304535380",
  "part_number": "PS17219659",
  "manufacturer": "Kenmore",
  "price": "112.02",
  "description": "",
  "rating": "95",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part#
5304535380 replaces these: 154331502, 5304498202, 5304498220, 5304517201,
5304517202 Back to Top",
  "review_count": "8",
  "appliance": "dishwasher",
  "compatible_models": [
    "58714000100",
    "58714000101",
    "58714000102",
    "58714001990",
    "58714001991",
    "58714001992",
    "58714001993",
    "58714002990",
```

"58714002991",
"58714002992",
"58714002993",
"58714003100",
"58714008001",
"58714008002",
"58714008003",
"58714009100",
"58714009101",
"58714009102",
"58714012400",
"58714012401",
"58714012402",
"58714012403",
"58714012404",
"58714012405",
"58714012406A",
"58714012407A",
"58714012408A",
"58714012409B",
"58714012410B",
"58714012411B"

]

},

{

"part_name": "BASKET ASM SILVERWARE WD28X24469",

"part_number": "PS12703061",

"manufacturer": null,

"price": "33.77",

"description": "This basket is part of a silverware basket that has 3 sections. This is the middle section of the basket.",

"rating": "92",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Leaking This part works with the following products: Dishwasher. Part# WD28X24469 replaces these: WD28X10037, WD28X10038, WD28X10040, WD28X10042, WD28X10058, WD28X10068, WD28X10106, WD28X10107, WD28X10108, WD28X10109, WD28X10153, WD28X10182, WD28X10209, WD28X24476, WD28X24477 Back to Top",

"review_count": "70",

"appliance": "dishwasher",

"compatible_models": [

"40201-0",

"402011",

"40205-0",

"402051",

"40206-0",

"402061",

"402070",

"403110",

"403111",

"405010",

"405011",

"405012",

"405050",

```
"405051",  
"405052",  
"405060",  
"405061",  
"405062",  
"4071100",  
"4071110",  
"4071120",  
"4071500",  
"4071510",  
"4071520",  
"4071600",  
"4071610",  
"4071620",  
"CDWT980V00SS",  
"CDWT980V05SS",  
"CDWT980V50SS"
```

```
]
```

```
},
```

```
{
```

```
"part_name": "Rack Carrier Kit - Right or Left side WD28X27241",
```

```
"part_number": "PS16219735",
```

```
"manufacturer": null,
```

```
"price": "14.70",
```

```
"description": "This part is the replacement carrier roller for your dishwasher. It is also  
known as the wheel support. It is made of gray plastic and is approximately 5 inches by 2  
inches. The carrier roller supports the wheels on your upper dish rack so it can slide in and
```

out of the dishwasher efficiently. This part has been redesigned by the manufacturer. This part can now be used on the right or left side of the rack. Because it is made of plastic, the roller can occasionally crack and break, and when this occurs, it will need to be replaced. If you notice that your dish rack is having difficulty sliding in and out, you should check to see if the roller is damaged. This is an OEM part from the manufacturer and it is sold individually. The roller itself, is replacement part number WD12X26146. The cover is no longer needed when replacing the rack carrier kit.",

"rating": "90",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WD28X27241 replaces these: WD12X10438, WD12X10439, WD12X10447, WD12X22656, WD12X22657 Back to Top",

"review_count": "6",

"appliance": "dishwasher",

"compatible_models": [

"ADT521PGF0BS",

"ADT521PGF0WS",

"ADT521PGF2BS",

"ADT521PGF2WS",

"ADT521PGF4BS",

"ADT521PGF4WS",

"ADT521PGF6BS",

"ADT521PGF6WS",

"ADT521PGJ0BS",

"ADT521PGJ0WS",

"ADT521PGJ2BS",

"ADT521PGJ2WS",

"ADT521PGJBS",

"ADT521PGJWS",

"DDT575SGF0BB",
"DDT575SGF0WW",
"DDT575SGF2BB",
"DDT575SGF2WW",
"DDT575SGF4BB",
"DDT575SGF4WW",
"DDT575SGF5BB",
"DDT575SGF5WW",
"DDT575SGF6BB",
"DDT575SGF6WW",
"DDT575SGF7BB",
"DDT575SGF7WW",
"DDT575SGF8BB",
"DDT575SGF8WW",
"DDT575SMF0ES",
"DDT575SMF2ES"

]

},

{

"part_name": "Upper Spray Arm Mount WP8539324",

"part_number": "PS11746245",

"manufacturer": "Kenmore",

"price": "10.38",

"description": "This upper spray arm mount has been redesigned by the manufacturer, so it not longer requires a clip and screw to be installed. To replace this part, first remove the rack stops from the upper dish rack and pull out the dish rack to work on it. Remove the screw holding the spray arm in place, take off the spray arm and slide out the feeding tube.

Flip the rack over to remove the mounting bracket from the mount. Snap the new mount into place and replace the other parts.",

"rating": "92",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Leaking | Noisy | Door won't close This part works with the following products: Dishwasher. Part# WP8539324 replaces these: AP6013024, 8268844, 8539324, 9742994, WP8539324VP Back to Top",

"review_count": "60",

"appliance": "dishwasher",

"compatible_models": [

"110773811",

"110773812",

"110773813",

"110773881",

"110773882",

"110773883",

"66515622000",

"66515624000",

"66515627000",

"66515629000",

"66515632000",

"66515634000",

"66515637000",

"66515639000",

"66515652000",

"66515654000",

"66515659000",

```
"66515682000",  
"66515684000",  
"66515689000",  
"66515701890",  
"66515701891",  
"66515701892",  
"66515702990",  
"66515705890",  
"66515705891",  
"66515705892",  
"66515707990",  
"66515708890",  
"66515708891"
```

```
]
```

```
},
```

```
{
```

```
"part_name": "Seal W10864081",
```

```
"part_number": "PS11731683",
```

```
"manufacturer": "Kenmore",
```

```
"price": "76.91",
```

```
"description": "This is a seal, but you may also know it as a door gasket and it is for your  
dishwasher. The seal forms a watertight barrier between the door and the dishwasher tub,  
detering water from escaping during a wash cycle. If your dishwasher is leaking you will  
need to replace the seal, as it is likely damaged. The first step should be to check the seal  
for buildup of food particles near the sides and the bottom of your appliance.",
```

```
"rating": "77",
```

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Dishwasher. Part# W10864081 replaces these: AP6004030, 8269110, W10179427, W10835073, WPW10179427 Back to Top",

"review_count": "13",

"appliance": "dishwasher",

"compatible_models": [

"2213222N414",

"2213223N414",

"2213229N414",

"2214523N611",

"2214545N711",

"2214715N710",

"2214792N512",

"2214793N512",

"665110739120",

"665110739130",

"665110739140",

"665110739190",

"66512762K312",

"66512762K313",

"66512763K312",

"66512763K313",

"66512769K312",

"66512769K313",

"66512772K312",

"66512772K313",

"66512772K314",

"66512773K313",

"66512773K314",

"66512774K312",

"66512774K313",

"66512776K311",

"66512776K312",

"66512776K314",

"66512779K312",

"66512779K313"

]

},

{

"part_name": "ROLLER CARRIER WD12X28078",

"part_number": "PS16226065",

"manufacturer": null,

"price": "22.43",

"description": "This part is the replacement carrier roller for your dishwasher. It is also known as the wheel support. It is made of gray plastic and is approximately 5 inches by 2 inches. The carrier roller supports the wheels on your upper dish rack so it can slide in and out of the dishwasher efficiently. This roller is for the right side of the dish rack, the left side is sold separately. Because it is made of plastic, the roller can occasionally crack and break, and when this occurs, it will need to be replaced. If you notice that your dish rack is having difficulty sliding in and out, you should check to see if the roller is damaged. This is an OEM part from the manufacturer and it is sold individually.",

"rating": "20",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WD12X28078 replaces these: WD12X10446, WD12X26144 Back to Top",

"review_count": "1",

"appliance": "dishwasher",

"compatible_models": [

"ADT521PGF0BS",

"ADT521PGF0WS",

"ADT521PGF2BS",

"ADT521PGF2WS",

"ADT521PGF4BS",

"ADT521PGF4WS",

"ADT521PGF6BS",

"ADT521PGF6WS",

"ADT521PGJ0BS",

"ADT521PGJ0WS",

"ADT521PGJ2BS",

"ADT521PGJ2WS",

"ADT521PGJBS",

"ADT521PGJWS",

"DDT575SGF0BB",

"DDT575SGF0WW",

"DDT575SGF2BB",

"DDT575SGF2WW",

"DDT575SGF4BB",

"DDT575SGF4WW",

"DDT575SGF5BB",

"DDT575SGF5WW",

"DDT575SGF6BB",

"DDT575SGF6WW",

```
"DDT575SGF7BB",
"DDT575SGF7WW",
"DDT575SGF8BB",
"DDT575SGF8WW",
"DDT575SMF0ES",
"DDT575SMF2ES"
]
},
{
  "part_name": "LOWER RACK ROLLER AND STUD ASSEMBLY WD12X27747",
  "part_number": "PS16618942",
  "manufacturer": null,
  "price": "9.95",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Back  
to Top",
  "review_count": null,
  "appliance": "dishwasher",
  "compatible_models": [
    "GDF450PGR0BB",
    "GDF450PGR0WW",
    "GDF450PGR1BB",
    "GDF450PGR1WW",
    "GDF450PGR3BB",
    "GDF450PGR3WW",
```

"GDF450PGRABB",
"GDF450PGRAWW",
"GDF450PSR0SS",
"GDF450PSR1SS",
"GDF450PSR3SS",
"GDF450PSRASS",
"GDF460PGT3BB",
"GDF460PGT3WW",
"GDF460PST3SS",
"GDF510PGR0BB",
"GDF510PGR0WW",
"GDF510PGR1BB",
"GDF510PGR1WW",
"GDF510PGR3BB",
"GDF510PGR3WW",
"GDF510PGR5BB",
"GDF510PSR0SS",
"GDF510PSR1SS",
"GDF510PSR3SS",
"GDF510PSR5SS",
"GDF510PSRASS",
"GDF511PGR0BB",
"GDF511PGR0WW",
"GDF511PGR1BB"
]
},


```
{
```

```
"part_name": "Circulation Pump W11612326",
```

```
"part_number": "PS16744934",
```

```
"manufacturer": "Kenmore",
```

```
"price": "69.99",
```

```
"description": "This circulation pump is a genuine OEM replacement part designed for use in dishwashers. It is responsible for circulating water throughout the dishwasher during the wash and rinse cycles. The circulation pump draws water from the dishwasher tub, pressurizes it, and then distributes it to the spray arms, which spray the water onto the dishes to remove food particles and debris. The circulation pump may fail due to several reasons such as an electrical fault, a blockage in the pump impeller, motor failure, or physical damage. A faulty pump will result in water leakages, unusually loud noises during use, reduced water circulation, and poor cleaning performance.",
```

```
"rating": "96",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Will Not Start This part works with the following products: Dishwasher. Part# W11612326 replaces these: W10805386, W10879262, W11521435 Back to Top",
```

```
"review_count": "5",
```

```
"appliance": "dishwasher",
```

```
"compatible_models": [
```

```
"2213809N710",
```

```
"2217383N710",
```

```
"2217389N710",
```

```
"66513002N511",
```

```
"66513003N511",
```

```
"66513004N511",
```

```
"66513009N511",
```

```
"66513802N710",
```

```
"66513803N710",
```

"66513804N710",
"66513809N710",
"66514312N413",
"66514313N413",
"66514319N413",
"66514422N511",
"66514423N511",
"66514429N511",
"66514502N020",
"66514509N020",
"66515112K218",
"66515113K218",
"66515114K218",
"66515119K218",
"66517152K217",
"66517159K217",
"66517382N710",
"66517383N710",
"66517389N710",
"66517482N710",
"66517489N710"

]

},

{

"part_name": "Lower Dishrack with Wheels WD28X26099",

"part_number": "PS12743260",

"manufacturer": null,

"price": "86.92",

"description": "Note: This \"Service Rack\" fits numerous models. Per factory, on some models, it may be necessary to move the silverware basket to the inside of the rack along the right side.",

"rating": "91",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher. Part# WD28X26099 replaces these: AP6980564, WD28X10370, WD28X10372, WD28X21715, WD28X21717, WD28X22358, WD28X22506, WD28X22619, WD28X22696, WD28X24396, WD28X24478, WD28X25959, WD28X26103 Back to Top",

"review_count": "96",

"appliance": "dishwasher",

"compatible_models": [

"ADT521PGF0BS",

"ADT521PGF2BS",

"ADT521PGF4BS",

"ADT521PGF4WS",

"ADT521PGF6BS",

"ADT521PGF6WS",

"ADT521PGJBS",

"ADT521PGJWS",

"DDT575SGF0BB",

"DDT575SGF0WW",

"DDT575SGF4BB",

"DDT575SGF4WW",

"DDT575SGF5BB",

"DDT575SGF5WW",

"DDT575SGF6BB",
"DDT575SGF6WW",
"DDT575SGF7BB",
"DDT575SGF7WW",
"DDT575SGF8BB",
"DDT575SGF8WW",
"DDT575SMF0ES",
"DDT575SMF4ES",
"DDT575SMF5ES",
"DDT575SMF6ES",
"DDT575SMF7ES",
"DDT575SMF8ES",
"DDT575SSF0SS",
"DDT575SSF4SS",
"DDT575SSF5SS",
"DDT575SSF6SS"

]

},

{

"part_name": "MID SPRAY ARM WD22X33498",

"part_number": "PS17137080",

"manufacturer": null,

"price": "22.49",

"description": "This OEM mid spray or center wash arm assembly distributes water and detergent in your dishwasher during the wash cycle. It has small nozzles that spray water onto your dishes and is located between the lower and upper rack. A broken assembly will result in weak water flow and ineffective dishwashing. It may also display signs of damage

such as cracks, breaks, or missing nozzles. Additionally, a malfunctioning assembly can cause imbalanced water flow, potentially leading to damage to other dishwasher components such as filters or pumps. Prompt replacement is necessary to ensure proper dishwashing performance and prevent further damage. To install this to your appliance, you will need to snap its mounting bracket onto the rack before attaching the arms onto it. This replacement part is sold individually.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Noisy This part works with the following products: Dishwasher. Part# WD22X33498 replaces these: WD22X10089, WD22X26622, WD22X27740 Back to Top",

"review_count": "10",

"appliance": "dishwasher",

"compatible_models": [

"ADT521PGF0BS",

"ADT521PGF0WS",

"ADT521PGF2BS",

"ADT521PGF2WS",

"ADT521PGF4BS",

"ADT521PGF4WS",

"ADT521PGF6BS",

"ADT521PGF6WS",

"ADT521PGJ0BS",

"ADT521PGJ0WS",

"ADT521PGJ2BS",

"ADT521PGJ2WS",

"CDT800P2N2S1",

"CDT800P2N3S1",

"CDT800P2N4S1",

"CDT800P2N5S1",
"DDT575SGF0BB",
"DDT575SGF0WW",
"DDT575SGF2BB",
"DDT575SGF2WW",
"DDT575SGF4BB",
"DDT575SGF4WW",
"DDT575SGF5BB",
"DDT575SGF5WW",
"DDT575SGF6BB",
"DDT575SGF6WW",
"DDT575SGF7BB",
"DDT575SGF7WW",
"DDT575SGF8BB",
"DDT575SGF8WW"

]

},

{

"part_name": "Upper Rack Assembly WD28X30219",

"part_number": "PS16618975",

"manufacturer": null,

"price": "74.96",

"description": "This dishrack is for dishwashers. The dishrack holds the dishes in place during the dishwashing cycle. Follow the instructions in the manual when installing this part.",

"rating": "89",

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly This part works with the following products: Dishwasher. Part# WD28X30219 replaces these: WD28X10347, WD28X10348, WD28X10352, WD28X22626, WD28X23156, WD28X24397, WD28X24421, WD28X25018, WD28X25189, WD28X25190, WD28X25491, WD28X25656, WD28X26104 Back to Top",

"review_count": "40",

"appliance": "dishwasher",

"compatible_models": [

"ADT521PGF0BS",

"ADT521PGF0WS",

"ADT521PGF2BS",

"ADT521PGF2WS",

"ADT521PGJ0BS",

"ADT521PGJ0WS",

"ADT521PGJ2BS",

"ADT521PGJ2WS",

"ADT521PGJBS",

"ADT521PGJWS",

"CDT725SSF0SS",

"DDT575SGF0BB",

"DDT575SGF0WW",

"DDT575SMF0ES",

"DDT575SSF0SS",

"GDF450PGR1BB",

"GDF450PGR1WW",

"GDF450PGR3WW",

"GDF450PGRABB",

"GDF450PGRAWW",
"GDF450PSR1SS",
"GDF450PSR3SS",
"GDF460PGT3BB",
"GDF460PGT3WW",
"GDF460PST3SS",
"GDF510PGD0BB",
"GDF510PGD0WW",
"GDF510PGD1BB",
"GDF510PGD1WW",
"GDF510PGD2BB"

]

},

{

"part_name": "LOWER RACK ROLLER WD12X26146",

"part_number": "PS16217024",

"manufacturer": null,

"price": "13.11",

"description": "This is a lower rack roller for your dishwasher. It attaches in the lower roller assembly on the bottom of your rack to allow the rack to smoothly slide in and out. This replacement part is 1.5 inches in diameter and is charcoal in color. There are four rollers in total, please consider replacing your other rollers at the same time as they may be wearing at the same rate. Sold individually.",

"rating": "94",

"troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WD12X26146 replaces these: WD12X10435 Back to Top",

"review_count": "20",

"appliance": "dishwasher",

"compatible_models": [

"ADT521PGF0BS",

"ADT521PGF0WS",

"ADT521PGF2BS",

"ADT521PGF2WS",

"ADT521PGF4BS",

"ADT521PGF4WS",

"ADT521PGF6BS",

"ADT521PGF6WS",

"ADT521PGJ0BS",

"ADT521PGJ0WS",

"ADT521PGJ2BS",

"ADT521PGJ2WS",

"ADT521PGJBS",

"ADT521PGJWS",

"CDT706P2M4S1",

"CDT706P2M5S1",

"CDT725SSF0SS",

"CDT725SSF2SS",

"CDT725SSF4SS",

"CDT725SSF6SS",

"CDT725SSF7SS",

"CDT800P2N0S1",

"CDT800P2N2S1",

"CDT800P2N3S1",

```
"CDT800P2N4S1",  
"CDT800P2N5S1",  
"CDT805M5N0S5",  
"CDT805M5N2S5",  
"CDT805M5N3S5",  
"CDT805M5N4S5"  
]  
},  
{  
  "part_name": "LOWER SPRAY ARM WD22X33499",  
  "part_number": "PS17137081",  
  "manufacturer": null,  
  "price": "19.70",
```

"description": "This lower spray arm assembly in your dishwasher distributes water and detergent during the washing cycle by spinning around and spraying water in different directions. You can usually find it attached to a support or hub at the bottom of the dishwasher. If this part is broken, you might notice some signs. You might hear a knocking or banging sound coming from the dishwasher. The spray arm may not rotate properly or might seem wobbly. It is important to replace a damaged arm assembly as your dishes will not get cleaned properly, and they will still have dirt on them even after a wash cycle. It can also cause the dishwasher to have a bad smell because of leftover food residue. To remove your existing arm assembly, you will need to release its locking mechanism before lifting it out of your appliance. Please be informed that this OEM-verified part is sold individually.",

```
"rating": "97",
```

"troubleshooting_tips": "This part fixes the following symptoms: Not cleaning dishes properly | Noisy | Leaking This part works with the following products: Dishwasher. Part# WD22X33499 replaces these: WD22X10091, WD22X25962, WD22X26621, WD22X27724
Back to Top",

```
"review_count": "27",
```

```
"appliance": "dishwasher",
```

"compatible_models": [

"ADT521PGF0BS",

"ADT521PGF0WS",

"ADT521PGF2BS",

"ADT521PGF2WS",

"ADT521PGF4BS",

"ADT521PGF4WS",

"ADT521PGF6BS",

"ADT521PGF6WS",

"ADT521PGJ0BS",

"ADT521PGJ0WS",

"ADT521PGJ2BS",

"ADT521PGJ2WS",

"CDT800P2N2S1",

"CDT800P2N3S1",

"CDT800P2N4S1",

"CDT800P2N5S1",

"DDT575SGF0BB",

"DDT575SGF0WW",

"DDT575SGF2BB",

"DDT575SGF2WW",

"DDT575SGF4BB",

"DDT575SGF4WW",

"DDT575SGF5BB",

"DDT575SGF5WW",

"DDT575SGF6BB",

```
"DDT575SGF6WW",
"DDT575SGF7BB",
"DDT575SGF7WW",
"DDT575SGF8BB",
"DDT575SGF8WW"
]
},
{
  "part_name": "Lower Rack And Swb Replacement Kit WD28X28918",
  "part_number": "PS16618974",
  "manufacturer": null,
  "price": "91.18",
  "description": "This dish rack is for dishwashers. Dish rack holds the dishes in place during the dish washing cycle",
  "rating": "96",
  "troubleshooting_tips": "This part works with the following products: Dishwasher. Part# WD28X28918 replaces these: WD28X10349, WD28X10371, WD28X22659, WD28X23157, WD28X25958 Back to Top",
  "review_count": "18",
  "appliance": "dishwasher",
  "compatible_models": [
    "ADT521PGF0WS",
    "ADT521PGF2WS",
    "ADT521PGJ0BS",
    "ADT521PGJ0WS",
    "ADT521PGJ2BS",
    "ADT521PGJ2WS",
```

"GDF510PGD4BB",
"GDF510PGD4WW",
"GDF510PGD6BB",
"GDF510PGD6WW",
"GDF510PGJ0BB",
"GDF510PGJ0WW",
"GDF510PGJ2BB",
"GDF510PGJ2WW",
"GDF510PGJ4BB",
"GDF510PGJ4WW",
"GDF510PGJ5BB",
"GDF510PGJ5WW",
"GDF510PGJ6BB",
"GDF510PGJ6WW",
"GDF510PMD4SA",
"GDF510PMD6SA",
"GDF510PMJ0SA",
"GDF510PMJ2SA",
"GDF510PMJ4SA",
"GDF510PMJ5SA",
"GDF510PMJ6SA",
"GDF510PSD4SS",
"GDF510PSD6SS",
"GDF510PSJ0SS"

]

},

```
{
```

```
"part_name": "CONFIGURED UI BOARD WD21X31902C",
```

```
"part_number": "PS17137058",
```

```
"manufacturer": null,
```

```
"price": "216.55",
```

```
"description": "This is the user interface control board for various dishwashers. The user interface panel is what you directly interact with on your dishwasher to start and stop it and select the specific cycle you want. If your user interface panel is not responding and you have tested your dishwasher to ensure no other part could be at fault, it will need to be replaced immediately for it to regain function. Replacing this panel will requires some disassembly of your dishwasher, and will require tools like a screwdriver, wrench, and a pair of pliers. This OEM user interface panel measures approximately 14-inches wide and is sold individually.",
```

```
"rating": "97",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start This part works with the following products: Dishwasher. Part# WD21X31902C replaces these: WD21X22175, WD21X22236, WD21X22804, WD21X22955, WD21X22956, WD21X23462, WD21X23702, WD21X23709, WD21X26178, WD21X31902, WD21X32000 Back to Top",
```

```
"review_count": "19",
```

```
"appliance": "dishwasher",
```

```
"compatible_models": [
```

```
"GDF610PGJ0BB",
```

```
"GDF610PGJ0WW",
```

```
"GDF610PGJ2BB",
```

```
"GDF610PGJ2WW",
```

```
"GDF610PGJ4BB",
```

```
"GDF610PGJ4WW",
```

```
"GDF610PGJ5BB",
```

```
"GDF610PGJ5WW",
```

"GDF610PGJ6BB",
"GDF610PGJ6WW",
"GDF610PMJ0ES",
"GDF610PMJ2ES",
"GDF610PMJ4ES",
"GDF610PMJ5ES",
"GDF610PMJ6ES",
"GDF610PSJ0SS",
"GDF610PSJ2SS",
"GDF610PSJ4SS",
"GDF610PSJ5SS",
"GDF610PSJ6SS",
"GDF620HGJ0BB",
"GDF620HGJ0WW",
"GDF620HGJ2BB",
"GDF620HGJ2WW",
"GDF620HGJ4BB",
"GDF620HGJ4WW",
"GDF620HGJ5BB",
"GDF620HGJ5WW",
"GDF620HGJ6BB",
"GDF620HGJ6WW"

]

},

{

"part_name": "TRANSFORMER 00628522",

```
"part_number": "PS8729253",  
"manufacturer": null,  
"price": "122.98",  
"description": "",  
"rating": null,  
"troubleshooting_tips": "This part works with the following products: Freezer,  
Refrigerator. Part# 00628522 replaces these: AP5669120, 00623752, 623752, 628522  
Back to Top",  
"review_count": null,  
"appliance": "refrigerator",  
"compatible_models": [  
  "B18IF800SP",  
  "B30BB830SS",  
  "B30IR800SP",  
  "B36BT830NS",  
  "T18ID800LP",  
  "T18ID800RP",  
  "T18IF800SP",  
  "T24ID800LP",  
  "T24IF800SP",  
  "T24IR800SP",  
  "T30BB810SS",  
  "T30BB820SS",  
  "T30IB800SP",  
  "T30IF800SP",  
  "T30IR800SP"  
]
```



```
},  
{  
  "part_name": "DEFLECTOR 2176095",  
  "part_number": "PS326755",  
  "manufacturer": "Kenmore",  
  "price": "52.19",  
  "description": "",  
  "rating": null,  
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#  
2176095 replaces these: AP2981156, 448887, 2176095 Back to Top",  
  "review_count": null,  
  "appliance": "refrigerator",  
  "compatible_models": [  
    "10650442900",  
    "10650442901",  
    "10650442902",  
    "10650442903",  
    "10650443900",  
    "10650443901",  
    "10650443902",  
    "10650443903",  
    "10650444900",  
    "10650444901",  
    "10650444902",  
    "10650444903",  
    "10650446900",
```

```
"10650446901",
"10650446902",
"10650446903",
"10650449900",
"10650449901",
"10650449902",
"10650449903",
"10650452900",
"10650452901",
"10650452902",
"10650452903",
"10650453900",
"10650453901",
"10650453902",
"10650453903",
"10650454900",
"10650454901"
]
},
{
  "part_name": "Chute WP67006534",
  "part_number": "PS11743698",
  "manufacturer": "Kenmore",
  "price": "64.13",
  "description": "",
  "rating": null,
```

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WP67006534 replaces these: 67004120, 67005036, 67006534 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"59655652500",

"59655653500",

"59655654500",

"59655659500",

"59655662500",

"59655663500",

"59655664500",

"59655669500",

"59657012600",

"59657013600",

"59657016600",

"59657019600",

"59657043600",

"59657049600",

"59657053600",

"59657059600",

"ACD2232HRB",

"ACD2232HRB0",

"ACD2232HRS",

"ACD2232HRS0",

"ACD2232HRW",

```
"ACD2232HRW0",
"ACD2234HRB",
"ACD2234HRQ",
"ACD2234HRS",
"ACD2234HRW",
"ACD2234KRS",
"ACD2238HTS",
"ASD2324HEB",
"ASD2324HEQ"
]
},
{
  "part_name": "Chute WP13005702B",
  "part_number": "PS11738675",
  "manufacturer": null,
  "price": "144.46",
  "description": "",
  "rating": "90",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
WP13005702B replaces these: 13005702B, W10187470 Back to Top",
  "review_count": "2",
  "appliance": "refrigerator",
  "compatible_models": [
    "JFI2089AEB10",
    "JFI2089AEB2",
    "JFI2089AEP10",
```

"JFI2089AEP12",
"JFI2089AEP13",
"JFI2089AEP14",
"JFI2089AEP2",
"JFI2089AEP3",
"JFI2089AEP4",
"JFI2089AEP5",
"JFI2089AEP6",
"JFI2089AEP7",
"JFI2089AEP8",
"JFI2089AEP9",
"JFI2089AES10",
"JFI2089AES2",
"JFI2089AES3",
"JFI2089AEW10",
"JFI2089AEW2",
"JFI2089ATS2",
"JFI2089WES0",
"JFI2089WES1",
"JFI2089WES10",
"JFI2089WES2",
"JFI2089WES3",
"JFI2089WES4",
"JFI2089WES5",
"JFI2089WES6",
"JFI2089WES8",

```
"JFI2089WES9"
]
},
{
  "part_name": "DEFLECTOR W10261263",
  "part_number": "PS4704374",
  "manufacturer": "Kenmore",
  "price": "9.41",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "10676392410",
    "10676392411",
    "10676392412",
    "10676392413",
    "10676393411",
    "10676393412",
    "10676393413",
    "10676399411",
    "10676399412",
    "10676399413",
    "10686393310",
```

```
"10686399310",  
"WRT111SFAB00",  
"WRT111SFAF00",  
"WRT111SFAW00",  
"WRT111SFDB00",  
"WRT111SFDB01",  
"WRT111SFDB02",  
"WRT111SFDB03",  
"WRT111SFDM00",  
"WRT111SFDM01",  
"WRT111SFDM02",  
"WRT111SFDM03",  
"WRT111SFDW00",  
"WRT111SFDW01",  
"WRT111SFDW02",  
"WRT111SFDW03"  
]  
,  
{  
  "part_name": "DEFLECTOR W10157765",  
  "part_number": "PS2338558",  
  "manufacturer": "Kenmore",  
  "price": "35.25",  
  "description": "",  
  "rating": null,
```

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# W10157765 replaces these: W10157765 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"10672002010",

"10672002011",

"10672002013",

"10672002015",

"10672003010",

"10672003011",

"10672003012",

"10672003013",

"10672003014",

"10672003016",

"10672003017",

"10672003018",

"10672009010",

"10672009011",

"10672009013",

"10672009015",

"10672013017",

"596467934251",

"596467934351",

"596467934451",

"596467934951",


```
"59672002010",
"59672002011",
"59672002013",
"59672002015",
"59672003010",
"59672003011",
"59672003012",
"59672003013",
"59672003014"
]
},
{
  "part_name": "Dispenser Funnel Chute - White WP13005704W",
  "part_number": "PS11738679",
  "manufacturer": "Kenmore",
  "price": "172.25",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WP13005704W replaces these: 13005704W Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "59678332800",
    "59678332801",
    "59678332802",
```

"59678333800",
"59678333801",
"59678333802",
"59678339800",
"59678339801",
"59678532800",
"59678532801",
"59678532802",
"59678533800",
"59678533801",
"59678533802",
"59678539800",
"59678539801",
"59679242010",
"59679242011",
"59679242012",
"59679242013",
"59679242015",
"59679242016",
"59679242017",
"59679243010",
"59679243011",
"59679243016",
"59679243017",
"59679249010",
"59679249011",

```
"59679249012"
]
},
{
  "part_name": "CHUTE 5303918484",
  "part_number": "PS3409460",
  "manufacturer": "Kenmore",
  "price": "25.97",
  "description": "",
  "rating": "60",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 5303918484 replaces these: AP4565656, 242105401 Back to Top",
  "review_count": "2",
  "appliance": "refrigerator",
  "compatible_models": [
    "25370312211",
    "25370312212",
    "25370312213",
    "25370312214",
    "25370313210",
    "25370313211",
    "25370313212",
    "25370313213",
    "25370313214",
    "25370319211",
    "25370319212",
```

```
"25370319213",  
"25370319214",  
"CFD26WIS0",  
"CFD26WIS1",  
"CFD26WIS3",  
"CFD26WIS4",  
"CFD26WIS5",  
"CFD26WIS6",  
"CFD27WIPB2",  
"CFD27WIPS2",  
"CFD27WIPW2",  
"CFD28WIB5",  
"CFD28WIB6",  
"CFD28WIB8",  
"CFD28WIB9",  
"CFD28WIBA",  
"CFD28WIBB",  
"CFD28WIBC",  
"CFD28WIQB0"  
]  
,  
{  
  "part_name": "Chute WP13005705",  
  "part_number": "PS11738680",  
  "manufacturer": null,  
  "price": "214.80",
```

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WP13005705 replaces these: AP6005628, 13005703AP, 13005705, W10191149, W10192824 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"7MI2569VEM1",

"7MI2569VEM10",

"7MI2569VEM2",

"7MI2569VEM3",

"7MI2569VEM4",

"KFIS20XVBL00",

"KFIS20XVBL1",

"KFIS20XVBL2",

"KFIS20XVMS00",

"KFIS20XVMS1",

"KFIS20XVMS10",

"KFIS20XVMS11",

"KFIS20XVMS2",

"KFIS20XVMS3",

"KFIS20XVMS4",

"KFIS20XVMS5",

"KFIS20XVMS6",

"KFIS20XVMS7",

"KFIS20XVMS8",

```
"KFIS20XVWH00",
"KFIS20XVWH1",
"KFIS20XVWH2",
"KFIS25XVBL00",
"KFIS25XVBL1",
"KFIS25XVMS00",
"KFIS25XVMS1",
"KFIS25XVMS10",
"KFIS25XVMS2",
"KFIS25XVMS3",
"KFIS25XVMS4"
]
},
{
  "part_name": "Chute WP13005703W",
  "part_number": "PS11738677",
  "manufacturer": null,
  "price": "251.36",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WP13005703W replaces these: 13005703Q, 13005703W, W10191155 Back to Top",
  "review_count": "1",
  "appliance": "refrigerator",
  "compatible_models": [
    "KFIS20XVBL00",
```

"KFIS20XVBL1",
"KFIS20XVBL2",
"KFIS20XVBL3",
"KFIS20XVBL4",
"KFIS20XVBL5",
"KFIS20XVBL7",
"KFIS20XVBL8",
"KFIS20XVMS00",
"KFIS20XVMS1",
"KFIS20XVMS2",
"KFIS20XVWH00",
"KFIS20XVWH1",
"KFIS20XVWH2",
"KFIS20XVWH3",
"KFIS20XVWH4",
"KFIS20XVWH5",
"KFIS20XVWH7",
"KFIS20XVWH8",
"KFIS25XVBL00",
"KFIS25XVBL1",
"KFIS25XVBL2",
"KFIS25XVBL3",
"KFIS25XVBL4",
"KFIS25XVBL5",
"KFIS25XVBL6",
"KFIS25XVMS00",

```
"KFIS25XVMS1",
"KFIS25XVWH00",
"KFIS25XVWH1"
]
},
{
  "part_name": "Dispenser Funnel Chute - Grey WP13005706",
  "part_number": "PS11738681",
  "manufacturer": "Kenmore",
  "price": "149.10",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
WP13005706 replaces these: 13005706 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "596379243017",
    "59678332800",
    "59678332801",
    "59678332802",
    "59678333800",
    "59678333801",
    "59678333802",
    "59678333803",
    "59678339800",
```


"59678339801",
"59678532800",
"59678532801",
"59678532802",
"59678533800",
"59678533801",
"59678533802",
"59678539800",
"59678539801",
"59679242010",
"59679242011",
"59679242016",
"59679242017",
"59679243010",
"59679243011",
"59679243012",
"59679243013",
"59679243014",
"59679243016",
"59679243017",
"59679243018"

]

},

{

"part_name": "Defrost Heater with Thermostat WR51X442",

"part_number": "PS303933",

"manufacturer": "Kenmore",

"price": "126.79",

"description": "This part assembly has 2 functions: The defrost heater keeps the cooling coils from frosting over and the thermostat senses that the heat near the cooling coils has reached the desired temperature. Used with side by side models.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Freezer not defrosting | Freezer section too warm | Frost buildup This part works with the following products: Refrigerator. Part# WR51X442 replaces these: AP2071464, 1972, WR51X442, WR51X0342, WR51X0371, WR51X0442, WR51X0463, WR51X342, WR51X371, WR51X463 Back to Top",

"review_count": "16",

"appliance": "refrigerator",

"compatible_models": [

"36348042890",

"36348042891",

"36348042892",

"36348042893",

"36348047890",

"36348047891",

"36348047892",

"36348047893",

"36348252890",

"36348252891",

"36348252892",

"36348252893",

"36348257890",

"36348257891",

```
"36348257892",
"36348257893",
"36358042890",
"36358042891",
"36358042892",
"36358042893",
"36358047890",
"36358047891",
"36358047892",
"36358047893",
"36358062890",
"36358062891",
"36358062892",
"36358062893",
"36358067890",
"36358067891"
]
},
{
  "part_name": "DEFROST HEATER WP12729128",
  "part_number": "PS11738607",
  "manufacturer": "Kenmore",
  "price": "88.43",
  "description": "",
  "rating": "100",
```

"troubleshooting_tips": "This part fixes the following symptoms: Freezer not defrosting | Fridge too warm | Frost buildup This part works with the following products: Refrigerator. Part# WP12729128 replaces these: AP6005557, 12729128 Back to Top",

"review_count": "1",

"appliance": "refrigerator",

"compatible_models": [

"10672002010",

"10672002011",

"10672002013",

"10672002015",

"10672003010",

"10672003011",

"10672003012",

"10672003013",

"10672003014",

"10672003016",

"10672003017",

"10672003018",

"10672009010",

"10672009011",

"10672009013",

"10672009015",

"596467934251",

"596467934351",

"596467934451",

"596467934951",

"59665232404",

```
"59665232405",
"59665234404",
"59665234405",
"59665239404",
"59665239405",
"59665332602",
"59665333602",
"59665339602",
"59666122702"
]
},
{
  "part_name": "Defrost Heater WR51X10038",
  "part_number": "PS303768",
  "manufacturer": null,
  "price": "75.70",
  "description": "Also known as Heater Conduction.",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Freezer not defrosting | Freezer section too warm | Frost buildup This part works with the following products: Refrigerator. Part# WR51X10038 replaces these: AP2639820, 880036, WR51X10051 Back to Top",
  "review_count": "3",
  "appliance": "refrigerator",
  "compatible_models": [
    "36211XBMBRWW",
    "36211XBMDRWW",
```

"36211XBMERWW",
"36211XBMFRWW",
"36211XBRERWW",
"36211XBRFRWW",
"36411XBRERWW",
"36411XBRFRWW",
"37511KBSARWW",
"37511KBSEWW",
"38181KBPARWW",
"38181KBPCRWW",
"38181KBRARWW",
"38185KBPARBB",
"38185KBPCRBB",
"38185KBRARBB",
"38187KBPARCC",
"38187KBPCRCC",
"38187KBRARCC",
"38341FBMERWW",
"38341FBMFRWW",
"38351HBMERWW",
"38351HBMFRWW",
"38351HBRERWW",
"38351HBRFRWW",
"38371PBRBRWW",
"38451HBRERWW",
"38451HBRFRWW",

```
"38471PBRBRWW",
"38471PBRDRWW"
]
},
{
  "part_name": "Defrost Heater 5303918410",
  "part_number": "PS2369212",
  "manufacturer": "Kenmore",
  "price": "100.91",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm |
Freezer not defrosting This part works with the following products: Refrigerator. Part#
5303918410 replaces these: AP4455011, 75303918410 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "20462151B",
    "2537034241E",
    "2537034241F",
    "2537034241H",
    "2537034241J",
    "2537034341F",
    "2537034341G",
    "2537034341H",
    "2537034341J",
    "25370347411",
```

```
"2537034941H",
"2537034941J",
"2537041341C",
"2537041341F",
"2537041341H",
"25370417410",
"25370417412",
"2537041941C",
"2537041941D",
"2537044341A",
"2537044341C",
"2537044341D",
"2537044341E",
"25370447411",
"90462157B",
"CFD26SDS0",
"CFD26WIS0",
"CFD26WIS1",
"CFD26WIS3",
"CFD26WIS4"
]
},
{
  "part_name": "Defrost Heater 216730700",
  "part_number": "PS426768",
  "manufacturer": "Kenmore",
```


"price": "90.72",

"description": "This part is located at the bottom of the evaporator. The defrost heater heats the evaporator in the defrost mode of operation to keep the cooling coils from frosting over. The thermostat must be replaced when replacing the defrost heater.",

"rating": null,

"troubleshooting_tips": "This part fixes the following symptoms: Frost buildup This part works with the following products: Freezer, Refrigerator. Part# 216730700 replaces these: AP2113768, 890572, 297216100, 297216101, 7216730700, 7297216100 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"25321021100",

"25321021101",

"25321021102",

"25321021103",

"25321021104",

"25321021105",

"25321041100",

"25321041101",

"25321041102",

"25321041103",

"25321041104",

"25321041105",

"25321041107",

"25321041108",

"25321082100",

"25321082101",

"25321082102",
"25321082103",
"25321082104",
"25321082106",
"25321082107",
"25321721100",
"25321721101",
"25321721102",
"25321721103",
"25321741100",
"25321741101",
"25321741102",
"25321741103",
"25321741104"

]

},

{

"part_name": "Defrost Heater 242044113",

"part_number": "PS2581596",

"manufacturer": "Kenmore",

"price": "81.86",

"description": "",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Freezer not defrosting |
Fridge too warm | Frost buildup This part works with the following products: Refrigerator.
Part# 242044113 replaces these: AP4527302, 240316107, 241940201, 7240316107,
7241940201 Back to Top",

```
"review_count": "2",  
"appliance": "refrigerator",  
"compatible_models": [  
  "25344302400",  
  "25344302401",  
  "25344303400",  
  "25344303401",  
  "25344303402",  
  "25344303403",  
  "25344304400",  
  "25344304401",  
  "25344309400",  
  "25344309401",  
  "25344333600",  
  "25344333601",  
  "25344333602",  
  "25344333603",  
  "25344333604",  
  "25344333605",  
  "25344333606",  
  "25344333607",  
  "25344333608",  
  "25344333609",  
  "2534433360A",  
  "25344352400",  
  "25344352401",
```

```
"25344352403",
"25344352404",
"25344352405",
"25344352406",
"25344352407",
"25344352408",
"25344352409"
]
},
{
  "part_name": "Defrost Heater Harness Kit WR51X10101",
  "part_number": "PS1993872",
  "manufacturer": "Kenmore",
  "price": "61.62",
  "description": "This dual heater kit replaces the single heater. It's redesigned to use two heating elements for a better defrost cycle.",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Freezer section too warm | Freezer not defrosting | Freezer too cold This part works with the following products: Refrigerator. Part# WR51X10101 replaces these: AP4355467, 1399613, WR51X10101, WR51X10032, WR51X10053, WR51X10097 Back to Top",
  "review_count": "15",
  "appliance": "refrigerator",
  "compatible_models": [
    "36348042894",
    "36348042896",
    "36348042897",
```

"36348047894",
"36348047896",
"36348047897",
"36348252894",
"36348252896",
"36348252897",
"36348257894",
"36348257896",
"36348257897",
"36350221000",
"36350222000",
"36350227000",
"36350232000",
"36350237000",
"36350242000",
"36350247000",
"36358042894",
"36358042896",
"36358042897",
"36358047894",
"36358047896",
"36358047897",
"36358062894",
"36358062896",
"36358062897",
"36358067894",

"36358067897"

]

},

{

"part_name": "FLIPPER MULLION Assembly COMPL XL WPW10624451",

"part_number": "PS11756814",

"manufacturer": "Kenmore",

"price": "101.18",

"description": "",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# WPW10624451 replaces these: W10434693, W10448918, W10624451 Back to Top",

"review_count": "3",

"appliance": "refrigerator",

"compatible_models": [

"10673002510",

"10673002511",

"10673003510",

"10673003511",

"10673009510",

"10673009511",

"10679402410",

"10679472410",

"10679472411",

"10679473410",

"10679473411",

```
"59673002510",
"59673003510",
"59673009510",
"KFFS20EYBL00",
"KFFS20EYBL01",
"KFFS20EYBL02",
"KFFS20EYBL04",
"KFFS20EYMS00",
"KFFS20EYMS01",
"KFFS20EYMS02",
"KFFS20EYMS04",
"KFFS20EYWH00",
"KFFS20EYWH01",
"KFFS20EYWH02",
"KFFS20EYWH04",
"KRFF300EBL00",
"KRFF300ESS00",
"KRFF300ESS01",
"KRFF300ESS03"
]
},
{
  "part_name": "Mullion Articulation Assembly WR17X12591",
  "part_number": "PS2340319",
  "manufacturer": null,
  "price": "182.80",
```

"description": "Also known as a mullion heater. This mullion rail is white in colour. The door mullion rail creates an airtight seal between the doors on a French door refrigerator.",

"rating": "84",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# WR17X12591 replaces these: AP4363643, 1477374, WR17X12591, WR17X12591, WR17X12596 Back to Top",

"review_count": "11",

"appliance": "refrigerator",

"compatible_models": [

"GFRF2KBXAWW",

"GFRF2KBYAWW",

"GFRF2KBYCWW",

"GFRF2KBYHWW",

"GFSF2HCYAWW",

"GFSF2HCYCWW",

"GFSF2HCYHWW",

"GFSF2KEXACC",

"GFSF2KEXAWW",

"GFSF2KEYACC",

"GFSF2KEYAWW",

"GFSF2KEYCCC",

"GFSF2KEYCWW",

"GFSF2KEYHCC",

"GFSF2KEYHWW",

"GFSL2KEXALS",

"GFSL2KEYALS",

"GFSL2KEYCLS",

"GFSL2KEYHLS",
"GFSS2HCYASS",
"GFSS2HCYCSS",
"GFSS2HCYHSS",
"GFSS2HCYJ SS",
"GFSS2HCYJSS",
"GFSS2KEXASS",
"GFSS2KEYASS",
"GFSS2KEYCSS",
"GFSS2KEYHSS",
"GNE22GGAEFWW",
"GNE22GGEBFWW"

]

},

{

"part_name": "Defrost Heater and Bracket Assembly WR51X10055",

"part_number": "PS303781",

"manufacturer": "Kenmore",

"price": "106.41",

"description": "The defrost heater keeps the cooling coils from frosting over. The heater will get hot and melt any ice or frost build up around the coils.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Freezer not defrosting | Freezer section too warm | Frost buildup This part works with the following products: Refrigerator. Part# WR51X10055 replaces these: AP3183311, 914088, WR51X10055, WR51X10030 Back to Top",

"review_count": "30",

"appliance": "refrigerator",

"compatible_models": [

"36350622000",

"36350627000",

"36358072894",

"36358072896",

"36358075894",

"36358075896",

"36358077894",

"36358077896",

"36358472894",

"36358472896",

"36358472897",

"36358475894",

"36358475896",

"36358475897",

"36358477894",

"36358477896",

"36358477897",

"36358772894",

"36358772896",

"36358775894",

"36358775896",

"36358777894",

"36358777896",

"36358892894",

"36358892896",

"36358892897",

"36358892898",

"36358895894",

"36358895896",

"36358895897"

]

},

{

"part_name": "Electronic Control WPW10310240",

"part_number": "PS11752535",

"manufacturer": "Kenmore",

"price": "562.88",

"description": "This electronic board manages and monitors the cooling and defrost times of your refrigerator and other functions. If your refrigerator is not cooling properly because the dispenser is flapping between open or closed positions, or there are problems with the display lights flashing, replacing your control board can be the solution. Remember to unplug your refrigerator from the power source before beginning this installation project. Refer to the manual provided by the manufacturer for installation instructions and accurate guidance.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start This part works with the following products: Refrigerator. Part# WPW10310240 replaces these: AP6019229, 12920717SP, 12920719SP, 12920721, 12920724, W10162662, W10164420, W10164422, W10165854, W10191108, W10213583, W10310240 Back to Top",

"review_count": "2",

"appliance": "refrigerator",

"compatible_models": [

"59677532601",

"59677532602",
"59677532603",
"59677533601",
"59677533602",
"59677533603",
"59677539601",
"59677539602",
"59677539603",
"59678332800",
"59678332801",
"59678333800",
"59678333801",
"59678333803",
"59678339800",
"59678339801",
"59678339802",
"59678532800",
"59678532801",
"59678533800",
"59678533801",
"59678539800",
"59678539801",
"59678539802",
"59679242012",
"59679243012",
"59679243014",

```
"59679249012",
"7GI5FSAXVY00",
"7GI5FSAXVY1"
]
},
{
  "part_name": "CONTROL 297415203",
  "part_number": "PS12364256",
  "manufacturer": "Kenmore",
  "price": "99.96",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
297415203 replaces these: AP6285803, 297415201, 297415202 Back to Top",
  "review_count": "1",
  "appliance": "refrigerator",
  "compatible_models": [
    "25360722013",
    "25360722014",
    "25360722015",
    "25370722410",
    "FFRU17B2QWA",
    "FFRU17B2QWB",
    "FFRU17B2QWC",
    "FFRU17B2QWD",
    "FFRU17B2QWE",
```

```
"FFRU17G8QWA",
"FFRU17G8QWB",
"FFRU17G8QWC",
"FRU17B2JW24",
"FRU17B2JW25",
"FRU17B2JW26",
"FRU17G4JW23",
"FRU17G4JW24",
"FRU17G4JW25"
]
},
{
  "part_name": "Defrost Timer Kit - 120V 60Hz R0131577",
  "part_number": "PS2167006",
  "manufacturer": "Kenmore",
  "price": "31.79",
  "description": "The timer will shut off the cooling system of the refrigerator and the defrost heater will turn on.",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Freezer section too warm | Freezer not defrosting | Fridge runs too long This part works with the following products: Refrigerator. Part# R0131577 replaces these: AP4246797, 1156627, R0131577, 0312555, 101229304, 10129304, 10530702, 10530703, 14205006, 14205629, 14206787, 14212499, 312555, 4344280, 8170404, D3932103, D70041-4, D7004101, D7004104, D7004110 ... Show more , D7790403, R0131577, R0131577VP, Y0312555, Y312555 Show less Back to Top",
  "review_count": "3",
  "appliance": "refrigerator",
```

```
"compatible_models": [  
  "1999A",  
  "1999A-P1193906WL",  
  "1999CIW",  
  "1999CIWA",  
  "1999CIWL-P1121502WL",  
  "1999CIWW",  
  "1999CIWW-P1121502WW",  
  "1999W",  
  "1999W-P1193906WW",  
  "2599A",  
  "2599A-P1190419WL",  
  "2599CIWA",  
  "2599CIWL-P1121501WL",  
  "2599CIWW",  
  "2599CIWW-P1121501WW",  
  "2599W",  
  "2599W-P1190419WW",  
  "2699A",  
  "2699W",  
  "35271",  
  "35271-P1121805W",  
  "35271W-P1121805WW",  
  "35278",  
  "35278-P1121806W",  
  "35278L-P1121806WL",
```

```
"35501",
"35501-P1121711W",
"35501W-P1121711WW",
"35508",
"35508-P1121712W"
]
},
{
  "part_name": "Defrost Timer WR9X489",
  "part_number": "PS310858",
  "manufacturer": "Kenmore",
  "price": "50.67",
  "description": "This device acts like a clock. It continually advances and alternates between activating the cooling cycle and the defrost heater.",
  "rating": "91",
  "troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Freezer section too warm | Freezer not defrosting | Fridge runs too long This part works with the following products: Refrigerator. Part# WR9X489 replaces these: AP2061695, 2578, WR9X489, WR09X0427, WR09X0469, WR09X0488, WR09X0489, WR9X427, WR9X469, WR9X488 Back to Top",
  "review_count": "13",
  "appliance": "refrigerator",
  "compatible_models": [
    "36348042890",
    "36348042891",
    "36348042892",
    "36348042893",
```


"36348042894",
"36348042896",
"36348042897",
"36348047890",
"36348047891",
"36348047892",
"36348047893",
"36348047894",
"36348047896",
"36348047897",
"36348252890",
"36348252891",
"36348252892",
"36348252893",
"36348252894",
"36348252896",
"36348252897",
"36348257890",
"36348257891",
"36348257892",
"36348257893",
"36348257894",
"36348257896",
"36348257897",
"36350221000",
"36350222000"

```
]
},
{
  "part_name": "Capacitor,Electric Appliance Film,Box 0CZZJB2014L",
  "part_number": "PS3517229",
  "manufacturer": "LG",
  "price": "39.80",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator,
Freezer. Part# 0CZZJB2014L replaces these: AP4591438, 0CBZJB2001E, 0CZZJB2012G,
0CZZJB2012J, 0CZZJB2014D Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "46_66012",
    "46_66812",
    "46_66815",
    "65002",
    "65004",
    "65009",
    "65012",
    "65014",
    "65019",
    "65202",
    "65204",
    "65209",
```

```
"65212",
"65214",
"65219",
"68002",
"68003",
"68006",
"68009",
"68032",
"68033",
"68036",
"68039",
"68272",
"68274",
"68279",
"69004",
"69009",
"69292",
"69293"
]
},
{
  "part_name": "Capacitor WR55X24065",
  "part_number": "PS10065391",
  "manufacturer": "Kenmore",
  "price": "55.81",
```

"description": "This part helps the compressor kick on and off while maintaining a constant temperature to keep things frozen in your freezer.",

"rating": null,

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start | Freezer section too warm This part works with the following products: Refrigerator, Freezer. Part# WR55X24065 replaces these: WR62X0050, WR62X0080, WR62X10046, WR62X10049, WR62X10053, WR62X50, WR62X80 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"36211XBMBRWW",

"36211XBMERWW",

"36211XBRERWW",

"36357552790",

"36357552791",

"36357557790",

"36357557791",

"36358092890",

"36358095890",

"36358097890",

"36358472890",

"36358472893",

"36358472894",

"36358472896",

"36358475890",

"36358475893",

"36358475894",

"36358475896",

"36358477890",

"36358477893",

"36358477894",

"36358477896",

"36358482890",

"36358482893",

"36358485890",

"36358485893",

"36358551890",

"36358552890",

"36358557890",

"36358572890"

]

},

{

"part_name": "CAPACITOR 5304470340",

"part_number": "PS2351333",

"manufacturer": "Kenmore",

"price": "9.92",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator, Freezer. Part# 5304470340 replaces these: AP4374147, 5304513803 Back to Top",

"review_count": null,

"appliance": "refrigerator",

```
"compatible_models": [  
  "25317512710",  
  "25317812710",  
  "25317822710",  
  "25370013810",  
  "FFBN1721TV0",  
  "FFCL1542AW",  
  "FFCL2042AW",  
  "FFCL2542AW",  
  "FFPT10F0KB0",  
  "FFPT10F0KM0",  
  "FFPT10F0KV0",  
  "FFPT10F0KW0",  
  "FFPT12F0KB0",  
  "FFPT12F0KM0",  
  "FFPT12F0KV0",  
  "FFPT12F0KW0",  
  "FRQG1721AV",  
  "FRT105GW0",  
  "FRT125GW0"  
]  
},  
{  
  "part_name": "Run Capacitor 218909912",  
  "part_number": "PS817298",  
  "manufacturer": "Kenmore",
```

"price": "58.87",

"description": "This part helps the compressor kick on and off while maintaining a constant temperature to keep things frozen in your freezer.",

"rating": "87",

"troubleshooting_tips": "This part fixes the following symptoms: Won't start | Will Not Start | Too warm | Freezer section too warm This part works with the following products: Refrigerator, Freezer. Part# 218909912 replaces these: AP3267296, 1014579, 216787800, 7218909912 Back to Top",

"review_count": "3",

"appliance": "refrigerator",

"compatible_models": [

"25311301100",

"25311311100",

"25311312100",

"25311312101",

"25311521100",

"25311521102",

"25311531100",

"25311531101",

"25311541100",

"25311541102",

"25311711100",

"25311911100",

"25311911101",

"25312021101",

"25312541100",

"25313051100",

```
"25313500101",
"25313500102",
"25313500103",
"25313511101",
"25313511102",
"25313711101",
"25313711102",
"25313712101",
"25313911100",
"25313911102",
"25314502100",
"25314502101",
"25314512100",
"25314512101"
]
},
{
  "part_name": "Run Capacitor 297286802",
  "part_number": "PS3408827",
  "manufacturer": "Kenmore",
  "price": "41.85",
  "description": "This part helps the compressor kick on and off while maintaining a
constant temperature to keep things frozen in your freezer.",
  "rating": "80",
  "troubleshooting_tips": "This part fixes the following symptoms: Won't start | Fridge too
warm | Too warm This part works with the following products: Freezer, Refrigerator. Part#
```


297286802 replaces these: AP4587598, 216696700, 216985000, 216985002, 216985010, 218909911, 297286801 [Back to Top](#)",

"review_count": "5",

"appliance": "refrigerator",

"compatible_models": [

"25311301101",

"25311511100",

"25311511101",

"25311711101",

"25311711102",

"25312112410",

"25312512410",

"25312512411",

"25312810510",

"25312812510",

"25312822510",

"25312912410",

"25313500100",

"25313511100",

"25313711100",

"25313712100",

"25314502102",

"25314502103",

"25314502104",

"25314502105",

"25314512102",

"25314512103",

"25314512104",

"25314702102",

"25314702103",

"25314702104",

"25314712102",

"25314712103",

"25314922101",

"25314932101"

]

},

{

"part_name": "Run Capacitor WR55X24064",

"part_number": "PS11764031",

"manufacturer": "Kenmore",

"price": "77.06",

"description": "This part helps the compressor kick on and off while maintaining a constant temperature to keep things frozen in your freezer. This part has been updated by the manufacturer and may appear different than the original, but should function the same.",

"rating": "86",

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start | Fridge too warm | Freezer section too warm | Fridge and Freezer are too warm This part works with the following products: Refrigerator, Freezer, Range. Part# WR55X24064 replaces these: AP6031641, RF-1400-022, RF-1400-07, RF-1400-17, WB38X10104, WB38X10106, WR55X20800, WR55X23731, WR55X30629, WR62X055, WR62X10018, WR62X10040, WR62X10048, WR62X79, WR87X27279 Back to Top",

"review_count": "7",

"appliance": "refrigerator",

"compatible_models": [

"31181-1",

"31191-1",

"31261-1",

"31261-2",

"31261-3",

"31269-1",

"31271-1",

"31271-2",

"31271-3",

"31291-1",

"31291-2",

"31291-3",

"31296-1",

"31296-2",

"31299-1",

"31299-2",

"31341-1",

"31361-1",

"31361-2",

"31371-1",

"31371-2",

"31391-1",

"31391-2",

"31396-1",

```
"31396-2",
"31399-1",
"31399-2",
"31461-1",
"31491-1",
"31496-1"
]
},
{
  "part_name": "Capacitor WPW10350564",
  "part_number": "PS11753490",
  "manufacturer": "Kenmore",
  "price": "72.95",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Will Not Start | Fridge and Freezer are too warm | Fridge too warm This part works with the following products: Refrigerator, Freezer. Part# WPW10350564 replaces these: AP6020176, W10350564 Back to Top",
  "review_count": "1",
  "appliance": "refrigerator",
  "compatible_models": [
    "10641122211",
    "10641122212",
    "10641122213",
    "10641123211",
    "10641123212",
```

"10641129211",
"10641129212",
"10641129213",
"10641132710",
"10641132712",
"10641133710",
"10641133712",
"10641139710",
"10641139712",
"10641152210",
"10641152211",
"10641153210",
"10641153211",
"10641154210",
"10641159210",
"10641159211",
"10641159212",
"10641162310",
"10641163310",
"10641169310",
"10641172710",
"10641172711",
"10641172713",
"10641172714",
"10641173710"

]

```
},
```

```
{
```

```
"part_name": "Run Capacitor 5304464438",
```

```
"part_number": "PS2333670",
```

```
"manufacturer": "Kenmore",
```

```
"price": "53.48",
```

```
"description": "The run capacitor helps the compressor kick on and off while maintaining a constant temperature in your fridge and freezer. You may need to replace your run capacitor if your refrigerator or freezer section will not start, if they are too warm, or if your refrigerator has become too noisy. Replacing the run capacitor is a relatively easy project. For this repair you will only need a 1/4 inch nut driver and needle nose pliers. Remember to disconnect the power and water supply line to the unit before you begin this repair. For full step by step instructions, simply click on the video below.",
```

```
"rating": "92",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start | Fridge too warm | Freezer section too warm | Too warm This part works with the following products: Refrigerator, Freezer, Wine and Beverage Cooler. Part# 5304464438 replaces these: AP4315853, 1381223, 5304464438, 216236200, 216236300, 216985003, 218719201, 218909901, 218909913, 3015552, 3017761, 3091424, 5303289028, 5303310070, 7218909913, 75304464438, F000300399, F300399 Back to Top",
```

```
"review_count": "9",
```

```
"appliance": "refrigerator",
```

```
"compatible_models": [
```

```
"25310301000",
```

```
"25310301001",
```

```
"25310311000",
```

```
"25310311001",
```

```
"25310311002",
```

```
"25311312102",
```

"25311321100",
"25311321101",
"25311351100",
"25311351101",
"25311351102",
"25311521103",
"25311531102",
"25311821100",
"25311821101",
"25312021100",
"25312021102",
"25312541102",
"25312551100",
"25313009100",
"25313051101",
"25313051102",
"25313051103",
"25313351100",
"25313551100",
"25313551101",
"25314092101",
"25314092102",
"25314092103",
"25314342101"

]

},

```
{
```

```
"part_name": "Run Capacitor - 120V 297286803",
```

```
"part_number": "PS3495561",
```

```
"manufacturer": "Kenmore",
```

```
"price": "38.37",
```

```
"description": "This part helps the compressor kick on and off while maintaining a constant temperature to keep things frozen in your freezer. The run capacitor is attached to the compressor. This part is 120 volts and 15 mfd. The run capacitor helps the compressor kick on and off while maintaining a constant temperature to keep things frozen in your freezer. If your refrigerator is too warm, will not start, or your freezer section is too warm, you may need to replace this part. This is a genuine OEM part. Please remember to disconnect power to your refrigerator before starting your repair.",
```

```
"rating": "89",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Won't start | Fridge too warm | Will Not Start | Too warm This part works with the following products: Refrigerator, Freezer. Part# 297286803 replaces these: AP5306470, 215329902, 216985001, 218909915, 297286804, 7216985001, 7218909915 Back to Top",
```

```
"review_count": "16",
```

```
"appliance": "refrigerator",
```

```
"compatible_models": [
```

```
"25312112411",
```

```
"25316082100",
```

```
"25316082101",
```

```
"25316082106",
```

```
"25316092100",
```

```
"25316092101",
```

```
"25316582100",
```

```
"25316582101",
```

```
"25316592100",
```



```
"25316592101",  
"25321042410",  
"25321242410",  
"25321742510",  
"25321742512",  
"25321742513",  
"25321742515",  
"25321742516",  
"25322040510",  
"25322042410",  
"25322042411",  
"25322042412",  
"25322052610",  
"25322052611",  
"25322442410",  
"25322442412",  
"25322442413",  
"25322442414",  
"25322742410",  
"25326052101",  
"25326062101"  
]  
},  
{  
  "part_name": "Crisper Drawer Roller 242236801",  
  "part_number": "PS7321350",
```

"manufacturer": "Kenmore",

"price": "27.57",

"description": "Sold individually.",

"rating": "20",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 242236801 replaces these: AP5669872, 242236802 Back to Top",

"review_count": "1",

"appliance": "refrigerator",

"compatible_models": [

"25370312212",

"25370312213",

"25370312214",

"25370313212",

"25370313213",

"25370313214",

"25370319212",

"25370319213",

"25370319214",

"25370342210",

"25370342410",

"25370342411",

"25370342412",

"25370342413",

"25370342414",

"25370342415",

"25370342416",

"25370342417",

"25370342418",

"25370342419",

"2537034241A",

"2537034241B",

"2537034241C",

"25370343210",

"25370343410",

"25370343411",

"25370343412",

"25370343413",

"25370343414",

"25370343415"

]

},

{

"part_name": "ROLLER Assembly WR02X13658",

"part_number": "PS8757904",

"manufacturer": null,

"price": "8.06",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator, Range.
Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"CFE28TP2MBS1",

"CFE28TP2MCS1",

"CFE28TP2MDS1",

"CFE28TP2MES1",

"CFE28TP2MFS1",

"CFE28TP2MGS1",

"CFE28TP2MHS1",

"CFE28TP2MIS1",

"CFE28TP2MJS1",

"CFE28TP2MKS1",

"CFE28TP3MBD1",

"CFE28TP3MBW2",

"CFE28TP3MCD1",

"CFE28TP3MDD1",

"CFE28TP3MFD1",

"CFE28TP3MGD1",

"CFE28TP3MHD1",

"CFE28TP3MID1",

"CFE28TP3MJD1",

"CFE28TP3MKD1",

"CFE28TP4MBW2",

"CFE28TP4MCW2",

"CFE28TP4MDW2",

"CFE28TP4MEW2",

"CFE28TP4MFW2",

```
"CFE28TP4MGW2",
"CFE28TP4MHW2",
"CFE28TP4MIW2",
"CFE28TP4MJW2",
"CFE28TP4MKW2"
]
},
{
  "part_name": "Axle WPW10257246",
  "part_number": "PS11751309",
  "manufacturer": "Kenmore",
  "price": "33.71",
  "description": "Sold individually.",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
WPW10257246 replaces these: W10257246 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "10641162310",
    "10641163310",
    "10641169310",
    "1064651773510",
    "10651132210",
    "10651133210",
    "10651134210",
```

```
"10651135610",  
"10651136210",  
"10651139210",  
"10651139214",  
"10651142110",  
"10651142111",  
"10651143110",  
"10651143111",  
"10651149110",  
"10651149111",  
"10651149112",  
"10651152110",  
"10651153110",  
"10651153111",  
"10651153112",  
"10651159110",  
"10651162210",  
"10651163210",  
"10651164210",  
"10651169210",  
"10651172310",  
"10651173310",  
"10651179310"  
]  
,  
{
```

"part_name": "Single Roller - Left Front WPW10515763",

"part_number": "PS11755876",

"manufacturer": "Kenmore",

"price": "51.52",

"description": "Sold individually.",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Refrigerator, Freezer. Part# WPW10515763 replaces these: AP6022543, W10130460, W10212382, W10237085, W10275850, W10515763 Back to Top",

"review_count": "3",

"appliance": "refrigerator",

"compatible_models": [

"10669312310",

"10672002010",

"10672002011",

"10672002013",

"10672002015",

"10672003010",

"10672003011",

"10672003012",

"10672003013",

"10672003014",

"10672003016",

"10672003017",

"10672003018",

"10672009010",

"10672009011",

"10672009013",
"10672009015",
"10672012010",
"10672013010",
"10672013017",
"10672019010",
"596379243017",
"596467934251",
"596467934351",
"596467934451",
"596467934951",
"59665332602",
"59665333602",
"59665339602",
"59666022703"

]

},

{

"part_name": "Ice Auger Motor Shaft WP2188917",

"part_number": "PS11739142",

"manufacturer": "Kenmore",

"price": "60.39",

"description": "This part is the drive shaft for the auger.",

"rating": "96",

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker won't dispense ice | Ice maker not making ice This part works with the following products:

Refrigerator. Part# WP2188917 replaces these: AP6006077, 2188916, 2188917, 2198624, 2220187, 2220188, 2221087, 8206730, 999536, WP999536 Back to Top",

"review_count": "18",

"appliance": "refrigerator",

"compatible_models": [

"10641522500",

"10641523500",

"10641524500",

"10641529500",

"10644022600",

"10644022601",

"10644022602",

"10644022603",

"10644023600",

"10644023601",

"10644023602",

"10644023603",

"10644024600",

"10644029600",

"10644029601",

"10644029602",

"10644029603",

"10644032600",

"10644032601",

"10644032602",

"10644032603",

```
"10644033600",
"10644033601",
"10644033602",
"10644033603",
"10644034600",
"10644039600",
"10644039601",
"10644039602",
"10644039603"
]
},
{
  "part_name": "WHEEL PAN COVER WR01X10209",
  "part_number": "PS283653",
  "manufacturer": "Kenmore",
  "price": "9.48",
  "description": "",
  "rating": "20",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
WR01X10209 replaces these: AP3669902, 912670, WR1X10209 Back to Top",
  "review_count": "1",
  "appliance": "refrigerator",
  "compatible_models": [
    "ADR20KGEARWW",
    "ADR20KSEARES",
    "ADRF0MBZARWW",
```

"ADRF0MBZBRWW",
"ADRF0MBZGRWW",
"ADRS0MBZARSS",
"ADRS0MBZBRSS",
"ADRS0MBZGRSS",
"CFRS2MIDASS",
"CNE22SSEAFSS",
"CNR22SSEAFES",
"CNS23SSHAFSS",
"CSCP5UGXAFSS",
"CSCP5UGXCFSS",
"CSCP5UGXDFSS",
"CSDP5UGDBFSS",
"CSHS5UGXBSS",
"CSHS5UGXCSS",
"CSHS6UGZBSS",
"CSHS6UGZEES",
"CSHS6UGZFSS",
"CSS25USWASS",
"CSS25USWCSS",
"CSS25USWS",
"CSW25LSWASS",
"CZS22MP2NDS1",
"CZS22MP2NES1",
"CZS22MP2NHS1",
"CZS22MSKBHSS",

```
"CZS22MSKEHSS"
]
},
{
  "part_name": "Single Roller - Right Front WPW10515762",
  "part_number": "PS11755875",
  "manufacturer": "Kenmore",
  "price": "51.04",
  "description": "Sold individually.",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator,
Freezer. Part# WPW10515762 replaces these: AP6022542, W10130459, W10212381,
W10237087, W10275849, W10515762 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "10669312310",
    "10672002010",
    "10672002011",
    "10672002013",
    "10672002015",
    "10672003010",
    "10672003011",
    "10672003012",
    "10672003013",
    "10672003014",
    "10672003016",
```

```
"10672003017",
"10672003018",
"10672009010",
"10672009011",
"10672009013",
"10672009015",
"10672012010",
"10672013010",
"10672013017",
"10672019010",
"596379243017",
"596467934251",
"596467934351",
"596467934451",
"596467934951",
"59665332602",
"59665333602",
"59665339602",
"59666022703"
]
},
{
  "part_name": "Defrost Timer - 120V 60Hz WR9X502",
  "part_number": "PS310869",
  "manufacturer": "Kenmore",
  "price": "93.21",
```

"description": "This defrost timer will cycle for 25 minutes after every six hours of run time. The timer itself is made of plastic, and its terminals are bent, the leads are internal, and the label is orange. If you notice that your fridge is too warm, the fridge is running for a long time or is leaking, it could be due to the defrost timer becoming inactive. The defrost timer is found underneath the light cover (may need to remove lightbulb) and will need to be removed along with the air inlet assembly and housing.",

"rating": "83",

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Freezer section too warm | Freezer not defrosting | Fridge and Freezer are too warm This part works with the following products: Refrigerator, Freezer. Part# WR9X502 replaces these: AP2061708, 310900, WR9X502, WR09X0278, WR09X0283, WR09X0313, WR09X0329, WR09X0334, WR09X0339, WR09X0342, WR09X0350, WR09X0356, WR09X0363, WR09X0364, WR09X0366, WR09X0369, WR09X0375, WR09X0376, WR09X0387, WR09X0408 ... Show more , WR09X0409, WR09X0412, WR09X0413, WR09X0414, WR09X0418, WR09X0419, WR09X0428, WR09X0432, WR09X0436, WR09X0438, WR09X0453, WR09X0464, WR09X0465, WR09X0466, WR09X0468, WR09X0470, WR09X0471, WR09X0478, WR09X0479, WR09X0481, WR09X0484, WR09X0486, WR09X0487, WR09X0490, WR09X0495, WR09X0496, WR09X0497, WR09X0502, WR09X0503, WR09X0504, WR09X0512, WR09X0526, WR09X0528, WR09X0576, WR09X0587, WR09X0594, WR09X10049, WR09X5127, WR09X5161, WR09X5162, WR09X5163, WR09X5164, WR09X5192, WR09X5202, WR09X5204, WR09X5211, WR09X5225, WR9X10049, WR9X278, WR9X283, WR9X313, WR9X329, WR9X334, WR9X339, WR9X342, WR9X350, WR9X356, WR9X363, WR9X364, WR9X366, WR9X369, WR9X375, WR9X376, WR9X387, WR9X408, WR9X409, WR9X412, WR9X413, WR9X414, WR9X418, WR9X419, WR9X428, WR9X432, WR9X436, WR9X438, WR9X453, WR9X464, WR9X465, WR9X466, WR9X468, WR9X470, WR9X471, WR9X478, WR9X479, WR9X481, WR9X484, WR9X486, WR9X487, WR9X490, WR9X495, WR9X503, WR9X504, WR9X512, WR9X5127, WR9X5161, WR9X5162, WR9X5163, WR9X5164, WR9X5192, WR9X5202, WR9X5204, WR9X5211, WR9X5225, WR9X526, WR9X528, WR9X576, WR9X587, WR9X594 Show less Back to Top",

"review_count": "7",

"appliance": "refrigerator",

"compatible_models": [

"140060A",

"31361-1",

"31361-2",
"31371-1",
"31371-2",
"31391-1",
"31391-2",
"31396-1",
"31396-2",
"31399-1",
"31399-2",
"31461-1",
"31491-1",
"31496-1",
"31499-1",
"31880",
"3222-00LOS00-A",
"3222-00ROS00-A",
"33110-4",
"33111-4",
"33118-4",
"33119-4",
"33120-1",
"33121-1",
"33128-1",
"33129-1",
"36110-4",
"36110-7",

```
"36111-4",  
"36111-7"  
]  
,  
{  
  "part_name": "Defrost Timer - 120V 60Hz 215846604",  
  "part_number": "PS423802",  
  "manufacturer": "Kenmore",  
  "price": "32.51",
```

"description": "This defrost timer is designed for use in your refrigerator. The defrost timer acts as a clock, that switches the refrigerator from the freezing cycle to the defrost cycle and back. If your refrigerator is running non-stop, or is not running at all, you may need to check and replace the defrost timer. This is a 6 hour and 21 minute defrost timer. This part is made of white plastic, with 4 metal prongs protruding from one end. To complete this repair, you will need to access the old defrost timer which is located inside the console on the roof of your refrigerator. To complete this repair, you will need a 1/4-inch nut driver, a flat blade screwdriver, and a Phillips screwdriver. Be sure to disconnect power from your refrigerator before you begin this repair.",

```
"rating": "77",
```

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Freezer not defrosting | Fridge and Freezer are too warm | Will Not Start This part works with the following products: Refrigerator, Freezer. Part# 215846604 replaces these: AP2592907, 442754, 08000035, 08003824, 08011620, 241809401, 241809402, 29811-3, 3001268, 3007400, 5300541134, 5300800692, 5303007400, 5308000035, 5308003824, 54113-1, 54113-4, 55448-3, 55448-4, 55467-1 ... Show more , 8000035, 8003824, 8011620, F111695, F111812, G000158274, G000158291, G000173814, G000187005, G000187464, G158274, G158291, G163818, G169069, G173814, G174821, G178820, G185160, G187464, K1224661, K1224662, K1226501, K1226502, K1227229, K1227920, K1227927, K1228104, K1228105, K1230354, K1230534, K1233374, K1233375, NR00422503, R000422503, R000900129, R422503, W188C189A06, W188C189A07, WR422503 Show less Back to Top",

```
"review_count": "11",
```


"appliance": "refrigerator",

"compatible_models": [

"2533111330L",

"2533111530L",

"2536080240J",

"2536080440J",

"25361502407",

"25361502408",

"25361502409",

"2536151240A",

"2536151240B",

"2536151240C",

"25361522011",

"25361522012",

"25361522013",

"25361522014",

"25361522016",

"25361522017",

"25361522018",

"25361522019",

"2536152201A",

"2536152201D",

"25361532805",

"25361532806",

"25361534805",

"25361534806",

"25361537805",

"25361537806",

"25361542011",

"25361542012",

"25361542013",

"25361542014"

]

},

{

"part_name": "Defrost Timer W10822278",

"part_number": "PS11723171",

"manufacturer": "Kenmore",

"price": "35.85",

"description": "The Defrost Timer (Defrost control) acts like a clock by switching on the defrost heater circuit after a predetermined amount of compressor run time. This allows the defrost circuit to clear the evaporator of ice or frost to maintain proper airflow. If this part is not working, it can lead to temperature increases in your refrigerator. If the compressor circuit fails, no cooling will take place; if the defrost circuit isn't activated, ice will quickly build up on the evaporator coils and reduce airflow and efficiency. If the timer doesn't advance or if the contacts have no continuity, the timer will need to be replaced. This part is located inside of the control housing on most models, and is approximately 3 inches long and 2.5 inches wide. This part is constructed of plastic and metal, and comes in white. It features 1 defrost timer, along with all necessary mounting hardware and installation instructions",

"rating": "84",

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Freezer not defrosting | Freezer section too warm | Leaking This part works with the following products: Refrigerator, Freezer. Part# W10822278 replaces these: AP5985208, 0053736, 0055525, 0056627, 0056768, 0056906, 0056907, 0057052, 0311209, 104039, 1101021, 1105267, 1113225, 1114246, 1114248, 1114264, 1114283, 1114287, 1115416, 1118626 ... Show more , 1127570, 1127571, 1127591, 14210016, 1530557,

1548140, 1549238, 1549252, 1549256, 1833663, 1850019, 1850038, 20009000, 20009023, 20009037, 20103015, 20142257, 20143568, 20144431, 20144520, 2149098, 2154665, 2154666, 2154912, 2154982, 2154983, 2154984, 2162046, 2162347, 2172691, 2176335, 2176340, 2176646, 2176648, 2188371, 2188372, 2188375, 2188376, 2193084, 2199008, 4210521, 4210579, 4210778, 4318057, 4339497, 4339856, 4343354, 4343402, 4356929, 4389238, 480561, 482489, 482493, 483212, 511883, 513588, 513590, 513629, 513630, 530213, 530214, 530557, 530558, 531714, 54113-3, 54113001, 548044, 548121, 548140, 548709, 549090, 549091, 549238, 549239, 549252, 549253, 549256, 549257, 549875, 549876, 56906, 798629, 8133, 833531, 833663, 833757, 833795, 833840, 850019, 850038, 850343, 850344, 850345, 850608, 850609, 850694, 850695, 850731, 850845, 850847, 850878, 850879, 851061, 851106, 851160, 851161, 851200, 851269, 851406, 851701, 851971, 938035, 940074, 943428, 943434, 943435, 943436, 945486, 945512, 945513, 945514, 978266, 978472, 989280, 989281, D70041-12, D7004112, FSP482493, R0950029, R0950217, W10740039, W10822278VP, Y0053736, Y0055525, Y0056627, Y0056768, Y0056906, Y0311209 Show less Back to Top",

"review_count": "35",

"appliance": "refrigerator",

"compatible_models": [

"106106-8130600",

"106106-8130610",

"106106-8130620",

"106106-8130630",

"106106-8130640",

"106106-8130650",

"106106-8130660",

"106106-8130680",

"106106-8130690",

"1061068130670",

"10640212010",

"10640212011",

```
"10641012100",
"10641012101",
"10641012104",
"10641014100",
"10641014101",
"10641014104",
"10641212100",
"10641212101",
"10641214100",
"10641214101",
"10641512100",
"10641512101",
"10641514100",
"10641514101",
"10641519100",
"10641519101",
"10647021790",
"10647021791"
]
},
{
  "part_name": "Electronic Control Board WPW10503278",
  "part_number": "PS11755733",
  "manufacturer": "Kenmore",
  "price": "161.75",
```

"description": "The electronic control board is used in refrigerators to monitor and manage the temperature settings, such as cooling or defrosting times. If your fridge or freezer is too warm, too cold, is not defrosting, will not start, and/or runs too long then replacing the control board could solve your appliance problem. The tools needed for this installation project is a small flat blade screwdriver. *Please note: the board will need to be programmed after installation. Remember to unplug refrigerator from power source as a safety precaution. Refer to the manual provided by the manufacturer for further installation instructions and accurate guidance.",

"rating": "93",

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Freezer not defrosting | Will Not Start | Fridge too cold This part works with the following products: Refrigerator. Part# WPW10503278 replaces these: AP6022400, 12002339, 12002445, 12002449, 12002508, 12002509, 12002567, 12002706, 12784415, 12784415V, 12868502, 12868510, 12868513, 67003867, 67004453, 67004496, 67004907, 67005043, 67005280, 67005281 ... Show more , 67006034, 67006209, 67006214, 67006216, 67006226, 67006712, 67006740, 8208187, W10165748, W10503278 Show less Back to Top",

"review_count": "22",

"appliance": "refrigerator",

"compatible_models": [

"10669312310",

"596467934251",

"596467934351",

"596467934451",

"596467934951",

"59655652500",

"59655653500",

"59655654500",

"59655659500",

"59657012600",

```
"59657013600",
"59657016600",
"59657019600",
"59665232400",
"59665232401",
"59665232404",
"59665234400",
"59665234401",
"59665234402",
"59665234404",
"59665239400",
"59665239401",
"59665239402",
"59665239404",
"59665239405",
"59665332600",
"59665332602",
"59665333602",
"59665339602",
"59665932300"
]
},
{
  "part_name": "Defrost Timer - 60Hz 120V 215846602",
  "part_number": "PS423801",
  "manufacturer": "Kenmore",
```

"price": "38.60",

"description": "This Defrost Timer works like a clock by switching on the defrost heater circuit after a predetermined amount of compressor run time. This allows the defrost circuit to clear the evaporator of ice or frost to maintain proper airflow. The defrost timer is located in the control housing which is in the refrigerator section of your appliance. If this part is not working, it can lead to temperature increases in your refrigerator. If the compressor circuit fails, no cooling will take place; if the defrost circuit isn't activated, ice will quickly build up on the evaporator coils and reduce airflow and efficiency. If the timer doesn't advance or if the contacts have no continuity, the timer will need to be replaced. This timer measures approximately 3 inches long and 2.5 inches wide, and is constructed of plastic and metal. It comes in black/white/silver and is sold individually. This replacement part features 1 defrost timer.",

"rating": "90",

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Freezer not defrosting | Freezer section too warm | Will Not Start This part works with the following products: Refrigerator. Part# 215846602 replaces these: AP2111929, 12762, 215846602, 00624728, 00626234, 00628510, 00628518, 0628510, 08000559, 08006054, 08006992, 08016919, 08950148, 215267800, 215846605, 215846606, 240371001, 241621501, 3001671, 3001701 ... Show more , 3015909, 3203657, 4013391050, 5300187484, 5300628518, 5301090474, 5303203657, 5303211155, 5303211680, 5303270622, 5303275811, 5303321133, 5303321915, 5304457327, 5308006054, 5308006992, 624728, 626234, 628510, 628518, 8000559, 8006054, 8016919, 8950148, C000062797, C62797, D007004112, DG187005, F000111695, G000187484, G172706, G174820, G186580, G187005, G187484, M1090167, M1090474, N8000559, R000900241, R000900764, R900241 Show less Back to Top",

"review_count": "39",

"appliance": "refrigerator",

"compatible_models": [

"15304-0A",

"15304-7A",

"177040A",

"177047A",

"17714-0A",

"17714-7A",
"178040A",
"178047A",
"25331113300",
"25331113302",
"25331113304",
"25331113308",
"2533111330A",
"2533111330B",
"2533111330C",
"2533111330D",
"2533111330E",
"2533111330F",
"2533111330G",
"2533111330H",
"2533111330J",
"2533111330K",
"25331115300",
"25331115302",
"25331115304",
"25331115308",
"2533111530A",
"2533111530B",
"2533111530C",
"2533111530D"

]


```
},
```

```
{
```

```
"part_name": "DEFROST TIMER 5304518034",
```

```
"part_number": "PS12585793",
```

```
"manufacturer": "Kenmore",
```

```
"price": "45.49",
```

```
"description": "This is a 120 volt defrost timer manufactured for refrigerators. The defrost timer manages the automatic defrost system in the unit. It acts like a clock by switching between activating the cooling cycle and the defrost heater to maintain the set thermostat temperature, preventing the unit from being too warm or cold. The defrost timer may need to be replaced if the fridge will not maintain its temperature or has frost buildup. Depending on the model, it could be located on the rear panel or ceiling of the fresh food compartment. Be sure to disconnect power to the refrigerator before replacing this part.",
```

```
"rating": "92",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Too warm | Frost buildup | Won't start | Fridge too warm This part works with the following products: Freezer, Refrigerator. Part# 5304518034 replaces these: AP6799886, 00624727, 00624729, 00626218, 00627159, 00628515, 00628516, 00628517, 08037960, 08037967, 216517400, 216563000, 216744400, 216744500, 297318010, 5304516309, 5308037967, 624727, 624729, 626218 ... Show more , 627159, 628515, 628516, 628517, 8037960, 8037967, F000127233, F000129880, F127233, F129880 Show less Back to Top",
```

```
"review_count": "14",
```

```
"appliance": "refrigerator",
```

```
"compatible_models": [
```

```
"25316562100",
```

```
"25316562101",
```

```
"25316572100",
```

```
"25316572101",
```

```
"25321021100",
```

"25321021101",
"25321021102",
"25321021103",
"25321021104",
"25321021105",
"25321041100",
"25321041101",
"25321041102",
"25321041103",
"25321041107",
"25321082102",
"25321082106",
"25321101100",
"25321411100",
"25321411101",
"25321411102",
"25321411103",
"25321411104",
"25321421100",
"25321421101",
"25321421102",
"25321421103",
"25321421104",
"25321421105",
"25321721100"

]

```
},  
{  
  "part_name": "Left Side Bracket W10850332",  
  "part_number": "PS11731140",  
  "manufacturer": "Kenmore",  
  "price": "71.68",  
  "description": "",  
  "rating": null,  
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#  
W10850332 replaces these: AP5989693, W10619219 Back to Top",  
  "review_count": null,  
  "appliance": "refrigerator",  
  "compatible_models": [  
    "59672382410",  
    "596723824102",  
    "59672382411",  
    "59672382413",  
    "59672383410",  
    "596723834102",  
    "59672383411",  
    "59672383412",  
    "59672383413",  
    "59672389410",  
    "59672389411",  
    "59672389412",  
    "59672389413",
```

```
"JFX2897DRM00",
"JFX2897DRM01",
"JFX2897DRM02",
"JFX2897DRP00",
"JFX2897DRP01",
"JFX2897DRP02",
"KFIS29PBMS01",
"KFIS29PBMS02",
"KFIS29PBMS03",
"KRMF606ESS00",
"KRMF606ESS01",
"WRF990SLAM01",
"WRF990SLAM02",
"WRF990SLAM03",
"WRF997SDDM00",
"WRF997SDDM02",
"WRV996FDEE00"
]
},
{
  "part_name": "BLOCK-PIV WPW10344432",
  "part_number": "PS11753272",
  "manufacturer": "Kenmore",
  "price": "10.80",
  "description": "",
  "rating": "100",
```

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WPW10344432 replaces these: W10344432 Back to Top",

"review_count": "1",

"appliance": "refrigerator",

"compatible_models": [

"59672382410",

"596723824102",

"59672382411",

"59672382413",

"59672383410",

"596723834102",

"59672383411",

"59672383412",

"59672383413",

"59672389410",

"59672389411",

"59672389412",

"59672389413",

"7MF2976AEM00",

"7MF2976AEM01",

"7MF2976AEM02",

"7MF2976AEM03",

"7WF736SDAM10",

"7WF736SDAM11",

"7WF736SDAM12",

"7WF736SDAM13",

```
"7WF736SDAM14",
"IX7DDEXDSM00",
"IX7DDEXDSM01",
"IX7DDEXDSM02",
"JFX2897DRM00",
"JFX2897DRM01",
"JFX2897DRM02",
"JFX2897DRP00",
"JFX2897DRP01"
]
},
{
  "part_name": "BRACKET 297092701",
  "part_number": "PS1527470",
  "manufacturer": "Kenmore",
  "price": "42.05",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator,
Freezer. Part# 297092701 replaces these: AP3960116, 7297092701 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "25344123800",
    "25344123801",
    "25344123802",
```

"25344123803",
"25344123804",
"25344123805",
"25344133800",
"25344133801",
"25344133802",
"25344133804",
"25344133805",
"25344743110",
"25344743111",
"25344753110",
"25344762704",
"25344762705",
"25344763704",
"25344772701",
"25344772702",
"25344773701",
"25344773703",
"25344823600",
"25344833600",
"25344833601",
"E32AF75FPS0",
"E32AF75FPS1",
"E32AF75FPS2",
"E32AF75FPS3",
"E32AF75FPS4",

```
"E32AF75FPS5"
]
},
{
  "part_name": "Holder WP2188919",
  "part_number": "PS11739144",
  "manufacturer": "Kenmore",
  "price": "9.75",
  "description": "",
  "rating": "60",
  "troubleshooting_tips": "This part fixes the following symptoms: Ice maker won't
dispense ice This part works with the following products: Refrigerator. Part# WP2188919
replaces these: 2188919 Back to Top",
  "review_count": "1",
  "appliance": "refrigerator",
  "compatible_models": [
    "10641162310",
    "10641163310",
    "10641169310",
    "10644022601",
    "10644022602",
    "10644022603",
    "10644023601",
    "10644023602",
    "10644023603",
    "10644029601",
    "10644029602",
```



```
"10644029603",
"10644032601",
"10644032602",
"10644032603",
"10644033601",
"10644033602",
"10644033603",
"10644039601",
"10644039602",
"10644039603",
"10644422601",
"10644422602",
"10644422603",
"10644423601",
"10644423602",
"10644423603",
"10644424601",
"10644424602",
"10644424603"
]
},
{
  "part_name": "Handle Mounting Block 242029301",
  "part_number": "PS3408605",
  "manufacturer": "Kenmore",
  "price": "19.99",
```

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 242029301 replaces these: AP4587476 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"25370412410",

"25370413410",

"25370419410",

"CFD26SDS0",

"CFD26WIS0",

"CFD26WIS1",

"CFD26WIS3",

"CFD26WIS4",

"CFD26WIS5",

"CFD26WIS6",

"CFD28SDS1",

"CFD28SDS6",

"CFD28SDS9",

"CFD28WIB5",

"CFD28WIB6",

"CFD28WIB8",

"CFD28WIB9",

"CFD28WIBA",

"CFD28WIBB",

"CFD28WIBC",

"CFD28WIS0",

"CFD28WIS1",

"CFD28WIS2",

"CFD28WIS3",

"CFD28WIS5",

"CFD28WIS6",

"CFD28WIS8",

"CFD28WIS9",

"CFD28WISA",

"CFD28WISB"

]

},

{

"part_name": "Ice Maker Cover Bracket WP2198641",

"part_number": "PS11739245",

"manufacturer": "Kenmore",

"price": "7.95",

"description": "This is the replacement ice maker cover bracket for your refrigerator. It is made of white plastic and is approximately 5 inches wide and 2 inches long. The ice maker cover bracket holds and supports the ice maker cover. If the ice maker cover is loose or missing, you may need to replace the bracket. You will also want to replace the bracket if it will not stay in place, or if it is cracked or broken. To replace the cover bracket, simply remove the ice maker cover, then use a ¼ inch nut driver to loosen and remove the bracket. Screw in the new bracket and replace the cover to complete your repair. This is an OEM part that is sold individually.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making ice This part works with the following products: Refrigerator. Part# WP2198641 replaces these: AP6006179, 2198641 Back to Top",

"review_count": "6",

"appliance": "refrigerator",

"compatible_models": [

"10641522500",

"10641523500",

"10641524500",

"10641529500",

"10644022600",

"10644022601",

"10644022602",

"10644022603",

"10644023600",

"10644023601",

"10644023602",

"10644023603",

"10644024600",

"10644029600",

"10644029601",

"10644029602",

"10644029603",

"10644032600",

"10644032601",

"10644032602",

"10644032603",

```
"10644033600",
"10644033601",
"10644033602",
"10644033603",
"10644034600",
"10644039600",
"10644039601",
"10644039602",
"10644039603"
]
},
{
  "part_name": "BRACKET 297092700",
  "part_number": "PS1527469",
  "manufacturer": "Kenmore",
  "price": "40.91",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator,
Freezer. Part# 297092700 replaces these: AP3960129, 7297092700 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "25344123800",
    "25344123801",
    "25344123802",
```

"25344123803",
"25344123804",
"25344123805",
"25344133800",
"25344133801",
"25344133802",
"25344133804",
"25344133805",
"25344743110",
"25344743111",
"25344753110",
"25344762701",
"25344762704",
"25344762705",
"25344763703",
"25344763704",
"25344772701",
"25344772702",
"25344773701",
"25344773703",
"25344823600",
"25344833600",
"25344833601",
"E32AF75FPS0",
"E32AF75FPS1",
"E32AF75FPS2",

"E32AF75FPS3"

]

},

{

"part_name": "Door Holder MEG61899901",

"part_number": "PS3535435",

"manufacturer": "LG",

"price": "22.82",

"description": "This is a manufacturer-approved refrigerator door closure for your refrigerator. It is made of white plastic and measures approximately 3 inches by 2 inches. If your old closure is damaged, your refrigerator door may not open and shut properly, and therefore it should be replaced.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator, Freezer. Part# MEG61899901 replaces these: AP4681026 Back to Top",

"review_count": "5",

"appliance": "refrigerator",

"compatible_models": [

"1867",

"48231784207",

"48231784214",

"48231784221",

"48231784412",

"495934",

"70322",

"70323",

```
"70329",  
"70332",  
"70333",  
"70339",  
"71032",  
"71033",  
"71036",  
"71039",  
"71042",  
"71043",  
"71049",  
"71052",  
"71053",  
"71054",  
"71056",  
"71059",  
"71062",  
"71063",  
"71069",  
"71072",  
"71073",  
"71079"  
]  
,  
{  
  "part_name": "Ice Chute Door 241688401",
```


"part_number": "PS1526426",

"manufacturer": "Kenmore",

"price": "46.55",

"description": "An ice chute is mounted to the interior panel and extends between the interior panel opening and the dispenser opening for transferring ice through the chute door.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker won't dispense ice | Door won't open or close | Ice maker dispenses too much ice This part works with the following products: Refrigerator. Part# 241688401 replaces these: AP3965146, 1196688, 5304421628, 7241688401 Back to Top",

"review_count": "3",

"appliance": "refrigerator",

"compatible_models": [

"25344302400",

"25344302401",

"25344303400",

"25344303401",

"25344303402",

"25344303403",

"25344304400",

"25344304401",

"25344309400",

"25344309401",

"25344333600",

"25344333601",

"25344333602",

```
"25344333603",  
"25344333604",  
"25344333605",  
"25344333606",  
"25344333607",  
"25344333608",  
"25344333609",  
"2534433360A",  
"25344352400",  
"25344352401",  
"25344352403",  
"25344352404",  
"25344352405",  
"25344352406",  
"25344352407",  
"25344352408",  
"25344352409"
```

```
]
```

```
},
```

```
{
```

```
"part_name": "Control Bracket WP2180226",
```

```
"part_number": "PS11739027",
```

```
"manufacturer": "Kenmore",
```

```
"price": "19.41",
```

```
"description": "This is a control bracket for your refrigerator, and may also be known as  
the dispenser control bracket. The function of this part is to hold the micro switches and  
the light socket in the freezer dispenser section in place. Its measurements are roughly 9
```

inches long and 5 inches high, and this model comes in white. The tools you will need in order to do this repair include a Phillips screw driver, a quarter-inch nut-driver, and a pair of needle-nose pliers. If your ice dispenser is not working properly, your bracket could be the problem.",

"rating": "98",

"troubleshooting_tips": "This part fixes the following symptoms: Not dispensing water | Ice maker won't dispense ice | Ice maker not making ice This part works with the following products: Refrigerator. Part# WP2180226 replaces these: AP6005965, 2180226, 2180228, 2180338, 2183771, W10139151, W10282667, WP2180226VP Back to Top",

"review_count": "117",

"appliance": "refrigerator",

"compatible_models": [

"10650022000",

"10650022001",

"10650022002",

"10650022003",

"10650022004",

"10650027000",

"10650027001",

"10650027002",

"10650027003",

"10650027004",

"10650032000",

"10650032001",

"10650032002",

"10650032003",

"10650032004",

"10650037000",

```
"10650037001",  
"10650037002",  
"10650037003",  
"10650037004",  
"10650202990",  
"10650202991",  
"10650202992",  
"10650202993",  
"10650203990",  
"10650203991",  
"10650203992",  
"10650203993",  
"10650204990",  
"10650204991"  
]  
},  
{  
  "part_name": "Evaporator Fan Blade Kit WR60X114",  
  "part_number": "PS304684",  
  "manufacturer": "Kenmore",  
  "price": "26.53",
```

"description": "This kit features a 5-blade plastic evaporator fan blade that rotates CCW and measures 4.5-inches in diameter and has a 3/8-inch-tall shaft. This kit also has a metal compression ring that secures the fan to the evaporator. The evaporator mechanism is normally located in the freezer and is responsible for pulling the warmer air over the condenser coils, cooling it off and then blowing and circulating that cooler air through the rest of the refrigerator. If the freezer compartment has a frost buildup or if there is a lack of cooling and airflow in your refrigerator, this fan likely needs to be replaced. To replace your

evaporator fan, you will likely need a screwdriver and a set of pliers and check your user manual for the exact location of your evaporator fan.",

"rating": "80",

"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Fridge too warm
This part works with the following products: Refrigerator, Range, Wall Oven, Range Hood.
Part# WR60X114 replaces these: AP2071753, 2611, SWR02X3198, SWR2X3198,
SWR60X0114, SWR60X114, WR02X3198, WR2X3198, WR60X0055, WR60X0080,
WR60X0107, WR60X0113, WR60X0114, WR60X0247, WR60X107, WR60X113,
WR60X114R, WR60X247, WR60X5003, WR60X55 ... Show more , WR60X80 Show less
Back to Top",

"review_count": "5",

"appliance": "refrigerator",

"compatible_models": [

"140060A",

"1CSF624J",

"31861-1",

"31880",

"34510-2",

"34510-3",

"34511-2",

"34511-3",

"34540-2",

"34541-2",

"34550-2",

"34551-2",

"34560-2",

"34561-2",

"34760-3",

"34760-7",

"34761-3",

"34761-7",

"34780-7",

"34781-7",

"36337400790",

"36337400791",

"36337400792",

"36337401790",

"36337401791",

"36337401792",

"36337408790",

"36337408791",

"36337408792",

"36337409790"

]

},

{

"part_name": "Evaporator Fan Blade WP2163777",

"part_number": "PS11738954",

"manufacturer": "Kenmore",

"price": "51.67",

"description": "This part is used to circulate air through the inside of the refrigerator to help improve the cooling efficiency.",

"rating": null,

"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Fridge too warm
This part works with the following products: Refrigerator, Freezer. Part# WP2163777
replaces these: AP6005892, 2163777, 2200509 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"10632242101",

"10632243101",

"10632249101",

"10632942101",

"10632943101",

"10632949101",

"10642102300",

"10642102301",

"10642104300",

"10642106300",

"10642106301",

"10660162990",

"10660167990",

"10660172990",

"10660172991",

"10660177990",

"10660182000",

"10660182001",

"10660184001",

"10660187000",

"10660192000",

```
"10660192001",
"10660194001",
"10660197000",
"10660212410",
"10660213410",
"10660214410",
"10660219410",
"10660232900",
"10660232902"
]
},
{
  "part_name": "BLADE CONF FAN Assembly WR60X24484",
  "part_number": "PS11726966",
  "manufacturer": "Kenmore",
  "price": "33.75",
  "description": "",
  "rating": "60",
  "troubleshooting_tips": "This part fixes the following symptoms: Noisy This part works with the following products: Refrigerator, Freezer. Part# WR60X24484 replaces these: AP5986493, WR60X10049, WR60X10206 Back to Top",
  "review_count": "2",
  "appliance": "refrigerator",
  "compatible_models": [
    "31261-1",
    "31261-2",
    "31261-3",
```


"31269-1",
"31271-1",
"31271-2",
"31271-3",
"31291-1",
"31291-2",
"31291-3",
"31296-1",
"31296-2",
"31299-1",
"31299-2",
"31341-1",
"31361-1",
"31361-2",
"31371-1",
"31371-2",
"31391-1",
"31391-2",
"31396-1",
"31396-2",
"31399-1",
"31399-2",
"31461-1",
"31491-1",
"31496-1",
"31499-1",

"3220-00LOS00-B"

]

},

{

"part_name": "Fan Blade and Spring Clip WPW10445742",

"part_number": "PS11754833",

"manufacturer": null,

"price": "16.13",

"description": "If you notice an unusual noise coming from your freezer, the evaporator fan blade might be the problem. Frost-free freezer models use evaporator fans to move air through the evaporator for more efficient cooling. If the evaporator fan blade gets damaged or worn it may become noisy. If the blade is loose on the motor shaft or if the fins are damaged, it should be replaced. Be sure to remove power to the appliance before attempting any repair. The evaporator fan assembly is located behind the air grille or evaporator cover and can normally be accessed by simply removing a few mounting screws. The fan blade is normally pressed on to the motor shaft and secured by a spring clip.",

"rating": "99",

"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Too warm | Frost buildup This part works with the following products: Freezer, Refrigerator. Part# WPW10445742 replaces these: AP6021509, 1-80250-101, 1-80250-102, 14214045, 4356920, 4390912, 68001595, W10445742 Back to Top",

"review_count": "13",

"appliance": "refrigerator",

"compatible_models": [

"AQF1201TRW03",

"AQF1613TEW03",

"AQF1613TEW04",

"AQF2013TEW03",

"AQF2013TEW04",
"AQU1627BRW03",
"AQU1827BRW03",
"AQU2027BRW03",
"AQU2027BRW04",
"AQU2027BRW05",
"AQU2027BRW06",
"DUF570WDD01",
"EL7JWKLMQ02",
"EL7JWKLMQ03",
"EL7JWKLMQ04",
"EL7JWKLMS02",
"EL7JWKLMS03",
"EL7JWKLMS04",
"EL88TRRWQ01",
"EL88TRRWQ02",
"EL88TRRWS01",
"EL88TRRWS02",
"EV160NQTQ00",
"EV160NQTQ01",
"EV161NZRQ00",
"EV161NZRQ02",
"EV161NZRQ04",
"EV161NZRQ05",
"EV161NQTQ00",
"EV161NQTQ01"

```
]
},
{
  "part_name": "Fan Blade W10156818",
  "part_number": "PS1964356",
  "manufacturer": "Kenmore",
  "price": "65.89",
  "description": "The fan blade is used to blow air over the condenser.",
  "rating": "99",
  "troubleshooting_tips": "This part fixes the following symptoms: Noisy This part works with the following products: Refrigerator. Part# W10156818 replaces these: AP4323896, 1454592, 12825802, 12825802SP, 60683-1, 61006191, 67004952, 8208223, W10156818, W10162928 Back to Top",
  "review_count": "15",
  "appliance": "refrigerator",
  "compatible_models": [
    "10640212011",
    "10640262010",
    "10640263010",
    "10640263011",
    "10640269010",
    "10640562010",
    "10640563010",
    "10640563011",
    "10640569010",
    "10640569011",
    "10641122210",
```

```
"10641122211",
"10641122212",
"10641122213",
"10641123210",
"10641123211",
"10641123212",
"10641124210",
"10641129210",
"10641129211",
"10641129212",
"10641129213",
"10641152210",
"10641152211",
"10641153210",
"10641153211",
"10641154210",
"10641159210",
"10641159211",
"10641159212"
]
},
{
  "part_name": "Condenser Fans Blade Assembly WR60X10207",
  "part_number": "PS1022410",
  "manufacturer": null,
  "price": "17.87",
```

"description": "The condenser fan blade assembly helps to regulate the temperature in your refrigerator or freezer. This fan assembly has 4 blades, but other fans may have 3 blades, so be sure to check the number of blades on your fan. The fan blade is made of white plastic and is approximately 6 inches in diameter. If your freezer section is too warm, or you notice a strange noise coming from your refrigerator when it is running, you may need to replace the condenser fan blade assembly. This part is sold individually.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Freezer section too warm | Fridge too warm This part works with the following products: Refrigerator. Part# WR60X10207 replaces these: AP3868990, 1170123, WR60X10088 Back to Top",

"review_count": "2",

"appliance": "refrigerator",

"compatible_models": [

"36211XBMBRWW",

"36211XBMDRWW",

"36211XBMERWW",

"36211XBMFRWW",

"36211XBRERWW",

"36211XBRFRWW",

"36411XBRERWW",

"36411XBRFRWW",

"37511KBSARWW",

"37511KBSERWW",

"38181KBPARWW",

"38181KBPCRWW",

"38181KBRARWW",

"38185KBPARBB",

"38185KBPCRBB",

"38185KBRARBB",
"38187KBPARCC",
"38187KBPCRCC",
"38187KBRARCC",
"38341FBMERWW",
"38351HBMERWW",
"38371PBRBRWW",
"38451HBRERWW",
"38471PBRBRWW",
"38471PBRDRWW",
"38471PBRERWW",
"38471PBRFRWW",
"38471PBRJRWW",
"38471PBRLRWW",
"38471PBRMRWW"

]

},

{

"part_name": "Fan Blade 240524102",

"part_number": "PS2361234",

"manufacturer": "Kenmore",

"price": "19.99",

"description": "This part blows air over the condenser.",

"rating": "99",

"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Clicking sound |
Fridge too warm This part works with the following products: Refrigerator, Freezer. Part#

240524102 replaces these: AP4393271, 1512553, 240524101, 240560001, 7240524101
Back to Top",

"review_count": "15",

"appliance": "refrigerator",

"compatible_models": [

"25331113300",

"25331113302",

"25331113304",

"25331113308",

"2533111330A",

"2533111330B",

"2533111330C",

"2533111330D",

"2533111330E",

"2533111330F",

"2533111330G",

"2533111330H",

"2533111330J",

"2533111330K",

"2533111330L",

"25331115300",

"25331115302",

"25331115304",

"25331115308",

"2533111530A",

"2533111530B",

"2533111530C",

"2533111530D",

"2533111530E",

"2533111530F",

"2533111530G",

"2533111530H",

"2533111530J",

"2533111530K",

"2533111530L"

]

},

{

"part_name": "Evaporator Fan Blade 5308000010",

"part_number": "PS473177",

"manufacturer": "Kenmore",

"price": "47.79",

"description": "This evaporator fan blade is a genuine OEM part that is sourced directly from the manufacturer. The evaporator fan blade circulates air through the refrigerator to control the amount of cold air goes that goes to internal compartments of the unit. It may need to be replaced if the fridge is noisy or not cold enough. This part is made of plastic and is sold individually. It will be necessary to disconnect power to the refrigerator and empty the freezer compartment of the refrigerator. The tools needed to complete this repair are a 1/4 inch nut driver and a pair of needle nose pliers.",

"rating": "96",

"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Fridge too warm
This part works with the following products: Refrigerator, Freezer. Part# 5308000010
replaces these: AP2152058, 1083, 08000010, 216325600, 218649000, 3001215,
3001357, 75308000010, 8000010, C000040268, C000048770, C000048771,
C000071211, C000071213, C000289200, C48770, G000126599, G000174705,

G126599, G162599 ... Show more , G164094, G174705, G185153, G98355, G98356,
K1202161, K1202162, K1203079, K1209388, R000900758 Show less Back to Top",

"review_count": "5",

"appliance": "refrigerator",

"compatible_models": [

"15304-0A",

"15304-7A",

"177040A",

"177047A",

"17714-0A",

"17714-7A",

"178040A",

"178047A",

"20462151B",

"25314772100",

"25314772101",

"25314772102",

"25314772103",

"25316562100",

"25316562101",

"25316572100",

"25316572101",

"25321021100",

"25321021101",

"25321021102",

"25321021103",

```
"25321021104",
"25321021105",
"25321041100",
"25321041101",
"25321041102",
"25321041103",
"25321041104",
"25321041105",
"25321041107"
]
},
{
  "part_name": "Evaporator Fan Blade WR60X10204",
  "part_number": "PS1018129",
  "manufacturer": null,
  "price": "17.05",
  "description": "This blade attaches to the evaporator motor.",
  "rating": "95",
  "troubleshooting_tips": "This part fixes the following symptoms: Noisy | Fridge too warm  
| Clicking sound This part works with the following products: Refrigerator. Part#  
WR60X10204 replaces these: AP3868989, 1170120, WR60X10047, WR60X10188 Back to  
Top",
  "review_count": "7",
  "appliance": "refrigerator",
  "compatible_models": [
    "36211XBMBRWW",
    "36211XBMDRWW",
```

"36211XBMERWW",
"36211XBMFRWW",
"36211XBRERWW",
"36211XBRFRWW",
"36411XBRERWW",
"36411XBRFRWW",
"37511KBSARWW",
"37511KBSERWW",
"38341FBMERWW",
"38341FBMFRWW",
"38351HBMERWW",
"38351HBMFRWW",
"38351HBRERWW",
"38351HBRFRWW",
"38451HBRERWW",
"38451HBRFRWW",
"A3315ABRERWW",
"A3315ABRFRWW",
"A3315ABRW",
"A3316ABSARBB",
"A3316ABSARWW",
"A3316ABSB",
"A3316ABSBRBB",
"A3316ABSBRWW",
"A3316ABSERBB",
"A3316ABSERWW",

"A3316ABSW",

"A3317ABRERWW"

]

},

{

"part_name": "SENSOR,TEMPERATURE 6500JB2002X",

"part_number": "PS3636270",

"manufacturer": "LG",

"price": "20.34",

"description": "This is a temperature sensor for various models of LG refrigerators. Temperature sensors are used to adjust the level of cooling depending on the internal temperature of the refrigerator. If your refrigerator is warm or not cooling consistently, ensure your evaporator fan is not blocked, before replacing this sensor. To replace this sensor, you will need a screwdriver and a set of pliers, and simply need to unplug the old sensor, and plug in the new one. This temperature sensor is a genuine OEM part that is sold individually and does not come with any other parts or accessories.",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator, Freezer. Part# 6500JB2002X replaces these: 6500JB2002P Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"48231784412",

"495934",

"70322",

"70323",

"70329",

"70332",

```
"70333",  
"70339",  
"70355",  
"70357",  
"71032",  
"71033",  
"71036",  
"71039",  
"71043",  
"71049",  
"71052",  
"71053",  
"71054",  
"71059",  
"71062",  
"71063",  
"71069",  
"71072",  
"71073",  
"71079",  
"71082",  
"71099",  
"71312"  
]  
,  
{
```

```
"part_name": "Thermistor WP2188819",
"part_number": "PS11739131",
"manufacturer": "Kenmore",
"price": "35.63",
"description": "This part is used to detect the temperature in the air inside of your
refrigerator.",
"rating": null,
"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Fridge
too cold | Freezer too cold This part works with the following products: Refrigerator. Part#
WP2188819 replaces these: AP6006067, 2188819, 2216113 Back to Top",
"review_count": null,
"appliance": "refrigerator",
"compatible_models": [
  "10651792410",
  "10651792411",
  "10651792412",
  "10651793410",
  "10651793411",
  "10651793412",
  "10651799410",
  "10651799411",
  "10651799412",
  "10651799413",
  "10652202100",
  "10652202101",
  "10652203100",
  "10652203101",
```

```
"10652204100",
"10652204101",
"10652209100",
"10652209101",
"10652252100",
"10652254100",
"10652259100",
"10652262100",
"10652264100",
"10652269100",
"10652292100",
"10652293100",
"10652294100",
"10652299100",
"10652552100",
"10652554100"
]
},
{
  "part_name": "THERMISTOR W10316760",
  "part_number": "PS2580944",
  "manufacturer": "Kenmore",
  "price": "102.03",
  "description": "",
  "rating": "60",
```


"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Fridge too cold This part works with the following products: Refrigerator. Part# W10316760 replaces these: AP4538142, 12791417, 12791417SP, 12791419SP, W10280385, W10280386, W10308052, W10316760VP, W10323459, W10438639, W10438761, W10452402, WPW10323459 Back to Top",

"review_count": "1",

"appliance": "refrigerator",

"compatible_models": [

"10641162310",

"10641163310",

"10641169310",

"1064651773510",

"10651132210",

"10651132213",

"10651133210",

"10651133213",

"10651134210",

"10651134213",

"10651135610",

"10651136210",

"10651139210",

"10651139213",

"10651139214",

"10651142110",

"10651142111",

"10651143110",

"10651143111",

"10651149110",

"10651149111",

"10651149112",

"10651152110",

"10651152112",

"10651153110",

"10651153111",

"10651153112",

"10651159110",

"10651163210",

"10651164210"

]

},

{

"part_name": "Temperature Sensor 297110400",

"part_number": "PS1527511",

"manufacturer": "Kenmore",

"price": "65.37",

"description": "Also known as a thermistor.",

"rating": null,

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too cold This part works with the following products: Refrigerator, Freezer. Part# 297110400 replaces these: AP3969404, 7297110400 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"25344123800",

"25344123801",
"25344123802",
"25344123803",
"25344123804",
"25344123805",
"25344133800",
"25344133801",
"25344133802",
"25344133804",
"25344133805",
"25344743110",
"25344743111",
"25344753110",
"25344823600",
"25344833600",
"E32AF75FPS0",
"E32AF75FPS2",
"E32AF75FPS3",
"E32AF75FPS4",
"E32AF75FPS5",
"E32AF75FPS6",
"E32AF75GTT0",
"E32AF75JPS0",
"E32AF75JPS1",
"E32AF75JPS2",
"E32AF85PQSA",

"E32AF85PQSB",

"E32AF85PQSC",

"E32AF85PQSD"

]

},

{

"part_name": "Temperature Sensor 240597203",

"part_number": "PS1765215",

"manufacturer": "Kenmore",

"price": "40.47",

"description": "This temperature sensor, also known as a thermistor, is responsible for preventing the evaporator within your refrigerator from overheating during its defrosting cycle. This sensor is compatible with various makes and models of refrigerator and is sold as an individual part. This sensor works with the electronic control board within your refrigerator to control the temperature by turning the compressor on or off. If your fridge is too warm or too cold, consider changing the thermistor with this genuine OEM part, and make sure to disconnect the power to the refrigerator before doing any repairs.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Fridge too cold This part works with the following products: Refrigerator, Wine and Beverage Cooler. Part# 240597203 replaces these: AP4032998, 1258948, 240597201, 240597202, 7240597203 Back to Top",

"review_count": "2",

"appliance": "refrigerator",

"compatible_models": [

"20462151B",

"25344302400",

"25344302401",

"25344303400",

"25344303401",
"25344303402",
"25344303403",
"25344304400",
"25344304401",
"25344309400",
"25344309401",
"25344333600",
"25344333601",
"25344333602",
"25344333603",
"25344333604",
"25344333605",
"25344333606",
"25344333607",
"25344333608",
"25344333609",
"2534433360A",
"25344352400",
"25344352401",
"25344352403",
"25344352404",
"25344352405",
"25344352406",
"25344352407",
"25344352408"

]

},

{

"part_name": "Thermistor 12002355",

"part_number": "PS2003772",

"manufacturer": "Kenmore",

"price": "45.45",

"description": "This long harness thermistor kit is what helps monitor and regulate the temperature inside your refrigerator. It can be located in either the freezer compartment near the evaporator coils or in the fresh food compartment near the airflow channels, depending on the model. If you notice issues like excessive icing in the freezer, inadequate cooling in the refrigerator, temperature fluctuations, or error messages on the display panel, it indicates a potential problem with the thermistor. Since your fridge will not be able to maintain the desired temperature, this results in food spoilage, inefficient cooling, and potential damage to the cooling components. To replace the thermistor, disconnect it from the connector plug or wiring harness and remove any mounting brackets or clips using a screwdriver if necessary. Remember to consult your user manual to determine the required number of thermistors, as they are sold individually as OEM replacement parts.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too cold | Fridge too warm | Freezer too cold | Freezer section too warm This part works with the following products: Refrigerator. Part# 12002355 replaces these: AP4009169, 1057227, 12002355, 12002355VP, 12002356, 12791403, 12791403SP, 12791404, 12791404SP, 12791405, 12791405SP, 12791406, 12791406SP, 12791407, 12791407SP, 12791409SP, 12791411, 67003871, 67003872, 67004034 ... Show more , 67004035, 67005103, 67006645, 8208196, 8208278, Y67003872 Show less Back to Top",

"review_count": "4",

"appliance": "refrigerator",

"compatible_models": [

"10669312310",

"10678586800",

"59655652500",
"59655653500",
"59655654500",
"59655659500",
"59655662500",
"59655663500",
"59655664500",
"59655669500",
"59665232400",
"59665232401",
"59665232402",
"59665232403",
"59665234400",
"59665234401",
"59665234402",
"59665234403",
"59665239400",
"59665239401",
"59665239402",
"59665239403",
"59665262700",
"59665264700",
"59665269700",
"59665332600",
"59665333700",
"59665339700",

```
"59665932300",
"59665932400"
]
},
{
  "part_name": "Refrigerator Temperature Sensor WPW10383615",
  "part_number": "PS11753994",
  "manufacturer": "Kenmore",
  "price": "40.52",
  "description": "This temperature sensor is for refrigerators.\r\n\r\nThe temperature sensor senses the temperature inside the refrigerator and sends information to the electronic control.\r\n\r\nUnplug the refrigerator and safely store any food that could deteriorate while the power is off before installing this part. Wear work gloves to protect your hands. The thermistor itself, part WPW10383615, should test at these Ohms depending on temperature. It's recommended to test at room temperature and again in a glass of ice water to make sure it's sensing temperatures properly. So it should read around 3000 - 5000 Ohms at room temperature 7000 - 10000 Ohms at 0°C and 20000 Ohms at - 15°C.",
  "rating": "85",
  "troubleshooting_tips": "This part fixes the following symptoms: Freezer not defrosting | Frost buildup | Fridge too warm | Too warm This part works with the following products: Refrigerator, Freezer. Part# WPW10383615 replaces these: AP6020675, W10383615, WPW10383615VP Back to Top",
  "review_count": "4",
  "appliance": "refrigerator",
  "compatible_models": [
    "10632242101",
    "10632243101",
    "10632249101",
```


"10632942101",
"10632943101",
"10632949101",
"10670212410",
"10670213410",
"10670214410",
"10670219410",
"10673002510",
"10673003510",
"10673009510",
"10679402410",
"10679403410",
"10679472410",
"10679473410",
"59673002510",
"59673003510",
"59673009510",
"5GT118FFEW00",
"5MT519SFEG00",
"5MT519SFEH00",
"5MT711BFEH00",
"5VM1BXGFYA00",
"5VM9BXGFYA00",
"5VM9BXGFYW00",
"5VWT51SFYF00",
"5VWT51SFYW00",

```
"5VWT59SFYF00"
]
},
{
  "part_name": "Ice Maker Bin Temperature Sensor WPW10511923",
  "part_number": "PS11755842",
  "manufacturer": "Kenmore",
  "price": "73.57",
  "description": "This bin temperature sensor is for ice makers.\r\n\r\nThe bin temperature sensor monitors the temperature in the ice maker bin and sends the temperature reading to the electronic control board.\r\n\r\nDisconnect the power before installing this part. Wear work gloves to protect your hands.",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Ice Maker, Refrigerator. Part# WPW10511923 replaces these: AP6022509, W10511923 Back to Top",
  "review_count": "14",
  "appliance": "refrigerator",
  "compatible_models": [
    "10689553102",
    "10689592101",
    "10689592102",
    "10689593101",
    "10689593102",
    "10689599100",
    "10689599102",
    "59689553101",
    "59689592101",
```

```
"59689593101",
"59689599101",
"GI15NDXZB0",
"GI15NDXZB1",
"GI15NDXZB2",
"GI15NDXZQ0",
"GI15NDXZQ1",
"GI15NDXZQ2",
"GI15NDXZS0",
"GI15NDXZS1",
"GI15NDXZS2",
"GI15PDXZS0",
"GI15PDXZS1",
"JIM158XYCX0",
"JIM158XYCX1",
"JIM158XYCX2",
"JIM158XYRS0",
"JIM158XYRS1",
"JIM158XYRS2",
"JIM159XYCX0",
"JIM159XYRS0"
]
},
{
  "part_name": "Relay and Overload Combination WPW10189190",
  "part_number": "PS11749877",
```

"manufacturer": "Kenmore",

"price": "105.26",

"description": "This part is both the start relay and the overload. The start relay boosts the compressor, and then shuts off as soon as the motor gets up to speed and the overload provides extra protection against excessive temperatures.",

"rating": "90",

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start | Fridge too warm | Freezer section too warm | Clicking sound This part works with the following products: Refrigerator, Freezer. Part# WPW10189190 replaces these: AP6016586, 10097201, 14200214, 14203585, 18516-3, 2-35154-010, 2255554, 2319793, 4343850, 4344041, 4357156, 61002047, 61002971, 65529-1, 68001457, 68001622, W10189190, W10197427, Y0303053, Y0313053 Back to Top",

"review_count": "8",

"appliance": "refrigerator",

"compatible_models": [

"10640562010",

"10640563010",

"10640563011",

"10640569010",

"10640569011",

"10641562800",

"10641562801",

"10641562802",

"10641563800",

"10641563801",

"10641563802",

"10641563803",

"10641563805",

```
"10641564800",
"10641564801",
"10641564802",
"10641569800",
"10641569801",
"10641569802",
"10650292010",
"10650293010",
"10650299010",
"10650442900",
"10650442901",
"10650442902",
"10650442903",
"10650443900",
"10650443901",
"10650443902",
"10650443903"
]
},
{
  "part_name": "OVERLOAD PTCR COMBO WR07X10131",
  "part_number": "PS2577842",
  "manufacturer": null,
  "price": "47.30",
  "description": "",
  "rating": "84",
```

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start | Clicking sound | Fridge and Freezer are too warm | Fridge too warm This part works with the following products: Refrigerator. Part# WR07X10131 replaces these: AP4538934, WR08X10074, WR08X10089, WR08X10111, WR09X10124 Back to Top",

"review_count": "5",

"appliance": "refrigerator",

"compatible_models": [

"A3316ABSFRBB",

"A3316ABSFRWW",

"ADRF0MBZARWW",

"ADRS0MBZARSS",

"CFE26KP2NTS1",

"CFE26KP2TNS1",

"CFE28TP2MIS1",

"CFE28TP2MJS1",

"CFE28TP2MKS1",

"CFE28TP3MID1",

"CFE28TP3MJD1",

"CFE28TP3MKD1",

"CFE28TP4MIW2",

"CFE28TP4MJW2",

"CFE28TP4MKW2",

"CFE28TP4MLW2",

"CFE28TSHESS",

"CFE28TSHFSS",

"CFE28TSHGSS",

"CFE28TSHISS",

"CFE28TSHJSS",
"CFE28TSHKSS",
"CFE28TSHLSS",
"CFE28TSHMSS",
"CFE28TSHNSS",
"CFE28TSHOSS",
"CFE28UEL BDS",
"CFE28USHBSS",
"CFE28USHCSS",
"CFE28USHESS"

]

},

{

"part_name": "Compressor Start Relay WR07X26748",

"part_number": "PS11766700",

"manufacturer": "Kenmore",

"price": "16.88",

"description": "This part is the replacement compressor start relay for your refrigerator. It is made of black plastic and is approximately 1 ¼ inches long and 1 inch wide. The compressor start relay attaches to the compressor and helps to start the compressor motor. If the compressor will not start, or if your refrigerator or freezer is too warm, you may need to replace the compressor start relay. This part is sold individually. It is an OEM part sourced directly from the manufacturer.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start | Fridge too warm | Freezer section too warm | Won't start This part works with the following products: Refrigerator, Freezer. Part# WR07X26748 replaces these: AP6034304, WR07X0192, WR07X0194, WR07X0214, WR07X0216, WR07X10035, WR07X10051,

WR07X10064, WR7X10035, WR7X10064, WR7X192, WR7X194, WR7X214, WR7X216
[Back to Top](#)",

"review_count": "3",

"appliance": "refrigerator",

"compatible_models": [

"36130-5",

"36211XBMBRWW",

"3638400410",

"3638400411",

"3638400414",

"3638400417",

"3638400480",

"3638400481",

"3638400484",

"3638400487",

"3638480611",

"3638480681",

"3638500410",

"3638500411",

"3638500414",

"3638500417",

"3638500480",

"3638500481",

"3638500484",

"3638500487",

"3638500510",


```
"3638500511",
"3638500514",
"3638500517",
"3638500580",
"3638500581",
"3638500584",
"3638500587",
"3638502510",
"3638502513"
]
},
{
  "part_name": "HEAT EXCHANGER 297217900",
  "part_number": "PS2332236",
  "manufacturer": "Kenmore",
  "price": "65.72",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Freezer,
Refrigerator. Part# 297217900 replaces these: AP4339297, 216666100, 216751100,
297231800, 297319400, 297440900, 5304494381, 5304504767, 5304506363,
5304506539, 7216751100, 7297217900, 7297231800 Back to Top",
  "review_count": "1",
  "appliance": "refrigerator",
  "compatible_models": [
    "25322040510",
    "25322042410",
```

"25322042411",
"25322052610",
"25322052611",
"25322742410",
"25322742411",
"25322742412",
"25327002410",
"25327002411",
"25327003410",
"25327003411",
"25327003412",
"25327009410",
"25327009411",
"25327009412",
"25327702411",
"25328052800",
"25328052801",
"253280528010",
"253280528011",
"253280528012",
"253280528013",
"253280528014",
"253280528015",
"253280528016",
"25328052802",
"25328052803",

"25328052805",

"25328052806"

]

},

{

"part_name": "Refrigerator Compressor Start Relay Kit 5304491941",

"part_number": "PS8689661",

"manufacturer": "Kenmore",

"price": "105.57",

"description": "Compressor start relay kit is an original equipment manufacturer (OEM) part that fits some Kenmore, Frigidaire, Electrolux, Crosley, Gibson and White-Westinghouse refrigerators. It also fits some Kenmore, Frigidaire and Gibson upright freezers.\r\n\r\nCompressor start relay kit includes the compressor start relay, run capacitor, wire harness adapter, 2 wire terminals, 2 wire connectors, 2 pieces of wire connection shrink tubing, the wire retaining clip and kit instructions sheet.\r\n\r\nClarification of instructions: Kit 5304491941 now uses a wire harness with white wires; attach the red compressor power wire to the wire harness adapter's white wire that plugs into the start device terminal at the outside edge of the start device.\r\n\r\nReplaces original refrigerator and freezer compressor start relay part numbers 216649316, 218721119, 241524601, 241524605 and 5304468029.\r\n\r\nFits some refrigerators in the following series: Kenmore and Kenmore Elite 253; Frigidaire FRS, FRT, FRX, FSC, GLH, GLR, GS2, NGS, PHS, PLH and PLRS; Electrolux E23; Crosley CRSE; Gibson GRS and GRT; and White-Westinghouse WRS and WRT. Also fits some upright freezers in these series: Kenmore 253; Frigidaire FFU; and Gibson GFU.",

"rating": "80",

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start | Freezer section too warm | Fridge too warm | Fridge and Freezer are too warm This part works with the following products: Refrigerator, Freezer. Part# 5304491941 replaces these: AP5736381, 216649316, 218721119, 218721125, 241524601, 241524605, 5304468029
Back to Top",

"review_count": "1",

"appliance": "refrigerator",

"compatible_models": [

"25321711103",

"25323714100",

"25331430102",

"25331430103",

"25331430104",

"25331430105",

"25331432102",

"25331432103",

"25331432104",

"25331432105",

"25331434102",

"25331434103",

"25331434104",

"25331434105",

"25331437102",

"25331437103",

"25331437104",

"25331437105",

"25331438102",

"25331438103",

"25331438104",

"25331438105",

"25331439102",

"25331439103",

"25331439104",

```

    "25331439105",
    "25331440300",
    "25331440301",
    "25331442300",
    "25331442301"
  ]
},
{
  "part_name": "Filter - Drier 5303305677",
  "part_number": "PS464532",
  "manufacturer": "Kenmore",
  "price": "12.09",
  "description": "A filter-drier in a refrigerator has two essential functions. The first is to absorb system contaminants, such as water, which can create acids. The second is to provide physical filtration. This means trapping moisture, small metal chips, and dirt found in the refrigerant gas. If your refrigerator motor is constantly running, but the refrigerator is not getting cold, the issue could be due to a damaged or faulty filter-drier. Faulty filter-driers are sometimes the cause for abnormal freezer compartment temperatures and partially frosted evaporators. This filter-drier is approximately 11 inches long. Remember to disconnect the power from your refrigerator before beginning this repair.",
  "rating": null,
  "troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm This part works with the following products: Refrigerator, Freezer, Wine and Beverage Cooler. Part# 5303305677 replaces these: AP2146580, 632247, 0000021534, 0000025284, 08000027, 08002682, 08003599, 09948634, 12-121-00, 13900, 19919-20, 19919-21, 215062400, 215174600, 21534, 215987000, 216099900, 216634500, 216938600, 216938601 ... Show more , 216987500, 216987501, 218018000, 218374600, 218541000, 218944001, 218944002, 241863101, 242047501, 242047601, 242047603, 242047604, 242190201, 242190205, 25284, 297396810, 297396820, 297396860, 3001188, 3007351, 5300152474, 5303212179, 5304432418, 5304433938, 5308000027, 7241863101, 75303305677, 8000027, 8002682, 8003599, 9948634, C000038816,
```

C000062762, C000101601, C101601, DG152474, DG186717, F000095348, F000114259, F114259, F114467, F57308, F59348, F59667, F89348, G000152474, G000186717, G113802, G126108, G130541, G133131, G133132, G139368, G152474, G164636, G177375, G182474, G183485, G183642, G185165, G186717, G82520, G84078, G88044, G88045, G88048, G88674, G89597, K1123736, K1124054, K1124582, K1155177, K1159554, K1159591, K1166077, K1167150, K1206977, K1243117, K5015601, K5060201, M1090660, N8037919, R000900983, R009000149, WC040067, WC101601 Show less Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"15304-0A",

"15304-7A",

"177040A",

"177047A",

"17714-0A",

"17714-7A",

"178040A",

"178047A",

"19844C",

"19844D",

"20462151B",

"25310301000",

"25310301001",

"25310311000",

"25310311001",

"25310311002",

"25310911990",

"25310911991",

"25310911992",

"25311301100",

"25311301101",

"25311311100",

"25311312100",

"25311312101",

"25311312102",

"25311321100",

"25311321101",

"25311351100",

"25311351101",

"25311351102"

]

},

{

"part_name": "Compressor Start Relay 297237702",

"part_number": "PS3502347",

"manufacturer": "Kenmore",

"price": "78.51",

"description": "The start relay briefly boosts the compressor, and then shuts off as soon as the motor gets up to speed.\nNote: This part has been updated by the manufacturer. It may differ in appearance but will still function the same as the original.",

"rating": "89",

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start | Won't start | Fridge too warm This part works with the following products: Refrigerator, Freezer.

Part# 297237702 replaces these: AP5306469, 241527801, 241527803, 297237800, 5304492394, 7297237800 [Back to Top](#)",

"review_count": "7",

"appliance": "refrigerator",

"compatible_models": [

"25326052101",

"25326062101",

"25326072100",

"25326082100",

"25326092100",

"25326093100",

"25344352400",

"25344352401",

"25344352403",

"25344352404",

"25344352405",

"25344352407",

"25344352409",

"25344353400",

"25344353401",

"25344353402",

"25344353403",

"25344353404",

"25344353405",

"25344353407",

"25344353409",


```
"25344354400",
"25344354401",
"25344354403",
"25344354404",
"25344354405",
"25344354407",
"25344354409",
"25344359400",
"25344359401"
]
},
{
  "part_name": "Start Device 297259515",
  "part_number": "PS11728176",
  "manufacturer": "Kenmore",
  "price": "58.89",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part fixes the following symptoms: Won't start This part works with the following products: Refrigerator, Freezer. Part# 297259515 replaces these: AP5986809, 297259502, 297259510 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "25312822510",
    "25321042410",
    "25321042411",
```

"25321742510",
"25321742511",
"25321742512",
"25321742513",
"25321742514",
"25321742515",
"25321742516",
"25322040510",
"25322042410",
"25322042411",
"25322042412",
"25322052610",
"25322052611",
"25322742410",
"25322742411",
"25322742412",
"25327002410",
"25327002411",
"25327003410",
"25327003411",
"25327003412",
"25327009410",
"25327009411",
"25327009412",
"25327702411",
"25328042808",

```
"25328042809"

],
{
  "part_name": "Refrigerator Compressor Start Relay WPW10197428",
  "part_number": "PS11750123",
  "manufacturer": "Kenmore",
  "price": "76.29",
  "description": "This compressor start relay is for refrigerators. The compressor start relay attaches to the compressor and helps start the compressor motor. Safely store any food that could deteriorate while the power is off and unplug the refrigerator before installing this part.",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Will Not Start | Fridge and Freezer are too warm | Clicking sound | Fridge too warm This part works with the following products: Refrigerator. Part# WPW10197428 replaces these: AP6016830, W10128791, W10128795, W10197428, WPW10197428VP Back to Top",
  "review_count": "6",
  "appliance": "refrigerator",
  "compatible_models": [
    "10632852011",
    "10632853011",
    "10632862011",
    "10632863011",
    "10641132710",
    "10641132712",
    "10641133710",
    "10641133712",
```

"10641139710",
"10641139712",
"10641162310",
"10641163310",
"10641169310",
"10641172710",
"10641172711",
"10641172713",
"10641172714",
"10641173710",
"10641173711",
"10641173713",
"10641173714",
"10641179711",
"10641179713",
"10641179714",
"1064641133710",
"1064641173713",
"1064650043714",
"1064651339710",
"10650022211",
"10650023211"

]

},

{

"part_name": "Compressor Start Device and Capacitor W10613606",

"part_number": "PS8746522",

"manufacturer": "Kenmore",

"price": "75.87",

"description": "This includes both the run capacitor and the start relay. The capacitor helps the compressor kick on and off while maintaining a constant temperature to keep things frozen in your freezer.\r\nThe start relay boosts the compressor, and then shuts off as soon as the motor gets up to speed and the overload provides extra protection against excessive temperatures.",

"rating": "88",

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start | Fridge too warm | Fridge and Freezer are too warm | Freezer section too warm This part works with the following products: Refrigerator, Freezer. Part# W10613606 replaces these: AP5787784, 14217273, 67003186, 67003764, 67005560, 67005561, 67005562, 8171210, 8208290, 8208368, C8931605, W10416065, W10613606VP Back to Top",

"review_count": "28",

"appliance": "refrigerator",

"compatible_models": [

"1999A",

"1999A-P1193906WL",

"1999W",

"1999W-P1193906WW",

"2599A",

"2599A-P1190419WL",

"2599W",

"2599W-P1190419WW",

"35271",

"35271-P1121805W",

"35271W-P1121805WW",

```
"35278",
"35278-P1121806W",
"35278L-P1121806WL",
"35501",
"35501-P1121711W",
"35501W-P1121711WW",
"35508",
"35508-P1121712W",
"35508L-P1121712WL",
"35541",
"35541-P1121709W",
"35541W-P1121709WW",
"35548",
"35548-P1121710W",
"35548L-P1121710WL",
"36051",
"36051-P1122003W",
"36051W-P1122003WW",
"36058"
]
},
{
  "part_name": "Kickplate Grille WPW10534162",
  "part_number": "PS11756056",
  "manufacturer": "Kenmore",
  "price": "75.86",
```

"description": "This kickplate grille is attached to the bottom of the refrigerator.",

"rating": "99",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WPW10534162 replaces these: AP6022719, 12880102B, 67006954, W10236196, W10236196N, W10534162, W10534162N Back to Top",

"review_count": "12",

"appliance": "refrigerator",

"compatible_models": [

"10672002010",

"10672002011",

"10672002013",

"10672002015",

"10672003010",

"10672009010",

"10672009011",

"10672009013",

"10672009015",

"596467934251",

"596467934351",

"596467934451",

"596467934951",

"59665332602",

"59665332701",

"59665333602",

"59665333700",

"59665333701",

"59665339602",

"59665339700",

"59665339701",

"59667252601",

"59667252701",

"59667253600",

"59667253601",

"59667253602",

"59667253702",

"59667254601",

"59667254701",

"59667259600"

]

},

{

"part_name": "Toe Kick Plate - White WPW10534161",

"part_number": "PS11756055",

"manufacturer": "Kenmore",

"price": "71.19",

"description": "This kickplate grille is attached to the bottom of the refrigerator.",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator, Freezer. Part# WPW10534161 replaces these: AP6022718, 12880102W, 67007004, W10236195, W10236195N, W10534161, W10534161N Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"10672002010",

"10672002011",
"10672002013",
"10672002015",
"10672003010",
"10672009010",
"10672009011",
"10672009013",
"10672009015",
"596467934251",
"596467934351",
"596467934451",
"596467934951",
"59665332600",
"59665332602",
"59665333602",
"59665339602",
"59666122700",
"59666122702",
"59667252600",
"59667252601",
"59667254601",
"59667259601",
"59668252801",
"59668252802",
"59668253801",
"59668253802",

```
"59668254801",
"59668254802",
"59668259801"
]
},
{
  "part_name": "GRILLE-FRT WPW10534160",
  "part_number": "PS11756054",
  "manufacturer": "Kenmore",
  "price": "57.39",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
WPW10534160 replaces these: 12880102AP, W10236194, W10236194N, W10534160,
W10534160N Back to Top",
  "review_count": "3",
  "appliance": "refrigerator",
  "compatible_models": [
    "10672002010",
    "10672003010",
    "10672003011",
    "10672003012",
    "10672003013",
    "10672003014",
    "10672003016",
    "10672003017",
    "10672003018",
```

"10672009010",
"596379243017",
"596467934251",
"596467934351",
"596467934451",
"596467934951",
"59669382010",
"59669383010",
"59672002010",
"59672003010",
"59672003011",
"59672003012",
"59672003013",
"59672003014",
"59672003016",
"59672003017",
"59672003018",
"59672009010",
"59678332802",
"59678333802",
"59678333803"

]

},

{

"part_name": "Grille, Shroud WPW10175909",

"part_number": "PS11749612",

"manufacturer": "Kenmore",

"price": "54.87",

"description": "",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WPW10175909 replaces these: 13024802, 13024803, 67001079, 67006609, 8170881, W10175909 Back to Top",

"review_count": "4",

"appliance": "refrigerator",

"compatible_models": [

"10669312310",

"10672002011",

"10672002013",

"10672002015",

"10672003010",

"10672003011",

"10672003012",

"10672003013",

"10672003014",

"10672003016",

"10672003017",

"10672003018",

"10672009010",

"10672009011",

"10672009013",

"10672009015",

"10672013017",

```
"10678586800",  
"596467934251",  
"596467934351",  
"596467934451",  
"596467934951",  
"59662212200",  
"59662213200",  
"59662214200",  
"59662219200",  
"59662222200",  
"59662224200",  
"59662232200",  
"59662234200"
```

```
]
```

```
},
```

```
{
```

```
"part_name": "GRILLE W10803964",
```

```
"part_number": "PS11722923",
```

```
"manufacturer": "Kenmore",
```

```
"price": "70.83",
```

```
"description": "This is a kickplate, but you may also know it as a grate or a grille. It is a  
part for your refrigerator. The purpose of the kickplate is to allow air to circulate by flowing  
through the grates and into the machine compartment. This circulation of air is necessary  
because it will then cool the condenser. Black in color.",
```

```
"rating": "100",
```

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# W10803964 replaces these: 2186881B, 2186881W, 2198468B, 2198468TG, 2198468W, 4392875, 4392876, W10283941, W10283942, W10311028, W10311029 Back to Top",

"review_count": "4",

"appliance": "refrigerator",

"compatible_models": [

"10650502990",

"10650502991",

"10650503990",

"10650503991",

"10650504990",

"10650504991",

"10650509990",

"10650509991",

"10650542000",

"10650542001",

"10650544000",

"10650544001",

"10650552000",

"10650552001",

"10650554000",

"10650554001",

"10650557000",

"10650557001",

"10650559000",

"10650559001",

"10650562990",

```
"10650562991",
"10650562992",
"10650564990",
"10650564991",
"10650564992",
"10650567990",
"10650567991",
"10650567992",
"10650569990"
]
},
{
  "part_name": "Kickplate Grille - Black WP67006687",
  "part_number": "PS11743705",
  "manufacturer": "Kenmore",
  "price": "72.57",
  "description": "Clips are sold separately. NOTE: As per the manufacture the white
kickplate is no longer available.",
  "rating": "99",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
WP67006687 replaces these: AP6010523, 67006497, 67006498, 67006687, 67006836,
WP67006836 Back to Top",
  "review_count": "12",
  "appliance": "refrigerator",
  "compatible_models": [
    "59657012600",
    "59657013600",
```

"59657016600",
"59657019600",
"59657043600",
"59657049600",
"59657053600",
"59657059600",
"AC2224GEKB12",
"AC2224GEKS",
"AC2224GEKS13",
"AC2224GEKW",
"AC2224GEKW12",
"AC2224PEKB12",
"AC2224PEKW12",
"AC2225GEKB13",
"AC2225GEKS14",
"AC2225GEKW13",
"AC2228HEKB",
"AC2228HEKB0",
"AC2228HEKB13",
"AC2228HEKS",
"AC2228HEKS0",
"AC2228HEKS14",
"AC2228HEKW",
"AC2228HEKW0",
"AC2228HEKW13",
"ACD2234HRB",


```
"ACD2234HRW",
"ACD2234KRS"
]
},
{
  "part_name": "Kickplate Grille - Black WPW10534153",
  "part_number": "PS11756051",
  "manufacturer": "Kenmore",
  "price": "81.44",
  "description": "This kickplate grille is attached to the bottom of the refrigerator.",
  "rating": "90",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
WPW10534153 replaces these: AP6022714, 12880103B, 67006375, W10244561,
W10244561N, W10534153, W10534153N Back to Top",
  "review_count": "17",
  "appliance": "refrigerator",
  "compatible_models": [
    "10672012010",
    "10672013010",
    "10672019010",
    "10678586800",
    "59672012010",
    "59672012011",
    "59672012012",
    "59672012014",
    "59672012016",
    "59672013010",
```

"59672013011",
"59672013012",
"59672013014",
"59672019010",
"59672019011",
"59672019012",
"59672019014",
"59672019016",
"59676572601",
"59676572701",
"59676573702",
"59676574601",
"59676574701",
"59676579600",
"59676579601",
"59676579701",
"59676582501",
"59676582601",
"59676582602",
"59676582701"

]

},

{

"part_name": "Kickplate Grille - Apollo Gray WPW10534155",
"part_number": "PS11756053",
"manufacturer": "Kenmore",

"price": "79.99",

"description": "This kickplate grille is attached to the bottom of the refrigerator.",

"rating": "89",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WPW10534155 replaces these: AP6022716, 12880103AP, W10120000, W10191107, W10244558, W10244558N, W10534155, W10534155N Back to Top",

"review_count": "21",

"appliance": "refrigerator",

"compatible_models": [

"10672012010",

"10672013010",

"10672013017",

"10672019010",

"10678586800",

"59672012010",

"59672012011",

"59672012012",

"59672012014",

"59672013010",

"59672013011",

"59672013012",

"59672013013",

"59672013014",

"59672013015",

"59672013017",

"59672019010",

"59672019011",

"59672019012",
"59672019014",
"59677592800",
"59677592801",
"59677592802",
"59677592803",
"59677593800",
"59677593801",
"59677593802",
"59677593803",
"59677594800",
"59677594801"

]

},

{

"part_name": "BEARING WR2X8057",

"part_number": "PS298807",

"manufacturer": null,

"price": "18.89",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WR2X8057 replaces these: AP2059834, 298327, WR02X8057 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"SC4DLB",
"SC4DLC",
"SC4DLD",
"SC4DLE",
"SC4SSA",
"SC4SSB",
"SSD4CLB",
"TAC4SNYAW",
"TAC4SNYBW",
"TAW4SPB",
"TAW4SPC",
"TAW4SPD",
"TAW4SPE",
"TAX4ANXAWN",
"TAX4ANXBWN",
"TAX4ANXCWN",
"TAX4ANXEWN",
"TAX4DNTWH",
"TAX4DNXAWH",
"TAX4DNXBWH",
"TAX4DNXCWH",
"TAX4DNXWH",
"TAX4DNYBWH",
"TAX4DNYCWH",
"TAX4SNSA",
"TAX4SNSAWH",

```
"TAX4SNSBWH",
"TAX4SNTWH",
"TAX4SNXAWH",
"TAX4SNXBWH"
]
},
{
  "part_name": "BEARING W10891600",
  "part_number": "PS12070092",
  "manufacturer": null,
  "price": "18.46",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Back  
to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "ASI2575FRB00",
    "ASI2575FRS00",
    "ASI2575FRW00",
    "WRS325FDAB04",
    "WRS325FDAM04",
    "WRS325FDAT04",
    "WRS325FDAW04"
  ]
}
```

```
},
{
  "part_name": "BEARING 00605381",
  "part_number": "PS10057733",
  "manufacturer": null,
  "price": "6.33",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 00605381 replaces these: AP5950258, 605381 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "B11CB50SSS",
    "B11CB81SSS"
  ]
},
{
  "part_name": "Lock, Adjustable Bushing WP2004994",
  "part_number": "PS11738743",
  "manufacturer": null,
  "price": "7.60",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WP2004994 replaces these: 2004994 Back to Top",
  "review_count": null,
```

"appliance": "refrigerator",

"compatible_models": [

"106KSSS36QDW05",

"DYF42BIWS00",

"DYF42BNDI00",

"DYF48BIWS00",

"DYF48BNDI00",

"EF42DBSS",

"EF42NBSS",

"EF48DBSS",

"JF42CXFXDB00",

"JF42CXFXDB01",

"JF42PPFXDB00",

"JF42PPFXDB01",

"JF42SEFXDB00",

"JF42SEFXDB01",

"JF42SSFEXDA00",

"JF42SSFEXDA01",

"JF42SSFEXDA02",

"JS42CXDBDB00",

"JS42CXDUDB00",

"JS42CXDUDB02",

"JS42CXFXDB00",

"JS42PPDUDB00",

"JS42PPDUDB01",

"JS42PPDUDB02",


```
"JS42PPDUDB14",
"JS42PPDUDB15",
"JS42PPDUDB16",
"JS42PPDUDB20",
"JS42PPDUDE00",
"JS42PPDUDE01"
]
},
{
  "part_name": "BEARING 241760402",
  "part_number": "PS2331662",
  "manufacturer": null,
  "price": "15.90",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 241760402 replaces these: AP4315971, 7241760402 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "BGHS2634KE0",
    "BGHS2634KE1",
    "BGHS2634KE2",
    "CRSH237LB0",
    "CRSH237LB1",
    "CRSH237LB2",
```

```
"CRSH237LB3",  
"CRSH237LB4",  
"CRSH237LS0",  
"CRSH237LS1",  
"CRSH237LS2",  
"CRSH237LS3",  
"CRSH237LS4",  
"CRSH238MB1",  
"CRSH238MB2",  
"CRSH238MB3",  
"CRSH238MB4",  
"CRSH238MB5",  
"CRSH238MB6",  
"CRSH238MS1",  
"CRSH238MS2",  
"CRSH238MS3",  
"CRSH238MS4",  
"CRSH266MB2",  
"CRSH267LB0",  
"CRSH267LB2",  
"CRSH267LB3",  
"CRSH267LB5",  
"CRSH267LS0",  
"CRSH267LS2"  
]  
,
```

```
{
  "part_name": "Nut, Bearing WP1119018",
  "part_number": "PS11738298",
  "manufacturer": "Kenmore",
  "price": "7.60",
  "description": "",
  "rating": "80",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
WP1119018 replaces these: 1119018 Back to Top",
  "review_count": "1",
  "appliance": "refrigerator",
  "compatible_models": [
    "1064650043714",
    "10650022000",
    "10650022001",
    "10650022002",
    "10650022003",
    "10650022004",
    "10650022210",
    "10650022211",
    "10650023210",
    "10650023211",
    "10650027000",
    "10650027001",
    "10650027002",
    "10650027003",
```

```
"10650027004",
"10650029210",
"10650029211",
"10650029213",
"10650032000",
"10650032001",
"10650032002",
"10650032003",
"10650032004",
"10650037000",
"10650037001",
"10650037002",
"10650037003",
"10650037004",
"10650042710",
"10650042711"
]
},
{
  "part_name": "BEARING 241760404",
  "part_number": "PS2331664",
  "manufacturer": null,
  "price": "10.69",
  "description": "",
  "rating": null,
```

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 241760404 replaces these: AP4315972, 7241760404 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"BGHS2634KE0",

"BGHS2634KE1",

"BGHS2634KE2",

"CRSH237LB0",

"CRSH237LB1",

"CRSH237LB2",

"CRSH237LB3",

"CRSH237LB4",

"CRSH237LS0",

"CRSH237LS1",

"CRSH237LS2",

"CRSH237LS3",

"CRSH237LS4",

"CRSH238MB1",

"CRSH238MB2",

"CRSH238MB3",

"CRSH238MB4",

"CRSH238MB5",

"CRSH238MB6",

"CRSH238MS1",

"CRSH238MS2",

```
"CRSH238MS3",
"CRSH238MS4",
"CRSH266MB2",
"CRSH267LB0",
"CRSH267LB2",
"CRSH267LB3",
"CRSH267LB5",
"CRSH267LS0",
"CRSH267LS2"
]
},
{
  "part_name": "Ring, Thrust WP62658",
  "part_number": "PS11743303",
  "manufacturer": "Kenmore",
  "price": "8.08",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Washer, Washer  
Dryer Combo, Refrigerator. Part# WP62658 replaces these: 62658 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "10682872600",
    "110088732791",
    "11010202001",
```

"1101050299",
"11014852300",
"11015732400",
"11015842400",
"11015852400",
"11015862400",
"11015864400",
"11015942400",
"11015942401",
"11015944400",
"11015944401",
"11015952400",
"11015952401",
"11015954400",
"11015954401",
"11015962400",
"11015962401",
"11015964400",
"11015964401",
"11016102500",
"11016102501",
"11016102502",
"11016202690",
"11016212500",
"11016212501",
"11016212502",

```
"11016212503"
]
},
{
  "part_name": "Bushing Motor Mounting 241563601",
  "part_number": "PS977052",
  "manufacturer": "Kenmore",
  "price": "14.52",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part fixes the following symptoms: Noisy This part works with the following products: Refrigerator. Part# 241563601 replaces these: AP3706739, 1056621, 7241563601 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "25354362401",
    "25354362402",
    "25354362403",
    "25354362404",
    "25354362405",
    "25354362406",
    "25354362408",
    "25354362409",
    "2535436240A",
    "2535436240N",
    "2535436240P",
```



```
"25354363401",  
"25354363402",  
"25354363403",  
"25354363404",  
"25354363405",  
"25354363409",  
"2535436340A",  
"2535436340B",  
"2535436340N",  
"2535436340P",  
"25354364401",  
"25354364402",  
"25354364403",  
"25354364404",  
"25354364405",  
"25354364406",  
"25354364408",  
"25354364409",  
"2535436440A"  
]  
,  
{  
  "part_name": "Bearing Slide WR1X2048",  
  "part_number": "PS294809",  
  "manufacturer": "Kenmore",  
  "price": "10.22",
```

"description": "Sold individually.",

"rating": "80",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# WR1X2048 replaces these: AP2056821, 290510 Back to Top",

"review_count": "3",

"appliance": "refrigerator",

"compatible_models": [

"36348252893",

"36348252894",

"36348252896",

"36348252897",

"36348257893",

"36348257894",

"36348257896",

"36348257897",

"36350221000",

"36350222000",

"36350227000",

"36350232000",

"36350237000",

"36350242000",

"36350247000",

"36350622000",

"36350627000",

"36358072894",

"36358072896",

"36358075894",
"36358075896",
"36358077894",
"36358077896",
"36358251893",
"36358251894",
"36358252893",
"36358252894",
"36358252896",
"36358257893",
"36358257894"

]

},

{

"part_name": "DOOR SPRING 241688901",

"part_number": "PS1526431",

"manufacturer": "Kenmore",

"price": "22.09",

"description": "",

"rating": "60",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 241688901 replaces these: AP3965533, 1196692, 241688901, 5304421626, 5304426649, 7241688901 Back to Top",

"review_count": "2",

"appliance": "refrigerator",

"compatible_models": [

"25344302400",

"25344302401",
"25344303400",
"25344303401",
"25344303402",
"25344303403",
"25344304400",
"25344304401",
"25344309400",
"25344309401",
"25344333600",
"25344333601",
"25344333602",
"25344333603",
"25344333604",
"25344333605",
"25344333606",
"25344333607",
"25344333608",
"25344333609",
"2534433360A",
"25344352400",
"25344352401",
"25344352403",
"25344352404",
"25344352405",
"25344352406",

```
"25344352407",
"25344352408",
"25344352409"
]
},
{
  "part_name": "SPRING FF DOOR CLOSURE WR01X10255",
  "part_number": "PS283682",
  "manufacturer": null,
  "price": "26.99",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator, Freezer. Part# WR01X10255 replaces these: AP3669954, 944792, WR01X10856, WR1X10255 Back to Top",
  "review_count": "2",
  "appliance": "refrigerator",
  "compatible_models": [
    "CDB36LP2PBS1",
    "CDB36LP2PHS1",
    "CDB36LP2RBS1",
    "CDB36RP2PBS1",
    "CDB36RP2PHS1",
    "ZIC360NHALH",
    "ZIC360NHARH",
    "ZIC360NHBLH",
    "ZIC360NHBRH",
```

"ZIC360NHCLH",
"ZIC360NHCRH",
"ZIC360NMALH",
"ZIC360NMARH",
"ZIC360NMBLH",
"ZIC360NMBRH",
"ZIC360NMCLH",
"ZIC360NMCRH",
"ZIC360NNBLH",
"ZIC360NNBRH",
"ZIC360NNHLH",
"ZIC360NNHRH",
"ZIC360NPBLH",
"ZIC360NPBRH",
"ZIC360NRALH",
"ZIC360NRARH",
"ZIC360NRBLH",
"ZIC360NRBRH",
"ZIC360NRCLH",
"ZIC360NRCRH",
"ZIC360NRDLH"

]

},

{

"part_name": "SPRING- CH WP12565502",

"part_number": "PS11738537",

"manufacturer": "Kenmore",

"price": "11.13",

"description": "",

"rating": "70",

"troubleshooting_tips": "This part fixes the following symptoms: Not dispensing water
This part works with the following products: Refrigerator. Part# WP12565502 replaces
these: AP6005488, 12565501, 12565502 Back to Top",

"review_count": "2",

"appliance": "refrigerator",

"compatible_models": [

"59650002100",

"59650003100",

"59650004100",

"59650009100",

"59650012100",

"59650013100",

"59650014100",

"59650019100",

"59651672100",

"59651673100",

"59651674100",

"59651679100",

"59652672200",

"59652672201",

"59652672202",

"59652673200",

"59652673201",

"59652673202",

"59652674200",

"59652674201",

"59652674202",

"59652679200",

"59652679201",

"59652679202",

"59653462300",

"59653462301",

"59653462302",

"59653463300",

"59653463301",

"59653463302"

]

},

{

"part_name": "SPRING-ETC FRENCH WR02X13530",

"part_number": "PS3512841",

"manufacturer": null,

"price": "8.06",

"description": "SPRING-ETC FRENCH",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Back to Top",

"review_count": "2",

"appliance": "refrigerator",


```
"compatible_models": [  
  "DFSF9VKBABB",  
  "DFSF9VKBAAWW",  
  "DFSS9VKBASS",  
  "GFSF6PKBABB",  
  "GFSF6PKBAWW",  
  "GFSS6PKBASS",  
  "PFSF6PKXGBB",  
  "PFSF6PKXGWW",  
  "PFSS6PKXGSS"  
]  
,  
{  
  "part_name": "SPRING CLUTCH AM WR02X13645",  
  "part_number": "PS8757896",  
  "manufacturer": null,  
  "price": "8.06",  
  "description": "",  
  "rating": null,  
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Back  
to Top",  
  "review_count": null,  
  "appliance": "refrigerator",  
  "compatible_models": [  
    "CFE28TP2MBS1",  
    "CFE28TP2MCS1",
```

"CFE28TP2MDS1",
"CFE28TP2MES1",
"CFE28TP2MFS1",
"CFE28TP2MGS1",
"CFE28TP2MHS1",
"CFE28TP2MIS1",
"CFE28TP2MJS1",
"CFE28TP2MKS1",
"CFE28TP3MBD1",
"CFE28TP3MBW2",
"CFE28TP3MCD1",
"CFE28TP3MDD1",
"CFE28TP3MED1",
"CFE28TP3MFD1",
"CFE28TP3MGD1",
"CFE28TP3MHD1",
"CFE28TP3MID1",
"CFE28TP3MJD1",
"CFE28TP3MKD1",
"CFE28TP4MBW2",
"CFE28TP4MCW2",
"CFE28TP4MDW2",
"CFE28TP4MEW2",
"CFE28TP4MFW2",
"CFE28TP4MGW2",
"CFE28TP4MHW2",

```
"CFE28TP4MIW2",
"CFE28TP4MJW2"
]
},
{
  "part_name": "Torsion-Fit Spring WR49X10233",
  "part_number": "PS2374786",
  "manufacturer": "Kenmore",
  "price": "10.38",
  "description": "This part is the replacement torsion-fit spring for your refrigerator. It is made of metal and is sold individually. The torsion-fit spring provides tension to return the ice funnel back to its normal position after it dispenses ice. If your refrigerator is not dispensing ice or water properly, you may need to replace the torsion-fit spring. This is an OEM part sourced directly from the manufacturer.",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Not dispensing water This part works with the following products: Refrigerator. Part# WR49X10233 replaces these: AP4510574, 1557872, WR02X10584, WR2X10584 Back to Top",
  "review_count": "1",
  "appliance": "refrigerator",
  "compatible_models": [
    "A4425GDTABB",
    "A4425GDTAWW",
    "A4425GDTBBB",
    "A4425GDTBWW",
    "A4425GDTW",
    "BSS25GFPACC",
    "BSS25GFPWW",
```

"BSS25GFPCCC",
"BSS25GFPCWW",
"BSS25GFPDCC",
"BSS25GFPDWW",
"BSS25GFPECC",
"BSS25GFPEWW",
"BSS25GFPHCC",
"BSS25GFPHWW",
"BSS25JFRFWW",
"BSS25JFRJWW",
"BSS25JFTAWW",
"BSS25JFTBWW",
"BSS25JFTCWW",
"BSS25JFTDWW",
"BSS25JFTEWW",
"BSS25JFTGWW",
"BSS25JFTHWW",
"BSS25JFTIWW",
"BSS25JFTJWW",
"BSS25JFTNWW",
"BSS25JFTPWW",
"BSS25JSRFSS",
"BSS25JSRJSS"

]

},

{

"part_name": "SPRING HINGE MULLION WR01X11052",
"part_number": "PS6011724",
"manufacturer": null,
"price": "13.20",
"description": "",
"rating": "100",
"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator, Range. Back to Top",
"review_count": "1",
"appliance": "refrigerator",
"compatible_models": [
"CFE28TP2MBS1",
"CFE28TP2MCS1",
"CFE28TP2MDS1",
"CFE28TP2MES1",
"CFE28TP2MFS1",
"CFE28TP2MGS1",
"CFE28TP2MHS1",
"CFE28TP2MIS1",
"CFE28TP2MJS1",
"CFE28TP2MKS1",
"CFE28TP3MBD1",
"CFE28TP3MBW2",
"CFE28TP3MCD1",
"CFE28TP3MDD1",
"CFE28TP3MED1",

"CFE28TP3MFD1",
"CFE28TP3MGD1",
"CFE28TP3MHD1",
"CFE28TP3MID1",
"CFE28TP3MJD1",
"CFE28TP3MKD1",
"CFE28TP4MBW2",
"CFE28TP4MCW2",
"CFE28TP4MDW2",
"CFE28TP4MEW2",
"CFE28TP4MFW2",
"CFE28TP4MGW2",
"CFE28TP4MHW2",
"CFE28TP4MIW2",
"CFE28TP4MJW2"

]

},

{

"part_name": "Mullion Spring MHY62044103",

"part_number": "PS3630729",

"manufacturer": "LG",

"price": "8.76",

"description": "This spring is located on the mullion, or door flap, of your fridge. This spring is sourced from the genuine OEM manufacturer for various refrigerator models. It measures about 1.5 inches in total length, and is made entirely out of metal.",

"rating": "42",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator, Freezer. Part# MHY62044103 replaces these: AP5331239 Back to Top",

"review_count": "46",

"appliance": "refrigerator",

"compatible_models": [

"71042",

"71043",

"71049",

"71052",

"71053",

"71054",

"71059",

"71072",

"71073",

"71079",

"71092",

"71093",

"71099",

"72032",

"72033",

"72034",

"72036",

"79571042012",

"79571042013",

"79571043012",

"79571043013",

"79571049012",

"79571049013",

"79571052012",

"79571059012",

"79571062011",

"79571062012",

"79571063012",

"79571069011",

"79571069012"

]

},

{

"part_name": "Refrigerator Spring MHY62044106",

"part_number": "PS6012670",

"manufacturer": "LG",

"price": "15.27",

"description": "This is a replacement door mullion spring for your refrigerator. The door mullion is the flap that allows the doors on your French-door style refrigerator to close. The spring allows the mullion to fit into a latch on the refrigerator door frame, and lets the door stay closed properly. If you have a damaged spring, your door will not close properly. This part is sold individually.",

"rating": "75",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator, Freezer. Part# MHY62044106 replaces these: AP5657415, MHY62044104 Back to Top",

"review_count": "8",

"appliance": "refrigerator",

"compatible_models": [

"1867",
"48231784207",
"48231784214",
"48231784221",
"48231784412",
"495934",
"70322",
"70323",
"70329",
"70332",
"70333",
"70339",
"71052",
"71053",
"71054",
"71059",
"71072",
"71073",
"71079",
"71602",
"71603",
"71604",
"71606",
"71609",
"72032",
"72033",

```
"72039",
"72069",
"72493",
"72495"
]
},
{
  "part_name": "Bin Latch 2317277",
  "part_number": "PS1559884",
  "manufacturer": "Kenmore",
  "price": "37.25",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
2317277 replaces these: AP4030982, 2317277 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "10657022602",
    "10657022603",
    "10657023602",
    "10657023603",
    "10657024602",
    "10657024603",
    "10657026602",
    "10657026603",
```

"10657029602",
"10657029603",
"10657032602",
"10657032603",
"10657033602",
"10657033603",
"10657034602",
"10657034603",
"10657036602",
"10657036603",
"10657039602",
"10657039603",
"10657062602",
"10657062603",
"10657063602",
"10657063603",
"10657064602",
"10657064603",
"10657066602",
"10657066603",
"10657069602",
"10657069603"

]

},

{

"part_name": "Cam Assembly WP2182195",

"part_number": "PS11739045",

"manufacturer": "Kenmore",

"price": "9.75",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WP2182195 replaces these: 1110566, 1516847, 2161250, 2182008, 2182195, 516847, 938439 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"10640212010",

"10640212011",

"10641012100",

"10641012101",

"10641012104",

"10641014100",

"10641014101",

"10641014104",

"10641122210",

"10641122211",

"10641122212",

"10641122213",

"10641123210",

"10641123211",

"10641123212",

"10641124210",

```
"10641129210",
"10641129211",
"10641129212",
"10641129213",
"10641152210",
"10641152211",
"10641153210",
"10641153211",
"10641154210",
"10641159210",
"10641159211",
"10641159212",
"10641212100",
"10641212101"
]
},
{
  "part_name": "Door Lock Key 216362800",
  "part_number": "PS425605",
  "manufacturer": null,
  "price": "7.71",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Freezer, Refrigerator. Part# 216362800 replaces these: AP2113182 Back to Top",
  "review_count": null,
```

"appliance": "refrigerator",

"compatible_models": [

"B30LSPSC0",

"B30LSPSC1",

"CAF12",

"CAR11",

"CAR12",

"F22CW10",

"F22CW11",

"F22CW12",

"F22CW13",

"F22CW2",

"F22CW3",

"F22CW4",

"F22CW6",

"F22CW8",

"F22CW9",

"F22CWF0",

"F22CWF1",

"F22CWF2",

"F22CWF3",

"F22CWF4",

"GCBM18FQWA",

"GCBM18RQWA",

"KCBM180FQYA",

"KCBM180FQYB",

```
"KCBM180RQYA",
"KCBM180RQYB",
"KFS220RGW0",
"KFS220RGW1",
"KFS220RHY0",
"KFS220RHY1"
]
},
{
  "part_name": "Lever, Water Dispenser (Black) WPW10152859",
  "part_number": "PS11749102",
  "manufacturer": "Kenmore",
  "price": "50.45",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
WPW10152859 replaces these: 2180267, 2180270, 2180273, 2195090B, W10152859
Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "10644102300",
    "10644103300",
    "10644109300",
    "10645422800",
    "10645422801",
    "10645423800",
```

```
"10645423801",  
"10645429800",  
"10645429801",  
"10645432800",  
"10645432801",  
"10645433800",  
"10645433801",  
"10645439800",  
"10645439801",  
"10646022800",  
"10646022801",  
"10646023800",  
"10646023801",  
"10646029800",  
"10646029801",  
"10646032800",  
"10646032801",  
"10646033800",  
"10646033801",  
"10646039800",  
"10646039801",  
"10650222010",  
"10650223010",  
"10650228010"  
]  
},
```



```
{
  "part_name": "Freezer Door Key WP842177",
  "part_number": "PS11745972",
  "manufacturer": "Kenmore",
  "price": "7.91",
  "description": "Sold individually.",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Freezer,
Refrigerator. Part# WP842177 replaces these: 1111110, 14211802, 46000842177, 842177
Back to Top",
  "review_count": "2",
  "appliance": "refrigerator",
  "compatible_models": [
    "106722140",
    "106722141",
    "106722230",
    "106722231",
    "106722240",
    "106722241",
    "106722260",
    "106722261",
    "106722270",
    "106722420",
    "106722430",
    "106722431",
    "106722540",
    "106722541",
```

```
"106722550",
"106722551",
"106722560",
"106722561",
"106723140",
"106723230",
"106723231",
"106723240",
"106723260",
"106723520",
"106723530",
"106723540",
"106723550",
"106723560",
"106724230",
"106724231"
]
},
{
  "part_name": "Refrigerator Water Filter Cover Clip WP2223877",
  "part_number": "PS11739817",
  "manufacturer": null,
  "price": "45.93",
  "description": "The water filter cover holds the water filter cover in place in the water filter housing.",
  "rating": "100",
```

"troubleshooting_tips": "This part works with the following products: Refrigerator, Ice Maker. Part# WP2223877 replaces these: AP6006741, 2223877 Back to Top",

"review_count": "1",

"appliance": "refrigerator",

"compatible_models": [

"59672382410",

"596723824102",

"59672382411",

"59672382413",

"59672383410",

"596723834102",

"59672383411",

"59672383412",

"59672383413",

"59672389410",

"59672389411",

"59672389412",

"59672389413",

"7MF2976AEM00",

"7MF2976AEM01",

"7MF2976AEM02",

"7MF2976AEM03",

"7WF736SDAM10",

"7WF736SDAM11",

"7WF736SDAM12",

"7WF736SDAM13",

"7WF736SDAM14",

"EC3JHAXRL00",

"EC3JHAXRL01",

"EC3JHAXRL11",

"EC3JHAXRL12",

"EC3JHAXRL13",

"EC3JHAXRS00",

"EC3JHAXRS01",

"EC3JHAXRS11"

]

},

{

"part_name": "Freezer Door Key WP4356840",

"part_number": "PS11742410",

"manufacturer": null,

"price": "13.94",

"description": "This metal freezer door key has a cross shape and is approximately 2 inches long. If your freezer door will not stay shut, you can use the key as a quick fix to keep it closed. If your key will not lock, or unlock the freezer door, check to see if it has been bent or damaged. If the key is damaged, you should look to replace it to avoid damaging the lock. The key should engage the locking mechanism with ease. If the lock sticks when you turn the key, penetrating fluid should be used to loosen the mechanism. These keys are sold separately, and should be stored somewhere safe and not next to the unit.",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Freezer, Refrigerator. Part# WP4356840 replaces these: 14211356, 2-80060-106, 4356840 Back to Top",

"review_count": "3",

"appliance": "refrigerator",

"compatible_models": [

"AQF2013TEW03",

"AQF2013TEW04",

"AQU1625BEW",

"AQU1627BRW03",

"AQU1827BRW",

"AQU1827BRW03",

"AQU2024BRW03",

"AQU2027BRW03",

"AQU2027BRW04",

"AQU2027BRW05",

"AQU2027BRW06",

"CP1961XLQ00",

"EV120FXDN00",

"EV120FXDN01",

"EV120FXEN00",

"EV120FXEN01",

"EV120FXEN02",

"EV120FXG06",

"EV120FXGW00",

"EV120FXGW01",

"EV120FXGW02",

"EV120FXGW03",

"EV120FXGW04",

"EV120FXGW05",

```
"EV120FXGW06",
"EV120FXGW07",
"EV120FXKQ00",
"EV120FXKQ01",
"EV120FXKQ02",
"EV120FXKQ03"
]
},
{
  "part_name": "Door Handle with Mounting Block 218428121",
  "part_number": "PS427931",
  "manufacturer": null,
  "price": "47.51",
  "description": "This gray door handle can be used on either the fridge or freezer side. It comes with the mounting block, but does not include the screws.",
  "rating": "90",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 218428121 replaces these: AP2114546, 781148, 218428107 Back to Top",
  "review_count": "2",
  "appliance": "refrigerator",
  "compatible_models": [
    "25363702200",
    "25363702201",
    "25363702202",
    "25363702203",
    "25364702400",
    "BRT18HP7GC0",
```

```
"BRT18HP7JC0",  
"BRT18HP7JC1",  
"CRT182HNB0",  
"CRT182HNB1",  
"CRT182HNB2",  
"CRT182HNB3",  
"CRT182HNB4",  
"CRT182HNB5",  
"CRT182HNB6",  
"CRT182HNBW0",  
"CRT182HQB0",  
"CRT182HQB1",  
"CRT182HQB2",  
"CRT182HQB3",  
"CRT182HQB4",  
"CRT182IPB2",  
"CRT182IPB4",  
"CRT182IPB5",  
"CRT182IQB0",  
"CRT182IQB1",  
"CRT182IQB2",  
"CRT182IQB3",  
"CRT182IQB4A",  
"CRT182IQB8B"  
]  
},
```

```
{
  "part_name": "Control-humidity 241613501",
  "part_number": "PS1146890",
  "manufacturer": "Kenmore",
  "price": "10.12",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 241613501 replaces these: AP3867226, 1157211 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "25360112410",
    "25360113410",
    "25360113411",
    "25360119410",
    "25360523307",
    "25360523308",
    "25360523309",
    "2536052330A",
    "25360525306",
    "25360525308",
    "25360525309",
    "2536052530A",
    "25360602410",
    "25360602411",
```



```
"25360602412",
"25360602413",
"25360602414",
"25360602415",
"25360602416",
"25360603410",
"25360603411",
"25360603412",
"25360603413",
"25360603414",
"25360603415",
"25360603416",
"25360604410",
"25360604411",
"25360604412",
"25360604413"
]
},
{
  "part_name": "Control-humidity 241613502",
  "part_number": "PS1146891",
  "manufacturer": "Kenmore",
  "price": "35.30",
  "description": "",
  "rating": null,
```

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 241613502 replaces these: AP3867210, 1157212 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"25360082410",

"25360082411",

"25360082412",

"25360082413",

"25360082414",

"25360082415",

"25360082416",

"25360082417",

"25360083410",

"25360083411",

"25360083412",

"25360083413",

"25360083414",

"25360083415",

"25360083416",

"25360083417",

"25360085611",

"25360085612",

"25360085613",

"25360085614",

"25360087712",

```
"25360089410",
"25360089411",
"25360089412",
"25360089413",
"25360089414",
"25360089415",
"25360089416",
"25360089417",
"25360112410"
]
},
{
  "part_name": "KNOB CONTROL WR02X13355",
  "part_number": "PS2577840",
  "manufacturer": null,
  "price": "15.66",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
WR02X13355 replaces these: WR02X10508, WR2X10508 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "36211XBMBRWW",
    "36211XBMDRWW",
    "36211XBMERWW",
```

"36211XBMFRWW",
"36211XBRERWW",
"36211XBRFRWW",
"36411XBRERWW",
"36411XBRFRWW",
"37511KBSARWW",
"37511KBSERWW",
"38341FBMERWW",
"38341FBMFRWW",
"38351HBMERWW",
"38351HBMFRWW",
"38351HBRERWW",
"38351HBRFRWW",
"38451HBRERWW",
"38451HBRFRWW",
"A3315ABRERWW",
"A3315ABRFRWW",
"A3315ABRW",
"A3316ABSARBB",
"A3316ABSARWW",
"A3316ABSB",
"A3316ABSBRBB",
"A3316ABSBRWW",
"A3316ABSDRBB",
"A3316ABSDRWW",
"A3316ABSERBB",

```
"A3316ABSERWW"
]
},
{
  "part_name": "KNOB 5304490963",
  "part_number": "PS7784321",
  "manufacturer": null,
  "price": "39.25",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 5304490963 replaces these: AP5671973 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "FFET1022QB0",
    "FFET1022QS0",
    "FFET1022QW0",
    "FFET1222QB0",
    "FFET1222QS0",
    "FFET1222QW0",
    "FFPT10F3NB0",
    "FFPT10F3NM0",
    "FFPT10F3NW0",
    "FFPT12F3NB0",
    "FFPT12F3NM0",
```

```
"FFPT12F3NV0",
"FFPT12F3NW0",
"FFTR1022QB0",
"FFTR1022QM0",
"FFTR1022QW0",
"FFTR1222QB0",
"FFTR1222QM0",
"FFTR1222QW0"
]
},
{
  "part_name": "Damper Control Knob 240367001",
  "part_number": "PS430256",
  "manufacturer": "Kenmore",
  "price": "48.80",
  "description": "This white knob accepts a D-shaped shaft.",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 240367001 replaces these: AP2116138, 891320 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "25331113300",
    "25331113302",
    "25331113304",
    "25331113308",
```

"2533111330A",
"2533111330B",
"2533111330C",
"2533111330D",
"2533111330E",
"2533111330F",
"2533111330G",
"2533111330H",
"2533111330J",
"2533111330K",
"2533111330L",
"25331115300",
"25331115302",
"25331115304",
"25331115308",
"2533111530A",
"2533111530B",
"2533111530C",
"2533111530D",
"2533111530E",
"2533111530F",
"2533111530G",
"2533111530H",
"2533111530J",
"2533111530K",
"2533111530L"

```
]
},
{
  "part_name": "Bin Button - Blue WP2315403",
  "part_number": "PS11740351",
  "manufacturer": "Kenmore",
  "price": "27.92",
  "description": "",
  "rating": "94",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WP2315403 replaces these: AP6007239, 2198605, 2220686, 2255575, 2255816, 2301345, 2315403 Back to Top",
  "review_count": "3",
  "appliance": "refrigerator",
  "compatible_models": [
    "10641522500",
    "10641523500",
    "10641524500",
    "10641529500",
    "10644022600",
    "10644022601",
    "10644023600",
    "10644023601",
    "10644024600",
    "10644029600",
    "10644029601",
    "10644032600",
```



```
"10644032601",
"10644033600",
"10644033601",
"10644034600",
"10644039600",
"10644039601",
"10644102300",
"10644103300",
"10644109300",
"10644322400",
"10644323400",
"10644324400",
"10644329400",
"10644422600",
"10644422601",
"10644423600",
"10644423601",
"10644424600"
]
},
{
  "part_name": "Refrigerator Control Knob WR02X21250",
  "part_number": "PS11721880",
  "manufacturer": null,
  "price": "7.69",
  "description": ""
```

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WR02X21250 replaces these: AP5986429 Back to Top",

"review_count": "1",

"appliance": "refrigerator",

"compatible_models": [

"FBS15RCKJRWW",

"FBS15RCKLRWW",

"FBS15RCKMRWW",

"GAS18PGJFRWW",

"GAS18PGJJRWW",

"GAS18PGJLRWW",

"GAS18PSJFRSS",

"GAS18PSJJRSS",

"GAS18PSJLRSS",

"GIE16DGHBRBB",

"GIE16DGHBRWW",

"GIE16DGHCRBB",

"GIE16DGHCRWW",

"GIE16DGHHRBB",

"GIE16DGHHRWW",

"GIE16GSHBRSS",

"GIE16GSHCRSS",

"GIE16GSHHRSS",

"GIE16GSHLRSS",

"GIE16GSHMRSS",

```
"GIE18CTHBRBB",
"GIE18CTHBRWW",
"GIE18CTHDRBB",
"GIE18CTHDRWW",
"GIE18CTHERBB",
"GIE18CTHERWW",
"GIE18CTHGRBB",
"GIE18CTHGRWW",
"GIE18CTHHRBB",
"GIE18CTHHRWW"
]
},
{
  "part_name": "Thermostat Knob - White 216591506",
  "part_number": "PS11726369",
  "manufacturer": null,
  "price": "23.20",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Freezer,
Refrigerator. Part# 216591506 replaces these: AP5986782, 216423300, 216424800,
216591500, 216591501 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "B30LSPSC0",
    "B30LSPSC1",
```

"CAF11",
"CAF12",
"CAR11",
"CAR12",
"F22CW10",
"F22CW11",
"F22CW12",
"F22CW13",
"F22CW2",
"F22CW3",
"F22CW4",
"F22CW6",
"F22CW7",
"F22CW8",
"F22CW9",
"F22CWF0",
"F22CWF1",
"F22CWF2",
"F22CWF3",
"F22CWF4",
"FCFS181LQBA",
"FCFS201LFB0",
"FCFS201LFB1",
"FCFS201LFB2",
"FCFS201LFB3",
"FCFS201LFB4",

```
"FCFS201LFW0",
"FCFS201LFW2"
]
},
{
  "part_name": "BUTTON ASSEMBLY ABH74279601",
  "part_number": "PS3637214",
  "manufacturer": "LG",
  "price": "32.84",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Back  
to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "72043",
    "72053",
    "72063",
    "72093",
    "72183",
    "72193",
    "72353",
    "72373",
    "79572043110",
    "79572043112",
```

```
"79572043313",
"79572043315",
"79572043316",
"79572053110",
"79572053111",
"79572053112",
"79572053113",
"79572053114",
"79572053117",
"79572053118",
"79572053313",
"79572053316",
"79572053318",
"79572063110",
"79572063111",
"79572063112",
"79572063113",
"79572063117",
"79572063315",
"79572063317"
]
},
{
  "part_name": "Ice Bin Button WP2252265",
  "part_number": "PS11739853",
  "manufacturer": null,
```

"price": "32.76",

"description": "Blue in color.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker won't dispense ice This part works with the following products: Refrigerator. Part# WP2252265 replaces these: AP6006771, 2252265 Back to Top",

"review_count": "12",

"appliance": "refrigerator",

"compatible_models": [

"KBSD502ESS00",

"KBSD508ESS00",

"KSSC36QMS00",

"KSSC36QMS01",

"KSSC36QMS02",

"KSSC36QMS03",

"KSSC36QTS00",

"KSSC36QTS02",

"KSSC36QTS03",

"KSSC36QTS04",

"KSSC36QTS05",

"KSSC36QTS06",

"KSSC36QTS07",

"KSSC36QTS08",

"KSSC36QTS10",

"KSSC42QMS00",

"KSSC42QMS01",

"KSSC42QMS02",

"KSSC42QMS03",

"KSSC42QMU00",

"KSSC42QMU01",

"KSSC42QTS00",

"KSSC42QTS02",

"KSSC42QTS03",

"KSSC42QVS00",

"KSSC42QVS01",

"KSSC42QVS02",

"KSSC42QVS03",

"KSSC42QVS04",

"KSSC42QVS05"

]

},

{

"part_name": "Water Dispenser Button ABH74219603",

"part_number": "PS8748092",

"manufacturer": "LG",

"price": "56.57",

"description": "This water dispenser button is a genuine OEM part designed for LG refrigerators. When you push the button, a valve is activated inside the refrigerator, which releases water from the internal water supply. If the button is faulty, you will also likely notice that the dispenser can not release any water, or that it does so inconsistently. Over time the button may fail due to aging or due to accidental damage. You will need to replace the button if it is unresponsive when you push it, or if it seems stuck.",

"rating": "47",

"troubleshooting_tips": "This part fixes the following symptoms: Not dispensing water
This part works with the following products: Refrigerator. Part# ABH74219603 replaces
these: AP5782522, ABH74219601, ABH74219602, ABH74219604 Back to Top",

"review_count": "3",

"appliance": "refrigerator",

"compatible_models": [

"GR-J266LSJM",

"GR-J268LSJP",

"GR-J268LSJV",

"GR-J318LSBM",

"GR-J318LSJM",

"GR-J318LSJP",

"GR-J31ALSJP",

"GR-J31GHSJM",

"GR-J338HSJM",

"GR-J338HSJP",

"GR-L24GHSJM",

"GR-L268LSJM",

"GR-L268LSJP",

"GR-L318LSGP",

"GR-L318LSJM",

"GR-L318LSJP",

"GR-L31ALSJP",

"GR-L31GHSJF",

"GR-L31GHSJM",

"GR-L31GUSJM",

"GR-L338HSJM",

```
"GR-L338HSJP",
"GR-X23GHSJM",
"GR-X248LSJM",
"GR-X308LSJM",
"GR-X30GHSJM",
"GRL318LSJP",
"LFX25991ST",
"LFX25991ST00",
"LFX25991ST01"
]
},
{
  "part_name": "Humidity Slide Button WR02X11174",
  "part_number": "PS285537",
  "manufacturer": null,
  "price": "8.06",
  "description": "This humidity slide is located on the handle of the vegetable/meat
drawer.",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
WR02X11174 replaces these: AP3670764, 947457, WR02X10544, WR2X10544,
WR2X11174 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "BSS25GFPACC",
    "BSS25GFPAWW",
```

"BSS25GFPCCC",
"BSS25GFPCWW",
"BSS25GFPDCC",
"BSS25GFPDWW",
"BSS25GFPECC",
"BSS25GFPEWW",
"BSS25GFPHCC",
"BSS25GFPHWW",
"BSS25JFRFWW",
"BSS25JFRJWW",
"BSS25JFTAWW",
"BSS25JFTBWW",
"BSS25JFTCWW",
"BSS25JFTDWW",
"BSS25JFTEWW",
"BSS25JFTGWW",
"BSS25JFTHWW",
"BSS25JFTIWW",
"BSS25JFTJWW",
"BSS25JFTNWW",
"BSS25JFTPWW",
"BSS25JSRFSS",
"BSS25JSRJSS",
"BSS25JSTASS",
"BSS25JSTBSS",
"BSS25JSTCSS",

```
"BSS25JSTDSS",  
"BSS25JSTESS"  
]  
},  
{  
  "part_name": "Recess Trim - Black WR38X23216",  
  "part_number": "PS11737059",  
  "manufacturer": null,  
  "price": "36.50",  
  "description": "This part is a replacement recess trim for your refrigerator. It is the trim  
that runs around the perimeter of the ice/water dispenser. You will want to replace the  
recess trim if it is cracked or damaged. This part is black in color and is sold individually. It  
is approximately 16 inches long and 10 inches wide. It is a genuine OEM replacement part  
sourced directly from the manufacturer.",  
  "rating": "98",  
  "troubleshooting_tips": "This part fixes the following symptoms: Not dispensing water  
This part works with the following products: Refrigerator. Part# WR38X23216 replaces  
these: AP6024798, WR38X10302, WR38X10348 Back to Top",  
  "review_count": "9",  
  "appliance": "refrigerator",  
  "compatible_models": [  
    "A4425GDTABB",  
    "A4425GDTBBB",  
    "BSS25JSRFSS",  
    "BSS25JSRJSS",  
    "BSS25JSTASS",  
    "BSS25JSTBSS",  
    "BSS25JSTCSS",
```

```
"BSS25JSTDSS",  
"BSS25JSTEES",  
"BSS25JSTGSS",  
"BSS25JSTHSS",  
"BSS25JSTISS",  
"BSS25JSTJSS",  
"BSS25JSTNSS",  
"BSS25JSTPSS",  
"BSS25JSTRSS",  
"ESH22JFWABB",  
"ESH22JFWBBB",  
"ESH22JFWCBB",  
"ESH22JFWDBB",  
"ESH22JFWEBB",  
"ESH22JFXABB",  
"ESH22JFXJBB",  
"ESH22JFXKBB",  
"ESH22JSWASS",  
"ESH22JSWBSS",  
"ESH22JSWCSS",  
"ESH22JSWDSS",  
"ESH22JSWESS",  
"ESH22JSXASS"  
]  
,  
{
```

"part_name": "Crisper Shelf Front Trim - White WPW10231343",

"part_number": "PS11750691",

"manufacturer": "Kenmore",

"price": "76.23",

"description": "",

"rating": "90",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WPW10231343 replaces these: 12530629, 67002441, 67002523, 67003935, 67004369, W10231343, W10231343N Back to Top",

"review_count": "2",

"appliance": "refrigerator",

"compatible_models": [

"59669382010",

"59669383010",

"59675232400",

"59675234400",

"59675239400",

"59678282800",

"59678282802",

"59678282803",

"59678282900",

"59678282902",

"59678282903",

"59678283800",

"59678283802",

"59678283803",

"59678283804",

"59678283900",
"59678283902",
"59678283903",
"59678289800",
"59678289802",
"59678289803",
"59678289804",
"59678289900",
"ABB2224BRB01",
"ABB2224BRB02",
"ABB2224BRB03",
"ABB2224BRM01",
"ABB2224BRM02",
"ABB2224BRM03",
"ABB2224BRW01"

]

},

{

"part_name": "TRIM 242176404",

"part_number": "PS8689271",

"manufacturer": null,

"price": "50.13",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 242176404 replaces these: AP5690310 Back to Top",

```
"review_count": null,  
"appliance": "refrigerator",  
"compatible_models": [  
  "CFD27WIPS2",  
  "CFD27WIPS3",  
  "CFD28WIQS0",  
  "CFD28WIQS1",  
  "CFD28WIQS6",  
  "CFD28WIQS8",  
  "CFD28WIQS9",  
  "CFD28WIQSA",  
  "CFD28WIQSC",  
  "CFD28WIQSE",  
  "FFHB2740PS0",  
  "FFHB2740PS1",  
  "FFHB2740PS2",  
  "FFHB2740PS3",  
  "FFHB2740PS4",  
  "FFHB2740PS5",  
  "FFHB2740PS6A",  
  "FFHB2740PS7A",  
  "FFHB2740PS8A",  
  "FFHB2740PS9A",  
  "FFHB2740PSAA",  
  "FFHB2740PSBA",  
  "FFHB2740PSCA",
```



```
"FFHB2740PSDA",
"FFHB2740PSEA",
"FFSC2323TS0",
"FFSC2323TS3",
"FFSC2323TS4",
"FFSC2323TS6",
"FFSC2323TS7"
]
},
{
  "part_name": "Front Drawer Trim W11214888",
  "part_number": "PS12349362",
  "manufacturer": "Kenmore",
  "price": "38.92",
  "description": "Genuine OEM part",
  "rating": "80",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
W11214888 replaces these: AP6329115, W11084209 Back to Top",
  "review_count": "1",
  "appliance": "refrigerator",
  "compatible_models": [
    "10651782413",
    "10651783413",
    "10651783416",
    "10651789414",
    "WRS571CIHB00",
```

"WRS571CIHB01",
"WRS571CIHB02",
"WRS571CIHB04",
"WRS571CIHV00",
"WRS571CIHV01",
"WRS571CIHV02",
"WRS571CIHV04",
"WRS571CIHW00",
"WRS571CIHW01",
"WRS571CIHW02",
"WRS571CIHW04",
"WRS571CIHZ00",
"WRS571CIHZ01",
"WRS571CIHZ02",
"WRS571CIHZ04",
"WRS586FIEH04",
"WRS586FIEM04",
"WRS586FIEM05",
"WRS588FIHB00",
"WRS588FIHB04",
"WRS588FIHV00",
"WRS588FIHV04",
"WRS588FIHW00",
"WRS588FIHW04",
"WRS588FIHZ00"

]

```
},  
{  
  "part_name": "Refrigerator Door Trim W11126055",  
  "part_number": "PS12114451",  
  "manufacturer": null,  
  "price": "72.38",  
  "description": "",  
  "rating": null,  
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#  
W11126055 replaces these: AP6261398, W10719702 Back to Top",  
  "review_count": null,  
  "appliance": "refrigerator",  
  "compatible_models": [  
    "5GT118FFEW00",  
    "ART308FFDB00",  
    "ART308FFDB01",  
    "ART308FFDB02",  
    "ART308FFDB03",  
    "ART308FFDB06",  
    "ART308FFDB07",  
    "ART308FFDB08",  
    "ART308FFDB10",  
    "ART308FFDB11",  
    "ART308FFDM00",  
    "ART308FFDM01",  
    "ART308FFDM02",
```

```
"ART308FFDM03",
"ART308FFDM06",
"ART308FFDM07",
"ART308FFDM08",
"ART308FFDM10",
"ART308FFDM11",
"ART308FFDW00",
"ART308FFDW01",
"ART308FFDW02",
"ART308FFDW03",
"ART308FFDW06",
"ART308FFDW07",
"ART308FFDW08",
"ART308FFDW10",
"ART308FFDW11",
"ART318FFDB02",
"ART318FFDB03"
]
},
{
  "part_name": "Button Plug 240494001",
  "part_number": "PS430881",
  "manufacturer": "Kenmore",
  "price": "13.97",
  "description": "Sold individually.",
  "rating": null,
```

"troubleshooting_tips": "This part works with the following products: Refrigerator, Freezer. Part# 240494001 replaces these: AP2116551, 917518, 08000090, 215352201, 218110901, 218915701, 240383001, 240428301, 240479601, 297095300, 3001305, 5308000090, 53303W, 7240479601, 8000090, F140382-032, F140382032, G140630, G146392-01, G162971-01 ... Show more , G162977, G162977-01, G162997-01, G185175, R009000112 Show less Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"15304-0A",

"15304-7A",

"177040A",

"177047A",

"17714-0A",

"17714-7A",

"178040A",

"178047A",

"20462151B",

"25321742513",

"25321742514",

"25321742515",

"25321742516",

"25322042411",

"25322052610",

"25322052611",

"25322442413",

"25322442414",

```

"25322442415",
"25322442416",
"25322742411",
"25322742412",
"25323082100",
"25323082101",
"25323082102",
"25323082103",
"25323082104",
"25331113300",
"25331113302",
"25331113304"
]
},
{
  "part_name": "Door Mullion 241778808",
  "part_number": "PS3501044",
  "manufacturer": "Kenmore",
  "price": "230.27",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# 241778808 replaces these: AP5305304, 241778801, 7241778801 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [

```

"25370312211",
"25370312212",
"25370312213",
"25370312214",
"25370313213",
"25370319211",
"25370319212",
"25370319213",
"25370319214",
"25370342210",
"25370342410",
"25370342411",
"25370342412",
"25370342413",
"25370342414",
"25370342415",
"25370342416",
"25370342417",
"25370342418",
"25370342419",
"2537034241A",
"2537034241B",
"2537034241C",
"25370343411",
"25370343412",
"25370343413",

```
"25370343418",
"25370343419",
"2537034341A",
"2537034341B"
]
},
{
  "part_name": "Vertical Mullion Rail - White WP12722803W",
  "part_number": "PS11738597",
  "manufacturer": "Kenmore",
  "price": "163.44",
  "description": "White in color.",
  "rating": "91",
  "troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# WP12722803W replaces these: AP6005548, 12722803C, 12722803CN, 12722803W, 12722803WN, 12732501C, 12732501W, 67002718, 67002953, 67003263, 67003265, 67003434, 67005462, 8208249 Back to Top",
  "review_count": "11",
  "appliance": "refrigerator",
  "compatible_models": [
    "10672002010",
    "10672002011",
    "10672002013",
    "10672002015",
    "10672003010",
    "10672009010",
```



```
"10672009011",  
"10672009013",  
"10672009015",  
"10672012010",  
"10672013010",  
"10672019010",  
"10678586800",  
"59672002010",  
"59672002011",  
"59672002013",  
"59672002015",  
"59672003010",  
"59672009010",  
"59672009011",  
"59672009013",  
"59672009015",  
"59672012010",  
"59672012011",  
"59672012012",  
"59672012014",  
"59672012016",  
"59672013010",  
"59672013011",  
"59672013012"  
]  
},
```

```
{
  "part_name": "TRIM SHELF FZ WR38X10368",
  "part_number": "PS1015820",
  "manufacturer": null,
  "price": "11.64",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Back
to Top",
  "review_count": "1",
  "appliance": "refrigerator",
  "compatible_models": [
    "GSE23GGEBCBB",
    "GSE23GGEBCWW",
    "GSE23GGKECBB",
    "GSE23GGKECCC",
    "GSE23GGKECWW",
    "GSE23GGKJCBB",
    "GSE23GGKJCCC",
    "GSE23GGKJCWW",
    "GSE23GGKKCBB",
    "GSE23GGKKCCC",
    "GSE23GGKKCWW",
    "GSE23GGKNCBB",
    "GSE23GGKNCCC",
    "GSE23GGKNCWW",
  ]
}
```

```
"GSE23GGKPCBB",
"GSE23GGKPCCC",
"GSE23GGKPCWW",
"GSE23GGKRCBB",
"GSE23GGKRCCC",
"GSE23GGKRCWW",
"GSE23GGPBCBB",
"GSE23GGPBCWW",
"GSE23GGPECBB",
"GSE23GGPECWW",
"GSE23GSECCSS",
"GSE23GSEFCSS",
"GSE23GSKECSS",
"GSE23GSKJCSS",
"GSE23GSKKCSS",
"GSE23GSKMCSS"
]
},
{
  "part_name": "Shelf Front Trim - White 240357703",
  "part_number": "PS430138",
  "manufacturer": "Kenmore",
  "price": "56.03",
  "description": "",
  "rating": "100",
```

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 240357703 replaces these: AP2116048, 891226 Back to Top",

"review_count": "1",

"appliance": "refrigerator",

"compatible_models": [

"25360302410",

"25360302411",

"25360302412",

"25360302413",

"25360302414",

"25360302415",

"25360302610",

"25360302611",

"25360303410",

"25360303411",

"25360303412",

"25360303413",

"25360303414",

"25360303415",

"25360303610",

"25360303611",

"25360303612",

"25360304410",

"25360304411",

"25360304412",

"25360304413",

"25360304414",
"25360304415",
"25360304610",
"25360304611",
"25360309410",
"25360309411",
"25360309412",
"25360309413",
"25360309414"

]

},

{

"part_name": "Connector WP2198677",

"part_number": "PS11739248",

"manufacturer": "Kenmore",

"price": "26.87",

"description": "",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Refrigerator, Miscellaneous. Part# WP2198677 replaces these: 1533810, 2198677, 3191383, 4159059, 4159060, 4159061, 4166281, 4319153, 4378394, 533810, 544164, 59205-1, 596524, 61001615, 84319153, 867148, 9701146, 984495, B5706902, R9800655 ... Show more , Y61001615, YB5706902 Show less Back to Top",

"review_count": "1",

"appliance": "refrigerator",

"compatible_models": [

"10650582000",

"10650582001",
"10650584000",
"10650584001",
"10650585000",
"10650585001",
"10650589000",
"10650589001",
"10650592000",
"10650592001",
"10650592002",
"10650592003",
"10650593000",
"10650593001",
"10650593002",
"10650593003",
"10650594000",
"10650594001",
"10650594002",
"10650594003",
"10650599000",
"10650599001",
"10650599002",
"10650599003",
"10650782000",
"10650782001",
"10650784000",

```
"10650784001",
"10650785000",
"10650785001"
]
},
{
  "part_name": "Connector WP2154473",
  "part_number": "PS11738911",
  "manufacturer": "Kenmore",
  "price": "20.52",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
WP2154473 replaces these: AP6005850, 2154473, 2162412, 2162413 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "10650022000",
    "10650022001",
    "10650022002",
    "10650022003",
    "10650022004",
    "10650027000",
    "10650027001",
    "10650027002",
    "10650027003",
```

```
"10650027004",  
"10650032000",  
"10650032001",  
"10650032002",  
"10650032003",  
"10650032004",  
"10650037000",  
"10650037001",  
"10650037002",  
"10650037003",  
"10650037004",  
"10650202990",  
"10650202991",  
"10650202992",  
"10650202993",  
"10650203990",  
"10650203991",  
"10650203992",  
"10650203993",  
"10650204990",  
"10650204991"  
]  
},  
{  
  "part_name": "HARNESS 242213501",  
  "part_number": "PS10060215",
```


"manufacturer": "Kenmore",

"price": "99.65",

"description": "",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 242213501 replaces these: AP5952242, 242290502, 242303202 Back to Top",

"review_count": "1",

"appliance": "refrigerator",

"compatible_models": [

"25360002410",

"25360002411",

"25360022410",

"25360022411",

"25360022412",

"25360302410",

"25360302411",

"25360302412",

"25360303410",

"25360303411",

"25360303412",

"25360304410",

"25360304411",

"25360304412",

"25360309410",

"25360309411",

"25360309412",

"25360312410",

"25360312411",

"25360313410",

"25360313411",

"25360319410",

"25360319411",

"25360382410",

"25360382411",

"25360382412",

"25360383410",

"25360383411",

"25360383412",

"25360389410"

]

},

{

"part_name": "Ice Maker Wire Harness WP2187464",

"part_number": "PS11739095",

"manufacturer": "Kenmore",

"price": "53.58",

"description": "This wire harness has a flat connector.",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator, Ice Maker. Part# WP2187464 replaces these: 2187464, 627840, 628171, 628256, 628281
Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"1061118553",

"1062155184",

"1064211173",

"1064317943",

"10647021790",

"10647021791",

"10647022790",

"10647022791",

"10647028790",

"10647028791",

"10650022000",

"10650022001",

"10650022002",

"10650022003",

"10650022004",

"10650027000",

"10650027001",

"10650027002",

"10650027003",

"10650027004",

"10650032000",

"10650032001",

"10650032002",

"10650032003",

"10650032004",

```
"10650037000",
"10650037001",
"10650037002",
"10650037003",
"10650037004"
]
},
{
  "part_name": "Wiring Harness WPW10146386",
  "part_number": "PS11749066",
  "manufacturer": "Kenmore",
  "price": "51.64",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WPW10146386 replaces these: 12583401, 67002124, W10146386 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "59651672100",
    "59651673100",
    "59651674100",
    "59651679100",
    "59652672200",
    "59652672201",
    "59652672202",
```

"59652673200",
"59652673201",
"59652673202",
"59652674200",
"59652674201",
"59652674202",
"59652679200",
"59652679201",
"59652679202",
"59653462300",
"59653463300",
"59653464300",
"59653469300",
"59655652500",
"59655653500",
"59655654500",
"59655659500",
"59655662500",
"59655663500",
"59655664500",
"59655669500",
"59657002600",
"59657003600"

]

},

{

```
"part_name": "HARNS-WIRE W10488357",
"part_number": "PS3633164",
"manufacturer": null,
"price": "234.53",
"description": "",
"rating": "100",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
W10488357 replaces these: AP5608229, W10204884, W10405353 Back to Top",

"review_count": "1",
"appliance": "refrigerator",
"compatible_models": [
  "JUD248CCCX00",
  "JUD248CCRS00",
  "JUD248CWRS00",
  "JUD248CWRS01",
  "JUD248RCCX00",
  "JUD248RCRS00",
  "JUD248RWRS00",
  "KDDC24CVS00",
  "KDDC24CVS01",
  "KDDC24CVX01",
  "KDDC24RVS00",
  "KDDO24CVX00",
  "KDDO24CVX01",
  "KDDO24RVX00"
]
```

```
},  
{  
  "part_name": "Ice Maker Wire Harness WPD7813010",  
  "part_number": "PS11747840",  
  "manufacturer": "Kenmore",  
  "price": "51.14",  
  "description": "This part connects to the electrical and allows power to flow through  
your appliance.",  
  "rating": "100",  
  "troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making  
ice This part works with the following products: Refrigerator, Ice Maker. Part# WPD7813010  
replaces these: 07813003, 4344399, 67001189, 67001256, 67001489, 67006614,  
8170938, D7813002, D7813003, D7813004, D7813010, D7813010SP, D7813011,  
W10146389, W10153408 Back to Top",  
  "review_count": "2",  
  "appliance": "refrigerator",  
  "compatible_models": [  
    "10672002010",  
    "10672003010",  
    "10672003011",  
    "10672009010",  
    "10672012010",  
    "10672013010",  
    "10672019010",  
    "18914A",  
    "20804A",  
    "20914A",
```

```
"22504A",
"3550A",
"59661102100",
"59661102101",
"59661103100",
"59661103101",
"59661104100",
"59661104101",
"59661109100",
"59661109101",
"59661142100",
"59661142101",
"59661144100",
"59661144101",
"59661152100",
"59661152101",
"59661154100",
"59661154101",
"59661162100",
"59661162101"
]
},
{
  "part_name": "Terminal and Wire Kit 279318",
  "part_number": "PS334181",
  "manufacturer": "Kenmore",
```


"price": "67.90",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Dryer, Washer
Dryer Combo, Refrigerator. Part# 279318 replaces these: AP3133484, 469513, 279318,
339210, 339211, 348912, 348913 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"10686294140",

"10686294340",

"10686294540",

"10686294740",

"10686294840",

"10687884100",

"10687884300",

"10687884600",

"10688419100",

"10688419300",

"110088732791",

"11016611690",

"11016612690",

"1101820299",

"11060012000",

"11060012001",

"11060012002",

"11060022010",

```
"11060052990",
"11060052991",
"11060056990",
"11060056991",
"11060072990",
"11060072991",
"11060092990",
"11060092991",
"11060094990",
"11060094991",
"11060096990",
"11060096991"
]
},
{
  "part_name": "Ribbon Cable Harness 241680002",
  "part_number": "PS1526364",
  "manufacturer": "Kenmore",
  "price": "15.34",
  "description": "Used in the dispenser board area.",
  "rating": "89",
  "troubleshooting_tips": "This part fixes the following symptoms: Not dispensing water | Ice maker won't dispense ice | Light not working | Ice maker not making ice This part works with the following products: Refrigerator. Part# 241680002 replaces these: AP3965169, 1196633, 241680001, 241701201, 5304430811 Back to Top",
  "review_count": "7",
  "appliance": "refrigerator",
```

"compatible_models": [

"25344302400",

"25344302401",

"25344303401",

"25344303402",

"25344303403",

"25344304400",

"25344304401",

"25344309400",

"25344309401",

"25344333600",

"25344333601",

"25344333602",

"25344333603",

"25344333604",

"25344333605",

"25344333606",

"25344333607",

"25344333608",

"25344333609",

"2534433360A",

"25344382400",

"25344382402",

"25344382403",

"25344382404",

"25344382405",

```
"25344382406",  
"25344382407",  
"2534438240B",  
"25344383400",  
"25344383401"
```

```
]
```

```
},
```

```
{
```

```
"part_name": "Terminal Block WPW10245259",
```

```
"part_number": "PS11750972",
```

```
"manufacturer": null,
```

```
"price": "34.05",
```

```
"description": "This part is for oven ranges, it connects individual wires and protects the device from electrical surges, voltages, and current. With this part, the house power is connected to the range wire harness. Some symptoms replacing the terminal block could be a solution for are little to no heat when baking, element will not heat and/or it will not start. This part will prevent loosening and will reduce damage caused by corrosion (by two different metals). Refer to the instructional diagram for further replacement guidance and exact placement. You must unplug the appliance before installing this part and wear gloves to protect your hands.",
```

```
"rating": "89",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start | Element will not heat | Little to no heat when baking | Touchpad does not respond This part works with the following products: Range, Wall Oven, Microwave Oven Combo, Cooktop. Part# WPW10245259 replaces these: AP6017673, 0306379, 0B00200399, 14253508, 14265221, 14277260, 1867-255, 1867255, 4364187, 5-50044, 5-50834, 550044, 550834, 7-90272, 7401P002-60, 7401P028-60, 7401P038-60, 7401P039-60, 790272, 8189776 ... Show more , 880002, R0167038, W10245259, Y0306379, Y0B00200399 Show less Back to Top",
```

```
"review_count": "17",
```

"appliance": "refrigerator",

"compatible_models": [

"1058AF-CW",

"1058AF-CZ",

"1058AH-W",

"1058AH-Z",

"1058WF-CW",

"1058WF-CZ",

"1058WH-W",

"1068AH-CHZW",

"1068F-CZ",

"1068WH-CHZW",

"1500PAA",

"1500PAW",

"1500PRA",

"1500PRW",

"15GA-10",

"15GK-10",

"15GN-10",

"15GY-10",

"21433",

"28FA-6CXWV8",

"28FA-6CXWV8-94",

"28FA-6CXWV8-DZ",

"28FA-7CVWV8-94",

"28FA-7CXW",

```
"28FA-7CXW-19",
"28FA-7CXW-94",
"28FA-7CXWV8",
"28FA-7CXWV8-94",
"28FA-7CXWV8-QM",
"28FB-7CXW"
]
},
{
  "part_name": "RESERVOIR W10502642",
  "part_number": "PS3654989",
  "manufacturer": "Kenmore",
  "price": "120.22",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# W10502642 replaces these: AP5631141, W10273376, W10296371, W10336610, W10355526, W10365768, W10415891, W10502641 Back to Top",
  "review_count": "2",
  "appliance": "refrigerator",
  "compatible_models": [
    "59678332802",
    "59678333802",
    "59678333803",
    "59678339803",
    "59678532802",
    "59678533802",
```

"59678539803",
"59679242010",
"59679242011",
"59679242012",
"59679242013",
"59679243010",
"59679243011",
"59679243012",
"59679243013",
"59679243014",
"59679249010",
"59679249011",
"59679249012",
"59679249013",
"5967954201",
"59679542010",
"59679542011",
"59679542014",
"5967954301",
"59679543010",
"59679543011",
"59679543013",
"59679543014",
"59679543015"

]

},

```
{  
  "part_name": "Water Dispenser Reservoir Tubing WP2256126",  
  "part_number": "PS11739924",  
  "manufacturer": "Kenmore",  
  "price": "99.89",  
  "description": "This kit no longer includes the connectors. It is only the tubing/water  
reservoir.\r\nNote: This tubing requires an adapter coupler (PS369735) to take the tubing  
from 1/4 inch to 5/16 inch.",  
  "rating": "100",  
  "troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works  
with the following products: Refrigerator. Part# WP2256126 replaces these: AP6006838,  
1129170, 2000861, 2004947, 2006145, 2152110, 2155266, 2155290, 2155784,  
2157465, 2177993, 2196154, 2196171, 2209687, 2217199, 2256100, 2256126,  
4317969, 482108, 833898 ... Show more , 839912, 841915, 843451, 936479, 978031  
Show less Back to Top",  
  "review_count": "1",  
  "appliance": "refrigerator",  
  "compatible_models": [  
    "10644102300",  
    "10644103300",  
    "10644109300",  
    "10650022000",  
    "10650022001",  
    "10650022002",  
    "10650022003",  
    "10650022004",  
    "10650027000",  
    "10650027001",
```



```
"10650027002",
"10650027003",
"10650027004",
"10650032000",
"10650032001",
"10650032002",
"10650032003",
"10650032004",
"10650037000",
"10650037001",
"10650037002",
"10650037003",
"10650037004",
"10650202990",
"10650202991",
"10650202992",
"10650202993",
"10650203990",
"10650203991",
"10650203992"
]
},
{
  "part_name": "CONTAINER 11016449",
  "part_number": "PS11771279",
  "manufacturer": null,
```

```
"price": "44.62",
"description": "",
"rating": null,
"troubleshooting_tips": "This part works with the following products: Refrigerator. Back
to Top",
"review_count": null,
"appliance": "refrigerator",
"compatible_models": [
  "B21CL80SNS",
  "B21CL80SNS-02",
  "B21CL81SNS"
]
},
{
  "part_name": "Container WPW10317224",
  "part_number": "PS11752697",
  "manufacturer": null,
  "price": "69.56",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
WPW10317224 replaces these: W10317224 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "IX5BBEXDS00",
    "IX5BBEXDS01",
```

"KFFS20EYBL00",
"KFFS20EYBL01",
"KFFS20EYBL02",
"KFFS20EYBL04",
"KFFS20EYMS00",
"KFFS20EYMS01",
"KFFS20EYMS02",
"KFFS20EYMS04",
"KFFS20EYWH00",
"KFFS20EYWH01",
"KFFS20EYWH02",
"KFFS20EYWH04",
"KRFF300EBL00",
"KRFF300EBS00",
"KRFF300EBS01",
"KRFF300ESS00",
"KRFF300ESS01",
"KRFF300ESS02",
"KRFF300ESS03",
"KRFF300ESS04",
"KRFF300EWH00",
"KRFF300EWH01",
"KRFF300EWH03",
"KRFF300EWH04",
"MFF2055DRE00",
"MFF2055DRE01",

```
"MFF2055DRH00",
"MFF2055DRH01"
]
},
{
  "part_name": "CONTAINER 11016450",
  "part_number": "PS11771280",
  "manufacturer": null,
  "price": "43.40",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Back to Top",
  "review_count": "2",
  "appliance": "refrigerator",
  "compatible_models": [
    "B21CL80SNS",
    "B21CL80SNS-02",
    "B21CL81SNS"
  ]
},
{
  "part_name": "WATER TANK DISP Assembly WR17X12793",
  "part_number": "PS2577882",
  "manufacturer": null,
  "price": "51.83",
```

"description": "",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Not dispensing water This part works with the following products: Refrigerator. Part# WR17X12793 replaces these: WR17X12578 Back to Top",

"review_count": "1",

"appliance": "refrigerator",

"compatible_models": [

"CFRS2MIDASS",

"CNE22SSEAFSS",

"CNR22SSEAFES",

"CNR22SSEBFES",

"CNS23SSHAFSS",

"GFMS170GHOWW",

"GNE22GGEAFBB",

"GNE22GGEAFWW",

"GNE22GGEBFBB",

"GNE22GGEBFWW",

"GNE22GMEAES",

"GNE22GMEAFES",

"GNE22GMEBFES",

"GNE22GMECFES",

"GNE22GSEAFSS",

"GNE22GSEBFSS",

"GNS23GGHBFBB",

"GNS23GGHBFWW",

"GNS23GMHBFES",

```
"GNS23GSHBFSS",
"PFE22KSEAFSS",
"PFS23KSHAFSS",
"PFSF2MIXABB",
"PFSF2MIXAWW",
"PFSF2MIXBBB",
"PFSF2MIXBWW",
"PFSF2MIYABB",
"PFSF2MIYAWW",
"PFSF2MIYCBB",
"PFSF2MIYCWW"
]
},
{
  "part_name": "Refrigerator Water Reservoir AJL72911502",
  "part_number": "PS3618757",
  "manufacturer": "LG",
  "price": "64.98",
  "description": "The water reservoir holds the water for the water dispenser as the water chills.",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Refrigerator, Freezer. Part# AJL72911502 replaces these: AP5253633, AJL72911501, AJL72911503, AJL72911505, AJL72911511, MJM61844101, MJM62524601 Back to Top",
  "review_count": "2",
  "appliance": "refrigerator",
```

"compatible_models": [

"1867",

"48231784207",

"48231784214",

"48231784221",

"48231784412",

"70322",

"70323",

"70329",

"70332",

"70333",

"70339",

"70355",

"70357",

"71032",

"71033",

"71036",

"71039",

"71052",

"71053",

"71054",

"71056",

"71059",

"71062",

"71063",

"71069",

```
"71072",
"71073",
"71079",
"71092",
"71093"
]
},
{
  "part_name": "Fresh Food Door Gasket 2159075",
  "part_number": "PS323900",
  "manufacturer": "Kenmore",
  "price": "241.73",
  "description": "This door gasket is used to seal the refrigerator door when closed to keep the cool air inside and the room air out.",
  "rating": "80",
  "troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Door won't open or close This part works with the following products: Refrigerator. Part# 2159075 replaces these: AP3083603, 443020, 2159071, 2159075, 2159079, 2171177, 2177290, 2181889, 2196243, 2221302, 2309528, W10912123 Back to Top",
  "review_count": "1",
  "appliance": "refrigerator",
  "compatible_models": [
    "10640562010",
    "10640563010",
    "10640569010",
    "10641152210",
    "10641152211",
```


"10641153210",
"10641153211",
"10641154210",
"10641159210",
"10641159211",
"10641172710",
"10641172711",
"10641172713",
"10641172714",
"10641173710",
"10641173711",
"10641173713",
"10641173714",
"10641179711",
"10641179713",
"10641179714",
"10641512100",
"10641512101",
"10641514100",
"10641514101",
"10641519100",
"10641519101",
"10641562800",
"10641562801",
"10641562802"

]

```
},  
{  
  "part_name": "Refrigerator Ice Container Assembly 5304522718",  
  "part_number": "PS12731641",  
  "manufacturer": null,  
  "price": "175.20",  
  "description": "This ice container assembly is for refrigerators.\r\n\r\nIce container  
assembly stores the ice until needed and comes with the auger that rotates to move the ice  
into the dispenser chute. The assembly may include multiple parts; refer to your parts  
diagram for a complete list of parts included.\r\n\r\nFollow the instructions in the owner's  
manual when installing this part.",  
  "rating": "100",  
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#  
5304522718 replaces these: AP6976342, 5304504446 Back to Top",  
  "review_count": "3",  
  "appliance": "refrigerator",  
  "compatible_models": [  
    "DGHX2655TF0",  
    "DGHX2655TF5",  
    "DGHX2655TF6",  
    "DGHX2655TF8",  
    "DGHX2655TF9",  
    "FGSS2635TD0",  
    "FGSS2635TD4",  
    "FGSS2635TD5",  
    "FGSS2635TD6",  
    "FGSS2635TE0",
```

```
"FGSS2635TE4",
"FGSS2635TE5",
"FGSS2635TE6",
"FGSS2635TF0",
"FGSS2635TF1",
"FGSS2635TF5",
"FGSS2635TF6",
"FGSS2635TF7",
"FGSS2635TP0",
"FGSS2635TP4",
"FGSS2635TP5",
"FGSS2635TP6",
"FPSS2677RF0",
"FPSS2677RF1",
"LGHX2636TD0",
"LGHX2636TD8",
"LGHX2636TF0",
"LGHX2636TF4",
"LGHX2636TF5",
"LGHX2636TF7"
]
},
{
  "part_name": "Water Tank Assembly WR17X11440",
  "part_number": "PS783769",
  "manufacturer": null,
```

"price": "45.83",

"description": "This tank stores water until the water actuator is activated and water is requested.",

"rating": "98",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Not dispensing water | Leaks water This part works with the following products: Refrigerator. Part# WR17X11440 replaces these: AP3205548, 1091942 Back to Top",

"review_count": "45",

"appliance": "refrigerator",

"compatible_models": [

"39639USXAGV",

"CSHS5UGXBSS",

"CSHS5UGXCSS",

"CSHS6UGZBSS",

"CSHS6UGZESS",

"CSHS6UGZFSS",

"CSS25USWASS",

"CSS25USWCSS",

"CSS25USWS",

"CSW25LSWASS",

"CZS22MP2NBS1",

"CZS22MP2NDS1",

"CZS22MP2NES1",

"CZS22MP2NHS1",

"CZS22MSKBHSS",

"CZS22MSKEHSS",

"CZS22MSKKHSS",

"DSD26DGWABG",

"DSD26DGWB",

"DSD26DGWCBG",

"DSD26DHWABG",

"DSD26DHWB",

"DSD26DHWCBG",

"DSE25JBLJCTS",

"DSE25JBLKCTS",

"DSE25JEMGCDS",

"DSE25JEMKCDS",

"DSE25JGHBCBB",

"DSE25JGHBCWW",

"DSE25JGHECBB"

]

},

{

"part_name": "FOOT 00611357",

"part_number": "PS10057755",

"manufacturer": null,

"price": "7.34",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 00611357 replaces these: AP5950279, 611357 Back to Top",

"review_count": null,

"appliance": "refrigerator",

```
"compatible_models": [  
  "B10CB80NVB",  
  "B10CB80NVB-05",  
  "B10CB80NVS",  
  "B10CB80NVW",  
  "B11CB50SSS",  
  "B11CB81SSS"  
]  
,  
{  
  "part_name": "Dishwasher/Portable Washer Roller WP3370639",  
  "part_number": "PS11741296",  
  "manufacturer": "Kenmore",  
  "price": "31.27",  
  "description": "",  
  "rating": null,  
  
  "troubleshooting_tips": "This part works with the following products: Dishwasher,  
Washer, Refrigerator. Part# WP3370639 replaces these: 20010116, 300424, 300428,  
300449, 300451, 3370639, 3370640, 356385, 357042, 357358, 357422, 367306,  
660665, 718231, 718534, 718536, 718586 Back to Top",  
  
  "review_count": null,  
  
  "appliance": "refrigerator",  
  
  "compatible_models": [  
    "1107433700",  
    "11074411100",  
    "11074411200",  
    "11074411400",
```

"11074411600",
"11074450100",
"11074451100",
"11074470100",
"11074471100",
"11074490100",
"11074490110",
"11074490200",
"11074490210",
"11074490400",
"11074490410",
"11074490600",
"11074490610",
"11074491100",
"11074491200",
"11074491400",
"11074491600",
"11074550100",
"11074570100",
"11074590100",
"11074590110",
"11074590200",
"11074590400",
"11074590600",
"11074650100",
"11074650110"

```
]
},
{
  "part_name": "Leg Assembly,Adjust 4779JA3001E",
  "part_number": "PS3523585",
  "manufacturer": "LG",
  "price": "18.75",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 4779JA3001E replaces these: AP4437940, 4779JA3001A, 4779JA3001B, 4779JA3001D, 4779JA3001G, AFC73249601 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "51012",
    "51013",
    "51014",
    "51016",
    "51019",
    "51026",
    "51032",
    "51034",
    "51036",
    "51039",
    "51072",
    "51073",
```



```
"51074",  
"51076",  
"51079",  
"51086",  
"51089",  
"51093",  
"51099",  
"51312",  
"51313",  
"51314",  
"51316",  
"51319",  
"51323",  
"51329",  
"51373",  
"51374",  
"51376",  
"51379"  
]  
,  
{  
  "part_name": "Refrigerator Leveling Leg 5304519032",  
  "part_number": "PS12705443",  
  "manufacturer": null,  
  "price": "25.85",
```

"description": "The levelling leg supports the refrigerator. Adjust the height of the levelling leg to make the refrigerator level.",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 5304519032 replaces these: AP6834394 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"FFPA3322UM",

"FFPA33L2UM",

"FFPA4422UM",

"FFPA4433UM",

"FFPA44L3UM",

"FFPE3322UM",

"FFPE33B2UM",

"FFPE4533UB",

"FFPE4533UM",

"FFPE45B3UV",

"FFPE45L3UV",

"FFPS3133UM",

"FFPS31B2UV",

"FFPS31L2UV"

]

},

{

"part_name": "Cabinet Roller - Front and Rear WPW10138054",

"part_number": "PS11748930",

"manufacturer": null,

"price": "35.66",

"description": "Sold individually.",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Refrigerator, Range.
Part# WPW10138054 replaces these: AP6015649, 1112023, W10138054 Back to Top",

"review_count": "1",

"appliance": "refrigerator",

"compatible_models": [

"106KSSS36QDW05",

"4KSRF36DTX1",

"4KSRF36DTX2",

"4KSRF42DTX2",

"ARG490",

"ARG4901",

"DYF42BIWS00",

"DYF42BNDI00",

"DYF48BIWS00",

"DYF48BNDI00",

"EF42DBSS",

"EF42NBSS",

"EF48DBSS",

"JB36CXFXLB00",

"JB36CXFXRB00",

"JB36NXFXLE00",

"JB36NXFXLE01",

"JB36NFXLE05",
"JB36NFXLW00",
"JB36NFXLW01",
"JB36NFXLW02",
"JB36NFXLW03",
"JB36NFXLW04",
"JB36NFXLW05",
"JB36NFXRE00",
"JB36NFXRE01",
"JB36NFXRE05",
"JB36NFXRW00",
"JB36NFXRW01",
"JB36NFXRW02"

]

},

{

"part_name": "Leveler WPW10340017",

"part_number": "PS11753210",

"manufacturer": "Kenmore",

"price": "18.67",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WPW10340017 replaces these: AP6019899, W10340017 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"10676392410",

"10676392411",

"10676392412",

"10676392413",

"10676392414",

"10676393411",

"10676393412",

"10676393414",

"10676399411",

"10676399412",

"10676399413",

"10676399414",

"10686392310",

"10686399310",

"WRT111SFAB00",

"WRT111SFAF00",

"WRT111SFAW00",

"WRT111SFDB00",

"WRT111SFDB01",

"WRT111SFDB02",

"WRT111SFDB03",

"WRT111SFDB04",

"WRT111SFDM00",

"WRT111SFDM01",

"WRT111SFDM02",

```
"WRT111SFDM03",
"WRT111SFDM04",
"WRT111SFDW00",
"WRT111SFDW01",
"WRT111SFDW02"
]
},
{
  "part_name": "FOOT 00612791",
  "part_number": "PS8727619",
  "manufacturer": null,
  "price": "11.32",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Freezer, Refrigerator. Part# 00612791 replaces these: AP4428775, 612791 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "B22CS30SNI",
    "B22CS30SNS",
    "B22CS30SNS-01",
    "B22CS50SNB",
    "B22CS50SNB01",
    "B22CS50SNS",
    "B22CS50SNS/01",
```

```
"B22CS50SNW",  
"B22CS50SNW01",  
"B22CS80SNS",  
"B22CS80SNS-01",  
"B22CS80SNS-02",  
"B22CS80SNS-03",  
"B36CL80ENS",  
"B36CT80SNS",  
"KAD62A70",  
"KAD62A70NE",  
"KAD62A70SD",  
"KAD62A71",  
"KAD62A71NE",  
"KAD62P90",  
"KAD62P91",  
"KAD62S20",  
"KAD62S20SD",  
"KAD62S20TI",  
"KAD62S21",  
"KAD62S21TI",  
"KAD62S50",  
"KAD62S50SD",  
"KAD62S50TI"  
]  
,  
{
```

"part_name": "Foot Brake WPW10141622",
"part_number": "PS11748978",
"manufacturer": "Kenmore",
"price": "11.13",
"description": "",
"rating": "100",
"troubleshooting_tips": "This part works with the following products: Refrigerator, Freezer. Part# WPW10141622 replaces these: AP6015697, W10141622 Back to Top",
"review_count": "2",
"appliance": "refrigerator",
"compatible_models": [
"10641162310",
"10641163310",
"10641169310",
"1064651773510",
"10651132210",
"10651132213",
"10651133210",
"10651133213",
"10651134210",
"10651134213",
"10651135610",
"10651136210",
"10651139210",
"10651139213",
"10651139214",


```
"10651142111",  
"10651143111",  
"10651149111",  
"10651149112",  
"10651152112",  
"10651153111",  
"10651153112",  
"10651159111",  
"10651163210",  
"10651164210",  
"10651169210",  
"10651172310",  
"10651173310",  
"10651179310",  
"10651182112"  
]  
,  
{  
  "part_name": "Adjustable Leveling Foot - Black 216396900",  
  "part_number": "PS425733",  
  "manufacturer": "Kenmore",  
  "price": "25.80",
```

"description": "This part could be found underneath a fridge, dryer, or freezer. The original foot may be cracked, broken, or perhaps missing altogether. If you notice the appliance is uneven to the floor or wobbling, it may indicate that the levelling foot needs to be replaced. You will need pliers and a block of wood to perform this task. There will be one adjustable foot found in the package. Lift the dryer and place the wood to keep it propped

up. You may need to use the pliers to remove the old foot. Screw the new foot into place using your hand. Once the new leveling foot is in place, lift the appliance and remove the block. Test the machine out to ensure it is now sitting level."

"rating": null,

"troubleshooting_tips": "This part works with the following products: Freezer, Refrigerator, Dryer. Part# 216396900 replaces these: AP2113255, 446089, 134158000, 7216396900 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"20462151B",

"25320211000",

"25320211001",

"25320211002",

"25320402000",

"25320402002",

"25320402003",

"25320911000",

"25320911001",

"25320911002",

"25321021100",

"25321021101",

"25321021102",

"25321021103",

"25321021104",

"25321021105",

"25321041100",

"25321041101",

"25321041102",

"25321041103",

"25321041104",

"25321041105",

"25321041107",

"25321041108",

"25321042410",

"25321042411",

"25321042412",

"25321042413",

"25321042414",

"25321082100"

]

},

{

"part_name": "Defrost Drain Pan with Thermal Adhesive 5304443219",

"part_number": "PS979895",

"manufacturer": "Kenmore",

"price": "90.75",

"description": "",

"rating": null,

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Refrigerator. Part# 5304443219 replaces these: AP3777950, 1064738, 240598501 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"25331610104",

"25331612104",

"25331614104",

"25331619104",

"25360742400",

"25360742401",

"25360744400",

"25360744401",

"25360802400",

"25360802402",

"25360802404",

"25360802406",

"25360802407",

"25360802408",

"25360802409",

"2536080240A",

"2536080240B",

"2536080240C",

"25360804400",

"25360804402",

"25360804404",

"25360804406",

"25360804407",

"25360804408",

"25360804409",

```
"2536080440A",
"2536080440B",
"2536080440C",
"25360807400",
"25360807402"
]
},
{
  "part_name": "GRILL RECESS WR17X12898",
  "part_number": "PS3499774",
  "manufacturer": null,
  "price": "12.03",
  "description": "",
  "rating": "60",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Back  
to Top",
  "review_count": "2",
  "appliance": "refrigerator",
  "compatible_models": [
    "GSE23GSECCSS",
    "GSE23GSEFCSS",
    "GSE23GSKECSS",
    "GSE23GSKJCSS",
    "GSE23GSKKCSS",
    "GSE23GSKMCSS",
    "GSE23GSKNCSS",
```

"GSE23GSKPCSS",
"GSE23GSKRCSS",
"GSHL6KGZBCLS",
"GSHL6KGZCCLS",
"GSHL6KGZDCLS",
"GSHS3KGZBCSS",
"GSS23GSKECSS",
"GSS23GSKGCSS",
"GSS23GSKJCSS",
"GSS23GSKKCSS",
"GSS23GSKMCSS",
"GSS23GSKNCSS",
"GSS23GSKPCSS",
"GSS23GSKRCSS",
"GSS23HSHBCSS",
"GSS23HSHECSS",
"GSS23HSHJCSS",
"GSS23HSHKCSS",
"GSS23HSHMCSS",
"GSS23HSHNCSS",
"GSS23HSHPCSS",
"GSS23HSHRCSS",
"XSS23GSKBCSS"

]

},

{

"part_name": "Evaporator Drip Pan WR17X11843",

"part_number": "PS964475",

"manufacturer": null,

"price": "42.34",

"description": "This is the replacement evaporator drip pan, also known as the drain trough, for your refrigerator. You will find the drip pan in the fresh food section of the refrigerator. It collects any water that may drip off the evaporator. If your drip pan is rusted, or is leaking into the refrigerator, you may need to replace it. Before you install the new drip pan, you will want to thoroughly clean the areas around the evaporator to ensure there is no more remaining rust or debris. This part is sold individually and is an OEM part sourced directly from the manufacturer.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Refrigerator. Part# WR17X11843 replaces these: AP3796479, WR17X11708 Back to Top",

"review_count": "10",

"appliance": "refrigerator",

"compatible_models": [

"CSCP5UGXAFSS",

"CSCP5UGXCFSS",

"CSCP5UGXDFSS",

"CSDP5UGDBFSS",

"CZS25TSEBFSS",

"GHE25RGXAFSS",

"JCB870SF2SS",

"PCF23PGWABB",

"PCF23PGWAWW",

"PCF23PGWB",

```
"PCF23PGWCBB",
"PCF23PGWCWW",
"PCF23PGWW",
"PCF23RGWABB",
"PCF23RGWAWW",
"PCF23RGWB",
"PCF23RGWCBB",
"PCF23RGWCWW",
"PCF23RGWW",
"PCF25MGWABB",
"PCF25MGWACC",
"PCF25MGWAWW",
"PCF25MGWB",
"PCF25MGWC",
"PCF25MGWCBB",
"PCF25MGWCCC",
"PCF25MGWCWW",
"PCF25MGWW",
"PCF25NGWABB",
"PCF25NGWAWW"
]
},
{
  "part_name": "PAN-DRIP WPW10655367",
  "part_number": "PS11756973",
  "manufacturer": "Kenmore",
```


"price": "79.67",

"description": "",

"rating": "85",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Refrigerator. Part# WPW10655367 replaces these: AP6023628, W10189185, W10296784, W10655367 Back to Top",

"review_count": "4",

"appliance": "refrigerator",

"compatible_models": [

"10669312310",

"10672002010",

"10672002011",

"10672002013",

"10672002015",

"10672003010",

"10672003011",

"10672003012",

"10672003013",

"10672003014",

"10672003016",

"10672003017",

"10672003018",

"10672009010",

"10672009011",

"10672009013",

"10672009015",

"596379243017",

```
"596467934251",
"596467934351",
"596467934451",
"596467934951",
"59665232404",
"59665232405",
"59665234404",
"59665234405",
"59665239404",
"59665239405",
"59665332602",
"59665333602"
]
},
{
  "part_name": "Evaporator Drip Tray WPW10614158",
  "part_number": "PS11756735",
  "manufacturer": "Kenmore",
  "price": "76.96",
  "description": "This is the replacement evaporator drip tray for your refrigerator. It is made of white plastic and is approximately 19 inches by 9 inches. The evaporator drip tray sits below the evaporator to collect dripping water. If the drip tray is damaged, you may notice that your refrigerator is leaking. Because it is made of plastic, the drip tray can eventually develop a crack. You will need to pull out the refrigerator from the wall, and take off the bottom panel on the back of your refrigerator in order to access the drip tray for replacement. This is an OEM part sourced directly from the manufacturer.",
  "rating": "96",
```

"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Refrigerator. Part# WPW10614158 replaces these: AP6023392, 1105523, W10614158 Back to Top",

"review_count": "5",

"appliance": "refrigerator",

"compatible_models": [

"10640212010",

"10640262010",

"10640263010",

"10640269010",

"10640562010",

"10640563010",

"10640563011",

"10640569010",

"10640569011",

"10641012100",

"10641012101",

"10641012104",

"10641014100",

"10641014101",

"10641014104",

"10641122212",

"10641122213",

"10641123212",

"10641129212",

"10641129213",

"10641152211",

```
"10641153211",
"10641159211",
"10641159212",
"10641212100",
"10641212101",
"10641214100",
"10641214101",
"10641262800",
"10641262801"
]
},
{
  "part_name": "Drip Tray - Gray WPW10356019",
  "part_number": "PS11753651",
  "manufacturer": null,
  "price": "47.52",
  "description": "",
  "rating": "60",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WPW10356019 replaces these: AP6020332, W10356019 Back to Top",
  "review_count": "2",
  "appliance": "refrigerator",
  "compatible_models": [
    "5VWT71REYF00",
    "MFW2055DRE00",
    "MFW2055DRE01",
```

"MFW2055DRH00",
"MFW2055DRH01",
"MFW2055DRM00",
"MFW2055DRM01",
"MFW2055FRH00",
"MFW2055FRZ00",
"MFW2055YEB00",
"MFW2055YEB01",
"MFW2055YEB02",
"MFW2055YEM00",
"MFW2055YEM01",
"MFW2055YEM02",
"MFW2055YEW00",
"MFW2055YEW01",
"MFW2055YEW02",
"WRF560SEHB00",
"WRF560SEHB01",
"WRF560SEHB02",
"WRF560SEHB03",
"WRF560SEHV00",
"WRF560SEHV01",
"WRF560SEHV02",
"WRF560SEHV03",
"WRF560SEHW00",
"WRF560SEHW01",
"WRF560SEHW02",

```
"WRF560SEHW03"
]
},
{
  "part_name": "Condensation Drain Trough 216377000",
  "part_number": "PS425670",
  "manufacturer": null,
  "price": "178.09",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Freezer, Refrigerator. Part# 216377000 replaces these: AP2113207, 445952 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "B30LSPSC0",
    "B30LSPSC1",
    "CAF11",
    "CAF12",
    "CAR11",
    "CAR12",
    "F22CW10",
    "F22CW11",
    "F22CW12",
    "F22CW13",
    "F22CW2",
```

```
"F22CW3",
"F22CW4",
"F22CW6",
"F22CW7",
"F22CW8",
"F22CW9",
"F22CWF0",
"F22CWF1",
"F22CWF2",
"F22CWF3",
"F22CWF4",
"FCFS181LQBA",
"FCFS201LFB0",
"FCFS201LFB1",
"FCFS201LFB2",
"FCFS201LFB3",
"FCFS201LFB4",
"FCFS201LFW0",
"FCFS201LFW2"
]
},
{
  "part_name": "GRILL RECESS WR17X12873",
  "part_number": "PS3487846",
  "manufacturer": null,
  "price": "17.86",
```

"description": "",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WR17X12873 replaces these: AP4981516, WR17X12232 Back to Top",

"review_count": "4",

"appliance": "refrigerator",

"compatible_models": [

"DSE25JGHBCBB",

"DSE25JGHECBB",

"DSE26JGEBCBB",

"DSE26JGECCBB",

"DSHF6VGBBCBB",

"DSHF6VGBCCBB",

"DSHF9NGYACBB",

"DSHF9NGYBCBB",

"ESHF6PGYAEBCBB",

"ESHF6PGYCEBB",

"GSE23GGEBBCBB",

"GSE23GGKECBB",

"GSE23GGKJCBB",

"GSE23GGKKCBB",

"GSE23GGKNCBB",

"GSE23GGKPCBB",

"GSE23GGKRCBB",

"GSE23GGPBCBB",

"GSE23GGPECBB",


```
"GSE25GGHBCBB",
"GSE25GGHECBB",
"GSE25GGHHCBB",
"GSE25GGHJCBB",
"GSE25GGHKCBB",
"GSE25GGHNCBB",
"GSE25GGHPCBB",
"GSE25GGHRCBB",
"GSE25GGPBCBB",
"GSE25GGPECBB",
"GSE25GGPFCBB"
]
},
{
  "part_name": "Refrigerator Dispenser Drip Tray W10909034",
  "part_number": "PS11766752",
  "manufacturer": null,
  "price": "44.50",
  "description": "Genuine OEM part",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# W10909034 replaces these: AP6034203, W10654552 Back to Top",
  "review_count": "2",
  "appliance": "refrigerator",
  "compatible_models": [
    "KRMF606ESS00",
```

"KRMF606ESS01",
"KRMF706EBS00",
"KRMF706EBS01",
"KRMF706EBS04",
"KRMF706EBS05",
"KRMF706ESS00",
"KRMF706ESS01",
"KRMF706ESS02",
"KRMF706ESS04",
"KRMF706ESS05"

]

},

{

"part_name": "GRILL RECESS WR17X12884",
"part_number": "PS3487856",
"manufacturer": null,
"price": "17.06",
"description": "",
"rating": "100",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WR17X12884 replaces these: WR17X12231 Back to Top",

"review_count": "4",
"appliance": "refrigerator",
"compatible_models": [
"DSE25JGHBCWW",
"DSE25JGHECWW",

"DSE25JGHKCWW",
"DSE26JGEBCWW",
"DSE26JGECCWW",
"DSHF6VGBBCWW",
"DSHF6VGBCCWW",
"DSHF9NGYACWW",
"DSHF9NGYBCWW",
"ESHF6PGYAEWW",
"ESHF6PGYCEWW",
"GSE23GGEBCWW",
"GSE23GGKECWW",
"GSE23GGKJCWW",
"GSE23GGKKCWW",
"GSE23GGKNCWW",
"GSE23GGKPCWW",
"GSE23GGKRCWW",
"GSE23GGPBCWW",
"GSE23GGPECWW",
"GSE25GGHBCWW",
"GSE25GGHECWW",
"GSE25GGHHCWW",
"GSE25GGHKCWW",
"GSE25GGHNCWW",
"GSE25GGHPCWW",
"GSE25GGHRCWW",
"GSE25GGPBCWW",

```
"GSE25GGPECWW",
"GSE25GGPFCWW"
]
},
{
  "part_name": "Motor Housing WP2195914",
  "part_number": "PS11739202",
  "manufacturer": "Kenmore",
  "price": "45.39",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator, Ice
Maker, Freezer. Part# WP2195914 replaces these: AP6006137, 0056595, 2194712,
2195914, 627790, 628278, 628326, 8170932, 95103-1, R0183121, Y0056595 Back to
Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "1061118553",
    "1061118555",
    "1062155184",
    "10641162310",
    "10641163310",
    "10641169310",
    "10641522500",
    "10641523500",
    "10641524500",
```

```
"10641529500",
"1064211173",
"1064317943",
"10644022600",
"10644022601",
"10644022602",
"10644022603",
"10644023600",
"10644023601",
"10644023602",
"10644023603",
"10644024600",
"10644029600",
"10644029601",
"10644029602",
"10644029603",
"10644032600",
"10644032601",
"10644032602",
"10644032603",
"10644033600"
]
},
{
  "part_name": "HOUSING CONTROL WR17X12852",
  "part_number": "PS3406242",
```

"manufacturer": "Kenmore",

"price": "45.69",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WR17X12852 replaces these: WR17X10508, WR17X10663, WR17X11534, WR17X3726
Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"36211XBMBRWW",

"36211XBMDRWW",

"36211XBMERWW",

"36211XBMFRWW",

"36211XBRERWW",

"36211XBRFRWW",

"36367667790",

"36368432890",

"36368432891",

"36368432892",

"36368432893",

"36368432894",

"36368437890",

"36368437891",

"36368437892",

"36368437893",

"36368437894",

"36368662890",

"36368662891",

"36368662893",

"36368662894",

"36368667891",

"36368667893",

"36368667894",

"36368672891",

"36368672893",

"36368672894",

"36368672895",

"36368677891",

"36368677893"

]

},

{

"part_name": "CONTROL ASSEMBLY 242249002",

"part_number": "PS10066164",

"manufacturer": "Kenmore",

"price": "162.83",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 242249002 replaces these: AP5957325, 242249001 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"25360002410",

"25360002411",

"25360002412",

"25360002413",

"25360002414",

"25360002415",

"25360002610",

"25360022410",

"25360022411",

"25360022412",

"25360022413",

"25360022414",

"25360022415",

"25360022610",

"25360022611",

"25360082410",

"25360082411",

"25360082412",

"25360082413",

"25360082414",

"25360082415",

"25360083410",

"25360083411",

"25360083412",

"25360083413",


```
"25360083414",
"25360083415",
"25360085611",
"25360085612",
"25360089410"
]
},
{
  "part_name": "CONTROL ASSEMBLY 809091203",
  "part_number": "PS12724157",
  "manufacturer": null,
  "price": "262.45",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 809091203 replaces these: 809091201 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "FPBC2277RF0",
    "FPBC2277RF1",
    "FPBC2277RF2",
    "FPBC2277RF3",
    "FPBC2277RF4",
    "FPBC2277RF5",
    "FPBC2277RF7",
```

"FPBC2277RF8",
"FPBC2277RF9",
"FPBC2277RFA",
"FPBC2277RFB",
"FPBC2277RFC",
"FPBC2277RFD",
"FPBC2277RFG",
"FPBC2277RFH",
"FPBC2277RFJ",
"FPBC2277RFK",
"FPBC2278UF1",
"FPBC2278UF3",
"FPBC2278UF4",
"FPBC2278UF5",
"FPBC2278UF7",
"FPBG2277RF3",
"FPBS2777RF0",
"FPBS2777RF1",
"FPBS2777RF2",
"FPBS2777RF3",
"FPBS2777RF4",
"FPBS2777RF6",
"FPBS2777RF9"

]

},

{

"part_name": "COVER-ACCESS 241733901",
"part_number": "PS1526582",
"manufacturer": "Kenmore",
"price": "49.97",
"description": "",
"rating": null,
"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 241733901 replaces these: AP3960037, 1196793, 240326103, 241574601 Back to Top",
"review_count": null,
"appliance": "refrigerator",
"compatible_models": [
"25351232101",
"25351232102",
"25351232103",
"25351232104",
"25351232105",
"25351232106",
"25351234101",
"25351234102",
"25351234103",
"25351234104",
"25351234105",
"25351234106",
"25351392101",
"25351394101",
"25351399101",

"25352322200",
"25352322201",
"25352322202",
"25352322203",
"25352324200",
"25352324201",
"25352324202",
"25352324203",
"25352332200",
"25352332201",
"25352332202",
"25352334200",
"25352334201",
"25352334202",
"25352339200"

]

},

{

"part_name": "Case,Display 3110JA1096A",

"part_number": "PS3518271",

"manufacturer": "LG",

"price": "32.76",

"description": "",

"rating": "20",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 3110JA1096A replaces these: AP4437130, 3110JA1096A Back to Top",

```
"review_count": "1",  
"appliance": "refrigerator",  
"compatible_models": [  
  "65092",  
  "65093",  
  "69009",  
  "71304",  
  "71306",  
  "71309",  
  "75002",  
  "75004",  
  "75009",  
  "75014",  
  "75202",  
  "75212",  
  "75214",  
  "75219",  
  "75282",  
  "75284",  
  "75292",  
  "75293",  
  "75296",  
  "75299",  
  "76082",  
  "76083",  
  "76089",
```

```
"76203",
"76204",
"76209",
"76282",
"76284",
"76289",
"76292"
]
},
{
  "part_name": "Access Panel 241733902",
  "part_number": "PS1526583",
  "manufacturer": "Kenmore",
  "price": "62.79",
  "description": "This panel is located on the back of the refrigerator.",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 241733902 replaces these: AP3963448, 1196794, 240326104, 240326111, 241574602, 241574605, 241733905, 7241733902, 7241733905 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "25344302400",
    "25344303400",
    "25344303402",
    "25344303403",
    "25344304400",
```

"25344309400",
"25344333600",
"25344333601",
"25344333602",
"25344333603",
"25344333604",
"25344333605",
"25344333606",
"25344333607",
"25344333608",
"25344333609",
"2534433360A",
"25344352400",
"25344352401",
"25344352403",
"25344352404",
"25344352405",
"25344352406",
"25344352407",
"25344352408",
"25344352409",
"25344353400",
"25344353401",
"25344353402",
"25344353403"

]

```
},
{
  "part_name": "Refrigerator Flipper Assembly DA97-12947A",
  "part_number": "PS5575408",
  "manufacturer": null,
  "price": "176.97",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# DA97-12947A replaces these: AP5651850 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "RF220NCTASP",
    "RF220NCTASR",
    "RF220NCTASRAA",
    "RF221NCTASP",
    "RF221NCTASR",
    "RF221NCTASRAA",
    "RF22A4121SR",
    "RF22A4221SR"
  ]
},
{
  "part_name": "Rear Compressor Cover WP2188755",
  "part_number": "PS11739126",
```


"manufacturer": "Kenmore",

"price": "77.01",

"description": "Used to cover up the compressor components.",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WP2188755 replaces these: AP6006062, 2161367, 2171576, 2176140, 2188735, 2188739, 2188755, 2200472, 2204203, 2252035, 2252036 Back to Top",

"review_count": "3",

"appliance": "refrigerator",

"compatible_models": [

"10640562010",

"10640563010",

"10640563011",

"10640569010",

"10640569011",

"10641152210",

"10641152211",

"10641153210",

"10641153211",

"10641154210",

"10641159210",

"10641159211",

"10641159212",

"10641562800",

"10641562801",

"10641562802",

"10641563800",

```
"10641563801",  
"10641563802",  
"10641563803",  
"10641563805",  
"10641564800",  
"10641564801",  
"10641564802",  
"10641569800",  
"10641569801",  
"10641569802",  
"10650022210",  
"10650022211",  
"10650023210"  
]  
,  
{  
  "part_name": "FRONT-PAN WPW10688114",  
  "part_number": "PS11757139",  
  "manufacturer": null,  
  "price": "90.65",
```

"description": "This front panel is an authentic OEM replacement part that fits on the crisper drawer in refrigerators. It acts as a barrier between the contents of the drawer and the external environment of the refrigerator. It protects the contents of the crisper drawer from debris, odors, and other contaminants that may be present. The front panel also helps to control the amount of airflow and humidity within the drawer, helping to keep fruits and vegetables fresh longer. It also contributes to the overall appearance of the refrigerator, providing a finished look to the crisper drawer. If the front panel is damaged, it may become

difficult to slide the crisper drawer back and forth and the freshness of the food may be compromised.",

"rating": "98",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WPW10688114 replaces these: AP6023793, W10510693, W10688114 Back to Top",

"review_count": "10",

"appliance": "refrigerator",

"compatible_models": [

"7WF736SDAM10",

"7WF736SDAM11",

"7WF736SDAM12",

"7WF736SDAM13",

"7WF736SDAM14",

"WRF736SDAB00",

"WRF736SDAB10",

"WRF736SDAB11",

"WRF736SDAB12",

"WRF736SDAB13",

"WRF736SDAB14",

"WRF736SDAF00",

"WRF736SDAF10",

"WRF736SDAF12",

"WRF736SDAM00",

"WRF736SDAM10",

"WRF736SDAM11",

"WRF736SDAM12",

"WRF736SDAM13",

"WRF736SDAM14",
"WRF736SDAT00",
"WRF736SDAT10",
"WRF736SDAW00",
"WRF736SDAW10",
"WRF736SDAW11",
"WRF736SDAW12",
"WRF736SDAW13",
"WRF736SDAW14",
"WRF757SDEE00",
"WRF757SDEE01"

]

},

{

"part_name": "Kickplate Grille - White 240324409",

"part_number": "PS1525950",

"manufacturer": "Kenmore",

"price": "82.80",

"description": "This part attaches to the bottom of the refrigerator.",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 240324409 replaces these: AP3968412, 240324401, 240324402, 240424002, 241521601, 241521604, 241521613 Back to Top",

"review_count": "1",

"appliance": "refrigerator",

"compatible_models": [

"25344502608",

"25344502609",
"2534450260A",
"2534450260C",
"2534450360B",
"2534450960A",
"25344512608",
"25344512609",
"2534451260B",
"25351232101",
"25351232102",
"25351232103",
"25351232104",
"25351232105",
"25351232106",
"25351234101",
"25351234102",
"25351234104",
"25351234106",
"25351392101",
"25351392102",
"25351392103",
"25351392104",
"25351392105",
"25351392106",
"25351394101",
"25351399101",

```
"25351622100",
"25351622101",
"25351622102"
]
},
{
  "part_name": "Kickplate Grille with Clips 12321807Q",
  "part_number": "PS2006609",
  "manufacturer": "Kenmore",
  "price": "82.56",
  "description": "White in color.",
  "rating": "85",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
12321807Q replaces these: AP4011887, 942, 10470302, 10470306, 10810901,
12321807, 12321807Q, 12321811, 12321811Q, 4343605, 8170319, 8170741, 8208385,
R0131521 Back to Top",
  "review_count": "4",
  "appliance": "refrigerator",
  "compatible_models": [
    "2599CIWEA",
    "2599CIWEA-P1170601WL",
    "2599CIWEL-P1170601WL",
    "2599CIWEW",
    "2599CIWEW-P1170601WW",
    "2599W",
    "2599W-P1190419WW",
    "2699W",
```

"56957089791",
"56959082791",
"58632",
"58632-P1317501WW",
"59650392000",
"59650392001",
"59650392990",
"59650394000",
"59650394001",
"59650394990",
"59650399000",
"59650399001",
"59650399990",
"59650692000",
"59650692001",
"59650694000",
"59650694001",
"59650699000",
"59650699001",
"59657082790",
"59657082791",
"59657542790"

]

},

{

"part_name": "Kickplate Grille 241521603",

```
"part_number": "PS817886",
"manufacturer": "Kenmore",
"price": "106.26",
"description": "",
"rating": null,
"troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
241521603 replaces these: AP3574887, 1036849, 240324405 Back to Top",
"review_count": null,
"appliance": "refrigerator",
"compatible_models": [
  "25351392101",
  "25351394101",
  "25351399101",
  "25351399102",
  "25351399103",
  "25351399104",
  "25351399105",
  "25351399106",
  "25352339200",
  "25352339201",
  "25352339202",
  "25352349300",
  "25352349301",
  "25352349302",
  "25352349303",
  "25353213300",
```


"25353213301",
"25353219301",
"25353223300",
"25353223301",
"25353229300",
"25353229301",
"25353373300",
"25353373301",
"25353373302",
"25353379300",
"25353379301",
"25353379302",
"25354333300",
"25354333301"

]

},

{

"part_name": "Toe Kick - Stainless WR74X10222",

"part_number": "PS1518161",

"manufacturer": null,

"price": "130.48",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WR74X10222 replaces these: AP3996376, 1266214, WR74X10099, WR78X24604 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"ZIC36NMASSLH",

"ZIC36NMASSRH",

"ZICP360NXALH",

"ZICP360NXARH",

"ZICP360NXBLH",

"ZICP360NXBRH",

"ZICP360NXDLH",

"ZICP360NXDRH",

"ZICP360SLFSS",

"ZICP360SRFSS",

"ZICP720ASASS",

"ZICP720SASS",

"ZICS360NMALH",

"ZICS360NMARH",

"ZICS360NMBLH",

"ZICS360NMBRH",

"ZICS360NMCLH",

"ZICS360NMCRH",

"ZICS360NRALH",

"ZICS360NRARH",

"ZICS360NRBLH",

"ZICS360NRBRH",

"ZICS360NRCLH",

"ZICS360NRCRH",

```
"ZICS360NRDLH",
"ZICS360NRDRH",
"ZICS360NRELH",
"ZICS360NRERH",
"ZICS360NRFLH",
"ZICS360NRFRH"
]
},
{
  "part_name": "Kickplate Grille 240324411",
  "part_number": "PS1525951",
  "manufacturer": "Kenmore",
  "price": "53.80",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 240324411 replaces these: AP3968225, 1258868, 240324406, 241521606, 241521610, 241521615, 241521619 Back to Top",
  "review_count": "1",
  "appliance": "refrigerator",
  "compatible_models": [
    "25344309400",
    "25344309401",
    "25344352401",
    "25344352403",
    "25344353400",
    "25344353401",
```

"25344353402",
"25344353403",
"25344353404",
"25344353405",
"25344353406",
"25344353407",
"25344353408",
"25344353409",
"25344354401",
"25344354403",
"25344359400",
"25344359401",
"25344359403",
"25344359404",
"25344359405",
"25344359406",
"25344359407",
"25344359408",
"25344359409",
"25344382402",
"25344383400",
"25344383402",
"25344384402",
"25344389400"

]

},

```
{
  "part_name": "Kickplate Grille - White WR74X10271",
  "part_number": "PS2340504",
  "manufacturer": null,
  "price": "42.72",
  "description": "This part attaches to the bottom of the refrigerator. Clips sold individually.",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WR74X10271 replaces these: AP4363865, 1478260, WR74X10064, WR74X10071, WR74X10194 Back to Top",
  "review_count": "1",
  "appliance": "refrigerator",
  "compatible_models": [
    "DSE25JGHBCWW",
    "DSE25JGHECWW",
    "DSE25JGHKCWW",
    "DSE26JGEBCWW",
    "DSE26JGECCWW",
    "DSF25MGSBWW",
    "DSF26DHWAWW",
    "DSF26DHW CWW",
    "DSHF5PGXAEWW",
    "DSHF5PGXCEWW",
    "DSHF6VGBBCWW",
    "DSHF6VGBCCWW",
    "DSHF9NGYACWW",
  ]
}
```

```
"DSHF9NGYBCWW",
"DSR25UGTAWW",
"DSRF5KGXAEWW",
"DSRF5KGXCEWW",
"DSS25KGRAWW",
"DSS25KGRBWW",
"DSS25KGRCWW",
"DSS25KGRDWW",
"DSS25KGREWW",
"DSS25KGTAWW",
"DSS25KGTBWW",
"DSS25KGTEWW",
"DSS25LGPAWW",
"DSS25MGSCWW",
"ECF23KGTAWW",
"ECF23KGTEWW",
"ESF25KGTAWW"
]
},
{
  "part_name": "Kickplate Grille 241839407",
  "part_number": "PS1991401",
  "manufacturer": "Kenmore",
  "price": "53.06",
  "description": "This kickplate grille is attached to the bottom of the refrigerator.",
  "rating": "90",
```

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 241839407 replaces these: AP4318649, 1373195, 240368203, 240368207 Back to Top",

"review_count": "2",

"appliance": "refrigerator",

"compatible_models": [

"25331113300",

"25331113302",

"25331113304",

"25331113308",

"2533111330A",

"2533111330B",

"2533111330C",

"2533111330D",

"2533111330E",

"2533111330F",

"2533111330G",

"2533111330H",

"2533111330J",

"2533111330K",

"2533111330L",

"25331115300",

"25331115302",

"25331115304",

"25331115308",

"2533111530A",

"2533111530B",

```
"2533111530C",
"2533111530D",
"2533111530E",
"2533111530F",
"2533111530G",
"2533111530H",
"2533111530J",
"2533111530K",
"2533111530L"
]
},
{
  "part_name": "Kickplate Grille - Stainless 241969405",
  "part_number": "PS2363831",
  "manufacturer": null,
  "price": "61.66",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 241969405 replaces these: AP4433006, 241969407 Back to Top",
  "review_count": "1",
  "appliance": "refrigerator",
  "compatible_models": [
    "BGHS2644KF0",
    "BGHS2644KF1",
    "BGHS2644KF2",
```


"DGHK2355TF0",
"DGHS2644KF1",
"DGHS2644KF2",
"DGHS2644KF3",
"DGHS2665KF0",
"DGHS2665KF2",
"DGHX2655TF0",
"DGHX2655TF5",
"DGHX2655TF6",
"DGHX2655TF8",
"DGHX2655TF9",
"DGHX2655TFA",
"DGHX2655TFB",
"DGHX2655TFC",
"DGUS2645LF0",
"DGUS2645LF1",
"DGUS2645LF2",
"DGUS2645LF3",
"DGUS2645LF4",
"DGUS2645LF5",
"DGUS2645LF6A",
"FFSC2323TS0",
"FFSC2323TS3",
"FFSC2323TS4",
"FFSC2323TS6",
"FFSC2323TS7",

```
"FFSC2323TS8"
]
},
{
  "part_name": "Kickplate Grille 241839405",
  "part_number": "PS1991399",
  "manufacturer": "Kenmore",
  "price": "48.22",
  "description": "This white kickplate grill is attached to the bottom of the refrigerator.",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 241839405 replaces these: AP4318624, 1376942, 240368201, 240368205 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "25331800102",
    "25331800104",
    "25331802102",
    "25331802104",
    "25331802106",
    "25331802108",
    "2533180210A",
    "2533180210B",
    "2533180210C",
    "2533180210D",
    "25331804102",
```

```
"25331804104",  
"25331809102",  
"25331809104",  
"25331809106",  
"25331809108",  
"2533180910A",  
"2533180910B",  
"2533180910C",  
"2533180910D",  
"25331810300",  
"25331810302",  
"25331812300",  
"25331812302",  
"25331840100",  
"25331840102",  
"25331842100",  
"25331842102",  
"25331842104",  
"25331842106"  
]  
,  
{  
  "part_name": "Kickplate Grille WR74X10270",  
  "part_number": "PS2340503",  
  "manufacturer": "Kenmore",  
  "price": "39.01",
```

"description": "Clips sold separately.",

"rating": "95",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WR74X10270 replaces these: AP4363306, 1478259, WR74X10069, WR74X10127, WR74X10195, WR74X10374 Back to Top",

"review_count": "11",

"appliance": "refrigerator",

"compatible_models": [

"CSCP5UGXAFSS",

"CSW25LSWASS",

"CZS22MP2NBS1",

"CZS22MP2NDS1",

"CZS22MP2NES1",

"CZS22MP2NHS1",

"CZS22MSKBHSS",

"CZS22MSKEHSS",

"CZS22MSKKHSS",

"CZS25TSEBFSS",

"DSD26DGWABG",

"DSD26DGWB",

"DSD26DGWCBG",

"DSD26DHWABG",

"DSD26DHWB",

"DSD26DHWCBG",

"DSE25JBLJCTS",

"DSE25JBLKCTS",

"DSE25JEMGCDS",

"DSE25JEMKCDS",
"DSE25JGHBCBB",
"DSE25JGHECBB",
"DSE25JGHKCBB",
"DSE25JMHBCES",
"DSE25JMHECES",
"DSE25JMHKCES",
"DSE25JSHBCSS",
"DSE25JSHECSS",
"DSE25JSHKCSS",
"DSE26JGEBCBB"

]

},

{

"part_name": "INSULATION W11084829",

"part_number": "PS12070592",

"manufacturer": null,

"price": "26.97",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# W11084829 replaces these: W10792132 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"JFFCC72EFP00",

"JFFCC72EFP02",
"JFFCC72EFS00",
"JFFCC72EFS02",
"JFFCC72EFS03",
"JFFCC72EFS04",
"JFFCC72EHL",
"JFFCC72EHL01",
"JFFCC72EHL02",
"JFFCC72EHL03",
"JFFCC72EHL04",
"KRFC604FSS00",
"KRFC604FSS01",
"KRFC604FSS02",
"KRFC604FSS03",
"KRFC704FBS00",
"KRFC704FBS01",
"KRFC704FBS02",
"KRFC704FBS03",
"KRFC704FBS04",
"KRFC704FBS05",
"KRFC704FPS00",
"KRFC704FPS01",
"KRFC704FPS03",
"KRFC704FPS04",
"KRFC704FPS05",
"KRFC704FPS06",

```
"KRFC704FSS00",
"KRFC704FSS01",
"KRFC704FSS02"
]
},
{
  "part_name": "BLOCK- FIL WP12777701",
  "part_number": "PS11738614",
  "manufacturer": null,
  "price": "12.33",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
WP12777701 replaces these: 12777701, 67004092, 8208167 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "10672002010",
    "10672002011",
    "10672002013",
    "10672002015",
    "10672003010",
    "10672003011",
    "10672003012",
    "10672003013",
    "10672003014",
```

```
"10672003016",
"10672003017",
"10672003018",
"10672009010",
"10672009011",
"10672009013",
"10672009015",
"59655652500",
"59655653500",
"59655654500",
"59655659500",
"59655662500",
"59655663500",
"59655664500",
"59655669500",
"59657002600",
"59657003600",
"59657006600",
"59657009600",
"59657012600",
"59657013600"
]
},
{
  "part_name": "SLEEVE VINYL WR2X8344",
  "part_number": "PS298976",
```


"manufacturer": "Kenmore",
"price": "13.86",
"description": "",
"rating": null,
"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WR2X8344 replaces these: AP2060072, 298587, WR02X8344 Back to Top",
"review_count": null,
"appliance": "refrigerator",
"compatible_models": [
"31861-1",
"31880",
"36211XBMBRWW",
"36211XBMDRWW",
"36211XBMERWW",
"36211XBMFRWW",
"36211XBRERWW",
"36211XBRFRWW",
"36337400792",
"36337401792",
"36337408792",
"36337409792",
"36337450792",
"36337450890",
"36337451792",
"36337451890",
"36337458792",

"36337458890",

"36337459792",

"36337459890",

"36338450890",

"36338451890",

"36338458890",

"36338459890",

"36360242000",

"36360247000",

"36360249000",

"36360942000",

"36360947000",

"36360949000"

]

},

{

"part_name": "Insulation WP67003904",

"part_number": "PS11743565",

"manufacturer": "Kenmore",

"price": "4.45",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WP67003904 replaces these: 67003904, 8208194 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"59665232400",

"59665232401",

"59665234400",

"59665234401",

"59665239400",

"59665239401",

"59665932300",

"59665932400",

"59665932401",

"59665934300",

"59665934400",

"59665934401",

"59665939300",

"59665939400",

"59665939401",

"59666252400",

"59666252401",

"59666253400",

"59666253401",

"59666254400",

"59666254401",

"59666259400",

"59666259401",

"59666952400",

"59666952401",

```
"59666953400",
"59666953401",
"59666954400",
"59666954401",
"59666959400"
]
},
{
  "part_name": "Water Filter Cover Insulation - White 240394102",
  "part_number": "PS430416",
  "manufacturer": "Kenmore",
  "price": "43.09",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Refrigerator. Part# 240394102 replaces these: AP2116250, 891450, 240394101 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "25344352400",
    "25344352401",
    "25344352403",
    "25344352404",
    "25344352405",
    "25344352406",
    "25344352407",
```

"25344352408",
"25344352409",
"25344353400",
"25344353401",
"25344353402",
"25344353403",
"25344353404",
"25344353405",
"25344353406",
"25344353407",
"25344353408",
"25344353409",
"25344354400",
"25344354401",
"25344354403",
"25344354404",
"25344354405",
"25344354406",
"25344354407",
"25344354408",
"25344354409",
"25344359400",
"25344359401"

]

},

{

"part_name": "INSULATION 242096001",
"part_number": "PS3495507",
"manufacturer": "Kenmore",
"price": "15.09",
"description": "",
"rating": null,
"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 242096001 replaces these: AP5178318 Back to Top",
"review_count": null,
"appliance": "refrigerator",
"compatible_models": [
"20462151B",
"2537034241E",
"2537034241F",
"2537034241H",
"2537034241J",
"2537034341F",
"2537034341G",
"2537034341H",
"2537034341J",
"25370347411",
"2537034941J",
"2537044341A",
"2537044341C",
"2537044341D",
"2537044341E",

"25370447411",
"90462157B",
"CFD26WIS3",
"CFD26WIS4",
"CFD26WIS5",
"CFD26WIS6",
"CFD27WIPB2",
"CFD27WIPB3",
"CFD27WIPS2",
"CFD27WIPS3",
"CFD27WIPW2",
"CFD27WIPW3",
"CFD28WIB5",
"CFD28WIB6",
"CFD28WIB8"

]

},

{

"part_name": "Insert Kit 4388450",

"part_number": "PS371967",

"manufacturer": "Kenmore",

"price": "33.87",

"description": "This kit comes with two pieces.",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 4388450 replaces these: AP3109023, 777388, 2172599, 2174629, 2200788, 2210313, 2302584, 4388450 Back to Top",

```
"review_count": null,  
"appliance": "refrigerator",  
"compatible_models": [  
  "10666861790",  
  "10666862790",  
  "10666867790",  
  "10666868790",  
  "10667031790",  
  "10667031791",  
  "10667032791",  
  "10667038790",  
  "10667038791",  
  "10667062790",  
  "10667062791",  
  "10667067790",  
  "10667067791",  
  "10667181790",  
  "10667181792",  
  "10667188790",  
  "10667188792",  
  "10667292790",  
  "10667297790",  
  "10667821790",  
  "10667821791",  
  "10667828790",  
  "10667828791",
```



```
"10667861790",
"10667861791",
"10667868790",
"10667868791",
"10667992790",
"10667992791",
"10667997790"
]
},
{
  "part_name": "Door Insulation 241688601",
  "part_number": "PS1526428",
  "manufacturer": "Kenmore",
  "price": "51.25",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 241688601 replaces these: AP3965572, 1196690, 5304421625, 7241688601 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "25344302400",
    "25344302401",
    "25344303400",
    "25344303401",
    "25344303402",
```

"25344303403",
"25344304400",
"25344304401",
"25344309400",
"25344309401",
"25344333600",
"25344333601",
"25344333602",
"25344333603",
"25344333604",
"25344333605",
"25344333606",
"25344333607",
"25344333608",
"25344333609",
"2534433360A",
"25344352400",
"25344352401",
"25344352403",
"25344352404",
"25344352405",
"25344352406",
"25344352407",
"25344352408",
"25344352409"

]

```
},  
{  
  "part_name": "Insulation 67003796",  
  "part_number": "PS1632252",  
  "manufacturer": "Kenmore",  
  "price": "26.75",  
  "description": "Fiber Acoustic.",  
  "rating": "100",  
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#  
67003796 replaces these: AP4077897, 12820503, 67001725, 67003796, 8170899,  
8171247 Back to Top",  
  "review_count": "1",  
  "appliance": "refrigerator",  
  "compatible_models": [  
    "10678586800",  
    "59655652500",  
    "59655653500",  
    "59655654500",  
    "59655659500",  
    "59655662500",  
    "59655663500",  
    "59655664500",  
    "59655669500",  
    "59657002600",  
    "59657003600",  
    "59657006600",  
    "59657009600",
```

```
"59657012600",
"59657013600",
"59657016600",
"59657019600",
"59657043600",
"59657049600",
"59665232402",
"59665232403",
"59665234402",
"59665234403",
"59665239402",
"59665239403",
"59665332600",
"59665333700",
"59665339700",
"59665932403",
"59665934403"
]
},
{
  "part_name": "Drawer Slide Rail 241762801",
  "part_number": "PS2350560",
  "manufacturer": null,
  "price": "177.49",
  "description": "",
  "rating": null,
```

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 241762801 replaces these: AP4373787, 7241762801 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"CFD26SDS0",

"CFD26WIS0",

"CFD26WIS1",

"CFD26WIS3",

"CFD28SDS1",

"CFD28WIS0",

"CFD28WIS1",

"CFD28WIS2",

"CFD28WIS3",

"EI27BS16JB0",

"EI27BS16JB1",

"EI27BS16JB2",

"EI27BS16JS0",

"EI27BS16JS1",

"EI27BS16JS2",

"EI27BS16JW0",

"EI27BS16JW1",

"EI27BS16JW2",

"EI27BS26JB0",

"EI27BS26JB1",

"EI27BS26JB3",

```
"EI27BS26JS0",
"EI27BS26JS1",
"EI27BS26JS3",
"EI27BS26JW0",
"EI27BS26JW1",
"EI27BS26JW3",
"EI28BS36IB0",
"EI28BS36IB1",
"EI28BS36IB2"
]
},
{
  "part_name": "RACK WR17X6236",
  "part_number": "PS294191",
  "manufacturer": null,
  "price": "180.61",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Back  
to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "BIS42AJB",
    "BIS42AJC",
    "BIS42AJD",
```

```
"BIS42CKB",
"BIS42CKC",
"BISB42EKB",
"BISB42EKC",
"BISB42ELB",
"BISB42ELC",
"BISB42ELD",
"BISB42ELE",
"BISW42EKB",
"BISW42EKC",
"BISW42ELB",
"BISW42ELC",
"BISW42ELD",
"BISW42ELE",
"ZIS42CMB",
"ZIS42CMC",
"ZISB42EMB",
"ZISB42EMC",
"ZISW42EMB",
"ZISW42EMC"
]
},
{
  "part_name": "RACK MGR62502001",
  "part_number": "PS11761961",
  "manufacturer": "LG",
```

```
"price": "213.91",
"description": "",
"rating": null,
"troubleshooting_tips": "This part works with the following products: Refrigerator. Back
to Top",
"review_count": null,
"appliance": "refrigerator",
"compatible_models": [
  "79579983510",
  "79579993510",
  "79983",
  "79993"
]
},
{
  "part_name": "RACK MGR62542101",
  "part_number": "PS12082049",
  "manufacturer": "LG",
  "price": "8.76",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Back
to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "LUPXC2386N",
```



```
"LUPXS3186N",
"URNTC2306N",
"URNTS3106N"
]
},
{
  "part_name": "RACK MGR62542002",
  "part_number": "PS12082048",
  "manufacturer": "LG",
  "price": "8.76",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Back
to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "LUPXC2386N",
    "LUPXS3186N",
    "URNTC2306N",
    "URNTS3106N"
  ]
},
{
  "part_name": "RACK MGR62542001",
  "part_number": "PS12082047",
```

```
"manufacturer": "LG",
"price": "8.76",
"description": "",
"rating": null,
"troubleshooting_tips": "This part works with the following products: Refrigerator. Back
to Top",
"review_count": null,
"appliance": "refrigerator",
"compatible_models": [
  "LUPXC2386N",
  "LUPXS3186N",
  "URNTC2306N",
  "URNTS3106N"
]
},
{
  "part_name": "RACK 5304490985",
  "part_number": "PS7784343",
  "manufacturer": null,
  "price": "91.32",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
5304490985 replaces these: AP5671995 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
```

"FFET1222QB0",
"FFET1222QS0",
"FFET1222QW0",
"FFPT12F3NB0",
"FFPT12F3NM0",
"FFPT12F3NV0",
"FFPT12F3NW0",
"FFTR1222QB0",
"FFTR1222QM0",
"FFTR1222QW0"

]

},

{

"part_name": "RACK 5304494023",

"part_number": "PS10062871",

"manufacturer": "Kenmore",

"price": "115.23",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Freezer,
Refrigerator. Part# 5304494023 replaces these: AP5954555 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"25321042410",

"25321042411",

"25321042412",
"25321042413",
"25321042414",
"25321742510",
"25321742511",
"25321742512",
"25321742513",
"25321742514",
"25321742515",
"25321742516",
"25322040510",
"25322042410",
"25322042411",
"25322042412",
"25322052610",
"25322052611",
"25322742410",
"25322742411",
"25322742412",
"25370722410",
"BKFH17F1SW0",
"BKFH17F1SW1",
"BKFH17F1SW2",
"CCFU17M1TW0",
"CCFU17M1TW1",
"CCFU17M1TW2",

```
"CCFU17M1TW3",  
"CCFU21M1TW0"  
]  
,  
{  
  "part_name": "Lower Dishrack Kit W10311986",  
  "part_number": "PS2378335",  
  "manufacturer": "Kenmore",  
  "price": "189.45",  
  "description": "This kit comes with the wheels, bumpers, fold down tine and flexrow  
retainer.",  
  "rating": "76",  
  "troubleshooting_tips": "This part works with the following products: Dishwasher,  
Refrigerator, Range, Dryer. Part# W10311986 replaces these: AP4512509, 1557748,  
W10311986, 20081520, 20081521, 20081912, 20081914, 20082223, 20082241,  
20082691, 20082776, 20083202, 20083235, 20083447, 20083449, 20083454,  
20083488, 20083491, 20083588, 20083589 ... Show more , 20083590, 20083591,  
20083595, 20083650, 20083651, 20083652, 20083653, 20083654, 20084048,  
20084049, 20084051, 20084052, 20084054, 20084105, 20084107, 20084118,  
20084120, 20084122, 20106012, 20106013, 20106014, 3-993, 300563, 300900,  
300993, 301022, 301381, 301407, 302017, 302054, 302056, 302057, 302058, 302107,  
302109, 302161, 302172, 302333, 302336, 302405, 302406, 302429, 302486, 302488,  
302545, 302743, 302744, 302817, 303117, 303118, 303119, 303142, 303249, 303356,  
303357, 303565, 303661, 303850, 304176, 304177, 304180, 304181, 304182, 304183,  
304184, 304185, 304481, 304483, 304484, 304485, 304764, 304765, 304813, 304814,  
304815, 304816, 304817, 304821, 3367013, 3367014, 3367015, 3367023, 3367024,  
3367025, 3367033, 3367034, 3367035, 3367075, 3367116, 3367142, 3367143,  
3367181, 3367182, 3367290, 3367426, 3368252, 3368256, 3368312, 3368515,  
3368516, 3368518, 3368519, 3368598, 3368599, 3368602, 3368603, 3368605,  
3368606, 3368609, 3368610, 3368612, 3368613, 3368649, 3368650, 3368653,  
3368665, 3368668, 3368672, 3368673, 3368751, 3368817, 3368820, 3368822,  
3368823, 3368877, 3368878, 3369351, 3370214, 3370269, 3370270, 3370486,  
3370487, 3370488, 3370489, 3370490, 3370491, 3370492, 3370493, 3370542,
```

3370545, 3370786, 3370787, 3371373, 3371374, 3375084, 3375092, 3375100,
3382191, 3382192, 357442, 569204, 569238, 675132, 710404, 710770, 710914,
711156, 711353, 711468, 711708, 711997, 711998, 712421, 712444, 712993, 713238,
713346, 713727, 713757, 714182, 714898, 714899, 715300, 716036, 716095, 717520,
718131, 718303, 718384, 718722, 718723, 719328, 719972, 719973, 8051106,
8051107, 8051108, 8051109, 8051111, 8051112, 8051113, 8051722, 8051723,
8051873, 8051876, 8193771, 8268708, 8268709, 8519579, 8519581, 8519582,
8561713, 8561718, W10380384, W11300585 Show less Back to Top",

"review_count": "14",

"appliance": "refrigerator",

"compatible_models": [

"1423*0A",

"1423^0A",

"1423W0A",

"19385",

"19585",

"19985",

"2413*0A",

"2413^0A",

"2413W0A",

"2453*9A",

"2453*AA",

"2453^9A",

"2453^AA",

"2453W0A",

"2453W9A",

"2453WAA",

"2454X0A",

```
"2454X1A",
"2454X2A",
"2454X3A",
"2970A",
"303075",
"56424702400",
"56425702500",
"56428702700",
"56429701992",
"56460912100",
"56461040",
"56461042",
"56461042100"
]
},
{
  "part_name": "2 Piece Broiler Pan 4396923",
  "part_number": "PS971245",
  "manufacturer": null,
  "price": "37.47",
```

```
  "description": "This is cookware designed for use in your range or oven. It is a two-piece dish that is used to grill or cook food while the broil function is on, meaning it can withstand high temperatures. This set includes both the pan and the grid. The grid is the top part. The slotted design allows grease to easily drip into to the pan below. Not only does it catch all of the drippings, it also prevents splatter and smoke while cooking. The pan can also be used separately for baking and roasting. This cookware features a durable porcelain finish, which means it is incredibly easy to clean, and is dishwasher safe. It is roughly 1.5 inches
```

deep, and measures approximately 16.5 inches by 12.5 inches. If your two-piece broil pan is lost, rusted, or damaged this is the replacement you need.",

"rating": "65",

"troubleshooting_tips": "This part works with the following products: Range, Wall Oven, Microwave Oven Combo, Microwave. Part# 4396923 replaces these: AP3837379, 1156577, 0040589, 0040592, 0040612, 0040618, 0040621, 0040622, 0040623, 0040625, 0040626, 0042172, 0042173, 0042701, 0042709, 0045102, 0045107, 0047948, 0047949, 0047952 ... Show more , 0047954, 0087722, 0087723, 0087940, 0088301, 0088302, 0088555, 0088688, 0088689, 0088771, 0089096, 0089119, 0089120, 0089653, 0090001, 0091434, 0095943, 0098682, 0304451, 0308138, 0308139, 0314175, 0507212, 0507230, 0507253, 0507254, 06473900E, 06474000E, 0663202, 0663209, 0663214, 0663215, 0663216, 0663217, 087722CG, 087722U, 087723CG, 098682K, 10389301, 10389401, 11161, 11161CG, 12500100, 14201191, 14201274, 14201800, 14204579, 14206330, 14206780, 14208085, 14212673, 14222729, 14249531, 1430-280, 1430-281, 1430280, 1430280C, 1430281, 1430281C, 19950034, 241275, 241678, 242835, 252837, 258171, 258172, 261815, 263062, 263063, 268183, 304451CG, 304451E, 306190, 307220, 310976, 314175CG, 3147563, 3147564, 3147845, 3169076, 31793602CG, 31793702CG, 3179791, 3179797, 3401F001-11, 3401F001-13, 3401F004-11, 3401F004-13, 3401F004-15, 3401F004-19, 3401F004-23, 3401F008-13, 3401F008-15, 3401F009-19, 3401F009-23, 3401F010-23, 3401F012-15, 3401F012-19, 3401F012-23, 3401F015-15, 3401F015-19, 3401F015-23, 3401F016-19, 3401F016-23, 3401F020-19, 3401F022-23, 3413F002-11, 3413F002-13, 3413F002-15, 3413F006-13, 3413F006-15, 3413F007-23, 3413F008-23, 3413F010-15, 3413F012-15, 3413F012-19, 3413F013-19, 3413F015-19, 3413F016-19, 3413F017-23, 4157046, 4164250, 4164251, 4164371, 4165321, 4167414, 4167417, 4167488, 4167489, 4167490, 4167491, 4167702, 4167806, 420101GM, 420104GM, 4211944, 4211965, 4315095, 4327210, 4327211, 4331213, 4334897, 4334898, 4334899, 4336602, 4336666, 4349672, 4349673, 4350121, 4354048, 4354743, 4372001, 4372403, 4372404, 4378383, 4378383BULK, 4378383P, 4389456, 4389457, 4389921, 4389922, 4396923, 4396923BULK, 4421424, 5-50458, 5-50789, 5-50793, 5-50810, 5-50815, 5-51187, 5-51188, 5-51321, 5-60233, 5-60329, 5-60373, 5-60374, 5-60626, 5-60901, 5-60902, 5-80131, 507-229, 507-252, 53-2696-1, 53-2696-2, 54796P01, 54918P01, 550458, 550789, 550793, 550810, 550815, 551187, 551188, 551321, 56-2696-1, 560233, 560329, 560373, 560374, 560626, 560901, 560902, 580131, 5G06400253, 5G06600253, 61400GM, 661400GM, 663-202, 7-3165, 7-70422, 7-70905, 7-70925, 7-70926, 7-8810, 7-8811, 7-90043, 7-90044, 7-90232, 7-90407, 7-90408, 70001090, 70002176, 703164, 703165, 708810, 708811, 73001013, 770422, 770905, 770925,

770926, 790043, 790044, 790231, 790232, 790407, 790408, 7G08700460, 814157, 816437, 8189635, 8190971, 84378383, 865697, 866219, 868037, 868038, 868504, 87722-3, 87723-3, 87723CG, 879374, 879375, 88722CG, 8E06106453, 8G06106413, 93-5G-06400-25, 93-5G-06400-253, 94378383, 9751481GM, 98682, 9G06400415, 9G06400453, 9G06400460, 9G06400653, 9G06700415, 9G06700453, 9G06700459, 9G06700460, BP1, BP3600, BPK, CG981129, CG981879, CG981880, CG983490, D8510101, D8510201, D8527901, D8529101, D8567001, D8567101, D8583501, D8583601, F80-325, JA99708810, M67D28, R0156548, R0157701, R0157702, R0157703, R0157909, R0157910, R0178478, R0178732, R0180035, R0199098, R0199201, R0199202, R0199251, R0199252, R0703070, R0703071, R0710063, R0710110, R0710189, R0710196, R0760009, R0760018, R0760024, R0762021, R0762022, R0762095, W10126605, Y0040589, Y0040592, Y0040612, Y0040618, Y0040621, Y0040622, Y0040623, Y0040625, Y0040626, Y0042172, Y0042173, Y0042701, Y0042709, Y0045102, Y0045107, Y0047948, Y0047949, Y0047952, Y0047954, Y0087712, Y0087722, Y0087723, Y0087940, Y0088301, Y0088302, Y0088555, Y0088688, Y0088689, Y0088771, Y0089096, Y0089119, Y0089120, Y0089653, Y0090001, Y0091434, Y0095943, Y0098682, Y0304451, Y0308138, Y0308139, Y0314175, Y0507212, Y0507230, Y0507253, Y0507254, Y06473900E, Y06474000E, Y0663202, Y0663209, Y0663214, Y0663215, Y0663216, Y0663217, Y087722CG, Y087722U, Y087723CG, Y098682K, Y0I01500199, Y12500100, Y551321, Y708811, Y770905, Y770925, Y770926 Show less Back to Top",

"review_count": "4",

"appliance": "refrigerator",

"compatible_models": [

"1058AF-CW",

"1058AF-CZ",

"1058AH-W",

"1058AH-Z",

"1058WF-CW",

"1058WF-CZ",

"1058WH-W",

"1068AH-CHZW",

"1068F-CZ",
"1068WH-CHZW",
"1100PAA",
"1100PAW",
"1100PAW-K",
"1100PAW-KL",
"1100PAW-L",
"1100PRA",
"1100PRA-K",
"1100PRW",
"1100PRW-K",
"1111WAW",
"1111WAW-L",
"1111WRA",
"1111WRW",
"11GA-10",
"11GA-10K",
"11GA-2KW",
"11GK-10",
"11GK-10K",
"11GN-10"

]

},

{

"part_name": "Air Diffuser 241542001",

"part_number": "PS976957",

```
"manufacturer": "Kenmore",  
  
"price": "58.89",  
  
"description": "This part is the upper portion of the refrigerator air deflector and  
diffuser.",  
  
"rating": null,  
  
"troubleshooting_tips": "This part works with the following products: Refrigerator. Part#  
241542001 replaces these: AP3778384, 1064211 Back to Top",  
  
"review_count": null,  
  
"appliance": "refrigerator",  
  
"compatible_models": [  
    "25331113304",  
    "25331113308",  
    "2533111330A",  
    "2533111330B",  
    "2533111330C",  
    "2533111330D",  
    "2533111330E",  
    "2533111330F",  
    "2533111330G",  
    "2533111330H",  
    "2533111330J",  
    "2533111330K",  
    "2533111330L",  
    "25331115304",  
    "25331115308",  
    "2533111530A",  
    "2533111530B",
```

```
"2533111530C",
"2533111530D",
"2533111530E",
"2533111530F",
"2533111530G",
"2533111530H",
"2533111530J",
"2533111530K",
"2533111530L",
"25331440303",
"25331442303",
"25331444303",
"25331447303"
]
},
{
  "part_name": "DUCT AIR FZ WR17X11891",
  "part_number": "PS1022364",
  "manufacturer": null,
  "price": "48.96",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
WR17X11891 replaces these: AP3854272, 1169734 Back to Top",
  "review_count": "1",
  "appliance": "refrigerator",
```

"compatible_models": [

"37511KBSARWW",

"37511KBSERWW",

"A3316ABSARBB",

"A3316ABSARWW",

"A3316ABSB",

"A3316ABSBRBB",

"A3316ABSBRWW",

"A3316ABSDRBB",

"A3316ABSDRWW",

"A3316ABSERBB",

"A3316ABSERWW",

"A3316ABSFRBB",

"A3316ABSFRWW",

"A3316ABSGRBB",

"A3316ABSGRWW",

"A3316ABSHRBB",

"A3316ABSHRWW",

"A3316ABSJRBB",

"A3316ABSJRWW",

"A3316ABSW",

"CTH17RBT2RWW",

"CTH17RBTZRWW",

"CTS17RBSARWW",

"CTS17RBSBRWW",

"CTS17RBSDRWW",

"CTS17RBSERWW",
"CTS17RBSSGRWW",
"CTS17RBSSHRWW",
"CTS18FBSALWW",
"CTS18FBSARWW"

]

},

{

"part_name": "Air Duct Foam WR02X10701",

"part_number": "PS285117",

"manufacturer": "Kenmore",

"price": "21.30",

"description": "",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm This part works with the following products: Refrigerator. Part# WR02X10701 replaces these: AP3670271, 879086, WR02X9160, WR02X9292, WR2X10701, WR2X9160, WR2X9292
Back to Top",

"review_count": "3",

"appliance": "refrigerator",

"compatible_models": [

"36211XBMBRWW",

"36211XBMDRWW",

"36211XBMERWW",

"36211XBMFRWW",

"36368432890",

"36368432891",

"36368432892",
"36368432893",
"36368432894",
"36368437890",
"36368437891",
"36368437892",
"36368437893",
"36368437894",
"36368662890",
"36368662891",
"36368662893",
"36368662894",
"36368667890",
"36368667891",
"36368667893",
"36368667894",
"36368672891",
"36368672893",
"36368672894",
"36368672895",
"36368677891",
"36368677893",
"36368677894",
"36368677895"

]

},

```
{
  "part_name": "Humidity Control Damper 5304492617",
  "part_number": "PS8747037",
  "manufacturer": "Kenmore",
  "price": "7.32",
  "description": "This part is found on the side of some crisper pan covers. It will allow you
to adjust the humidity within the crisper pan.",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
5304492617 replaces these: AP5788653, 240361201, 240361202, 240361204,
240361206, 240361301 Back to Top",
  "review_count": "1",
  "appliance": "refrigerator",
  "compatible_models": [
    "25331123300",
    "25331123302",
    "25331125300",
    "25331125302",
    "25331133300",
    "25331133302",
    "25331133303",
    "25331133306",
    "25331135300",
    "25331135302",
    "25331135303",
    "25331135306",
    "25331143300",
```



```
"25331143302",
"25331143303",
"25331145300",
"25331145302",
"25331145303",
"25344703000",
"25344723100",
"25344723101",
"25344723102",
"25344723103",
"25344723104",
"25344723105",
"25344723106",
"25344723107",
"25344723108",
"25344723109",
"25344723110"
]
},
{
  "part_name": "Cover-fan 241652301",
  "part_number": "PS1148335",
  "manufacturer": "Kenmore",
  "price": "102.15",
  "description": "",
  "rating": null,
```

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 241652301 replaces these: AP3879553, 1164659, 240355401, 241652306 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"25331113300",

"25331113302",

"25331113304",

"25331113308",

"2533111330A",

"2533111330B",

"2533111330C",

"2533111330D",

"2533111330E",

"2533111330F",

"2533111330G",

"2533111330H",

"2533111330J",

"2533111330K",

"2533111330L",

"25331115300",

"25331115302",

"25331115304",

"25331115308",

"2533111530A",

"2533111530B",

```
"2533111530C",
"2533111530D",
"2533111530E",
"2533111530F",
"2533111530G",
"2533111530H",
"2533111530J",
"2533111530K",
"2533111530L"
]
},
{
  "part_name": "AIR-TOWER WP2254354",
  "part_number": "PS11739871",
  "manufacturer": "Kenmore",
  "price": "65.68",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
WP2254354 replaces these: 2254354 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "10660232900",
    "10660232902",
    "10660232903",
```

"10660232904",
"10660233900",
"10660233902",
"10660233903",
"10660233904",
"10660234900",
"10660234902",
"10660234903",
"10660234904",
"10660239900",
"10660239902",
"10660239903",
"10660239904",
"10661182900",
"10661182901",
"10661184900",
"10661184901",
"10661189900",
"10661189901",
"10662982301",
"10662984301",
"10662989301",
"10663142301",
"10663142303",
"10663144301",
"10663152301",

```
"10663154301"
]
},
{
  "part_name": "Air Duct Tower WR17X29345",
  "part_number": "PS12583167",
  "manufacturer": null,
  "price": "13.92",
  "description": "The Air Duct Tower is located on the back wall of freezer section of your refrigerator. This tower is part of the airflow system and delivers cool air to different levels of the compartment.",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WR17X29345 replaces these: WR17X30152 Back to Top",
  "review_count": "1",
  "appliance": "refrigerator",
  "compatible_models": [
    "FBS15RCKMRWW",
    "GIE16GSHMRSS",
    "GIE16GSHPRSS",
    "GIE17GSNBRSS",
    "GIE18CTHMRBB",
    "GIE18CTHMRWW",
    "GIE18DTNBRBB",
    "GIE18DTNBRWW",
    "GIE18GCHMRSA",
    "GIE18GCNBRSA",
```

```
"GIE18GSNBRSS",
"GIE18GTHMRBB",
"GIE18GTHMRCC",
"GIE18GTHMRWW",
"GIE18GTNBRBB",
"GIE18GTNBRWW",
"GIE18HGHMRBB",
"GIE18HGHMRWW",
"GIE18HSHMRSS",
"GPE16DTHMRWW",
"GPE17CTNBRWW",
"GTE15CTHMLWW",
"GTE15CTHMRBB",
"GTE15CTHMRCC",
"GTE15CTHMRWW",
"GTE15CTHPLWW",
"GTE15CTHPRBB",
"GTE15CTHPRWW",
"GTE15NTHMLWW",
"GTE15NTHMRWW"
]
},
{
  "part_name": "Air Diffuser W10899382",
  "part_number": "PS11769417",
  "manufacturer": "Kenmore",
```

"price": "111.86",

"description": "",

"rating": "96",

"troubleshooting_tips": "This part fixes the following symptoms: Clicking sound This part works with the following products: Refrigerator. Part# W10899382 replaces these: AP6034520, W10128734, W10793669, WPW10128734 Back to Top",

"review_count": "5",

"appliance": "refrigerator",

"compatible_models": [

"10654782800",

"10654782801",

"10654782802",

"10654782803",

"10654782804",

"10654783800",

"10654783801",

"10654783802",

"10654783803",

"10654783804",

"10654784800",

"10654784801",

"10654784802",

"10654784803",

"10654784804",

"10654786800",

"10654786801",

"10654786802",

```
"10654786803",
"10654786804",
"10654789800",
"10654789801",
"10654789802",
"10654789803",
"10654789804",
"10654790801",
"10654792800",
"10654792801",
"10654792802",
"10654792803"
]
},
{
  "part_name": "Bottom Air Diffuser 240362601",
  "part_number": "PS430203",
  "manufacturer": "Kenmore",
  "price": "55.55",
  "description": "",
  "rating": "20",
  "troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Refrigerator. Part# 240362601 replaces these: AP2116102, 891283 Back to Top",
  "review_count": "1",
  "appliance": "refrigerator",
  "compatible_models": [
```


"25331113300",
"25331113302",
"25331113304",
"25331113308",
"2533111330A",
"2533111330B",
"2533111330C",
"2533111330D",
"2533111330E",
"2533111330F",
"2533111330G",
"2533111330H",
"2533111330J",
"2533111330K",
"2533111330L",
"25331115300",
"25331115302",
"25331115304",
"25331115308",
"2533111530A",
"2533111530B",
"2533111530C",
"2533111530D",
"2533111530E",
"2533111530F",
"2533111530G",

```
"2533111530H",
"2533111530J",
"2533111530K",
"2533111530L"
]
},
{
  "part_name": "Refrigerator Air Duct Insulation WR02X20092",
  "part_number": "PS8688247",
  "manufacturer": null,
  "price": "8.06",
  "description": "The air duct insulation fits between the air duct and air duct cover, and prevents warmer air from entering the air duct.",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm This part works with the following products: Refrigerator. Part# WR02X20092 replaces these: AP5712604, WR02X12019 Back to Top",
  "review_count": "5",
  "appliance": "refrigerator",
  "compatible_models": [
    "37511KBSARWW",
    "37511KBSERWW",
    "A3316ABSARBB",
    "A3316ABSARWW",
    "A3316ABSB",
    "A3316ABSBRBB",
    "A3316ABSBRWW",
```

"A3316ABSDRBB",
"A3316ABSDRWW",
"A3316ABSERBB",
"A3316ABSERWW",
"A3316ABSFRBB",
"A3316ABSFRWW",
"A3316ABSGRBB",
"A3316ABSGRWW",
"A3316ABSHRBB",
"A3316ABSHRWW",
"A3316ABSJRBB",
"A3316ABSJRWW",
"A3316ABSW",
"CTH17RBT2RWW",
"CTH17RBTZRWW",
"CTS17RBSARWW",
"CTS17RBSBRWW",
"CTS17RBSDRWW",
"CTS17RBSERWW",
"CTS17RBSGRWW",
"CTS17RBSHRWW",
"CTS18FBSALWW",
"CTS18FBSARWW"

]

},

{

"part_name": "POWER CORD WR23X10744",
"part_number": "PS5135738",
"manufacturer": null,
"price": "49.68",
"description": "",
"rating": null,
"troubleshooting_tips": "This part works with the following products: Refrigerator. Back to Top",
"review_count": null,
"appliance": "refrigerator",
"compatible_models": [
"CWE23SSHBSS",
"CWE23SSHCSS",
"DFE28JGHBBB",
"DFE28JGHBWW",
"DFE28JGHCBB",
"DFE28JMHBB",
"DFE28JSHBSS",
"DFE28JSHCSS",
"DFE29JGDABB",
"DFE29JGDAWW",
"DFE29JGDBBB",
"DFE29JGDBWW",
"DFE29JGDCBB",
"DFE29JGDCWW",
"DFE29JGDDBB",

"DFE29JGDDWW",
"DFE29JGDEBB",
"DFE29JGDEWW",
"DFE29JGDFBB",
"DFE29JGDFWW",
"DFE29JGDGBB",
"DFE29JGDGWW",
"DFE29JGDHBB",
"DFE29JGDHWW",
"DFE29JGDIBB",
"DFE29JGDIWW",
"DFE29JMDAES",
"DFE29JMDBES",
"DFE29JMDCES",
"DFE29JMDDDES"

]

},

{

"part_name": "POWER CORD EAD62329151",

"part_number": "PS11775883",

"manufacturer": "LG",

"price": "60.30",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator. Back to Top",

```
"review_count": null,  
"appliance": "refrigerator",  
"compatible_models": [  
  "73153",  
  "73157",  
  "73163",  
  "73165",  
  "73167",  
  "74012",  
  "74013",  
  "74015",  
  "74019",  
  "74022",  
  "74023",  
  "74024",  
  "74025",  
  "74027",  
  "74029",  
  "74032",  
  "74039",  
  "74042",  
  "74043",  
  "74049",  
  "74073",  
  "74113",  
  "74302",
```

```
"74305",
"74307",
"74309",
"75042",
"75043",
"75049",
"75053"
]
},
{
  "part_name": "HARNESS-WIRING 241872701",
  "part_number": "PS2203350",
  "manufacturer": "Kenmore",
  "price": "97.00",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 241872701 replaces these: AP4347869, 1465367, 241607001 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "2533111330B",
    "2533111330C",
    "2533111330D",
    "2533111330E",
    "2533111330F",
```

"2533111330G",
"2533111330H",
"2533111330J",
"2533111330K",
"2533111330L",
"2533111530B",
"2533111530C",
"2533111530D",
"2533111530E",
"2533111530F",
"2533111530G",
"2533111530H",
"2533111530J",
"2533111530K",
"2533111530L",
"25360523308",
"25360523309",
"2536052330A",
"25360525308",
"25360525309",
"2536052530A",
"25360532408",
"25360534408",
"25360537408",
"25360723307"

]


```
},  
{  
  "part_name": "Power Cord WPW10242407",  
  "part_number": "PS11750904",  
  "manufacturer": "Kenmore",  
  "price": "50.77",  
  "description": "",  
  "rating": null,  
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#  
WPW10242407 replaces these: W10242407 Back to Top",  
  "review_count": null,  
  "appliance": "refrigerator",  
  "compatible_models": [  
    "10641162310",  
    "10641163310",  
    "10641169310",  
    "1064651773510",  
    "10651132210",  
    "10651132213",  
    "10651133210",  
    "10651133213",  
    "10651134210",  
    "10651134213",  
    "10651135610",  
    "10651136210",  
    "10651139210",
```

"10651139213",
"10651139214",
"10651163210",
"10651164210",
"10651169210",
"10651172310",
"10651173310",
"10651179310",
"10651182110",
"10651182112",
"10651183110",
"10651183112",
"10651189110",
"10651189112",
"10651712411",
"10651713411",
"10651719411"

]

},

{

"part_name": "Power Cord WR23X10300",

"part_number": "PS759476",

"manufacturer": "Kenmore",

"price": "29.52",

"description": "This heavy-duty cord has a three-pronged plug (2 electrical, 1 grounding).

The power cord supplies power to your refrigerator, allowing it to keep the contents inside cool. There could be an issue with your cord if you notice that the refrigerator will not turn

on, or intermittently turns on and off. Check the cord for fraying, or other visible damage. If the power cord shows any signs of damage, replace the cord immediately as it could become an electrical or fire hazard. Before you begin this repair, ensure that the power is disconnected from the unit, and that all food that could ruin is stored away while the power is off.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start This part works with the following products: Refrigerator, Freezer, Ice Maker, Wine and Beverage Cooler. Part# WR23X10300 replaces these: AP3203148, 948349, SWR23X0108, SWR23X108, WR23X0051, WR23X0067, WR23X0102, WR23X0107, WR23X0108, WR23X0109, WR23X0115, WR23X0125, WR23X0381, WR23X0384, WR23X0417, WR23X0420, WR23X10049, WR23X10077, WR23X10182, WR23X102 ... Show more , WR23X10242, WR23X10301, WR23X10311, WR23X10316, WR23X10369, WR23X10370, WR23X10371, WR23X10540, WR23X107, WR23X108, WR23X109, WR23X115, WR23X125, WR23X381, WR23X384, WR23X417, WR23X420, WR23X51, WR23X5177, WR23X67 Show less Back to Top",

"review_count": "3",

"appliance": "refrigerator",

"compatible_models": [

"31861-1",

"31880",

"36211XBMBRWW",

"36211XBMDRWW",

"36211XBMERWW",

"36211XBMFRWW",

"36211XBRERWW",

"36211XBRFRWW",

"36346964001",

"36346964009",

"36348042891",

```
"36348042892",  
"36348042893",  
"36348042894",  
"36348042896",  
"36348042897",  
"36348047891",  
"36348047892",  
"36348047893",  
"36348047894",  
"36348047896",  
"36348047897",  
"36348252891",  
"36348252892",  
"36348252893",  
"36348252894",  
"36348252896",  
"36348252897",  
"36348257891",  
"36348257892"  
]  
,  
{  
  "part_name": "CORD-SERVICE 241516904",  
  "part_number": "PS16227180",  
  "manufacturer": "Kenmore",  
  "price": "38.77",
```

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator, Wine and Beverage Cooler. Part# 241516904 replaces these: 7241516901 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"25370347411",

"2537034941H",

"25370417410",

"2537042341A",

"2537044341C",

"E23BC78IPS0",

"E23BC78ISS0",

"E23CS78HPS0",

"E23CS78HPS1",

"E23CS78HPS2",

"E23CS78HPS3",

"E23CS78HSS0",

"E23CS78HSS1",

"E23CS78HSS2",

"E23CS78HSS3",

"E24RD75HPS0",

"E24RD75HSS0",

"E24WC75HPS0",

"E24WC75HSS0",

```
"EI23BC55IB1",
"EI23BC55IS1",
"EI23BC55IW1",
"EI23BC56IB0",
"EI23BC56IS0",
"EI23BC56IW0",
"EI23CS55GB0",
"EI23CS55GB1",
"EI23CS55GS0",
"EI23CS55GS1",
"EI23CS55GW0"
]
},
{
  "part_name": "CORD-POWER W10820044",
  "part_number": "PS11727764",
  "manufacturer": "Kenmore",
  "price": "90.36",
  "description": "",
  "rating": "94",
  "troubleshooting_tips": "This part fixes the following symptoms: Will Not Start This part works with the following products: Washer, Refrigerator. Part# W10820044 replaces these: AP5988521, 285142, 285518, 285775, 285776, 285800, 3347005, 3348564, 3353152, 3360514, 3361759, 3948063, 3949248, 3956162, 62734, 661661, 8578842 Back to Top",
  "review_count": "3",
  "appliance": "refrigerator",
  "compatible_models": [
```

"10682872600",
"11010202000",
"11010202001",
"1101050299",
"11010502990",
"11010502991",
"11010852990",
"11010852991",
"11012202100",
"11012502100",
"11012852100",
"11013202200",
"11013212200",
"11014102300",
"11014112300",
"11014202300",
"11014212200",
"11014222300",
"11014502300",
"11014852300",
"11015732400",
"11015842400",
"11015852400",
"11015862400",
"11015864400",
"11015942400",

```
"11015942401",
"11015944400",
"11015944401",
"11015952400"
]
},
{
  "part_name": "Power Cord - Black WP67006506",
  "part_number": "PS11743694",
  "manufacturer": "Kenmore",
  "price": "30.17",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Will Not Start This part works with the following products: Refrigerator. Part# WP67006506 replaces these: 12583301, 67006506, 8170925 Back to Top",
  "review_count": "1",
  "appliance": "refrigerator",
  "compatible_models": [
    "59650002100",
    "59650003100",
    "59650004100",
    "59650009100",
    "59650012100",
    "59650013100",
    "59650014100",
    "59650019100",
```


"59651672100",
"59651673100",
"59651674100",
"59651679100",
"59652672200",
"59652672201",
"59652672202",
"59652673200",
"59652673201",
"59652673202",
"59652674200",
"59652674201",
"59652674202",
"59652679200",
"59652679201",
"59652679202",
"59653462300",
"59653462301",
"59653462302",
"59653463300",
"59653463301",
"59653463302"

]

},

{

"part_name": "Power Cord 241516901",

```
"part_number": "PS899529",
"manufacturer": "Kenmore",
"price": "26.24",
"description": "",
"rating": null,
"troubleshooting_tips": "This part works with the following products: Refrigerator, Wine
and Beverage Cooler. Part# 241516901 replaces these: AP3585947, 1037619 Back to Top",
"review_count": null,
"appliance": "refrigerator",
"compatible_models": [
  "20462151B",
  "25344302400",
  "25344302401",
  "25344303400",
  "25344303401",
  "25344303402",
  "25344303403",
  "25344304400",
  "25344304401",
  "25344309400",
  "25344309401",
  "25344333600",
  "25344333601",
  "25344333602",
  "25344333603",
  "25344333604",
```

"25344333605",

"25344333606",

"25344333607",

"25344333608",

"25344333609",

"2534433360A",

"25344352400",

"25344352401",

"25344352403",

"25344352404",

"25344352405",

"25344352406",

"25344352407",

"25344352408"

]

},

{

"part_name": "Power Cord Kit 4317824",

"part_number": "PS358548",

"manufacturer": "Kenmore",

"price": "26.84",

"description": "Includes power cord and all necessary parts needed for complete installation of cord.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start This part works with the following products: Dishwasher, Refrigerator. Part# 4317824 replaces these: AP3081233, 232, 302764, 3370315, 4317824, 4317824R, 675456, PT110 Back to Top",

```
"review_count": "1",  
"appliance": "refrigerator",  
"compatible_models": [  
  "2212413N414",  
  "2213092N413",  
  "2213099N413",  
  "2213222N414",  
  "2213223N414",  
  "2213229N414",  
  "2213473N413",  
  "2213479N413",  
  "2213804N710",  
  "2213809N710",  
  "2214523N611",  
  "2214545N711",  
  "2214715N710",  
  "2214792N512",  
  "2214793N512",  
  "2217383N710",  
  "2217389N710",  
  "56492441100",  
  "56493445100",  
  "56494372400",  
  "56494446400",  
  "56494449400",  
  "66213032K112",
```

```
"66213273K112",
"66512093K210",
"66512413N410",
"66512413N411",
"66512413N412",
"66512413N413",
"66512413N414"
]
},
{
  "part_name": "STARTER 242298401",
  "part_number": "PS8689298",
  "manufacturer": null,
  "price": "28.04",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 242298401 replaces these: AP5690329 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "CFTR1826LMC",
    "CRT182NB5",
    "CRT182NW5",
    "FFTR1513LWC",
    "FFTR1515LWB",
```

"FFTR1715LBE",
"FFTR1814LBE",
"FFTR1814LWE",
"FFTR1817LBC",
"FFTR1817LWC",
"FFTR18D2PB2",
"FFTR18D2PW2",
"FRT18G2NW4",
"FRT18L4JBJ",
"FRT18L4JMJ",
"FRT18L4JWJ",
"FTMD18P4KWB",
"LFTR1814LBC",
"LFTR1814LWC",
"LFTR1814NM3",
"LFTR1814NM4",
"NFTR18X4LBB",
"NFTR18X4LWB",
"NFTR18X4PS3",
"WRT8G3EWU",
"WWTR1802KWD"

]

},

{

"part_name": "STARTER 241707717",

"part_number": "PS2331560",

"manufacturer": null,

"price": "57.38",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator, Wine and Beverage Cooler. Part# 241707717 replaces these: AP4327175, 7241707717 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"E24RD75HPS0",

"E24RD75HPS1",

"E24RD75HSS0",

"E24RD75HSS1",

"E24RD75KPS0",

"E24RD75KPS1",

"E24RD75KSS0",

"E24WC75HPS0",

"E24WC75HPS1",

"E24WC75HSS0",

"E24WC75HSS1",

"EI24BC65GS0",

"EI24BC65GS1",

"EI24BC65GS2",

"EI24RD65HS0",

"EI24RD65HS1",

"EI24RD65KS0",

```
"EI24RD65KS1",
"EI24WC65GS0",
"EI24WC65GS1",
"EI24WC75HS0"
]
},
{
  "part_name": "Starter 241707725",
  "part_number": "PS3508262",
  "manufacturer": null,
  "price": "64.48",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 241707725 replaces these: AP5656812, 241707726 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "FFHS2313LS2",
    "FFSC2323LE2",
    "FFSC2323LEA",
    "FFSC2323LP6",
    "FFSC2323LP7",
    "FFSC2323LPA",
    "FFSC2323LSB",
    "FFSS2622NB4",
```


"FFSS2622NB5",
"FFSS2622NS0",
"FFSS2622NS4",
"FFSS2622NS5",
"FFSS2622NW4",
"FFSS2622NW5",
"FLS26Z2GKW4",
"WWSS2601KW2",
"WWSS2601KW5",
"WWSS2601KW6",
"WWSS2601KW7",
"WWSS2601KW8",
"WWSS2601NE1"

]

},

{

"part_name": "STARTER 5304491322",

"part_number": "PS8689445",

"manufacturer": null,

"price": "41.47",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 5304491322 replaces these: AP5690362 Back to Top",

"review_count": null,

"appliance": "refrigerator",

```
"compatible_models": [  
    "FFPT10F3NB0",  
    "FFPT10F3NM0",  
    "FFPT10F3NW0",  
    "FFPT12F3NB0",  
    "FFPT12F3NM0",  
    "FFPT12F3NV0",  
    "FFPT12F3NW0",  
    "FFTR1022QB0",  
    "FFTR1022QM0",  
    "FFTR1022QW0",  
    "FFTR1222QB0",  
    "FFTR1222QM0",  
    "FFTR1222QW0"  
]  
,  
{  
    "part_name": "STARTER 241941004",  
    "part_number": "PS3408514",  
    "manufacturer": "Kenmore",  
    "price": "82.14",  
    "description": "",  
    "rating": null,  
    "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#  
241941004 replaces these: AP4587430, 241527807, 241527808 Back to Top",  
    "review_count": null,
```

"appliance": "refrigerator",

"compatible_models": [

"25361532805",

"25361534805",

"25361537805",

"25361552012",

"25361552015",

"25361554012",

"25361554015",

"25361762016",

"25361762017",

"25361763016",

"25361763017",

"25361764016",

"25361764017",

"25361767016",

"25361767017",

"25361768016",

"25361768017",

"25361769016",

"25361769017",

"25361780016",

"25361780017",

"25361783016",

"25361783017",

"25361789016",

```
"25361789017",
"25361821014",
"25361827014",
"25368892010",
"25368893010",
"25368894010"
]
},
{
  "part_name": "STARTER 241707710",
  "part_number": "PS8689194",
  "manufacturer": null,
  "price": "48.77",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 241707710 replaces these: 241713502, 5304485337, 7241713502 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "CRSE234JB0",
    "CRSE234JB1",
    "CRSE234JQ0",
    "CRSE234JQ1",
    "CRSE234JSM0",
    "CRSE234JSM1",
```

"CRSE234JW0",
"CRSE234JW1",
"EI23SS55HB0",
"EI23SS55HS0",
"EI23SS55HW0",
"EW23SS65HB0",
"EW23SS65HS0",
"EW23SS65HW0",
"FRS3HF6JB0",
"FRS3HF6JQ0",
"FRS3HF6JSB0",
"FRS3HF6JW0",
"GLHS36EJB0",
"GLHS36EJSB0",
"GLHS36EJW0",
"GLHS37EHSB6",
"GLHS38EJB0",
"GLHS38EJPB0",
"GLHS38EJPW0",
"GLHS38EJQ0",
"GLHS38EJW0",
"GLHS39EJPB0",
"GLHS39EJPB1",
"GLHS39EJPW0"

]

},

```
{
  "part_name": "STARTER 241707709",
  "part_number": "PS1765256",
  "manufacturer": "Kenmore",
  "price": "64.50",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
241707709 replaces these: AP4033785, 1259167, 241713503 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "25344502608",
    "25344502609",
    "2534450260C",
    "25344503608",
    "25344503609",
    "2534450360C",
    "25344509608",
    "25344509609",
    "2534450960C",
    "25344512608",
    "25344512609",
    "25344513608",
    "25344513609",
    "25344519608",
```

```
"25344519609",  
"25355333607",  
"25357188604",  
"25361732805",  
"25361733901",  
"25361734805",  
"25361737805",  
"25361738805",  
"25361739901",  
"CRSE234FB3",  
"CRSE234FB4",  
"CRSE234FQ3",  
"CRSE234FQ4",  
"CRSE234FSM3",  
"CRSE234FSM4",  
"CRSE234FW3"  
]  
,  
{  
  "part_name": "STARTER 297259505",  
  "part_number": "PS9493837",  
  "manufacturer": "Kenmore",  
  "price": "52.51",  
  "description": "",  
  "rating": null,
```

"troubleshooting_tips": "This part works with the following products: Refrigerator, Freezer. Part# 297259505 replaces these: AP5807086 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"25312112410",

"25312512410",

"25312512411",

"25312810510",

"25312812510",

"25312912410",

"25360312411",

"25360312412",

"25360312413",

"25360312414",

"25360313411",

"25360313412",

"25360313413",

"25360313414",

"25360319411",

"25360319412",

"25360319413",

"25360319414",

"25360382411",

"25360382412",

"25360383411",


```
"25360383412",
"25360389411",
"25360389412",
"25361552019",
"25361554019",
"CFC092QWA",
"CFC162QWA",
"CFC162RCA",
"CFC183QWA"
]
},
{
  "part_name": "Start Relay 5304508629",
  "part_number": "PS12071169",
  "manufacturer": "Kenmore",
  "price": "36.46",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Will Not Start This part works with the following products: Refrigerator, Freezer. Part# 5304508629 replaces these: AP6230501, 5304470337, 5304486750, 5304486758 Back to Top",
  "review_count": "2",
  "appliance": "refrigerator",
  "compatible_models": [
    "25317512710",
    "25317812710",
    "FFCL1542AW",
```

"FFCL2042AW",
"FFCL2542AW",
"FFHT1824US",
"FFHT1824UW",
"FFPT10F0KB0",
"FFPT10F0KM0",
"FFPT10F0KV0",
"FFPT10F0KW0",
"FFPT10F3MB0",
"FFPT10F3MM0",
"FFPT10F3MV0",
"FFPT10F3MW0",
"FFPT12F0KB0",
"FFPT12F0KM0",
"FFPT12F0KV0",
"FFPT12F0KW0",
"FFPT12F3MB0",
"FFPT12F3MM0",
"FFPT12F3MV0",
"FFPT12F3MW0",
"FRQG1721AV",
"FRT105GW0",
"FRT125GW0"

]

},

{

"part_name": "Start Device 241941005",
"part_number": "PS4704897",
"manufacturer": "Kenmore",
"price": "113.00",
"description": "",
"rating": "100",
"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 241941005 replaces these: AP5645258 Back to Top",
"review_count": "1",
"appliance": "refrigerator",
"compatible_models": [
"25360022410",
"25360022411",
"25360082411",
"25360082412",
"25360082413",
"25360082414",
"25360082415",
"25360083411",
"25360083412",
"25360083413",
"25360083414",
"25360083415",
"25360089411",
"25360089412",
"25360089413",

"25360089414",
"25360089415",
"25360112410",
"25360113410",
"25360113411",
"25360119410",
"25360312410",
"25360312415",
"25360312416",
"25360313410",
"25360313415",
"25360313416",
"25360319410",
"25360319416",
"25360382410"

]

},

{

"part_name": "NAMEPLATE 242016301",

"part_number": "PS2378726",

"manufacturer": null,

"price": "13.04",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator, Freezer. Part# 242016301 replaces these: AP4512550, 297434600, 297434601 Back to Top",

```
"review_count": null,  
"appliance": "refrigerator",  
"compatible_models": [  
  "CFHT1814LZ0",  
  "CFHT1814LZ1",  
  "CFHT1814LZ3",  
  "CFHT1814LZ4",  
  "CFHT1826LP0",  
  "CFHT1826LP1",  
  "CFHT1826LP2",  
  "CFHT1826LP3",  
  "CFHT1826LP4",  
  "CFHT1826LP5",  
  "CFHT1826LP6",  
  "CFHT1826LP7",  
  "CFHT1842LS0",  
  "CFHT1842LS1",  
  "CFHT1842LS2",  
  "CFHT1842LS3",  
  "CFHT1842LS4",  
  "CFHT1842LS6",  
  "CFHT1842LS7",  
  "CFHT1842PS0",  
  "CFHT1842PS1",  
  "CFHT1842PS2",  
  "CFHT1842PS3",
```

"CFHT1842PS4",

"CFHT1843LS0",

"CFHT1843LS1",

"CFHT1843LS2",

"CFHT1843LS3",

"CFHT1843LS4",

"CFHT1843LS5"

]

},

{

"part_name": "CARD- HAND 67007028",

"part_number": "PS2070509",

"manufacturer": "Kenmore",

"price": "7.39",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 67007028 replaces these: AP4081474, 1394064, 67003975, 67004112, 67005034, 67007028 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"59675502400",

"59675503400",

"59675504400",

"59675509400",

"59675512400",

"59675513400",
"59675514400",
"59675519400",
"59675522400",
"59675523400",
"59675524400",
"59675529400",
"59675532400",
"59675533400",
"59675534400",
"59675539400",
"59676502500",
"59676503500",
"59676504500",
"59676509500",
"59676512500",
"59676513500",
"59676514500",
"59676519500",
"59676522500",
"59676523500",
"59676524500",
"59676529500",
"59676532500",
"59676533500"

]

```
},  
{  
  "part_name": "Nameplate (Grey) WPW10046610",  
  "part_number": "PS11748058",  
  "manufacturer": null,  
  "price": "45.20",  
  "description": "",  
  "rating": null,  
  "troubleshooting_tips": "This part works with the following products: Refrigerator, Ice  
Maker, Microwave, Wine and Beverage Cooler. Part# WPW10046610 replaces these:  
4344813, 8206517, W10046610, W10239386 Back to Top",  
  "review_count": null,  
  "appliance": "refrigerator",  
  "compatible_models": [  
    "EF36IWFSS",  
    "EF36IWFSSS0",  
    "EF36IWFSSS1",  
    "EF36IWFSSS2",  
    "K2TLEFFWMS00",  
    "K2TLEFFWMS01",  
    "K2TREFFWBL00",  
    "K2TREFFWMS00",  
    "K2TREFFWMS01",  
    "K2TREFFWWH00",  
    "K9TLEFFWMS00",  
    "K9TLEFFWMS01",  
    "K9TREFFWBL00",
```



```
"K9TREFFWMS00",
"K9TREFFWMS01",
"K9TREFFWWH00",
"KBCS24LSBS00",
"KBCS24LSBS01",
"KBCS24LSBS02",
"KBCS24LSBS03",
"KBCS24LSBS04",
"KBCS24RSBS00",
"KBCS24RSBS01",
"KBCS24RSBS02",
"KBCS24RSBS03",
"KBCS24RSBS04",
"KBCS24RSSH00",
"KBCS24RSSH01",
"KBCS24RSSH02",
"KBCS24RSSH03"
]
},
{
  "part_name": "BADGE Assembly GE WR04X10149",
  "part_number": "PS1016913",
  "manufacturer": null,
  "price": "56.01",
  "description": "",
  "rating": null,
```

"troubleshooting_tips": "This part works with the following products: Refrigerator. Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"38489KBSERSS",

"38489KBSJRSS",

"38489KBSNRSS",

"38489KBSRRSS",

"38489KBSURSS",

"38489KBSVRSS",

"38489KBSWRSS",

"GTH18ISDBRSS",

"GTH18ISDKRSS",

"GTH18ISDLRSS",

"GTH18ISXCRSS",

"GTH18ISXDRSS",

"GTH18SBTVRSS",

"GTH18SBXARSS",

"GTH18SBXBRSS",

"GTH18SBXCRSS",

"GTH18SBXDRSS",

"GTH20JBBABB",

"GTH20JBBARBB",

"GTH20JBBARSS",

"GTH20JBBARWW",

```
"GTH20JBBAWW",
"GTH20SBBASS",
"GTH21GBEWW",
"GTH21SBWASS",
"GTH21SBXASS",
"GTH21SCWASS",
"GTH21SCXASS",
"GTM18GBEDRES",
"GTM18GCEDRES"
]
},
{
  "part_name": "Nameplate WP2213265",
  "part_number": "PS11739712",
  "manufacturer": null,
  "price": "42.51",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator, Freezer, Air Conditioner. Part# WP2213265 replaces these: 1186026, 1187169, 2207087B, 2207087T, 2207087TG, 2207087W, 2212547, 2212548, 2212549, 2212550, 2213263, 2213265, 2214196N, 2214196T, 2214196W, 2220055, 2255121, 2262180, 2262218, 4390758 ... Show more , 67006066, 8209222 Show less Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "3WSC19D4AY00",
```

"3WSC19D4XB00",
"3WSC19D4XD00",
"3WSC19D4XW00",
"3WSC19D4XY00",
"3WSC19D4XY01",
"3WSC20N4AY00",
"3WSC20N4XB00",
"3WSC20N4XD00",
"3WSC20N4XW00",
"3WSC20N4XY00",
"3WSC20N4XY01",
"5ED2FHGXVA00",
"5ED2FHGXVQ00",
"5ED2FHKXRL03",
"5ED2FHKXRL04",
"5ED2FHKXRL05",
"5ED2FHKXVA00",
"5ED2FHKXVQ00",
"5ED5FHKXVA00",
"5ED5FHKXVQ00",
"5ED5FHKXVT00",
"5ET6WPKRQ00",
"5VET6WPKLQ01",
"5VET6WPKLQ02",
"5VET6WPKLQ03",
"5VET6WPKLQ04",

```
"5VET8WPKLQ01",
"5VET8WPKLQ02",
"5VET8WPKLQ04"
]
},
{
  "part_name": "NAME PLATE MFT62346511",
  "part_number": "PS11712057",
  "manufacturer": "LG",
  "price": "32.76",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# MFT62346511 replaces these: AP5978897, 3846JD1007G, 3846JD1009F, MFT62146301, MFT62366202 Back to Top",
  "review_count": "1",
  "appliance": "refrigerator",
  "compatible_models": [
    "495934",
    "GF5D906SL",
    "GM-818DTWA",
    "GR-382R",
    "GR-K192AF",
    "GR-K24PS",
    "GR-K303DS",
    "GR-K30PS",
    "GR-L218USGH",
```

```
"GR-L218USJH",
"GR-L247",
"GR-L247EQ",
"GR-L247W",
"GR-L288KVJP",
"GR382RASWCGSC",
"GR389R",
"GRL318LSJP",
"GRLRTP1231W",
"GRS507GSM1",
"GRT177IVDI",
"LBC20514SW",
"LBC20514TT",
"LBC22518ST",
"LBC22518WW",
"LBC22520SB",
"LBC22520ST",
"LBC22520SW",
"LBC22520TT",
"LBC24360ST"
]
},
{
  "part_name": "BLADE WR60X10291",
  "part_number": "PS2354839",
  "manufacturer": null,
```

```
"price": "8.19",
"description": "",
"rating": null,
"troubleshooting_tips": "This part works with the following products: Refrigerator. Back
to Top",
"review_count": null,
"appliance": "refrigerator",
"compatible_models": [
  "GTL12HBDBS",
  "GTL12HBXARBS",
  "GTR10HADWW",
  "GTR10HAXARWW",
  "GTR12HAXARWW",
  "GTR12HBDWW",
  "GTR12HBXARCC",
  "GTR12HBXARWW"
]
},
{
  "part_name": "BLADE 5304470311",
  "part_number": "PS2351311",
  "manufacturer": null,
  "price": "11.38",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
5304470311 replaces these: AP4374357 Back to Top",
```

```
"review_count": null,
"appliance": "refrigerator",
"compatible_models": [
  "FFPT10F0KB0",
  "FFPT10F0KM0",
  "FFPT10F0KV0",
  "FFPT10F0KW0",
  "FFPT10F3MB0",
  "FFPT10F3MM0",
  "FFPT10F3MV0",
  "FFPT10F3MW0",
  "FFPT12F0KB0",
  "FFPT12F0KM0",
  "FFPT12F0KV0",
  "FFPT12F0KW0",
  "FFPT12F3MB0",
  "FFPT12F3MM0",
  "FFPT12F3MV0",
  "FFPT12F3MW0",
  "FRT105GW0",
  "FRT125GW0"
]
},
{
  "part_name": "BLADE W10181990",
  "part_number": "PS2348434",
```



```
"manufacturer": "Kenmore",
"price": "13.71",
"description": "",
"rating": null,
"troubleshooting_tips": "This part works with the following products: Refrigerator. Back
to Top",
"review_count": null,
"appliance": "refrigerator",
"compatible_models": [
  "1064650043714",
  "10650022210",
  "10650022211",
  "10650023210",
  "10650023211",
  "10650029210",
  "10650029211",
  "10650029213",
  "10650042710",
  "10650042711",
  "10650042713",
  "10650042714",
  "10650042717",
  "10650043710",
  "10650043711",
  "10650043713",
  "10650043714",
```

```
"10650043717",
"10650045710",
"10650045711",
"10650045713",
"10650045715",
"10650049710",
"10650049711",
"10650049713",
"10650049714",
"10650049717",
"10651112710",
"10651112711",
"10651113210"
]
},
{
  "part_name": "BLADE W10341944",
  "part_number": "PS3501800",
  "manufacturer": "Kenmore",
  "price": "48.02",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Back  
to Top",
  "review_count": null,
  "appliance": "refrigerator",
```

"compatible_models": [

"10651182110",

"10651183110",

"10651189110",

"10654782804",

"10654783804",

"10654784804",

"10654786804",

"10654789804",

"10654792804",

"10654793804",

"10654794804",

"10654796804",

"10654799804",

"6WSC20C6XB02",

"6WSC20C6XB04",

"6WSC20C6XD02",

"6WSC20C6XD04",

"6WSC20C6XW02",

"6WSC20C6XW04",

"6WSC20C6XY02",

"6WSC20C6XY04",

"ED5FVAXWL01",

"GI7FVCXXY02",

"GI7FVCXXY03",

"KFIL27CXMS4",

```
"KFIL27CXMS5",
"KFIS27CXMS4",
"KSSO36QTB04",
"KSSO36QTX04",
"KSSS36QTB04"
]
},
{
  "part_name": "BLADE W10341943",
  "part_number": "PS3501799",
  "manufacturer": "Kenmore",
  "price": "48.02",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Back  
to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "10651182110",
    "10651183110",
    "10651189110",
    "10654782804",
    "10654783804",
    "10654784804",
    "10654786804",
```

```
"10654789804",  
"10654792804",  
"10654793804",  
"10654794804",  
"10654796804",  
"10654799804",  
"6WSC20C6XB02",  
"6WSC20C6XB04",  
"6WSC20C6XD02",  
"6WSC20C6XD04",  
"6WSC20C6XW02",  
"6WSC20C6XW04",  
"6WSC20C6XY02",  
"6WSC20C6XY04",  
"ED5FVAXWL01",  
"GI7FVCXXY02",  
"GI7FVCXXY03",  
"KFIL27CXMS4",  
"KFIL27CXMS5",  
"KFIS27CXMS4",  
"KSSO36QTB04",  
"KSSO36QTX04",  
"KSSS36QTB04"  
]  
,  
{
```

```
"part_name": "BLADE W10341942",
"part_number": "PS3501798",
"manufacturer": "Kenmore",
"price": "48.02",
"description": "",
"rating": null,
"troubleshooting_tips": "This part works with the following products: Refrigerator. Back
to Top",
"review_count": null,
"appliance": "refrigerator",
"compatible_models": [
  "10651182110",
  "10651183110",
  "10651189110",
  "10654782804",
  "10654783804",
  "10654784804",
  "10654786804",
  "10654789804",
  "10654792804",
  "10654793804",
  "10654794804",
  "10654796804",
  "10654799804",
  "6WSC20C6XB02",
  "6WSC20C6XB04",
```

"6WSC20C6XD02",
"6WSC20C6XD04",
"6WSC20C6XW02",
"6WSC20C6XW04",
"6WSC20C6XY02",
"6WSC20C6XY04",
"ED5FVAXWL01",
"GI7FVCXXY02",
"GI7FVCXXY03",
"KFIL27CXMS4",
"KFIL27CXMS5",
"KFIS27CXMS4",
"KSSO36QTB04",
"KSSO36QTX04",
"KSSS36QTB04"

]

},

{

"part_name": "BLADE 5308014583",

"part_number": "PS1137035",

"manufacturer": null,

"price": "9.92",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 5308014583 replaces these: 08001281, 08014583 Back to Top",

```
"review_count": null,
"appliance": "refrigerator",
"compatible_models": [
  "FPES19BDH1",
  "FPES19BDL1",
  "FPES19BDW1"
]
},
{
  "part_name": "BLADE 5304449102",
  "part_number": "PS1148848",
  "manufacturer": null,
  "price": "198.15",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Back
to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "E42BS75EPS",
    "E42BS75ETT"
  ]
},
{
  "part_name": "Refrigerator Evaporator Fan Blade DA31-00016A",
```


"part_number": "PS4138288",

"manufacturer": null,

"price": "25.00",

"description": "This evaporator fan blade is for refrigerators. Evaporator fan blade circulates air through the evaporator fins and interior compartment of the refrigerator to improve the cooling efficiency.",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# DA31-00016A replaces these: AP4138351, DA31-00016A Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [
"AC2125PSLB",
"AC2125PSLS",
"AC2125PSLW",
"AC2125PULB",
"AC2125PULS",
"AC2125PULW",
"AC2126HSLB",
"AC2126HSLS",
"AC2126HSLW",
"AC2126HULB",
"AC2126HULS",
"AC2126HULW",
"AC2127HSLB",
"AC2127HSLS",
"AC2127HSLW",

```
"AC2127HULB",
"AC2127HULS",
"AC2127HULW",
"BBF19KASW",
"BBF19KASWXAC",
"BBF21KASB",
"BBF21KASBXAC",
"BBF21KASW",
"BBF21KASWXAC",
"BS23DDBE1ADM",
"BS23DDBE1AMN",
"BS23DDBE1MTG",
"BS23DDBE1UK1",
"BS23DDBE1UK2",
"BS23DDBE1UK3"
]
},
{
  "part_name": "Refrigerator Ice Crusher Fixed Blade 241684303",
  "part_number": "PS12728806",
  "manufacturer": "Kenmore",
  "price": "13.41",
  "description": "The ice crusher blade grinds the ice cubes in the ice container to create crushed ice.",
  "rating": null,
```

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 241684303 replaces these: AP6972868, 241684301, 5304404353, 7241684301 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"25344302400",

"25344302401",

"25344303400",

"25344303401",

"25344303402",

"25344303403",

"25344304400",

"25344304401",

"25344309400",

"25344309401",

"25344333600",

"25344333601",

"25344333602",

"25344333603",

"25344333604",

"25344333605",

"25344333606",

"25344333607",

"25344333608",

"25344333609",

"2534433360A",

```
"25344352400",
"25344352401",
"25344352403",
"25344352404",
"25344352405",
"25344352406",
"25344352407",
"25344352408",
"25344352409"
]
},
{
  "part_name": "TRANSFORMER 00605681",
  "part_number": "PS8726484",
  "manufacturer": null,
  "price": "108.92",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator,
Freezer. Part# 00605681 replaces these: AP3962317, 605681 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "B36ET71SN",
    "B36ET71SNS",
    "B36IB70NSP",
```

```
"B36IB70NSP12",
"B36IT70NNP",
"B36IT70NNP08",
"B36IT71NNP",
"B36IT71NNP11",
"B36IT71SN",
"RB491700",
"RY491700",
"RY491701",
"T36BT71FS",
"T36BT71FSE",
"T36IB70CSS",
"T36IB70FSS",
"T36IB70NSP",
"T36IB70PSS",
"T36IT70CNS",
"T36IT70FNS",
"T36IT70NNP",
"T36IT70PNS",
"T36IT71FN",
"T36IT71FNS",
"T36IT71NNP"
]
},
{
  "part_name": "TRANSFORMER 00499930",
```

"part_number": "PS8723842",
"manufacturer": null,
"price": "192.30",
"description": "",
"rating": null,
"troubleshooting_tips": "This part works with the following products: Refrigerator, Freezer. Part# 00499930 replaces these: AP3955058, 499930 Back to Top",
"review_count": null,
"appliance": "refrigerator",
"compatible_models": [
"RB472701",
"RB491700",
"RB492701",
"RC462700",
"RC462701",
"RC472700",
"RC472701",
"RY491700",
"RY491701",
"RY492701",
"T24BR70FS",
"T24BR70FS-03",
"T24BR70FSE",
"T24IR70CSS-01",
"T24IR70FSS-01",
"T24IR70NSP",

"T24IR70PSS-01",
"T30BR70FS",
"T30BR70FS-10",
"T30BR70FSE",
"T30IR70CSS-01",
"T30IR70FSS-01",
"T30IR70NSP",
"T30IR70NSP-03",
"T30IR70NSP-05",
"T30IR70PSS",
"T36BT71FS",
"T36BT71FSE",
"T36IB70CSS",
"T36IB70FSS"

]

},

{

"part_name": "TRANSFORMER 00499846",

"part_number": "PS8723817",

"manufacturer": null,

"price": "444.02",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator, Freezer. Part# 00499846 replaces these: AP3955133, 499846 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"B18ID80NLP",

"B18ID80NRP",

"B18IF70NSP",

"B18IW50NSP",

"B24ID80NLP",

"B24ID80NRP",

"B24IF70NSP",

"B24IR70NSP",

"B24IW50NSP",

"B30IF70NSP",

"B30IR70NSP",

"B36ET71SN",

"B36ET71SNS",

"B36IB70NSP",

"B36IB70NSP12",

"B36IT70NNP",

"B36IT70NNP08",

"B36IT71NNP",

"B36IT71NNP11",

"B36IT71SN",

"RB491700",

"RC462700",

"RC472700",

"RF411700",


```
"RF461700",
"RF463700",
"RF463701",
"RF471700",
"RY491700",
"RY491701"
]
},
{
  "part_name": "TRANSFORMER WR55X25995",
  "part_number": "PS12172925",
  "manufacturer": null,
  "price": "105.28",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Ice Maker, Refrigerator. Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "UCC15NJBII",
    "UCC15NJCII",
    "UNC15NJBII"
  ]
},
{
```

```
"part_name": "TRANSFORMER WR62X10077",
"part_number": "PS2354849",
"manufacturer": null,
"price": "50.65",
"description": "",
"rating": null,
"troubleshooting_tips": "This part works with the following products: Refrigerator. Back
to Top",
"review_count": null,
"appliance": "refrigerator",
"compatible_models": [
  "ZISS42GDXASS"
]
},
{
  "part_name": "TRANSFORMER WR62X10076",
  "part_number": "PS2354848",
  "manufacturer": null,
  "price": "42.91",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Back
to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "ZISS42GDXASS"
```

```
]
},
{
  "part_name": "TRANSFORMER 11006454",
  "part_number": "PS11724882",
  "manufacturer": null,
  "price": "173.60",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator,
Freezer. Part# 11006454 replaces these: 00499928, 00644518, 499928, 644518 Back to
Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "B24IR70NSP",
    "B30IR70NSP",
    "B36ET71SN",
    "B36ET71SNS",
    "B36IB70NSP",
    "B36IB70NSP12",
    "B36IT70NNP",
    "B36IT70NNP08",
    "B36IT71NNP",
    "B36IT71NNP11",
    "B36IT71SN",
    "RB491700",
```

```
"RC462700",
"RC472700",
"RY491700",
"RY491701",
"T18IF70NSP",
"T24BR70FS",
"T24BR70FS-03",
"T24BR70FSE",
"T24IR70CSS-01",
"T24IR70FSS-01",
"T24IR70NSP",
"T24IR70PSS-01",
"T30BR70FS",
"T30BR70FS-10",
"T30BR70FSE",
"T30IR70CSS-01",
"T30IR70FSS-01",
"T30IR70NSP"
]
},
{
  "part_name": "Transformer WP11001154",
  "part_number": "PS11738264",
  "manufacturer": null,
  "price": "45.16",
  "description": "The transformer is for a personal beverage vending machine.",
```

```
"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
WP11001154 replaces these: 11001154 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

    "MBV1976AAB",

    "MBV1976AAP"

]
},
{

    "part_name": "TRANSFORMER FZ LIGHTS WR62X10030",

    "part_number": "PS651984",

    "manufacturer": null,

    "price": "249.94",

    "description": "",

    "rating": null,

    "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
WR62X10030 replaces these: AP3189470, 945680, WR62X10083, WR62X10086 Back to
Top",

    "review_count": null,

    "appliance": "refrigerator",

    "compatible_models": [

        "ZIS360NMA",

        "ZIS360NMB",

        "ZIS360NMC",

        "ZIS360NMD",
```

"ZIS360NRA",
"ZIS360NRB",
"ZIS360NRC",
"ZIS360NRD",
"ZIS360NRE",
"ZIS360NRF",
"ZIS360NRG",
"ZIS360NRH",
"ZIS360NRI",
"ZIS360NRJ",
"ZIS360NRK",
"ZIS360NXA",
"ZIS360NXB",
"ZIS360NXC",
"ZIS360NXD",
"ZIS420NHA",
"ZIS420NHB",
"ZIS420NMA",
"ZIS420NMB",
"ZIS420NMC",
"ZIS420NMD",
"ZIS420NRA",
"ZIS420NRB",
"ZIS420NRC",
"ZIS420NRD",
"ZIS420NRE"

```
]
},
{
  "part_name": "Electronic Control Board A01078804",
  "part_number": "PS10060580",
  "manufacturer": null,
  "price": "188.38",
  "description": "This electronic control board is for refrigerators.\r\n\r\nThe electronic control board manages the functions of the refrigerator such as cooling and defrost times.\r\n\r\nSafely store any food that could deteriorate while the power is off and unplug the refrigerator before installing this part. Wear work gloves to protect your hands.",
  "rating": "74",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# A01078804 replaces these: 242207704, 242282304, 5304498023 Back to Top",
  "review_count": "3",
  "appliance": "refrigerator",
  "compatible_models": [
    "CRSE233TB0",
    "CRSE233TS0",
    "CRSE233TW0",
    "CRSE263TB0",
    "CRSE263TD0",
    "CRSE263TS0",
    "CRSE263TW0",
    "CRSH232PB3",
    "CRSH232PB5",
    "CRSH232PB6",
```

```
"CRSH232PB7A",
"CRSH232PB8A",
"CRSH232PB9A",
"CRSH232PBBA",
"CRSH232PBEA",
"CRSH232PBFA",
"CRSH232PBHA",
"CRSH232PS3",
"CRSH232PS4",
"CRSH232PS5A",
"CRSH232PS6A",
"CRSH232PS7A",
"CRSH232PS9A",
"CRSH232PSCA",
"CRSH232PW3",
"CRSH232PW5",
"CRSH232PW6",
"CRSH232PW7A",
"CRSH232PW8A",
"CRSH232PW9A"
]
},
{
  "part_name": "Main Electronic Control Board WPW10312695",
  "part_number": "PS11752593",
  "manufacturer": "Kenmore",
```


"price": "255.00",

"description": "",

"rating": "95",

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start This part works with the following products: Refrigerator. Part# WPW10312695 replaces these: AP6019287, W10312695 Back to Top",

"review_count": "4",

"appliance": "refrigerator",

"compatible_models": [

"596379243017",

"59678332802",

"59678333802",

"59678339803",

"59678532802",

"59678533802",

"59678539803",

"59679242010",

"59679242011",

"59679242013",

"59679242015",

"59679242016",

"59679242017",

"59679243010",

"59679243011",

"59679243013",

"59679243016",

"59679243017",

"59679243018",

"59679249010",

"59679249011",

"59679249013",

"59679249015",

"59679249016",

"59679249017",

"5967954201",

"59679542010",

"59679542011",

"59679542014",

"59679542015"

]

},

{

"part_name": "ICE MAKER ASSY-LP W11658802",

"part_number": "PS17215831",

"manufacturer": "Kenmore",

"price": "161.01",

"description": "The ice maker includes the ice mold and the control device. The ice maker receives water from the water inlet valve and then holds the water in the ice mold until the water freezes solid.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making ice This part works with the following products: Refrigerator. Part# W11658802 replaces these: W10746960, W10917790, W11109572, W11188383, W11232541, W11294907, W11457039, W11483245, W11485529, W11554919, W11579560 Back to Top",

"review_count": "3",
"appliance": "refrigerator",
"compatible_models": [
"59672382413",
"59672383413",
"59672389413",
"7WF736SDAM14",
"IX7DDEXDSM02",
"JFX2897DRM02",
"JFX2897DRP02",
"KRFF507EBL01",
"KRFF507ESS01",
"KRFF507EWH01",
"KRFF507HBL00",
"KRFF507HBS00",
"KRFF507HBS02",
"KRFF507HBS03",
"KRFF507HBS04",
"KRFF507HPS00",
"KRFF507HPS01",
"KRFF507HPS02",
"KRFF507HPS03",
"KRFF507HPS04",
"KRFF507HWH00",
"KRFF507HWH02",
"KRFF507HWH03",

"KRFF577KBS02",
"KRFF577KPS02",
"KRFF707EBS00",
"KRFF707ESS01",
"KRMF606ESS01",
"KRMF706EBS01",
"KRMF706EBS04"

]

},

{

"part_name": "Water Fill Cup and Bearing WP628356",

"part_number": "PS11743318",

"manufacturer": "Kenmore",

"price": "40.29",

"description": "This refrigerator ice maker fill cup dispenses the water into the ice cube mold during the fill cycle. Replacing the water fill cup is a possible solution if you notice that the ice maker is leaking, or not making/dispensing ice. If you notice the fill cup has been damaged or cracked; replace the part straight away. This water fill cup is a genuine OEM part and will fit most refrigerators, but check the list of compatible brands to make sure yours is included before purchasing.",

"rating": "90",

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making ice | Leaking | Ice maker dispenses too much ice | Ice maker won't dispense ice This part works with the following products: Refrigerator, Ice Maker, Freezer. Part# WP628356 replaces these: AP6010142, 0056596, 0312737, 14211506, 2155035, 627791, 628356, 8170928, 95100-1, R0156227, R0156627, R0156839, Y0056596, Y0312737 Back to Top",

"review_count": "10",

"appliance": "refrigerator",

"compatible_models": [

"1061118553",
"1061118555",
"1062155184",
"10641522500",
"10641523500",
"10641524500",
"10641529500",
"1064211173",
"1064317943",
"10644022600",
"10644022601",
"10644022602",
"10644022603",
"10644023600",
"10644023601",
"10644023602",
"10644023603",
"10644024600",
"10644029600",
"10644029601",
"10644029602",
"10644029603",
"10644032600",
"10644032601",
"10644032602",
"10644032603",

```
"10644033600",
"10644033601",
"10644033602",
"10644033603"
]
},
{
  "part_name": "Ice Dispenser Solenoid and Door Kit 12001991",
  "part_number": "PS2003478",
  "manufacturer": null,
  "price": "158.58",
  "description": "In addition to the solenoid (115V), this kit also comes with a door strike and an ice door assembly. Please be advised the spring and roll pin are not included with this kit.",
  "rating": "87",
  "troubleshooting_tips": "This part fixes the following symptoms: Ice maker won't dispense ice | Not dispensing water | Door won't open or close | Leaking This part works with the following products: Refrigerator. Part# 12001991 replaces these: AP4009082, 940492, 12001991, 12001991, 61003121, 61003311, 61005560 Back to Top",
  "review_count": "13",
  "appliance": "refrigerator",
  "compatible_models": [
    "61004752",
    "61004753",
    "61004754",
    "ARS2760BW",
    "ASD2120DRQ",
```

"ASD2120DRW",
"ASD2123DRA",
"ASD2123DRQ",
"ASD2123DRW",
"ASD2514ARA",
"ASD2514ARQ",
"ASD2514ARW",
"CS21A5DA",
"CS21A5DW",
"CS21B5DA",
"CS21B5DQ",
"CS21B5DW",
"CS21F5DW",
"CS21G5DQ",
"CS21G5DW",
"CS23A6DA",
"CS23A6DW",
"CS23B6DA",
"CS23B6DQ",
"CS23B6DW",
"CS24G6DB",
"CS24G6DQ",
"CS24G6DW",
"CS25A7DA",
"CS25A7DQ"

]

},

{

"part_name": "Light Bulb - 7W W10857122",

"part_number": "PS11731356",

"manufacturer": null,

"price": "14.21",

"description": "Sold individually. This bulb is a 7-watt appliance incandescent light bulb. This appliance light bulb is two inches long. It is used for many clothes dryers. You will need a Phillips screwdriver and needle-nose pliers. Unplug the power from your dryer. You will find the light bulb by opening your dryer door and locating the casing surrounding the bulb on the top of the inside of the door. You will need to remove the single screw holding it in place to access the bulb. Twist the old bulb out of place. Use your pliers if the base of the bulb is still inside the socket once the glass part of the bulb has been removed. Check to make sure that the socket itself is not damaged. If the socket is damaged it will need to be replaced as well. Screw your new bulb into place.",

"rating": "80",

"troubleshooting_tips": "This part works with the following products: Refrigerator, Dryer, Washer Dryer Combo, Microwave. Part# W10857122 replaces these: AP5999271, 0056324, 14203519, 14218606, 3-7100, 307100, 60954, 63179-1, 63179-1A, 67001316, 67001316A, A0348401, A0365001, M0360001, M0360001Q, M036001, M3600-1, R0605087, W10856862, Y0056324 ... Show more , Y307100, Y60954 Show less Back to Top",

"review_count": "5",

"appliance": "refrigerator",

"compatible_models": [

"19902-0A",

"19903-0A",

"19922-0A",

"19922-7A",

"19923-0A",

"19923-7A",
"19972-0A",
"19972A",
"19972B",
"19972C",
"19973A",
"19973B",
"19973C",
"19992A",
"19993A",
"1999A",
"1999A-P1193906WL",
"1999CIW",
"1999CIWA",
"1999CIWEA",
"1999CIWEL-P1171101WL",
"1999CIWEW",
"1999CIWEW-P1171101WW",
"1999CIWL-P1121502WL",
"1999CIWW",
"1999CIWW-P1121502WW",
"1999IW",
"1999W",
"1999W-P1193906WW",
"20872A"

]

```
},
```

```
{
```

```
"part_name": "Run Capacitor WP65889-4",
```

```
"part_number": "PS11743364",
```

```
"manufacturer": "Kenmore",
```

```
"price": "66.66",
```

```
"description": "This part helps the compressor kick on and off while maintaining a constant temperature to keep things frozen in your freezer. If you are noticing temperature issues with your refrigerator or freezer, the run capacitor may need replacing. This repair is fairly easy to complete, and the only tools you will require are a 1/4 inch nut driver, and a 1/4 inch socket with a small ratchet. The run capacitor is located in the back of the fridge, so you will need to make sure you have room to work on this repair. Make sure to unplug the fridge prior to beginning the repair.",
```

```
"rating": "64",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start | Freezer section too warm | Fridge too warm | Fridge and Freezer are too warm This part works with the following products: Refrigerator. Part# WP65889-4 replaces these: AP6010187, 14202659, 14217273, 2252799, 2255130, 61002974, 61003525, 65889-4, 65889-5, 65889-8, 65922-1, 66121-1, 8170450, 8170462, C8931604, C8931608, C8931610, C8931612 Back to Top",
```

```
"review_count": "5",
```

```
"appliance": "refrigerator",
```

```
"compatible_models": [
```

```
"10640212010",
```

```
"10640212011",
```

```
"10640262010",
```

```
"10640263010",
```

```
"10640263011",
```

```
"10640269010",
```

```
"10641012104",  
"10641014104",  
"10641262800",  
"10641262801",  
"10641263800",  
"10641263801",  
"10641263802",  
"10641263804",  
"10641264800",  
"10641264801",  
"10641269800",  
"10641269801",  
"10644073600",  
"10644262600",  
"10644263600",  
"10644264600",  
"10644269600",  
"10648212500",  
"10649212700",  
"10649212701",  
"10650212010",  
"10650212011",  
"10650222010",  
"10650223010"  
]  
},
```

```
{
```

```
"part_name": "ARM-SHUT W11342242",
```

```
"part_number": "PS12712096",
```

```
"manufacturer": "Kenmore",
```

```
"price": "46.11",
```

```
"description": "This ice level arm, also known as an ice shutoff arm, is designed to detect the level of ice within the ice bin of your ice maker or refrigerator and turn it off when enough ice has been made. When the ice maker is empty, the arm will be down. When the ice maker is full, the arm will be raised, and over time, wear and tear to the level arm can cause the ice maker to stop making ice completely. To replace this arm, unplug your appliance and remove the ice making assembly, then pull the levelling arm out of the assembly and place the new one. Consisting of a long, angled metal arm and a plastic flap, this level arm is a genuine OEM part that is compatible with a wide-range of refrigerators and icemakers and measures at approximately 9-inches by 4.5-inches.",
```

```
"rating": "94",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making ice | Ice maker dispenses too much ice This part works with the following products: Refrigerator, Ice Maker. Part# W11342242 replaces these: 2160689, 2171593, 2209675, 2300169, 2304352, 2304354, 2313990, 4343695, 627913, 628187, 628310, 628323, 70142-1, W10889530, W11128135, W11188841, WP2304354 Back to Top",
```

```
"review_count": "6",
```

```
"appliance": "refrigerator",
```

```
"compatible_models": [
```

```
"1064211173",
```

```
"1064317943",
```

```
"10650022000",
```

```
"10650022001",
```

```
"10650022002",
```

```
"10650022003",
```

```
"10650022004",
```

```
"10650022210",  
"10650022211",  
"10650023210",  
"10650023211",  
"10650027000",  
"10650027001",  
"10650027002",  
"10650027003",  
"10650027004",  
"10650029210",  
"10650029211",  
"10650032000",  
"10650032001",  
"10650032002",  
"10650032003",  
"10650032004",  
"10650037000",  
"10650037001",  
"10650037002",  
"10650037003",  
"10650037004",  
"10650202990",  
"10650202991"  
]  
,  
{
```

"part_name": "Ice Maker Assembly Kit WR30X30972",

"part_number": "PS12727331",

"manufacturer": "Kenmore",

"price": "234.36",

"description": "",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Refrigerator, Ice Maker, Freezer. Part# WR30X30972 replaces these: AP6891612, WR29X5128, WR29X5178, WR30X28702, WR30X30719 Back to Top",

"review_count": "2",

"appliance": "refrigerator",

"compatible_models": [

"36348047891",

"36357552790",

"36357552791",

"36357557790",

"36357557791",

"36358042890",

"36358042891",

"36358042892",

"36358042893",

"36358042894",

"36358042896",

"36358042897",

"36358047890",

"36358047891",

"36358047892",

```
"36358047893",
"36358047894",
"36358047896",
"36358047897",
"36358062892",
"36358062893",
"36358062896",
"36358067892",
"36358067893",
"36358067897",
"36358072891",
"36358072892",
"36358075891",
"36358075892",
"36358075894"
]
},
{
  "part_name": "MULLION SPRING WR01X29937",
  "part_number": "PS12344714",
  "manufacturer": null,
  "price": "11.03",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Back
to Top",
```

```
"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

  "RBFS21TIAE",

  "RBFS21TIAP",

  "RBFS21TIAS"

]

},

{

  "part_name": "Upper Freezer Basket WR21X10208",

  "part_number": "PS2356327",

  "manufacturer": null,

  "price": "37.95",

  "description": "The freezer basket helps organize food in the freezer easier. The basket measures approximately 7 1/2” high by 16.75” deep. The freezer basket is white in color and made of metal. This is a genuine OEM part and is sold individually.",

  "rating": "95",

  "troubleshooting_tips": "This part works with the following products: Freezer. Part# WR21X10208 replaces these: AP4428485, RF-0300-20, RF-0300-29, WR21X10157, WR71X27815 Back to Top",

  "review_count": "16",

  "appliance": "refrigerator",

  "compatible_models": [

    "BFEQ50",

    "BFQ50",

    "ESCM050EC",

    "ESCM050EC01",
```


"FCM5CNAWWC",
"FCM5SUAWW",
"FCM5SUAWWC",
"FCM5SUBWW",
"FCM5SUCWW",
"FCM5SUDWW",
"FCM5SUEWW",
"FCM5SZABB",
"FCM7CNAWWC",
"FCM7DUAWW",
"FCM7DUBWW",
"FCM7DUCWW",
"FCM7DUDWW",
"FCM7DUFWW",
"FCM7DUGWW",
"FCM7DUHWW",
"FCM7SUAWW",
"FCM7SUAWWC",
"FCM7SUBWW",
"FCM7SUCWW",
"FCM7SUDWW",
"FCM7SUFWW",
"FCM7SUGWW",
"FCM7SUHWW",
"HCM050EB",
"HCM050EC"

```
]
},
{
  "part_name": "VEGETABLE PAN WR71X30982",
  "part_number": "PS12710434",
  "manufacturer": null,
  "price": "32.34",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
WR71X30982 replaces these: 0060221302D, WR71X27358, WR71X30050 Back to Top",
  "review_count": "1",
  "appliance": "refrigerator",
  "compatible_models": [
    "GTS18FGLCBB",
    "GTS18FGLCWW",
    "GTS18FGLDBB",
    "GTS18FGLDWW",
    "GTS18FGLEBB",
    "GTS18FGLEWW",
    "GTS18FGLFBB",
    "GTS18FGLFWW",
    "GTS18FMLCES",
    "GTS18FMLDES",
    "GTS18FMLEES",
    "GTS18FMLFES",
```

```
"GTS18FSLCSS",
"GTS18FSLDSS",
"GTS18FSLESS",
"GTS18FSLFSS",
"HRT18R1APB",
"HRT18R1APW",
"HRT18R1AWB",
"HRT18RCPB0",
"HRT18RCPB1",
"HRT18RCPW0",
"HRT18RCPW1",
"HRT18RCWB0",
"HRT18RCWB1",
"HRT18RCWW0",
"HRT18RCWW1",
"HT18TS32SW",
"HT18TS52SB",
"HT18TS52SW"
]
},
{
  "part_name": "REFRIGERATOR DOOR HANDLE WHITE WR12X31693",
  "part_number": "PS12723385",
  "manufacturer": null,
  "price": "181.95",
  "description": ""
```

```
"rating": "80",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
WR12X31693 replaces these: RF-3350-141, WR12X29327 Back to Top",

"review_count": "12",

"appliance": "refrigerator",

"compatible_models": [

    "HT18TS32SW",

    "HT18TS45SW",

    "HT18TS52SW",

    "HT18TS78SP",

    "HT21TS52SW",

    "HT21TS78SP",

    "HT21TS80SP",

    "HT21TS85SP"

]
},
{

    "part_name": "FRESH FOOD DOOR GASKET WHITE WR14X31072",

    "part_number": "PS12710385",

    "manufacturer": null,

    "price": "64.95",

    "description": "",

    "rating": "60",

    "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
WR14X31072 replaces these: RF-3100-269, WR14X27429, WR14X29325 Back to Top",

    "review_count": "2",

    "appliance": "refrigerator",
```

```
"compatible_models": [  
    "GTS21FGKBWW",  
    "GTS21FGKCWW",  
    "GTS21FGKDWW",  
    "GTS21FGKEWW",  
    "HRT21F2APP",  
    "HRT21R2APP",  
    "HT21TS52SW",  
    "HT21TS78SP",  
    "HT21TS80SP",  
    "HT21TS85SP",  
    "XTS21FGKBWW",  
    "XTS21FGKCWW"  
]  
,  
{  
    "part_name": "FULL WIRE SHELF WR71X28172",  
    "part_number": "PS12345213",  
    "manufacturer": "Kenmore",  
    "price": "17.62",
```

"description": "This white full wire shelf is an authentic OEM replacement part for refrigerators. It has dimensions of 10 inches by 15 inches and it is placed along the entire width of the refrigerator compartment. The shelf provides a stable and durable surface for storing food items and its placement can be adjusted according to your needs. Over time the shelf can break, bend, or become warped, due to age or excessive weight. It is important not to overload your shelf as this can lead to premature failure. Replacing the shelf is a simple repair that does not require specialized tools. To remove the old shelf,

simply lift it upward to disengage it from the support brackets and pull it out of the refrigerator. Position the new wire shelf on the brackets and ensure it is well aligned.",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WR71X28172 replaces these: RF-6350-233 Back to Top",

"review_count": "4",

"appliance": "refrigerator",

"compatible_models": [

"18392779",

"18393972",

"92779",

"93972",

"BCF27",

"BCF27B",

"BCFA27",

"BCFA27B",

"ECR27W",

"HC27SF10RB",

"HC27SF10RW",

"HRC2736BWB",

"HSA03WNCWW",

"HSA04WNCBB",

"HSA04WNCBPG",

"HSA04WNCWW",

"HSB03BB",

"HSB03BPG",

"HSB03VS"

```
]
},
{
  "part_name": "WATER VALVE WR57X32213",
  "part_number": "PS12744136",
  "manufacturer": null,
  "price": "32.33",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Back  
to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "GIE17GSNBRSS",
    "GIE17GSNDRSS",
    "GIE17GSNERSS",
    "GIE18DTNBRBB",
    "GIE18DTNBRWW",
    "GIE18DTNDRBB",
    "GIE18DTNDRWW",
    "GIE18DTNERBB",
    "GIE18DTNERWW",
    "GIE18GCNBRSA",
    "GIE18GCNDRSA",
    "GIE18GCNERSA",
```

```
"GIE18GSNDRSS",
"GIE18GSNERSS",
"GIE18GTNBRBB",
"GIE18GTNBRWW",
"GIE18GTNDRBB",
"GIE18GTNDRWW",
"GIE18GTNERBB",
"GIE18GTNERWW",
"GIE19JSNBRSS",
"GIE21GSHGSS",
"GIE21GTHGBB",
"GIE21GTHGWW",
"GIE22JMNBRSS",
"GIE22JSNBRSS",
"GIE22JTNBRBB",
"GIE22JTNBRWW",
"GPE17CTNBRWW",
"GPE17CTNDRWW"
]
},
{
  "part_name": "TRAY 00677090",
  "part_number": "PS8733831",
  "manufacturer": null,
  "price": "54.56",
  "description": ""
```


"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 00677090 replaces these: AP4513172, 677090 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"B26FT50SNS",

"B26FT70SNS",

"B26FT70SNS-01",

"B26FT80SNS",

"KFN91PJ10N"

]

},

{

"part_name": "BYPASS FILTER 10013297",

"part_number": "PS12747228",

"manufacturer": null,

"price": "35.17",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator. Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"B36CD50SNS",

"B36CL80ENS",

```
"B36CT80SNS"
]
},
{
  "part_name": "TRAY 12017983",
  "part_number": "PS12075548",
  "manufacturer": null,
  "price": "25.02",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Ice maker won't
dispense ice This part works with the following products: Refrigerator. Back to Top",
  "review_count": "1",
  "appliance": "refrigerator",
  "compatible_models": [
    "B21CL80SNS-02"
  ]
},
{
  "part_name": "DRAWER 11030666",
  "part_number": "PS12724319",
  "manufacturer": null,
  "price": "161.84",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Back
to Top",
```

```
"review_count": null,
"appliance": "refrigerator",
"compatible_models": [
  "B36CL80ENS",
  "B36CL80SNS",
  "B36CT80SNS"
]
},
{
  "part_name": "CLIP 00623317",
  "part_number": "PS8728848",
  "manufacturer": null,
  "price": "6.16",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator,
Freezer. Part# 00623317 replaces these: AP5323196, 00604666, 604666, 623317 Back to
Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "B24IR70NSP",
    "B30BB830SS",
    "B30IR70NSP",
    "B30IR800SP",
    "B36ET71SNS",
    "B36IB70NSP",
```

"B36IB70NSP12",
"B36IT70NNP",
"B36IT70NNP08",
"B36IT71NNP",
"B36IT71NNP11",
"CIB36P00",
"CIR24P00",
"CIR30P00",
"RB472301",
"RB472701",
"RB491200",
"RB491700",
"RB492301",
"RB492701",
"RC462200",
"RC462200AU",
"RC462301",
"RC462301AU",
"RC462700",
"RC462701",
"RC472200",
"RC472301",
"RC472700",
"RC472701"
]
},

```
{
  "part_name": "Door Closing Mechanism DA97-12625A",
  "part_number": "PS4176636",
  "manufacturer": null,
  "price": "29.79",
  "description": "This Samsung auto-close lever assembly is an OEM replacement part made for use in Samsung refrigerators. It is a black lever mechanism, measuring approximately 2 inches by 2 inches. When the fridge door is opened, this part ensures that the door that the door closes is able to close by itself and remains securely shut. If you notice that your fridge door can't seem to close properly, or it is unstable and slams shut, then the lever assembly will likely need to be replaced. This part is typically located at the top of the fridge door. Each auto-close lever is sold individually.",
  "rating": "87",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# DA97-12625A replaces these: AP5620329, DA97-13070A Back to Top",
  "review_count": "3",
  "appliance": "refrigerator",
  "compatible_models": [
    "00",
    "F261BEAESR",
    "RF220NCTABC",
    "RF220NCTASG",
    "RF220NCTASP",
    "RF220NCTASR",
    "RF220NCTASRAA",
    "RF220NCTAWW",
    "RF221NCTABC",
    "RF221NCTASP",
  ]
}
```

"RF221NCTASR",
"RF221NCTASRAA",
"RF221NCTAWW",
"RF22A4121SR",
"RF22K9381SG",
"RF22K9381SR",
"RF22K9581SG",
"RF22K9581SR",
"RF22K9588SG",
"RF22KREDBSG",
"RF22KREDBSR",
"RF22M9581SG",
"RF22M9581SR",
"RF22N9781SG",
"RF22N9781SR",
"RF22N9788SG",
"RF22NPEDBSG",
"RF22NPEDBSR",
"RF22R7351DT",
"RF22R7351SG"

]

},

{

"part_name": "Refrigerator Water Filter HAF-QIN/EXP",
"part_number": "PS17537652",
"manufacturer": null,

"price": "124.92",

"description": "This refrigerator water filter is supplied by Samsung to ensure it is an accurate fit for your fridge. It has a capacity of 300 gallons. The water filter helps to reduce water contamination by removing unwanted substances like chemicals and heavy metals which can make their way into your water supply. Each filter is tested and certified by NSF international as a guarantee of safety. If the filter light indicator on your fridge is red, this indicates that it is time to change your filter. Each filter also comes with a monthly reminder sticker inside the packaging to help you remember to change your filter.",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# HAF-QIN/EXP replaces these: DA29-00019A, DA97-17376B, HAF-QIN, HAF-QIN/EXP Back to Top",

"review_count": "1",

"appliance": "refrigerator",

"compatible_models": [

"BRF365200AP",

"RF22K9381SG",

"RF22K9581SG",

"RF22K9581SR",

"RF22KREDBSG",

"RF22KREDBSR",

"RF22R7351DT",

"RF22R7351SG",

"RF22R7351SR",

"RF22R7551SG",

"RF22R7551SR",

"RF23A967512",

"RF23A9675MT",

```
"RF23A9771SG",  
"RF23BB820012",  
"RF23BB8200AP",  
"RF23BB8900AC",  
"RF23BB8900AW",  
"RF23HCEDBSR",  
"RF23HCEDBWW",  
"RF23HCEDTSR",  
"RF23HTEDBSR",  
"RF23J9011SG",  
"RF23J9011SGAA",  
"RF23J9011SR",  
"RF23M8070DT",  
"RF23M8070SG",  
"RF23M8070SR",  
"RF23M8090SG",  
"RF23M8090SR"
```

```
]
```

```
},
```

```
{
```

```
"part_name": "Refrigerator Evaporator Fan Motor DA81-06013A",
```

```
"part_number": "PS9603956",
```

```
"manufacturer": null,
```

```
"price": "131.50",
```

```
"description": "This is an evaporator fan motor for a wide range of Samsung refrigerators.  
Evaporator fans pull warm air through evaporator coils to cool and maintain the internal  
temperature of the refrigerator. If the evaporator fan motor in your refrigerator is not working
```


properly, your fridge will not cool properly and may even prevent the ice maker and water dispenser from working, and it will ultimately need to be replaced. This OEM evaporator fan motor measures approximately 4 inches long by 4 inches wide and will need a screwdriver and needle nose pliers to be removed and installed.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Noisy
This part works with the following products: Refrigerator. Part# DA81-06013A replaces these: AP5914786, DA31-00287A Back to Top",

"review_count": "6",

"appliance": "refrigerator",

"compatible_models": [

"00",

"F261BEAESR",

"RF18A5101SG",

"RF18A5101SR",

"RF18A5101WW",

"RF18HFENBSG",

"RF18HFENBSR",

"RF18HFENBWW",

"RF20A5101SG",

"RF20A5101WW",

"RF20HFENBBC",

"RF20HFENBSG",

"RF20HFENBSR",

"RF20HFENBWW",

"RF22KREDBSG",

"RF22KREDBSR",

"RF22KREDBSRAA",

"RF22NPEDBSG",

"RF22NPEDBSR",

"RF22R7351DT",

"RF22R7351SG",

"RF22R7351SR",

"RF22R7551SG",

"RF22R7551SR",

"RF23A9071SR",

"RF23HCEDBBC",

"RF23HCEDBSG",

"RF23HCEDBSR",

"RF23HCEDBWW",

"RF23HCEDTSR"

]

},

{

"part_name": "French Door Hinge DA61-08305A",

"part_number": "PS4145262",

"manufacturer": null,

"price": "14.23",

"description": "This French door hinge is an authentic OEM part used in refrigerators. It is used to provide support and stability to the door allowing it to open and close smoothly. The hinge is vulnerable to wear and tear, and mechanical damage over time. A faulty door hinge will result in difficulty opening/closing the door, door misalignment, inadequate sealing, and increased energy consumption. To begin this repair, locate the screws that hold the hinge to the refrigerator frame and remove them. Carefully lift the door off the hinge and set it aside. Remove the faulty hinge and position the new one in its place."

Reattach the door to the new hinge and secure the hinge to the refrigerator frame using the appropriate fasteners.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Back to Top",

"review_count": "4",

"appliance": "refrigerator",

"compatible_models": [

"00",

"BRF365200AP",

"BRF425200AP",

"F261BEAESR",

"RF18A5101SG",

"RF18A5101SR",

"RF18A5101WW",

"RF18HFENBSG",

"RF18HFENBSR",

"RF18HFENBWW",

"RF20A5101SG",

"RF20A5101WW",

"RF20HFENBBC",

"RF20HFENBSG",

"RF20HFENBSR",

"RF20HFENBWW",

"RF220NCTABC",

"RF220NCTASG",

"RF220NCTASP",

"RF220NCTASR",
"RF220NCTASRAA",
"RF220NCTAWW",
"RF221NCTABC",
"RF221NCTASP",
"RF221NCTASR",
"RF221NCTASRAA",
"RF221NCTAWW",
"RF22A4121SR",
"RF22A4221SR",
"RF22K9381SG"

]

},

{

"part_name": "Ice Maker Assembly DA97-15217D",

"part_number": "PS12115595",

"manufacturer": null,

"price": "125.52",

"description": "The ice maker assembly contains the complete ice maker and housing. The assembly may include multiple parts; refer to your parts diagram for a complete list of parts included.",

"rating": "95",

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making ice This part works with the following products: Refrigerator. Part# DA97-15217D replaces these: AP6261445, DA97-12317A, DA97-12317B, DA97-12317D, DA97-15217A, DA97-15217B, DA97-15217E, DA97-15335A Back to Top",

"review_count": "4",

"appliance": "refrigerator",

"compatible_models": [

"RF25HMEDBBC",

"RF25HMEDBSG",

"RF25HMEDBSR",

"RF25HMEDBWW",

"RF25HMIDBSG",

"RF25HMIDBSR",

"RF263BEAEBBC",

"RF263BEAEBCAA",

"RF263BEAESG",

"RF263BEAESP",

"RF263BEAESPAA",

"RF263BEAESR",

"RF263BEAESRAA",

"RF263BEAEWW",

"RF263BEAEWWAA",

"RF263TEAEBBC",

"RF263TEAEBCAA",

"RF263TEAESG",

"RF263TEAESP",

"RF263TEAESR",

"RF263TEAESRAA",

"RF263TEAEWW",

"RF263TEAEWWAA",

"RF265BEAESG",

"RF265BEAESR",

"RF265BEAESRAA",

"RF26J7500BC",

"RF26J7500SR",

"RF26J7500WW",

"RF27T5201SG"

]

},

{

"part_name": "Temperature Sensor DA32-10104N",

"part_number": "PS4138666",

"manufacturer": null,

"price": "34.57",

"description": "This a genuine OEM temperature sensor, designed for use with refrigerators, and is an individual part. This temperature sensor is responsible for detecting and adjusting the temperature in your refrigerator. If your refrigerator is having issues with being either too cold, or too warm, it is likely that this sensor needs to be replaced. To replace it, ensure that your refrigerator is turned off before you locate it with your user manual and replace it.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm This part works with the following products: Refrigerator. Part# DA32-10104N replaces these: 114002, DA32-10104V Back to Top",

"review_count": "1",

"appliance": "refrigerator",

"compatible_models": [

"00",

"BRF425200AP",

"F261BEAESR",
"RF220NCTABC",
"RF220NCTASG",
"RF220NCTASP",
"RF220NCTASR",
"RF220NCTASRAA",
"RF220NCTAWW",
"RF221NCTABC",
"RF221NCTASP",
"RF221NCTASR",
"RF221NCTASRAA",
"RF221NCTAWW",
"RF22A4121SR",
"RF22A4221SR",
"RF22K9381SG",
"RF22K9381SR",
"RF22K9581SG",
"RF22K9581SR",
"RF22KREDBSG",
"RF22KREDBSR",
"RF22KREDBSRAA",
"RF22M9581SG",
"RF22M9581SR",
"RF22N9781SG",
"RF22N9781SR",
"RF22NPEDBSG",

```
"RF22NPEDBSR",  
"RF22R7351DT"  
]  
,  
{  
  "part_name": "Hinge - French Door DA61-03230B",  
  "part_number": "PS4143931",  
  "manufacturer": null,  
  "price": "8.25",
```

```
  "description": "This is a French door hinge that is compatible with various models of  
refrigerators and is used to control the mullion (long plastic strips) on the inside portion of  
the French doors. If you notice that your doors open and the mullion either moves freely or  
is stuck, this hinge needs to be replaced immediately to prevent issues with frost buildup,  
energy efficiency and temperature fluctuations. Replacing this hinge is quite simple, and  
you will only need a flathead and Philips-head screwdriver to do it. First, remove the screw  
covers from the securing screws for the mullion. Unscrew and remove the securing screws  
with your Philips-head screwdriver, and then pull the mullion up and out carefully to  
dislodge it from the fridge door. Near the middle of the mullion, disconnect the wire  
harness to remove the mullion completely. Remove the hinge cover with a flathead  
screwdriver to expose the hinge, and then carefully remove and replace the old hinge onto  
its attaching spring. Then you can simply reassemble the rest of the door assembly, along  
with the hinge cover and wire harness.",
```

```
  "rating": "92",
```

```
  "troubleshooting_tips": "This part fixes the following symptoms: Door won't open or  
close This part works with the following products: Refrigerator. Part# DA61-03230B  
replaces these: AP4141349 Back to Top",
```

```
  "review_count": "5",
```

```
  "appliance": "refrigerator",
```

```
  "compatible_models": [  
    "DFSF9VKBABB",
```


"DFSF9VKBAWW",
"DFSS9VKBASS",
"KF195ACEB",
"KF195ACEBXAC",
"KF195ACEW",
"KF195ACEWXAC",
"KF195ACRS",
"KF195ACRSXAC",
"KF215ACEB",
"KF215ACEBXAC",
"KF215ACEW",
"KF215ACEWXAC",
"KF215ACRS",
"KF215ACRSXAC",
"PFSF6PKXFWW",
"RF195ABBP",
"RF195ABBPXAC",
"RF195ABRS",
"RF195ABRSXAC",
"RF195ABWP",
"RF195ABWPXAC",
"RF195ACBP",
"RF195ACBPXAC",
"RF195ACRS",
"RF195ACRSXAC",
"RF195ACWP",

"RF195ACWPXAC",

"RF197ABBP",

"RF197ABBP/XAA"

]

},

{

"part_name": "Spring PIN - French DA81-01346A",

"part_number": "PS4163673",

"manufacturer": null,

"price": "4.66",

"description": "This pin acts as a sleeve for the French door spring in a refrigerator. This is a genuine OEM part that is sold individually and works with the spring within the door mullion to seal the door shut. If you need to replace the sleeve, check whether the spring in the door is still intact as well. You will only need to replace one spring sleeve pin per door, as there is only one sleeve on the upper part of the spring. To remove the spring and replace the mullion, do so with a set of needle-nose pliers and lift the lower side of the spring to easily pull it out, then you can replace the sleeve.?",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# DA81-01346A replaces these: AP4162150 Back to Top",

"review_count": "13",

"appliance": "refrigerator",

"compatible_models": [

"DFS9VKBABB",

"DFS9VKBAAWW",

"DFS9VKBASS",

"KF195ACEB",

"KF195ACEBXAC",
"KF195ACEW",
"KF195ACEWXAC",
"KF195ACRS",
"KF195ACRSXAC",
"KF215ACEB",
"KF215ACEBXAC",
"KF215ACEW",
"KF215ACEWXAC",
"KF215ACRS",
"KF215ACRSXAC",
"PFSF6PKXFWW",
"REFONLY4",
"REFSVC",
"RF195ABBP",
"RF195ABBPXAC",
"RF195ABRS",
"RF195ABRSXAC",
"RF195ABWP",
"RF195ABWPXAC",
"RF195ACBP",
"RF195ACBPXAC",
"RF195ACRS",
"RF195ACRSXAC",
"RF195ACWP",
"RF195ACWPXAC"

```
]
},
{
  "part_name": "Door Mullion Spring DA81-01345B",
  "part_number": "PS4163672",
  "manufacturer": null,
  "price": "9.44",
  "description": "The French door divider spring fits most Samsung French door style refrigerators. The spring applies tension between components in the refrigerator, which engages and retracts the door flap. This will allow the door to close properly. If the spring is broken, damaged, or faulty the door flap will swing open and block the door from closing, and you should look to replace the part straight away to prevent further damage to the door. The spring is a genuine OEM part, is made of metal, and measures at 1 1/2\" long. This part is also known as a refrigerator door mullion spring.",
  "rating": "94",
  "troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# DA81-01345B replaces these: AP4577072, DA61-07471A, DA81-01345A, WR02X12650 Back to Top",
  "review_count": "57",
  "appliance": "refrigerator",
  "compatible_models": [
    "DFSF9VKBABB",
    "DFSF9VKBAAWW",
    "DFSS9VKBASS",
    "GFSF6KEXABB",
    "GFSF6KEXACC",
    "GFSF6KEXAAWW",
    "GFSF6KEXBBB",
```

"GFSF6KEXBCC",
"GFSF6KEXBWW",
"GFSF6KEXCBB",
"GFSF6KEXCWW",
"GFSF6KEXDBB",
"GFSF6KEXDWW",
"GFSF6KEXEBB",
"GFSF6KEXEWW",
"GFSF6KKXABB",
"GFSF6KKXAWW",
"GFSF6KKXBBB",
"GFSF6KKXBWW",
"GFSF6KKYABB",
"GFSF6KKYAWW",
"GFSF6KKYBBB",
"GFSF6KKYBWW",
"GFSF6KKYCBB",
"GFSF6KKYCWW",
"GFSF6KKYDBB",
"GFSF6KKYDWW",
"GFSF6KKYEBB",
"GFSF6KKYEWW",
"GFSL6KEXALS"

]

},

{

"part_name": "Bimetal Defrost Thermostat WP4387503",

"part_number": "PS11742474",

"manufacturer": "Kenmore",

"price": "42.45",

"description": "This is a bimetal defrost thermostat for your refrigerator. It stops the fridge from overheating during the defrost cycle by protecting the evaporator. This clip-on thermostat will sense the temperature increase in the evaporator during the defrost process, and will cycle the defrost heater off after the ice or frost is melted. The most common reasons for needing to replace this part are if your unit is leaking, has inconsistent temperatures (too hot or too cold), you are seeing buildup of ice, or your appliance is running too long.",

"rating": "95",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Freezer not defrosting | Fridge too warm | Freezer section too warm This part works with the following products: Refrigerator, Freezer. Part# WP4387503 replaces these: AP6009317, 2149641, 2149643, 2163894, 2172694, 2182380, 2183072, 2221677, 4343917, 4387503, 61002113, R0950042, WP4387503VP Back to Top",

"review_count": "15",

"appliance": "refrigerator",

"compatible_models": [

"10642102300",

"10642102301",

"10642104300",

"10642106300",

"10642106301",

"10660162990",

"10660167990",

"10660172990",

"10660172991",

```
"10660177990",
"10660182000",
"10660182001",
"10660184001",
"10660187000",
"10660192000",
"10660192001",
"10660194001",
"10660197000",
"10660262990",
"10660262991",
"10660264991",
"10660267990",
"10660272990",
"10660272991",
"10660274991",
"10660277990",
"10660282990",
"10660282991",
"10660284991",
"10660287990"
]
},
{
  "part_name": "Door Light Switch WP2149705",
  "part_number": "PS11738900",
```

"manufacturer": "Kenmore",

"price": "30.31",

"description": "The purpose of the light switch in your refrigerator is to automatically turn on the light when the door is opened. If the light does not come on automatically when you open the door, the contacts inside the light switch may be burned out, meaning it is time to replace the switch. This package contains both the new light switch and a small plastic spacer. To complete this repair, you will need to remove the control panel section of your refrigerator. The only tools you will require for this repair are a 1/4-inch nut driver and maybe a small flat blade screwdriver. Be sure to disconnect the power source from the refrigerator before completing this repair.",

"rating": "83",

"troubleshooting_tips": "This part fixes the following symptoms: Light not working This part works with the following products: Refrigerator, Ice Maker. Part# WP2149705 replaces these: AP6005839, 0056777, 0311175, 1105461, 1116849, 1123922, 1123923, 14211289, 2149704, 2149705, 2219875, 2313410, 2321287, 99989716, R0950216, W10683583, W11439253, Y0056777, Y0311175 Back to Top",

"review_count": "14",

"appliance": "refrigerator",

"compatible_models": [

"10640212010",

"10640212011",

"10640262010",

"10640263010",

"10640263011",

"10640269010",

"10640562010",

"10640563010",

"10640563011",

"10640569010",


```
"10640569011",
"10641012100",
"10641012101",
"10641012104",
"10641014100",
"10641014101",
"10641014104",
"10641122210",
"10641122211",
"10641122212",
"10641122213",
"10641123210",
"10641123211",
"10641123212",
"10641124210",
"10641129210",
"10641129211",
"10641129212",
"10641129213",
"10641152210"
]
},
{
  "part_name": "Fresh Food Door Gasket WR24X10229",
  "part_number": "PS2364916",
  "manufacturer": "Kenmore",
```

"price": "99.90",

"description": "This white fresh food door gasket is used to seal the refrigerator door when closed to keep the cool air inside and the room air out.",

"rating": "80",

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm This part works with the following products: Refrigerator. Part# WR24X10229 replaces these: AP4435755, 1535747, WR24X0486, WR24X10051, WR24X486, WR78X11209 Back to Top",

"review_count": "4",

"appliance": "refrigerator",

"compatible_models": [

"36211XBMBRWW",

"36211XBMDRWW",

"36211XBMERWW",

"36211XBMFRWW",

"36211XBRERWW",

"36211XBRFRWW",

"36367667790",

"36368662890",

"36368662891",

"36368662893",

"36368662894",

"36368667890",

"36368667891",

"36368667893",

"36368667894",

"36368672891",

"36368672893",
"36368672894",
"36368672895",
"36368677891",
"36368677893",
"36368677894",
"36368677895",
"36369662990",
"36369662991",
"36369667990",
"36369667991",
"36378672891",
"36378672893",
"36378672894"

]

},

{

"part_name": "Fresh Food Door Gasket - White WR24X10231",

"part_number": "PS2359946",

"manufacturer": "Kenmore",

"price": "123.63",

"description": "This fresh food door gasket is used to seal the refrigerator door when closed to keep the cool air inside and the room air out.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Door Sweating | Door won't open or close This part works with the following products: Refrigerator. Part# WR24X10231 replaces these: AP4413149, 1535749, WR24X0485,

WR24X0518, WR24X10049, WR24X485, WR24X518, WR78X11201, WR78X11203 Back to Top",

"review_count": "2",

"appliance": "refrigerator",

"compatible_models": [

"36368432890",

"36368432891",

"36368432892",

"36368432893",

"36368432894",

"36368437890",

"36368437891",

"36368437892",

"36368437893",

"36368437894",

"36369462990",

"36369462991",

"36369467990",

"36369467991",

"3639604500",

"3639604501",

"3639604502",

"3639604510",

"3639604511",

"3639604512",

"3639604560",

"3639604561",

"3639604562",

"3639604580",

"3639604581",

"3639604582",

"3639604590",

"3639604591",

"3639604592",

"3639634211"

]

},

{

"part_name": "Door Shelf Retainer Bar End Cap - Left or Right Side WR2X8345",

"part_number": "PS298977",

"manufacturer": null,

"price": "30.99",

"description": "This end cap is sold individually. It can be used for the right or left side of either the freezer or refrigerator door shelves.",

"rating": "95",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WR2X8345 replaces these: AP2060073, 2343, WR2X8345, WR02X7617, WR02X8345, WR2X7617, WR71X2054 Back to Top",

"review_count": "14",

"appliance": "refrigerator",

"compatible_models": [

"31181-1",

"31861-1",

"31880",
"36211XBMBRWW",
"36211XBMDRWW",
"38011-1",
"38011-2",
"38021-1",
"38021-2",
"38041-1",
"38041-2",
"38080-1",
"38080-2",
"38081-1",
"38081-2",
"38085-1",
"38085-2",
"38087-1",
"38087-2",
"38088-1",
"38091-1",
"38191-1",
"38191-2",
"38211-1",
"38211-2",
"38230-1",
"38230-5",
"38231-1",

"38231-5",

"38241-1"

]

},

{

"part_name": "Crisper Drawer Cover WR32X10398",

"part_number": "PS890565",

"manufacturer": "Kenmore",

"price": "126.97",

"description": "The crisper drawer cover sits on top of your vegetable crispers and helps to maintain proper crisper temperatures. It also doubles as a sturdy lower shelf for extra storage in your refrigerator. If the drawer cover is damaged or cracked, it will not be able to do either of its jobs, and should be replaced. This replacement cover features shallow, wide grooves to prevent leaks and to catch spills. It also has rail brackets underneath to hold the drawer, allowing the drawer to slide in and out. It is made with some added structural rigidity that makes it stronger and more durable than the original. This model measures 24 1/2 inches long x 19 inches wide x 2 5/8 inches deep.",

"rating": "98",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# WR32X10398 replaces these: AP3426095, 1021733, WR32X10398, WR32X10353, WR32X1083, WR32X1086, WR32X1094, WR32X1107, WR32X1122 Back to Top",

"review_count": "82",

"appliance": "refrigerator",

"compatible_models": [

"3639604500",

"3639604501",

"3639604502",

"3639604510",

"3639604511",
"3639604512",
"3639604560",
"3639604561",
"3639604562",
"3639604580",
"3639604581",
"3639604582",
"3639604590",
"3639604591",
"3639604592",
"3639606411",
"3639606481",
"3639606500",
"3639606501",
"3639606502",
"3639606510",
"3639606511",
"3639606512",
"3639606580",
"3639606581",
"3639606582",
"3639606590",
"3639606591",
"3639606592",
"3639614200"


```
]
},
{
  "part_name": "Door Shelf Retainer 70197-1",
  "part_number": "PS2076360",
  "manufacturer": null,
  "price": "12.53",
  "description": "Sold Individually.",
  "rating": "97",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 70197-1 replaces these: AP4087619, 691795, 70197-1 Back to Top",
  "review_count": "6",
  "appliance": "refrigerator",
  "compatible_models": [
    "19124-0",
    "191340",
    "191347",
    "191450",
    "191457",
    "191550",
    "191557",
    "191650",
    "19175",
    "191750",
    "191751",
    "191757",
```

```
"2112247",  
"211240",  
"211340",  
"211347",  
"211440",  
"211447",  
"211540",  
"211640",  
"211740",  
"231740",  
"301040",  
"321240",  
"321340",  
"501340",  
"52154",  
"521540",  
"521547",  
"621260"  
]  
,  
{  
  "part_name": "Door Shelf Retainer Bar W11045462",  
  "part_number": "PS11775297",  
  "manufacturer": null,  
  "price": "54.72",
```

"description": "This refrigerator door shelf trim is approximately 28 inches long. It is all white in color, and it is made entirely of metal. NOTE: The image may not be of the exact product but will function properly.",

"rating": "50",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# W11045462 replaces these: AP6040105, 61001962, 61001963, 61001964, 61001965, 61002161, 61002162, 61002163, 61002398, 61002399, 61002400, 61002460, 61002461, 61002463, 61002550, 61002551, 61002608, 61002609, W11045326, W11084240 ... Show more , WP61001963, WP61002609 Show less Back to Top",

"review_count": "2",

"appliance": "refrigerator",

"compatible_models": [

"8ET15GKXJT",

"AT1521NDGW",

"ATB1511ARA",

"ATB1511ARW",

"ATB1710DRA",

"ATB1710DRQ",

"ATB1710DRW",

"ATB1712ARA",

"ATB1712ARW",

"ATB1713ARA",

"ATB1713ARW",

"ATB1910DRQ",

"ATB1910DRW",

"ATB1912ARA",

"ATB1912ARW",

"ATB1913ARA",

```
"ATB1913ARW",
"ATB1914ARA",
"ATB1914ARW",
"ATB2110DRQ",
"ATB2110DRW",
"ATB2112ARA",
"ATB2112ARW",
"ATB2113ARA",
"ATB2113ARQ",
"ATB2113ARW",
"ATF1910DRA",
"ATF1910DRQ",
"ATF1910DRW",
"ATF1913ARA"
]
},
{
  "part_name": "Shelf Retainer Bar End Cap WP61002112",
  "part_number": "PS11743131",
  "manufacturer": null,
  "price": "10.68",
```

"description": "The shelf retainer bar end cap is used to keep the retainer bar in place, and can be used on either the right or left hand side of the bar. This white, OEM end cap is approximately 2 inches long, and made entirely of plastic. The shelf bar and cap snap into place on the door to attach the door shelf bar to the inner door liner. This part is also known as a rail end cap. If the door bar is not properly attached to the inner door liner, your items will not be secure on the shelf, and are likely to fall.",

"rating": "93",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WP61002112 replaces these: AP6009957, 61001944, 61002112, WP61002112VP Back to Top",

"review_count": "8",

"appliance": "refrigerator",

"compatible_models": [

"8ET15GKXJT",

"AT1521NDGW",

"ATB1511ARA",

"ATB1511ARW",

"ATB1710DRA",

"ATB1710DRQ",

"ATB1710DRW",

"ATB1712ARA",

"ATB1712ARW",

"ATB1713ARA",

"ATB1713ARW",

"ATB1910DRQ",

"ATB1910DRW",

"ATB1912ARA",

"ATB1912ARW",

"ATB1913ARA",

"ATB1913ARW",

"ATB1914ARA",

"ATB1914ARW",

"ATB2110DRQ",

```
"ATB2110DRW",
"ATB2112ARA",
"ATB2112ARW",
"ATB2113ARA",
"ATB2113ARQ",
"ATB2113ARW",
"ATF1910DRA",
"ATF1910DRQ",
"ATF1910DRW",
"ATF1913ARA"
]
},
{
  "part_name": "40 WATT REFRIGERATOR BULB W11679940",
  "part_number": "PS17216393",
  "manufacturer": "Kenmore",
  "price": "8.89",
  "description": "Substituted with part number PS869887.",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator,
Freezer. Part# W11679940 replaces these: 2252970, 2255743, 2255743N, 2262009,
2311792, 2386, 2386-1, 31956-1, 4343345, 4343660, 4390465, 63001035, 67003568,
67003883, 68001557, 68001575, 68123-1, 8171221, 8208190, 88008545 ... Show more ,
946059, A0282801, A0282810V, A0282812, W10194422, W10194422V, W10311505,
W10311505N Show less Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
```

"compatible_models": [

"10632852010",

"10632852011",

"10632853010",

"10632853011",

"10632862010",

"10632862011",

"10632863010",

"10632863011",

"10632872010",

"10632873010",

"10632882010",

"10632883010",

"10632889010",

"10640262010",

"10640263010",

"10640263011",

"10640269010",

"10640562010",

"10640563010",

"10640563011",

"10640569010",

"10640569011",

"10641262800",

"10641262801",

"10641263800",

```
"10641263801",
"10641263802",
"10641263804",
"10641264800",
"10641264801"
]
},
{
  "part_name": "Bimetal Defrost Thermostat WP10442411",
  "part_number": "PS11738231",
  "manufacturer": "Kenmore",
  "price": "41.91",
  "description": "This refrigerator defrost thermostat will cut out at 55 degrees Fahrenheit and kick back in when the temperature drops to 20 degrees Fahrenheit. The thermostat itself is a little over an inch long while its extending wires are almost seven inches long.",
  "rating": "85",
  "troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Freezer not defrosting | Freezer section too warm | Frost buildup This part works with the following products: Refrigerator. Part# WP10442411 replaces these: AP6005218, 10442402, 10442407, 10442411, 4344231, 8170725, C8898601, C8978401, C8978402, WP10442411VP Back to Top",
  "review_count": "4",
  "appliance": "refrigerator",
  "compatible_models": [
    "18914A",
    "20804A",
    "20914A",
    "22504A",
```


"59661102100",
"59661102101",
"59661103100",
"59661103101",
"59661104100",
"59661104101",
"59661109100",
"59661109101",
"59661142100",
"59661142101",
"59661144100",
"59661144101",
"59661152100",
"59661152101",
"59661154100",
"59661154101",
"59661162100",
"59661162101",
"59661164100",
"59661164101",
"59661272100",
"59661272101",
"59661273100",
"59661273101",
"59661274100",
"59661274101"

```
]
},
{
  "part_name": "TRAY 11030672",
  "part_number": "PS12729559",
  "manufacturer": null,
  "price": "33.89",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Back  
to Top",
  "review_count": null,
  "appliance": "refrigerator",
  "compatible_models": [
    "B36CD50SNS",
    "B36CL80ENS",
    "B36CL80SNS",
    "B36CT80SNS"
  ]
},
{
  "part_name": "TRAY 00677095",
  "part_number": "PS8733834",
  "manufacturer": null,
  "price": "58.98",
  "description": "This is the replacement door bin or door tray for your refrigerator. It is  
made of white and clear plastic and is approximately 15 inches wide, 5 inches tall, and 8
```

inches deep. The door bin attaches to the refrigerator door and is used to store food. The main reason to replace the door bin is if the current bin is broken or missing. To complete this repair, simply snap the old bin out of the door, and replace it with the new bin. This part is sold individually and is an OEM part.",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 00677095 replaces these: AP4513174, 677095 Back to Top",

"review_count": "1",

"appliance": "refrigerator",

"compatible_models": [

"B26FT50SNS",

"B26FT70SNS",

"B26FT70SNS-01",

"B26FT80SNS",

"KFN91PJ10N"

]

},

{

"part_name": "WATER FILTER 11032531",

"part_number": "PS16221878",

"manufacturer": null,

"price": "70.07",

"description": "",

"rating": null,

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 11032531 replaces these: 11025825, 12028325, 12033030, 12036454, 17005582 Back to Top",

"review_count": null,

"appliance": "refrigerator",

"compatible_models": [

"B36CD50SNS",

"B36CL80ENS",

"B36CL80SNS",

"B36CT80SNS"

]

},

{

"part_name": "Refrigerator Shelf Frame (Glass not included) 241969501",

"part_number": "PS2363832",

"manufacturer": null,

"price": "76.24",

"description": "This refrigerator shelf frame is an OEM part that serves to support the glass above your meat pan or chill drawer in your refrigerator. White to off-white in color, this part does NOT include the glass pane that it supports, you will need to order this part separately. This part is sold individually and measures close to 18.5x18 inches in length and width. Most of our customers rated this repair as being very easy to carry out, taking less than 15 minutes and requiring no tools.",

"rating": "98",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 241969501 replaces these: 4433007, 1512992, 1512992, 241969501 Back to Top",

"review_count": "54",

"appliance": "refrigerator",

"compatible_models": [

"CRSE263TB0",

"CRSE263TD0",

"CRSE263TS0",

"CRSE263TW0",
"DGHS2665KF0",
"DGHS2665KF2",
"DGHX2655TF0",
"DGHX2655TF5",
"DGHX2655TF6",
"DGHX2655TF8",
"DGHX2655TF9",
"DGHX2655TFA",
"DGHX2655TFB",
"DGHX2655TFC",
"DGUS2635LE0",
"DGUS2635LE1",
"DGUS2635LE2",
"DGUS2635LP0",
"DGUS2635LP1",
"DGUS2635LP2",
"DGUS2645LF0",
"DGUS2645LF1",
"DGUS2645LF2",
"DGUS2645LF3",
"DGUS2645LF4",
"DGUS2645LF5",
"DGUS2645LF6A",
"FFSS2615TD0",
"FFSS2615TD1",

"FFSS2615TD2"

]

},

{

"part_name": "Refrigerator Water Filter XWFE",

"part_number": "PS16217433",

"manufacturer": null,

"price": "79.91",

"description": "This water filter is found in the rear upper-right corner of the interior of the refrigerator. If your model has a replacement indicator light it will turn red to signal the need for a replacement. If your model does not have an indicator light, the filter cartridge should be replaced every six months or earlier if you notice a decrease in the flow of water from the dispenser.\n\nThe filter media is carbon black and reduces leads, some pharmaceuticals, and fifty other contaminants. It is 2 inches deep, 6 inches high, 2.25 inches wide and weighs approximately 1 lbs. When it comes time to replace the filter, first discard the old one by turning it to the left to remove. It will release itself when it has been turned far enough. \n\nInstallation instructions are quick and simple but can vary slightly depending on if it is a bottom-freezer, side-by-side or multi-door bottom-freezer model. Refer to the user instructions for your filter. Do not forget to reset the filter change indicator if applicable. In bottom-freezer and side-by-side models this is done by pressing and holding the RESET WATER FILTER button for three seconds. On a multi-door bottom-freezer model, press the button underneath the Confirm Filter Change message while the water is dispensing. On select models this reset is done automatically once a new filter is installed.",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Refrigerator, Freezer. Part# XWFE replaces these: XWF Back to Top",

"review_count": "16",

"appliance": "refrigerator",

"compatible_models": [

"CFE26KP2NBS1",

"CFE26KP2NKS1",
"CFE26KP2NLS1",
"CFE26KP2NNS1",
"CFE26KP2NTS1",
"CFE26KP2NWS1",
"CFE26KP2TNS1",
"CQE28DM5NBS5",
"CVE28DM5NBS5",
"CVE28DM5NS5",
"CVE28DP2NBS1",
"CVE28DP2NS1",
"CVE28DP3NBD1",
"CVE28DP3ND1",
"CVE28DP4NBW2",
"CVE28DP4NCW2",
"CVE28DP4NW2",
"CWE19SP2NBS1",
"CWE19SP2NLS1",
"CWE19SP2NNS1",
"CWE19SP2NTS1",
"CWE19SP2NWS1",
"CWE19SP2TNS1",
"CWE19SP3NBD1",
"CWE19SP3NKD1",
"CWE19SP3NND1",
"CWE19SP3NTD1",

"CWE19SP3NWD1",

"CWE19SP3TND1",

"CWE19SP4NBW2"

]

},

{

"part_name": "Air Filter PAULTRA2",

"part_number": "PS12586284",

"manufacturer": null,

"price": "20.30",

"description": "This package contains one carbon activated filter for refrigerators with Pure Air Ultra II filtration systems. The air filter cleans the air and absorbs strong odors from fragrant foods, such as onions, garlic, seafood, and over-ripe fruits and vegetables. By absorbing these unpleasant smells, it will also improve the flavor of your ice cubes. \nThis is a simple repair that does not require tools for installation or removal. Start by removing the plastic wrap on the new filter, remove the cover from the housing inside the refrigerator, remove the old filter, place the new filter into the housing, and close the cover. Depending on the model of your appliance, you may need to reset the filter reminder. This part is OEM official, guaranteeing a smooth install and proper fit.",

"rating": "97",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# PAULTRA2 replaces these: 242047805 Back to Top",

"review_count": "12",

"appliance": "refrigerator",

"compatible_models": [

"20462151B",

"90462157B",

"DGHD2361TF0",

"DGHD2361TF1",

"DGHD2361TF2",
"DGHD2361TF3",
"EI33AR80WS0",
"FG4H2272UF",
"FGHB2868TD0",
"FGHB2868TD1",
"FGHB2868TD2",
"FGHB2868TD3",
"FGHB2868TD4",
"FGHB2868TD5",
"FGHB2868TD6",
"FGHB2868TD8",
"FGHB2868TE0",
"FGHB2868TE1",
"FGHB2868TE2",
"FGHB2868TE3",
"FGHB2868TE4",
"FGHB2868TE5",
"FGHB2868TF0",
"FGHB2868TF1",
"FGHB2868TF2",
"FGHB2868TF3",
"FGHB2868TF4",
"FGHB2868TF5",
"FGHB2868TF6",
"FGHB2868TF7"

```
]
},
{
  "part_name": "Ice Container and Auger Assembly 241860803",
  "part_number": "PS1991430",
  "manufacturer": "Kenmore",
  "price": "176.73",
  "description": "This assembly includes the auger and blades.",
  "rating": "97",
  "troubleshooting_tips": "This part fixes the following symptoms: Ice maker won't  
dispense ice | Ice maker not making ice | Ice maker dispenses too little ice This part works  
with the following products: Refrigerator. Part# 241860803 replaces these: AP4300918,  
1376941, 241860803, 218842802, 240323804, 240323808, 240323813 Back to Top",
  "review_count": "43",
  "appliance": "refrigerator",
  "compatible_models": [
    "25350682000",
    "25350682001",
    "25350682002",
    "25350683000",
    "25350683001",
    "25350683002",
    "25350684000",
    "25350684001",
    "25350684002",
    "25350689000",
    "25350689001",
```

```
"25350689002",  
"25351232101",  
"25351232102",  
"25351232103",  
"25351232104",  
"25351232105",  
"25351232106",  
"25351234101",  
"25351234102",  
"25351234103",  
"25351234104",  
"25351234105",  
"25351234106",  
"25351392101",  
"25351392102",  
"25351392103",  
"25351392104",  
"25351392105",  
"25351392106"  
]  
,  
{  
  "part_name": "REFRIGERATOR Ice Maker Replacement WPW10300022",  
  "part_number": "PS11752389",  
  "manufacturer": "Kenmore",  
  "price": "165.82",
```

"description": "The replacement ice maker does not include a new ice level arm, or wire harness, these components will need to be reused from original ice maker.",

"rating": "95",

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making ice This part works with the following products: Refrigerator. Part# WPW10300022 replaces these: AP6019085, W10122556, W10300022, W10377190 Back to Top",

"review_count": "26",

"appliance": "refrigerator",

"compatible_models": [

"1064650043714",

"10650022210",

"10650022211",

"10650023210",

"10650023211",

"10650029210",

"10650029211",

"10650029213",

"10650042710",

"10650042711",

"10650042713",

"10650042714",

"10650043710",

"10650043711",

"10650043713",

"10650043714",

"10650045710",

"10650045711",

```
"10650045713",
"10650045715",
"10650049710",
"10650049711",
"10650049713",
"10650049714",
"10651112710",
"10651112711",
"10651113210",
"10651113710",
"10651113711",
"10651115710"
]
},
{
  "part_name": "Ice Maker Assembly - 8 Cube 2198597",
  "part_number": "PS869316",
  "manufacturer": "Kenmore",
  "price": "144.95",
  "description": "This Ice Maker (Icemaker Assembly, Complete Icemaker Assembly, Ice  
Maker Assembly, Refrigerator Ice Maker) can be used with 25-27 cubic feet refrigerators  
that have a vertical auger dispenser located on the freezer door. It's used to make ice.  
When this part fails, no ice cubes will be made. It could prevent the icemaker from filling  
with water or just prevent the harvesting of the ice cubes. This is a sign the part should be  
replaced. The parts electrical contacts and motor can fail due to normal wear and tear. The  
icemaker attaches to the ceiling of the freezer compartment. This assembly measures 11  
inches by 5 inches, is constructed of plastic and metal, and comes in black/white.",
  "rating": "95",
```

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making ice | Ice maker won't dispense ice | Leaking | Won't start This part works with the following products: Refrigerator. Part# 2198597 replaces these: AP3182733, 1016069, 2198597, 2198597, 2198597R, 2198597VP, 2198678, 626663, W10122502, W10190960, W11381367 Back to Top",

"review_count": "99",

"appliance": "refrigerator",

"compatible_models": [

"10641522500",

"10641523500",

"10641524500",

"10641529500",

"10644022600",

"10644022601",

"10644022602",

"10644022603",

"10644023600",

"10644023601",

"10644023602",

"10644023603",

"10644024600",

"10644029600",

"10644029601",

"10644029602",

"10644029603",

"10644032600",

"10644032601",

```
"10644032602",
"10644032603",
"10644033600",
"10644033601",
"10644033602",
"10644033603",
"10644034600",
"10644039600",
"10644039601",
"10644039602",
"10644039603"
]
},
{
  "part_name": "Ice Maker WR30X10093",
  "part_number": "PS1993870",
  "manufacturer": "Kenmore",
  "price": "216.03",
```

"description": "This 10 by 5 inch ice maker (Electromechanical Icemaker Kit, Ice Maker Assembly) produces ice. This particular model will produce seven crescent shaped cubes every cycle. It is constructed of plastic and metal, and comes in black/white. This kit includes a set of installation instructions, a 4-pin round plug-in connector, 6 post plug-in connectors, tube and fill cup. The ideal temperature of a freezer is zero degrees Fahrenheit. If the temperature in your freezer is at an appropriate level yet ice is still not being made, it could be an issue with the water inlet valve or your ice maker assembly. If you determine it is the ice maker, this is the replacement you need. The ice maker can break from normal wear and accidental damage. Ice makers will need to be replaced every 3-10 years depending on the frequency of usage and water quality. This model is mounted on the freezer wall.",

"rating": "93",

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making ice | Ice maker won't dispense ice | Leaking | Ice maker dispenses too little ice This part works with the following products: Refrigerator, Ice Maker, Freezer, Wine and Beverage Cooler. Part# WR30X10093 replaces these: AP4345120, 1399596, WR30X10093, 200D1181G026, 66042, JS-2, JS2, MSE1, SWR29X5110, SWR29X5114, SWR29X5115, SWR29X5119, SWR29X5121, SWR29X5126, SWR29X5128, WR29X0157, WR29X0158, WR29X0160, WR29X0185, WR29X0191 ... Show more , WR29X10080, WR29X157, WR29X158, WR29X160, WR29X191, WR29X20949, WR29X27993, WR29X5007, WR29X5012, WR29X5023, WR29X5110, WR29X5114, WR29X5115, WR29X5119, WR29X5121, WR29X5126, WR29X5127, WR29X5144, WR29X5162, WR29X5167, WR29X5174, WR29X5177, WR29X5183, WR29X5189, WR29X5190, WR30M0149, WR30M0153, WR30M149, WR30M153, WR30X0138, WR30X0147, WR30X0148, WR30X0159, WR30X0169, WR30X0199, WR30X0203, WR30X0213, WR30X0214, WR30X0238, WR30X0241, WR30X0259, WR30X0282, WR30X0283, WR30X0289, WR30X0290, WR30X0304, WR30X0306, WR30X0307, WR30X0310, WR30X0315, WR30X0318, WR30X0320, WR30X0327, WR30X0328, WR30X0329, WR30X10012, WR30X10014, WR30X10043, WR30X10044, WR30X10058, WR30X10061, WR30X10082, WR30X10102, WR30X10109, WR30X10111, WR30X10139, WR30X138, WR30X147, WR30X148, WR30X159, WR30X169, WR30X199, WR30X203, WR30X213, WR30X214, WR30X238, WR30X241, WR30X259, WR30X27952, WR30X282, WR30X282R, WR30X283, WR30X28699, WR30X28700, WR30X28705, WR30X28735, WR30X289, WR30X290, WR30X29421, WR30X304, WR30X304R, WR30X306, WR30X307, WR30X310, WR30X315, WR30X318, WR30X320, WR30X327, WR30X328, WR30X329 Show less Back to Top",

"review_count": "77",

"appliance": "refrigerator",

"compatible_models": [

"31181-1",

"31191-1",

"3210-00LOS00-A",

"3210-00ROS00-A",

"36348042890",

"36348042891",
"36348047890",
"36348047891",
"36350221000",
"36350222000",
"36350227000",
"36350232000",
"36350237000",
"36350242000",
"36350247000",
"36350622000",
"36350627000",
"36357552790",
"36357552791",
"36357557790",
"36357557791",
"36358042890",
"36358042891",
"36358042892",
"36358042893",
"36358042894",
"36358042896",
"36358042897",
"36358047890",
"36358047891"

]

```
},
{
  "part_name": "Screw 240521303",
  "part_number": "PS1526032",
  "manufacturer": "Kenmore",
  "price": "25.92",
  "description": "This small, Phillips-head screw works with your refrigerator/freezer. It screws in to the freezer door and connects to the door handle. This part is made of stainless steel and is sold individually. This is an OEM part sourced directly from the manufacturer.",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Refrigerator, Freezer. Part# 240521303 replaces these: AP3959998, 1196408, 240521301 Back to Top",
  "review_count": "3",
  "appliance": "refrigerator",
  "compatible_models": [
    "25323024101",
    "25323024102",
    "25323024103",
    "25323024104",
    "25323114101",
    "25323114102",
    "25323414101",
    "25323424101",
    "25323424102",
    "25323424104",
    "25323429100",
```

```
"25323714101",  
"25323724101",  
"25323725101",  
"25324042100",  
"25324042101",  
"25324042102",  
"25324042103",  
"25324042104",  
"25324082100",  
"25324082101",  
"25324082102",  
"25324082103",  
"25324082104",  
"25324092101",  
"25324092102",  
"25324092103",  
"25324092104",  
"25324092105",  
"25324422100"  
]  
,  
{  
  "part_name": "Screw - Kit of Four 5304515677",  
  "part_number": "PS12365992",  
  "manufacturer": "Kenmore",  
  "price": "16.03",
```

"description": "This screw is used in refrigerators. The screw can be loosened or tightened with a Phillips-head or square-head screwdriver. This screw is used to secure the refrigerator handle to the refrigerator door. This is an OEM part sourced directly from the manufacturer.",

"rating": "74",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 5304515677 replaces these: AP6333077, 240383401, 240383406, 7240383406 Back to Top",

"review_count": "3",

"appliance": "refrigerator",

"compatible_models": [

"25331113308",

"2533111330A",

"2533111330B",

"2533111330C",

"25331115302",

"25331115308",

"2533111530B",

"2533111530C",

"25331125302",

"25331133302",

"25331133303",

"25331133306",

"25331135302",

"25331135303",

"25331135306",

"25331143302",

```
"25331145302",  
"25331145303",  
"25331430100",  
"25331430101",  
"25331430106",  
"25331432100",  
"25331432101",  
"25331432106",  
"25331434100",  
"25331434101",  
"25331434106",  
"25331434107",  
"25331437100",  
"25331437101"  
]  
,  
{  
  "part_name": "Lid Bumper WR02X10540",  
  "part_number": "PS284979",  
  "manufacturer": "Kenmore",  
  "price": "10.96",
```

```
  "description": "The lid bumper or evaporator fan motor bumper in your refrigerator  
prevents the fan motor from scraping against the side bracket. If your refrigerator/freezer is  
noisy, the bumper could be worn down or missing, and the sound could be a result of the  
motor scraping the side bracket. You will find it between the fan motor and the side bracket  
on the evaporator fan motor assembly. To access the bumper, you will need to remove the  
evaporator fan motor assembly from the freezer. This part is made of orange rubber and is
```

less than half an inch in diameter. It has a rounded top and a slightly pointed bottom, and is sold individually.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Fridge too warm
This part works with the following products: Refrigerator, Freezer, Range, Dryer. Part#
WR02X10540 replaces these: AP3414570, 912732, 123C8091P002, WR02X11329,
WR2X10540 Back to Top",

"review_count": "2",

"appliance": "refrigerator",

"compatible_models": [

"36211XBMBRWW",

"36211XBMDRWW",

"36211XBMERWW",

"36211XBMFRWW",

"36211XBRERWW",

"36211XBRFRWW",

"36411XBRERWW",

"36411XBRFRWW",

"37511KBSARWW",

"37511KBSERWW",

"38181KBRARWW",

"38185KBRARBB",

"38187KBRARCC",

"38341FBMERWW",

"38341FBMFRWW",

"38351HBMERWW",

"38351HBMFRWW",

"38351HBRERWW",

"38351HBRFRWW",

"38451HBRERWW",

"38451HBRFRWW",

"38481KBRARWW",

"38481KBRCRWW",

"38481KBRDRWW",

"38481KBRKRWW",

"38481KBRORWW",

"38481KBRTRWW",

"38481KBRVRWW",

"38485KBRARBB",

"38485KBRCRBB"

]

},

{

"part_name": "Handle Screw MJB63190001",

"part_number": "PS8752913",

"manufacturer": "LG",

"price": "9.34",

"description": "This handle screw, also known as a mounting bolt, is a mounting screw to help secure the door handle to your refrigerator door. If your handle is loose, you may just need to tighten the screw. If your screw is missing or broken, it may need to be replaced. There are multiple handle screws on your fridge, please consider ordering extra as they commonly wear at the same rate. This is about 1 inch long and metallic in color.",

"rating": "74",

"troubleshooting_tips": "This part works with the following products: Refrigerator, Freezer. Part# MJB63190001 replaces these: AP5787341, 4620JJ2010C, 4620JJ2010J, 4620JJ3007A, 4620JJ3007B, 4620JJ3007D, MJB63189701, MJB63190006 Back to Top",

"review_count": "6",

"appliance": "refrigerator",

"compatible_models": [

"1867",

"48231784207",

"48231784214",

"48231784221",

"48231784412",

"495934",

"51012",

"51013",

"51014",

"51016",

"51019",

"51022",

"51023",

"51026",

"51032",

"51034",

"51036",

"51072",

"51073",

"51074",

"51076",

"51079",

"51086",

"51089",

"51093",

"51099",

"51312",

"51313",

"51314"

]

},

{

"part_name": "Screw WPW10661886",

"part_number": "PS11757021",

"manufacturer": "Kenmore",

"price": "12.71",

"description": "This mounting screw is a genuine OEM replacement part for the door handle in your refrigerator. If you are having trouble shutting the refrigerator door, or opening it, replacing this screw can help solve the issue. Replacing this part is easy and requires minimal disassembly of the refrigerator end cap handle. You will need a screwdriver to complete this repair.",

"rating": "80",

"troubleshooting_tips": "This part works with the following products: Refrigerator, Dryer, Freezer. Part# WPW10661886 replaces these: AP6023675, W10303465, W10460893, W10661886, WPW10661886VP Back to Top",

"review_count": "3",

"appliance": "refrigerator",

"compatible_models": [

"10641122210",

"10641122211",
"10641122212",
"10641122213",
"10641123210",
"10641123211",
"10641123212",
"10641124210",
"10641129210",
"10641129211",
"10641129212",
"10641129213",
"10641132710",
"10641132712",
"10641133710",
"10641133712",
"10641133715",
"10641139710",
"10641139712",
"10641152210",
"10641152211",
"10641153210",
"10641153211",
"10641154210",
"10641159210",
"10641159211",
"10641159212",

"10641162310",

"10641163310",

"10641169310"

]

},

{

"part_name": "Evaporator/Condensor Fan Grommet WR02X10098",

"part_number": "PS284555",

"manufacturer": "Kenmore",

"price": "11.58",

"description": "This evaporator fan motor grommet, or condenser fan grommet is built for refrigerators. It provides a cushion between the fan motor and the motor mounting bracket. It is made of round, black plastic and is approximately one inch in diameter. If your grommet is torn or damaged and you are getting noise from the fan motor, you may need to replace it. This is an OEM part sourced directly from the manufacturer.",

"rating": "99",

"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Fridge too warm | Freezer section too warm | Clicking sound This part works with the following products: Refrigerator. Part# WR02X10098 replaces these: AP3647189, 772715, WR02X10822, WR2X10098, WR2X10822 Back to Top",

"review_count": "12",

"appliance": "refrigerator",

"compatible_models": [

"31181-1",

"31191-1",

"3210-00LOS00-A",

"3210-00ROS00-A",

"36211XBMBRWW",

"36211XBMDRWW",
"36211XBMERWW",
"36211XBMFRWW",
"36211XBRERWW",
"36211XBRFRWW",
"36348042891",
"36348042892",
"36348042893",
"36348042894",
"36348042896",
"36348042897",
"36348047891",
"36348047892",
"36348047893",
"36348047894",
"36348047896",
"36348047897",
"36348252891",
"36348252892",
"36348252893",
"36348252894",
"36348252896",
"36348252897",
"36348257891",
"36348257892"

]

```
},
```

```
{
```

```
  "part_name": "Retaining Ring WP9703438",
```

```
  "part_number": "PS11746909",
```

```
  "manufacturer": null,
```

```
  "price": "7.87",
```

```
  "description": "This part is a retaining ring, sometimes called a retaining clip, that holds the drum support roller onto the shaft of a dryer. It is made entirely of metal and measures less than an inch in diameter. The retaining ring is a genuine OEM part sourced directly from the manufacturer. The ring may vary in appearance due to manufacturer substitution, but the function is the same. You may need to replace this part if the dryer is noisy during tumbling, will not tumble, or takes too long to dry. Be sure to check drum support roller kit and shaft before ordering parts.",
```

```
  "rating": "74",
```

```
  "troubleshooting_tips": "This part fixes the following symptoms: Noisy This part works with the following products: Mixer, Dryer, Refrigerator, Washer Dryer Combo. Part# WP9703438 replaces these: AP6013682, 4-10233, 410233, 4176072, 65100-1, 9703438, WP9703438VP Back to Top",
```

```
  "review_count": "3",
```

```
  "appliance": "refrigerator",
```

```
  "compatible_models": [
```

```
    "3K45SS",
```

```
    "3K5SS",
```

```
    "3KSM150PSTAQ0",
```

```
    "3KSM150PSTBM0",
```

```
    "3KSM150PSTBW0",
```

```
    "3KSM150PSTCB0",
```

```
    "3KSM150PSTCLO",
```

```
    "3KSM150PSTCU0",
```

"3KSM150PSTDRO",

"3KSM150PSTDRO5",

"3KSM150PSTERO",

"3KSM150PSTERO5",

"3KSM150PSTGAO",

"3KSM150PSTICO",

"3KSM150PSTICO5",

"3KSM150PSTLRO",

"3KSM150PSTMHO",

"3KSM150PSTMYO",

"3KSM150PSTOBO",

"3KSM150PSTPAO",

"3KSM150PSTPA5",

"3KSM150PSTPKO",

"3KSM150PSTTGO",

"3KSM150PSTVBO",

"3KSM150PSTWHO",

"3KSM150PSTWMO",

"3KSM5CBTERO",

"3KSM5CBTWHO",

"3KSM6583TERO",

"3KSM6583TGUO"

]

},

{

"part_name": "Hinge Bearing 240328201",

"part_number": "PS429803",

"manufacturer": "Kenmore",

"price": "14.52",

"description": "Sold individually. Also known as a short door closing cam.",

"rating": "98",

"troubleshooting_tips": "This part fixes the following symptoms: Clicking sound | Door won't open or close | Noisy | Door Sweating This part works with the following products: Refrigerator. Part# 240328201 replaces these: AP2115808, 891001, 240328201, 240561601 Back to Top",

"review_count": "28",

"appliance": "refrigerator",

"compatible_models": [

"25344302400",

"25344302401",

"25344304400",

"25344304401",

"25344333600",

"25344333601",

"25344333602",

"25344333603",

"25344333604",

"25344333605",

"25344333606",

"25344333607",

"25344333608",

"25344333609",

"2534433360A",

```
"25344352400",  
"25344352401",  
"25344352403",  
"25344352404",  
"25344352405",  
"25344352406",  
"25344352407",  
"25344352408",  
"25344352409",  
"25344353401",  
"25344353403",  
"25344354400",  
"25344354401",  
"25344354403",  
"25344354404"  
]  
,  
{  
  "part_name": "Hinge Bracket WP2183805",  
  "part_number": "PS11739061",  
  "manufacturer": "Kenmore",  
  "price": "10.72",
```

"description": "This hinge bracket, also known as a door stop, is attached to the bottom of the door and is used to limit how far the door swings out to protect the refrigerator itself, and any surrounding cabinets from potential damage. If your fridge is having issues opening or staying closed, check the hinges for any damage or cracking. To replace this bracket, simply remove the door off your refrigerator, unscrew and remove this bracket from the

bottom of the door, and install the new one. This hinge bracket is an OEM replacement and is compatible with several different makes and models of refrigerator.",

"rating": "36",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator, Freezer. Part# WP2183805 replaces these: AP6005999, 1107202, 1115910, 2159254, 2159364, 2159367, 2159368, 2160810, 2183805, 2189202, 944035, 944036 Back to Top",

"review_count": "5",

"appliance": "refrigerator",

"compatible_models": [

"10632242101",

"10632243101",

"10632249101",

"10632842010",

"10632852010",

"10632852011",

"10632853010",

"10632853011",

"10632862010",

"10632862011",

"10632863010",

"10632863011",

"10632872010",

"10632873010",

"10632882010",

"10632883010",

"10632889010",

```
"10632942101",
"10632943101",
"10632949101",
"10639420990",
"10639422990",
"10639424990",
"10639427990",
"10639430990",
"10639432990",
"10639434990",
"10639437990",
"10642102300",
"10642102301"
]
},
{
  "part_name": "Hinge Bearing 5304507147",
  "part_number": "PS11770609",
  "manufacturer": "Kenmore",
  "price": "7.28",
  "description": "This door hinge bushing, or hinge bearing, is a genuine OEM replacement part for your refrigerator. The hinge bearing helps the refrigerator door stay on track when opening and closing, ensuring it is flush with the cabinet when closed. You will need a screwdriver and a ratchet in order to complete this repair.",
  "rating": "80",
```

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# 5304507147 replaces these: AP6038497, 240311202, 240527102 Back to Top",

"review_count": "1",

"appliance": "refrigerator",

"compatible_models": [

"25331113300",

"25331113302",

"25331113304",

"25331113308",

"2533111330A",

"2533111330B",

"2533111330C",

"2533111330D",

"2533111330E",

"2533111330F",

"2533111330G",

"2533111330H",

"2533111330J",

"2533111330K",

"2533111330L",

"25331115300",

"25331115302",

"25331115304",

"25331115308",

"2533111530A",

"2533111530B",

"2533111530C",

"2533111530D",

"2533111530E",

"2533111530F",

"2533111530G",

"2533111530H",

"2533111530J",

"2533111530K",

"2533111530L"

]

},

{

"part_name": "Hinge Bearing 5304507146",

"part_number": "PS11770608",

"manufacturer": "Kenmore",

"price": "7.28",

"description": "This is a replacement hinge bearing for your refrigerator. The hinge bearing is found on the door hinge, and reduces friction when the door opens and closes. If the bearing is damaged, you may not be able to open or close the door properly, and in this case, it will need to be replaced. It is made of white plastic and is approximately 2 inches long and 1 inch in diameter. This part is sold individually and is a genuine OEM part.",

"rating": "75",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# 5304507146 replaces these: AP6038496, 240311201, 240527101 Back to Top",

"review_count": "4",

"appliance": "refrigerator",

"compatible_models": [

"25331420100",
"25331420101",
"25331420104",
"25331422100",
"25331422101",
"25331422103",
"25331424100",
"25331424101",
"25331424102",
"25331427100",
"25331427101",
"25331428100",
"25331428101",
"25331428103",
"25331429100",
"25331429101",
"25331429102",
"25331429103",
"25331429104",
"25331430100",
"25331430101",
"25331430102",
"25331430104",
"25331430105",
"25331430106",
"25331432100",

```
"25331432101",  
"25331432102",  
"25331432103",  
"25331432104"  
]  
,  
{  
  "part_name": "Door Stopper 4620JJ2009A",  
  "part_number": "PS3523083",  
  "manufacturer": "LG",  
  "price": "13.55",  
  "description": "The door stop, or door stopper, is used in refrigerators. This door stop  
helps keep the door in position and in balance. This part is attached to the bottom of the  
door and it keeps it from opening and hitting the side of the refrigerator cabinet. If you find  
your door hits and scratches your lower cabinet when you open your fridge door, installing  
this part can be a solution to this problem. Make sure to unplug your appliance from the  
power source before installing this part and safely store food to prevent it from  
deteriorating. Refer to the diagram provided by the manufacturer for further instruction.",  
  "rating": "84",  
  "troubleshooting_tips": "This part fixes the following symptoms: Door won't open or  
close This part works with the following products: Refrigerator, Freezer. Part# 4620JJ2009A  
replaces these: AP4437762, 4620JJ2006A, 4620JJ2009A, 4620JJ2009B Back to Top",  
  "review_count": "5",  
  "appliance": "refrigerator",  
  "compatible_models": [  
    "48231784412",  
    "495934",  
    "66212",
```

"66222",
"66922",
"69293",
"69299",
"69372",
"69374",
"69376",
"69379",
"69912",
"69913",
"69972",
"69974",
"69979",
"70329",
"71012",
"71013",
"71014",
"71016",
"71019",
"71022",
"71023",
"71024",
"71026",
"71029",
"71082",
"71083",

```
"71322"
]
},
{
  "part_name": "Hinge Bearing 240328203",
  "part_number": "PS976452",
  "manufacturer": "Kenmore",
  "price": "17.25",
  "description": "Sold individually.",
  "rating": "99",
  "troubleshooting_tips": "This part fixes the following symptoms: Clicking sound | Door won't open or close | Noisy | Door Sweating This part works with the following products: Refrigerator. Part# 240328203 replaces these: AP3757897, 1056737, 7240328203 Back to Top",
  "review_count": "58",
  "appliance": "refrigerator",
  "compatible_models": [
    "25344303403",
    "25344309400",
    "25344309401",
    "25344352401",
    "25344352403",
    "25344353400",
    "25344353401",
    "25344353402",
    "25344353403",
    "25344353404",
```


"25344353405",
"25344353406",
"25344353407",
"25344353408",
"25344353409",
"25344354401",
"25344354403",
"25344359400",
"25344359401",
"25344359403",
"25344359404",
"25344359405",
"25344359406",
"25344359407",
"25344359408",
"25344359409",
"25344382402",
"25344383400",
"25344383401",
"25344383402"

]

},

{

"part_name": "CAM-DOOR WPW10470155",
"part_number": "PS11755285",
"manufacturer": "Kenmore",

"price": "8.00",

"description": "",

"rating": "80",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close | Clicking sound This part works with the following products: Refrigerator. Part# WPW10470155 replaces these: AP6021957, W10397037, W10470155 Back to Top",

"review_count": "2",

"appliance": "refrigerator",

"compatible_models": [

"10673002510",

"10673002511",

"10673003510",

"10673003511",

"10673009510",

"10673009511",

"10679402410",

"10679472410",

"10679472411",

"10679473410",

"10679473411",

"59673002510",

"59673003510",

"59673009510",

"IX5BBEXDS00",

"IX5BBEXDS01",

"KFFS20EYBL00",

"KFFS20EYBL01",

"KFFS20EYBL02",
"KFFS20EYBL04",
"KFFS20EYMS00",
"KFFS20EYMS01",
"KFFS20EYMS02",
"KFFS20EYMS04",
"KFFS20EYWH00",
"KFFS20EYWH01",
"KFFS20EYWH02",
"KFFS20EYWH04",
"KRFF300EBL00",
"KRFF300EBS00"

]

},

{

"part_name": "Refrigerator Door Shelf Bin - Clear WR71X11044",

"part_number": "PS6011779",

"manufacturer": null,

"price": "67.10",

"description": "Clear plastic gallon refrigerator door bin. It is used for storing fresh food and it is the right hand side.",

"rating": "96",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WR71X11044 replaces these: AP5656690, WR71X11059 Back to Top",

"review_count": "25",

"appliance": "refrigerator",

"compatible_models": [

"CFE28TP2MBS1",
"CFE28TP2MCS1",
"CFE28TP2MDS1",
"CFE28TP2MES1",
"CFE28TP2MFS1",
"CFE28TP2MGS1",
"CFE28TP2MHS1",
"CFE28TP2MIS1",
"CFE28TP2MJS1",
"CFE28TP2MKS1",
"CFE28TP3MBD1",
"CFE28TP3MBW2",
"CFE28TP3MCD1",
"CFE28TP3MDD1",
"CFE28TP3MED1",
"CFE28TP3MFD1",
"CFE28TP3MGD1",
"CFE28TP3MHD1",
"CFE28TP3MID1",
"CFE28TP3MJD1",
"CFE28TP3MKD1",
"CFE28TP4MBW2",
"CFE28TP4MCW2",
"CFE28TP4MDW2",
"CFE28TP4MEW2",
"CFE28TP4MFW2",

"CFE28TP4MGW2",

"CFE28TP4MHW2",

"CFE28TP4MIW2",

"CFE28TP4MJW2"

]

},

{

"part_name": "Door Shelf End Cap - Left or Right Side 215473602",

"part_number": "PS422925",

"manufacturer": "Kenmore",

"price": "9.22",

"description": "The door shelf end cap, or door bin support, secures the rack in a refrigerator or freezer door. Note that this fits on either the left or right hand side. If the end caps of your refrigerator or freezer are broken or cracked, or if your food retainer bar is not staying in place, then replacing the door support can solve this problem. No tools are needed for this repair project. To repair, first remove the end cap by pushing upward or downwards to slide it out the end of the rail. Next, replace with new end cap and line it up to clip it back onto the rail. It comes in white and measures about two inches high.

Remember to wear gloves for safety.",

"rating": "94",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 215473602 replaces these: AP2111276, 441121, 215473601 Back to Top",

"review_count": "12",

"appliance": "refrigerator",

"compatible_models": [

"25336600890",

"25336600891",

"25336600892",

"25336600894",
"25336600895",
"25336600896",
"25336600898",
"25336601890",
"25336601891",
"25336601892",
"25336601894",
"25336601895",
"25336601896",
"25336601898",
"25336608890",
"25336608891",
"25336608892",
"25336608894",
"25336608895",
"25336608896",
"25336608898",
"25336609890",
"25336609891",
"25336609892",
"25336609894",
"25336609895",
"25336609896",
"25336609898",
"25336610890",

"25336610891"

]

},

{

"part_name": "Door Shelf End Cap - Left or Right Side 215267701",

"part_number": "PS422444",

"manufacturer": "Kenmore",

"price": "5.25",

"description": "This end cap can be used for the right or left side of the refrigerator door shelf or the freezer door shelf. It is white in color, made of plastic material and measures about 2 inches high by 3 inches deep. This might need to be replaced if it has broken or worn over time. This repair requires no tools. You will need to open your fridge, pull upwards on the existing end cap, and pull outwards. There is a locking tab on either end so it does not matter if the top or bottom comes out first. Slide the new end cap onto the rail and it is installed.",

"rating": "100",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 215267701 replaces these: AP2110843, 444 Back to Top",

"review_count": "10",

"appliance": "refrigerator",

"compatible_models": [

"25336600890",

"25336600891",

"25336600892",

"25336600894",

"25336600895",

"25336600896",

"25336600898",

```
"25336601890",  
"25336601891",  
"25336601892",  
"25336601894",  
"25336601895",  
"25336601896",  
"25336601898",  
"25336608890",  
"25336608891",  
"25336608892",  
"25336608894",  
"25336608895",  
"25336608896",  
"25336608898",  
"25336609890",  
"25336609891",  
"25336609892",  
"25336609894",  
"25336609895",  
"25336609896",  
"25336609898",  
"25336610890",  
"25336610891"  
]  
,  
{
```


"part_name": "Refrigerator Door Shelf Retainer Bar - Cut to Fit 240331401",

"part_number": "PS429820",

"manufacturer": "Kenmore",

"price": "37.60",

"description": "This door shelf retainer bar is a replacement part for your refrigerator. To replace this part, you may need a flat blade screwdriver to apply leverage. Pop out the end caps on the shelf you are replacing, and remove the bar. Pull the end caps off the bar, and place them on the new one. Snap the end caps and new retainer bar back into place.",

"rating": "88",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 240331401 replaces these: AP2115820, 891017, 240331401, 240331402, 240331403, 240331404, 240331405, 240331408, 240331410, 240331415, 240331416 Back to Top",

"review_count": "19",

"appliance": "refrigerator",

"compatible_models": [

"25331420100",

"25331420101",

"25331422100",

"25331422101",

"25331424100",

"25331424101",

"25331427100",

"25331427101",

"25331428100",

"25331428101",

"25331429100",

"25331429101",

```
"25331430100",
"25331430101",
"25331430102",
"25331432100",
"25331432101",
"25331432102",
"25331434100",
"25331434101",
"25331434102",
"25331437100",
"25331437101",
"25331437102",
"25331438100",
"25331438101",
"25331438102",
"25331439100",
"25331439101",
"25331439102"
]
},
{
  "part_name": "Door Shelf Retainer Bar End Cap - Left Side 240311501",
  "part_number": "PS429667",
  "manufacturer": "Kenmore",
  "price": "10.75",
```

"description": "This is a replacement end cap for your freezer or refrigerator shelf retainer bar. You will need a flat blade screwdriver to complete this repair. To replace this part, remove the retainer bar by popping the end caps out of place. Use the screwdriver to pop out the individual end cap you are replacing. Secure the new one in place with the locking tabs and re-insert the retainer bar.",

"rating": "95",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 240311501 replaces these: AP2115699, 868747, 240311501, 240311501 Back to Top",

"review_count": "4",

"appliance": "refrigerator",

"compatible_models": [

"25331420100",

"25331420101",

"25331422100",

"25331422101",

"25331424100",

"25331424101",

"25331427100",

"25331427101",

"25331428100",

"25331428101",

"25331429100",

"25331429101",

"25331430100",

"25331430101",

"25331430102",

"25331432100",

```
"25331432101",
"25331432102",
"25331434100",
"25331434101",
"25331434102",
"25331437100",
"25331437101",
"25331437102",
"25331438100",
"25331438101",
"25331438102",
"25331439100",
"25331439101",
"25331439102"
]
},
{
  "part_name": "Door Shelf Retainer Bar End Cap - Right Side 240311502",
  "part_number": "PS429668",
  "manufacturer": "Kenmore",
  "price": "10.75",
  "description": "This replacement bar end cap can be used for a shelf in your freezer. The end cap is 4.25 inches long and 2.4 inches wide. You may need a flat blade screwdriver in order to pop out the existing end cap. Slide the new cap in place, making sure the locking tab is secure, and replace the bar.",
  "rating": "97",
```

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 240311502 replaces these: AP2115700, 868748, 240311502, 240311502 Back to Top",

"review_count": "34",

"appliance": "refrigerator",

"compatible_models": [

"25331420100",

"25331420101",

"25331422100",

"25331422101",

"25331424100",

"25331424101",

"25331427100",

"25331427101",

"25331428100",

"25331428101",

"25331429100",

"25331429101",

"25331430100",

"25331430101",

"25331430102",

"25331432100",

"25331432101",

"25331432102",

"25331434100",

"25331434101",

"25331434102",

"25331437100",

"25331437101",

"25331437102",

"25331438100",

"25331438101",

"25331438102",

"25331439100",

"25331439101",

"25331439102"

]

},

{

"part_name": "Door Shelf Bin W11239961",

"part_number": "PS12578777",

"manufacturer": null,

"price": "98.90",

"description": "This is a door shelf bin made for use within some models of refrigerators. This shelf bin is used to hold food items and containers, but if it is cracked or damaged and no longer able to hold any items, it needs to be replaced immediately. This shelf measures 15-inches wide at its widest point, and 13-inches wide where it would be installed, as well as 6.5-inches deep and 3.5-inches tall. This shelf bin is an OEM part, and does not come with any other shelves or parts.",

"rating": "90",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# W11239961 replaces these: AP6333410, W10900538 Back to Top",

"review_count": "28",

"appliance": "refrigerator",

"compatible_models": [

"8WRS21SNHW00",
"IRS335SDHM00",
"WRS311SDHB00",
"WRS311SDHB01",
"WRS311SDHB03",
"WRS311SDHM00",
"WRS311SDHM01",
"WRS311SDHM02",
"WRS311SDHM04",
"WRS311SDHM05",
"WRS311SDHT00",
"WRS311SDHT01",
"WRS311SDHT03",
"WRS311SDHW00",
"WRS311SDHW01",
"WRS311SDHW03",
"WRS312SNHB00",
"WRS312SNHB01",
"WRS312SNHB02",
"WRS312SNHB05",
"WRS312SNHM00",
"WRS312SNHM01",
"WRS312SNHM02",
"WRS312SNHM03",
"WRS312SNHM06",
"WRS312SNHW00",

```
"WRS312SNHW01",  
"WRS312SNHW02",  
"WRS312SNHW05",  
"WRS315SDHB00"
```

```
]
```

```
},
```

```
{
```

```
"part_name": "Light Socket 218906802",
```

```
"part_number": "PS3655096",
```

```
"manufacturer": "Kenmore",
```

```
"price": "21.96",
```

```
"description": "The light socket on your refrigerator houses the light bulb and connects it  
to the power source. If you notice that your refrigerator light does not come on when you  
open the door, you may need to replace the light socket. This light socket is made of white  
plastic with two metal prongs. The light socket is located inside the refrigerator. Many of our  
customers have rated this repair as easy. To complete this repair, simply pop the old socket  
out with a small flat blade screwdriver and disconnect the wires. Then simply reconnect  
the wires to the new socket, and snap it in place with the locking tab.",
```

```
"rating": "88",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Light not working This  
part works with the following products: Refrigerator. Part# 218906802 replaces these:  
AP5630701, 08000815, 08002736, 218906801, 218906803, 241513901, 3001221,  
5300067580, 5301205309, 5308000815, 8000815, 8002736, C000067580, F98501,  
G000166565, G000168510, G166565, G168510, K1205309, K1209665 ... Show more ,  
K1221996 Show less Back to Top",
```

```
"review_count": "10",
```

```
"appliance": "refrigerator",
```

```
"compatible_models": [  
  "15304-0A",
```


"15304-7A",
"177040A",
"177047A",
"17714-0A",
"17714-7A",
"178040A",
"178047A",
"25336600890",
"25336600891",
"25336600892",
"25336600894",
"25336600895",
"25336600896",
"25336600898",
"25336601891",
"25336601892",
"25336601894",
"25336601895",
"25336601896",
"25336601898",
"25336608890",
"25336608891",
"25336608892",
"25336608894",
"25336608895",
"25336608896",

```
"25336608898",
"25336609891",
"25336609892"
]
},
{
  "part_name": "Refrigerator LED Light and Cover Assembly WR55X25754",
  "part_number": "PS12172918",
  "manufacturer": null,
  "price": "30.43",
  "description": "The light and cover assembly illuminates the interior of the refrigerator compartment.",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Light not working This part works with the following products: Refrigerator. Part# WR55X25754 replaces these: AP6261806 Back to Top",
  "review_count": "1",
  "appliance": "refrigerator",
  "compatible_models": [
    "DFE28JBLBTS",
    "DFE28JBLDTS",
    "DFE28JBLETS",
    "DFE28JBLFTS",
    "DFE28JBLGTS",
    "DFE28JELCDS",
    "DFE28JELDDS",
    "DFE28JELEDS",
```

"DFE28JELFDS",
"DFE28JELGDS",
"DFE28JELHDS",
"DFE28JMKGES",
"DFE28JMKHES",
"DFE28JMKIES",
"DFE28JMKJES",
"DFE28JMKKES",
"DFE28JMKLES",
"DFE28JMKMES",
"DFE28JSKGSS",
"DFE28JSKHSS",
"DFE28JSKISS",
"DFE28JSKJSS",
"DFE28JSKKSS",
"DFE28JSKLSS",
"DFE28JYNBFS",
"GFD28GBLBTS",
"GFD28GBLCTS",
"GFD28GBLDTS",
"GFD28GBLETS",
"GFD28GBLFTS"

]

},

{

"part_name": "Refrigerator Light Bulb 5304517886",

"part_number": "PS12712277",

"manufacturer": "Kenmore",

"price": "56.71",

"description": "This is an LED light for a variety of refrigerator models. This 3.8W LED light is used to shine and adequately light the contents of your refrigerator when you open its door. If your current light is significantly dimmer than normal, or simply not working anymore, it will need to be replaced. To replace this bulb, unplug your fridge momentarily, and then simply unthread the old one and screw in the new one. This bulb is sold individually and does not come with any other parts.",

"rating": "86",

"troubleshooting_tips": "This part works with the following products: Refrigerator, Freezer. Part# 5304517886 replaces these: AP6873911, 216518100, 216518101, 216988000, 216988100, 241552801, 241552807, 297114000, 5304495326, 5304509249, 5304520040, 7216988100, 7241552801, 7297114000 Back to Top",

"review_count": "7",

"appliance": "refrigerator",

"compatible_models": [

"25312512410",

"25312512411",

"25322040510",

"25322042410",

"25322042411",

"25322042412",

"25322052610",

"25322052611",

"25322442410",

"25322442411",

"25322442412",

```
"25322442413",
"25322442414",
"25322442415",
"25322742411",
"25322742412",
"25326042100",
"25326072100",
"25326072101",
"25326072102",
"25326072103",
"25326082100",
"25326082101",
"25326082102",
"25326092100",
"25326092101",
"25326093100",
"25326202100",
"25326202101",
"25326452100"
]
},
{
  "part_name": "LED Light Control Board WPW10515058",
  "part_number": "PS11755867",
  "manufacturer": "Kenmore",
  "price": "183.50",
```

"description": "This 2-plug LED light control board is a genuine OEM replacement part designed for refrigerators. It fits into the fresh food section of the refrigerator. The LED light helps users easily see the contents of the fridge, even in low-light conditions. LED lights are a popular choice due to their energy efficiency, longer lifespan, and ability to produce bright and consistent lighting. Compared to traditional incandescent or fluorescent lights, LED lights consume less energy, generate less heat, and have a much longer operational lifespan, making them a preferred choice-",

"rating": "88",

"troubleshooting_tips": "This part fixes the following symptoms: Light not working This part works with the following products: Refrigerator. Part# WPW10515058 replaces these: AP6022534, W10465957, W10515058, W10522611, WPW10515058VP Back to Top",

"review_count": "15",

"appliance": "refrigerator",

"compatible_models": [

"10641122210",

"10641122211",

"10641122212",

"10641122213",

"10641123210",

"10641123211",

"10641123212",

"10641124210",

"10641129210",

"10641129211",

"10641129212",

"10641129213",

"10641152210",

"10641152211",

```
"10641153210",  
"10641153211",  
"10641154210",  
"10641159210",  
"10641159211",  
"10641159212",  
"10651122210",  
"10651122211",  
"10651123210",  
"10651123211",  
"10651124210",  
"10651124211",  
"10651129210",  
"10651129211",  
"10651129212",  
"10651132210"  
]  
,  
{  
  "part_name": "LED Light WPW10515057",  
  "part_number": "PS11755866",  
  "manufacturer": "Kenmore",  
  "price": "109.45",
```

"description": "This genuine OEM LED light is compatible with refrigerators. It has a length of 5.25 inches and a width of 2.24 inches. It is designed to fit into the freezer section of the appliance. The light has a white plastic housing and a translucent shield for protection. The light illuminates the interior of the refrigerator and allows you to easily view

the contents inside and find stored items, especially in low light conditions. The LED light is known for its energy efficiency, longevity, and bright lighting.",

"rating": "92",

"troubleshooting_tips": "This part fixes the following symptoms: Light not working This part works with the following products: Refrigerator. Part# WPW10515057 replaces these: AP6022533, W10398007, W10515057 Back to Top",

"review_count": "9",

"appliance": "refrigerator",

"compatible_models": [

"10641122210",

"10641122211",

"10641122212",

"10641122213",

"10641123210",

"10641123211",

"10641123212",

"10641124210",

"10641129210",

"10641129211",

"10641129212",

"10641129213",

"10641152210",

"10641152211",

"10641153210",

"10641153211",

"10641154210",

"10641159210",

"10641159211",

"10641159212",

"10651122210",

"10651122211",

"10651123210",

"10651123211",

"10651124210",

"10651124211",

"10651129210",

"10651129211",

"10651129212",

"10651132210"

]

},

{

"part_name": "Light Bulb - 10W WP22002263",

"part_number": "PS11739347",

"manufacturer": "Kenmore",

"price": "16.30",

"description": "This ten watt appliance light bulb is two inches tall. It is used with both washers and dryers.",

"rating": "79",

"troubleshooting_tips": "This part works with the following products: Refrigerator, Dryer, Washer Dryer Combo, Wine and Beverage Cooler. Part# WP22002263 replaces these: AP6006279, 14200559, 14201091, 14210279, 14212817, 14218420, 17512, 18445, 21074, 21120, 22002263, 245535, 262465, 263313, 28329, 3178641, 3406124, 3406125, 3406126, 35001138 ... Show more , 4159007, 4173328, 4323686, 4343839, 4344602, 4344740, 4350095, 4352209, 4713-001199, 528513, 550025, 790862,

790871, 8206780, 851389, W10299463, W10809512, W11385701, WP22002263VP
Show less Back to Top",

"review_count": "16",

"appliance": "refrigerator",

"compatible_models": [

"10644102300",

"10644103300",

"10644109300",

"10650212011",

"10650343011",

"10650522102",

"10650524102",

"10650532102",

"10650534102",

"10651042101",

"10651044101",

"10651049101",

"10651062101",

"10651064101",

"10651069101",

"10651103111",

"10651252103",

"10651252104",

"10651254103",

"10651254104",

"10651259103",

"10651259104",

"10651262102",

"10651262103",

"10651262104",

"10651262105",

"10651264102",

"10651264103",

"10651264104",

"10651264105"

]

},

{

"part_name": "LED Light Module W11043011",

"part_number": "PS12070396",

"manufacturer": null,

"price": "87.31",

"description": "This LED light is for refrigerators.\r\n\r\nThe LED light attaches inside the cabinet and illuminates the inside of the refrigerator or freezer.\r\n\r\nSafely store any food that could deteriorate while the power is off and unplug the refrigerator before installing this part.",

"rating": "99",

"troubleshooting_tips": "This part fixes the following symptoms: Light not working This part works with the following products: Refrigerator. Part# W11043011 replaces these: W10866538 Back to Top",

"review_count": "38",

"appliance": "refrigerator",

"compatible_models": [

"AFI2539ERB02",
"AFI2539ERM03",
"AFI2539ERW02",
"IX7DDEXGZ001",
"IX7DDEXGZ002",
"MFI2570FEB01",
"MFI2570FEW01",
"MFI2570FEZ03",
"MFI2570FEZ04",
"MFI2570FEZ05",
"MFI2570FEZ06",
"WRF555SDFZ",
"WRF555SDFZ03",
"WRF555SDFZ04",
"WRF555SDFZ05",
"WRF555SDFZ07",
"WRF555SDFZ08",
"WRF555SDHV01",
"WRF555SDHV02",
"WRX735SDBE02",
"WRX735SDBH02",
"WRX735SDBM",
"WRX735SDBM02",
"WRX735SDBM04",
"WRX735SDHB00",
"WRX735SDHV00",

```
"WRX735SDHW00",
"WRX735SDHZ00",
"WRX735SDHZ01"
]
},
{
  "part_name": "Refrigerator Freezer Door Gasket - Gray 5304501270",
  "part_number": "PS11704172",
  "manufacturer": "Kenmore",
  "price": "140.00",
  "description": "This door gasket is for the freezer door on the refrigerator. The gasket is grey in color. This part is approximately 34-1/2\" wide x 24\" long. The door gasket is on the inner door panel and creates a seal around the door to prevent warm air from entering the freezer compartment.",
  "rating": "78",
  "troubleshooting_tips": "This part fixes the following symptoms: Frost buildup | Freezer not defrosting | Door Sweating | Freezer section too warm This part works with the following products: Refrigerator. Part# 5304501270 replaces these: AP5981856, 241778308 Back to Top",
  "review_count": "10",
  "appliance": "refrigerator",
  "compatible_models": [
    "20462151B",
    "25370312213",
    "25370313210",
    "25370313211",
    "25370313212",
    "25370313213",
```

"25370313214",
"25370319213",
"2537034241E",
"2537034241F",
"2537034241J",
"25370343210",
"25370343410",
"25370343411",
"25370343412",
"25370343413",
"25370343414",
"2537034341F",
"2537034341G",
"2537034341H",
"2537034341J",
"2537034941J",
"25370413410",
"25370413411",
"25370413412",
"25370413413",
"25370413414",
"25370413415",
"25370413417",
"25370413418"

]

},

```
{  
  "part_name": "Fresh Food Door Gasket - Black 241872512",  
  "part_number": "PS1991436",  
  "manufacturer": "Kenmore",  
  "price": "161.23",  
  "description": "This door gasket is used to seal the refrigerator door when closed to keep  
the cool air inside and the room air out.",  
  "rating": "100",  
  "troubleshooting_tips": "This part fixes the following symptoms: Door won't open or  
close | Fridge too warm | Door Sweating | Leaking This part works with the following  
products: Refrigerator. Part# 241872512 replaces these: AP4316031, 1379488,  
241872512, 240390704, 240514612, 240542112, 240542124, 5304439526 Back to Top",  
  "review_count": "7",  
  "appliance": "refrigerator",  
  "compatible_models": [  
    "25331113300",  
    "25331113302",  
    "25331113304",  
    "25331113308",  
    "2533111330A",  
    "2533111330B",  
    "2533111330C",  
    "2533111330D",  
    "2533111330E",  
    "2533111330F",  
    "2533111330G",  
    "2533111330H",
```

```
"2533111330J",
"2533111330K",
"2533111330L",
"25331115300",
"25331115302",
"25331115304",
"25331115308",
"2533111530A",
"2533111530B",
"2533111530C",
"2533111530D",
"2533111530E",
"2533111530F",
"2533111530G",
"2533111530H",
"2533111530J",
"2533111530K",
"2533111530L"
]
},
{
  "part_name": "Refrigerator Freezer Gasket 5304505782",
  "part_number": "PS11766245",
  "manufacturer": "Kenmore",
  "price": "203.13",
```


"description": "This is a door gasket for the freezer compartment of various refrigerators. Door gaskets are used to seal the cold interior of the freezer compartment, from the warm and ambient temperature of your home. If this door gasket on your freezer door is damaged, moldy, or warped and unable to close and seal properly, it needs to be replaced immediately. This door gasket is gray in color and is easy to remove and install. To replace it, carefully pull and remove the old gasket off, and wrap the new gasket around the perimeter of the door frame. This gasket is sold individually, and does not come with any accessories.",

"rating": "74",

"troubleshooting_tips": "This part fixes the following symptoms: Frost buildup | Door Sweating | Door won't open or close | Leaking This part works with the following products: Refrigerator, Freezer. Part# 5304505782 replaces these: AP6030127, 216522370 Back to Top",

"review_count": "3",

"appliance": "refrigerator",

"compatible_models": [

"25344743110",

"25344743111",

"25344753110",

"E32AF75JPS0",

"E32AF75JPS1",

"E32AF75JPS2",

"E32AF85PQSA",

"E32AF85PQSB",

"E32AF85PQSC",

"E32AF85PQSD",

"E32AF85PQSE",

"E32AR75JPS0",

"E32AR75JPS1",

```
"E32AR75JPS2",
"E32AR85PQSA",
"E32AR85PQSB",
"E32AR85PQSC",
"E32AR85PQSD",
"E32AR85PQSE",
"E32AR85PQSF",
"EI32AF65JS0",
"EI32AF65JS1",
"EI32AF65JS2",
"EI32AF65JS3",
"EI32AF80QSA",
"EI32AF80QSB",
"EI32AF80QSC",
"EI32AF80QSD",
"EI32AF80QSE",
"EI32AR65JS0"
]
},
{
  "part_name": "Refrigerator Door Gasket 5304507200",
  "part_number": "PS11770644",
  "manufacturer": "Kenmore",
  "price": "143.22",
```

"description": "This door gasket, also known as a door seal, is sourced from the original equipment manufacturer for use in refrigerators and freezers. It is a flexible rubber strip that runs along the edge of the appliance door. It creates an airtight seal between the door

and cabinet to prevent cold air from escaping, and warm air from entering the refrigerator, to ensure that the temperature in the appliance remains constant. Over time, the door gasket can lose its elasticity or tear. In this case, you will likely notice frost build-up, increased noise, and inconsistent temperatures. Peel the faulty gasket off the refrigerator frame and remove any debris or residue on the surface. Carefully place the new seal along the edge of the door and press it firmly into place. Secure it with the appropriate fasteners and close the door to verify that there are no gaps between the door and cabinet.",

"rating": "88",

"troubleshooting_tips": "This part fixes the following symptoms: Frost buildup | Door Sweating | Too warm | Leaking This part works with the following products: Freezer, Refrigerator. Part# 5304507200 replaces these: AP6038516, 216522309, 216522310, 216522359, 5304408631, 5304507214, 7216522309 Back to Top",

"review_count": "13",

"appliance": "refrigerator",

"compatible_models": [

"25321711100",

"25321711101",

"25321711102",

"25321711103",

"25321711104",

"25321721100",

"25321721101",

"25321721102",

"25321721103",

"25321741100",

"25321741101",

"25321741102",

"25321741103",

"25321741104",

"25321741105",
"25321741106",
"25323714100",
"25323714101",
"25323724100",
"25323724101",
"25323725100",
"25323725101",
"25324722100",
"25324722101",
"25324722102",
"25324722103",
"25324722104",
"25324752100",
"25324752101",
"25324752102"

]

},

{

"part_name": "Refrigerator Door Gasket - Black 242193212",

"part_number": "PS9493822",

"manufacturer": "Kenmore",

"price": "148.06",

"description": "This gasket is for the refrigerator door. The gasket is black in colour. The door gasket is on the inner door panel and creates a seal around the door to prevent warm air from entering the refrigerator compartment.",

"rating": "87",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close | Fridge too warm | Leaking | Door Sweating This part works with the following products: Refrigerator. Part# 242193212 replaces these: AP5806924 Back to Top",

"review_count": "3",

"appliance": "refrigerator",

"compatible_models": [

"25360413710",

"25360413712",

"25360413713",

"25360413716",

"25360413717",

"25360419410",

"25360419411",

"25360419412",

"25360419413",

"25360419414",

"25360419610",

"25360419611",

"25360419612",

"25360419613",

"25360419614",

"25360419616",

"25360419617",

"2536041961A",

"2536041961C",

"2536041961E",

"25360502614",

"25360502616",

"25360502617",

"25360503410",

"25360503411",

"25360503412",

"25360503413",

"25360504614",

"25360504616",

"25360504617"

]

},

{

"part_name": "Refrigerator Door Gasket - Gray 241778307",

"part_number": "PS3408461",

"manufacturer": "Kenmore",

"price": "142.83",

"description": "This door gasket is an authentic OEM replacement part sourced directly from the manufacturer for use in refrigerators. The gasket is a flexible strip of gray rubber. It is designed to create an airtight seal when the door is closed. This seal ensures that cold air cannot escape the fridge and warm air cannot enter. The gasket helps to maintain the desired temperature inside the appliance to keep food fresh and prevent excessive energy usage Over time the gasket may tear, wear down or fall off. Regular cleaning and maintenance is essential for optimal refrigerator performance.",

"rating": "99",

"troubleshooting_tips": "This part fixes the following symptoms: Door Sweating | Fridge too warm | Door won't open or close This part works with the following products: Refrigerator. Part# 241778307 replaces these: AP4587413, 241778307 Back to Top",

"review_count": "12",

"appliance": "refrigerator",

"compatible_models": [

"20462151B",

"2537034241E",

"2537034241F",

"2537034241J",

"2537034341F",

"2537034341G",

"2537034341H",

"2537034341J",

"2537034941J",

"2537041341C",

"2537041341F",

"2537041341H",

"2537041941C",

"2537041941D",

"2537042341A",

"2537044341A",

"2537044341C",

"2537044341D",

"2537044341E",

"CFD26SDS0",

"CFD26WIS0",

"CFD26WIS1",

"CFD26WIS3",

"CFD26WIS4",

"CFD26WIS5",
"CFD26WIS6",
"CFD27SDPS0",
"CFD27WIPS2",
"CFD27WIPS3",
"CFD28SDQS0"

]

},

{

"part_name": "Refrigerator Door Gasket - White 242193206",

"part_number": "PS9493819",

"manufacturer": "Kenmore",

"price": "148.06",

"description": "This is an OEM door gasket, also known as a door seal, for various refrigerators. A door gasket is used to create a barrier between the warmer, ambient temperature of your home, and the cooler interior of the refrigerator. But if used for a long period of time, or simply after general wear and tear, this gasket can tear, break, and/or warp. If your gasket is broken, warped, or moldy, it will need to be replaced immediately. To replace this gasket, carefully peel out the old gasket and discard it, then carefully wrap the new gasket around the frame of the fridge door to install it. This door gasket is white and rectangular and measures 28.5 inches long, .75 inches thick, and approximately 42 inches wide. This door gasket is sold individually and does not come with any other parts or accessories.",

"rating": "84",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close | Door Sweating | Fridge too warm This part works with the following products: Refrigerator. Part# 242193206 replaces these: AP5806733 Back to Top",

"review_count": "10",

"appliance": "refrigerator",

"compatible_models": [

"25360412410",

"25360412411",

"25360412412",

"25360412413",

"25360412415",

"25360412610",

"25360412611",

"25360412612",

"25360412613",

"25360412614",

"25360412618",

"2536041261B",

"2536041261C",

"2536041261E",

"2536041261F",

"25360419614",

"25360502410",

"25360502411",

"25360502412",

"25360502413",

"25360502414",

"25360502610",

"25360502611",

"25360502612",

"25360502613",

```
"25360502614",
"25360502616",
"25360502617",
"25360502619",
"2536050261A"
]
},
{
  "part_name": "Door Switch Kit W10169313",
  "part_number": "PS1964648",
  "manufacturer": null,
  "price": "29.92",
  "description": "This part replaces two terminal switches in a dryer and prevents the dryer from running when the door is open. This includes two connectors. If your dryer will not shut off, start, or does not tumble, replacing the door switch can solve this appliance problem. The tools needed for replacement are a screw driver and wire strippers. Make sure to attach the two wires to the right two poles of the new switch, to do this you can check the resistance of the switch. Unplug the dryer before installing this part, also refer to the diagram provided by the manufacturer.",
  "rating": "93",
  "troubleshooting_tips": "This part fixes the following symptoms: Won't Start | Noisy This part works with the following products: Dryer, Washer, Washer Dryer Combo, Refrigerator. Part# W10169313 replaces these: AP4319999, 1378530, 3-4575, 3-4576, 3-5753, 3-5754, 304575, 304576, 305753, 305754, 33001508, 33001509, 5-4570, 504570, 56052, 57012, 62872, R0602515, W10169313, W10169313VP ... Show more , WPY304575, Y304575, Y304576, Y305753, Y305754, Y504570, Y62872 Show less Back to Top",
  "review_count": "19",
  "appliance": "refrigerator",
  "compatible_models": [
```

"7493-LEM437",
"ADE30RGS171TW01",
"ADE3LRGS171TW01",
"ADE41FSS171TN01",
"ADE4BFGS171TW01",
"ADE4BRGS171TW01",
"ADE7005AKW",
"ADE7005AYW",
"ADE9005AGW",
"ADG30RGS111TW01",
"ADG3LRGS111TW01",
"ADG41FSS111TN01",
"ADG4BFGS111TW01",
"ADG4BRGS111TW01",
"ADG7005AWW",
"AE3213",
"AE3413",
"AE4113",
"AE4213",
"AE4413",
"AE5113",
"AE5213",
"AE5413",
"AE7133",
"AE7233",
"AE9133",

```
"AE9233",
"AE9433",
"AEE933",
"AEE953"
]
},
{
  "part_name": "SWITCH 216822900",
  "part_number": "PS427069",
  "manufacturer": "Kenmore",
  "price": "64.43",
  "description": "This part turns the light on/off as the door opens and closes.",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Light not working This
part works with the following products: Freezer, Refrigerator. Part# 216822900 replaces
these: AP2113900, 216822901, 216922800, 216998000, 216998100, 7216822900,
7216998000 Back to Top",
  "review_count": "6",
  "appliance": "refrigerator",
  "compatible_models": [
    "25311312101",
    "25311312102",
    "25311351102",
    "25311521102",
    "25311521103",
    "25311531101",
    "25311531102",
```

```
"25311531103",  
"25311541102",  
"25311821101",  
"25312021100",  
"25312021101",  
"25312021102",  
"25312112410",  
"25312112411",  
"25312512410",  
"25312512411",  
"25312541100",  
"25312541102",  
"25312551100",  
"25312810510",  
"25312812510",  
"25312822510",  
"25313009100",  
"25313051100",  
"25313051101",  
"25313051102",  
"25313051103",  
"25313312101",  
"25313351100"  
]  
,  
{
```

"part_name": "Micro Switch WP2162361",

"part_number": "PS11738948",

"manufacturer": "Kenmore",

"price": "23.00",

"description": "This switch is located inside the dispenser.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Not dispensing water | Ice maker won't dispense ice | Leaking This part works with the following products: Refrigerator. Part# WP2162361 replaces these: AP6005886, 1119206, 2162361 Back to Top",

"review_count": "17",

"appliance": "refrigerator",

"compatible_models": [

"10644102300",

"10644103300",

"10644109300",

"10645422800",

"10645422801",

"10645423800",

"10645423801",

"10645429800",

"10645429801",

"10645432800",

"10645432801",

"10645433800",

"10645433801",

"10645439800",

```
"10645439801",  
"10646022800",  
"10646022801",  
"10646023800",  
"10646023801",  
"10646029800",  
"10646029801",  
"10646032800",  
"10646032801",  
"10646033800",  
"10646033801",  
"10646039800",  
"10646039801",  
"10650022000",  
"10650022001",  
"10650022002"  
]  
,  
{
```

```
  "part_name": "Refrigerator Door Switch 6600JB1010A",
```

```
  "part_number": "PS3529268",
```

```
  "manufacturer": "LG",
```

```
  "price": "31.51",
```

```
  "description": "The interior light in your refrigerator is controlled by a switch that is  
activated when the door is opened and closed. If your refrigerator light will not turn on, or  
stays on when the door is closed, you could have a faulty switch. The switch is spring-  
loaded and is a generally closed type of switch meaning there should be no continuity
```

when the button is pushed, and continuity through the switch when it is no longer engaged. This plastic, white, OEM switch is sourced directly from the manufacturer, is sold individually and is easy to replace. The repair usually takes less than 15 minutes and requires a flat-blade screwdriver and needle-nose pliers.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Light not working This part works with the following products: Refrigerator, Freezer. Part# 6600JB1010A replaces these: AP4442090, 6600JB1004A, 6600JB1004G, 6600JB1004H, 6600JB1004N, 6600JB1010A Back to Top",

"review_count": "87",

"appliance": "refrigerator",

"compatible_models": [

"65002",

"65004",

"65009",

"65012",

"65014",

"65019",

"65092",

"65093",

"65202",

"65204",

"65209",

"65212",

"65214",

"65219",

"68002",

"68003",


```
"68006",  
"68009",  
"68032",  
"68033",  
"68036",  
"68039",  
"68272",  
"68274",  
"68279",  
"69004",  
"69009",  
"71016",  
"71019",  
"71022"  
]  
,  
{  
  "part_name": "Light Switch WR23X23343",  
  "part_number": "PS10066583",  
  "manufacturer": "Kenmore",  
  "price": "8.69",
```

```
  "description": "This is the light switch that goes in your refrigerator. If the light is not  
working or stays on, you may need to replace the switch. It is made of mainly white plastic,  
and is an OEM part, directly from the manufacturer. Be sure to disconnect the refrigerator  
from the power source before you begin this repair. To remove the switch, simply use a  
flathead screwdriver to pop the switch out from the refrigerator wall, then disconnect the  
wires. Reconnect the wires to the new switch, snap it into place, and the repair is  
complete."
```

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Light not working |
Fridge too warm This part works with the following products: Refrigerator. Part#
WR23X23343 replaces these: AP5957928, WR23X10175, WR23X10530 Back to Top",

"review_count": "36",

"appliance": "refrigerator",

"compatible_models": [

"39631UGXAWW",

"39639USXAGV",

"CSCP5UGXAFSS",

"CSCP5UGXCFSS",

"CSCP5UGXDFSS",

"CSDP5UGDBFSS",

"CSHS5UGXBSS",

"CSHS5UGXCSS",

"CSHS6UGZBSS",

"CSHS6UGZEES",

"CSHS6UGZFSS",

"CSS25USWASS",

"CSS25USWCSS",

"CSS25USWS",

"CZS22MP2NBS1",

"CZS22MP2NDS1",

"CZS22MP2NES1",

"CZS22MP2NHS1",

"CZS22MSKBHSS",

"CZS22MSKEHSS",

"CZS22MSKKHSS",

"CZS25TSEBFSS",

"DSD26DGWABG",

"DSD26DGWB",

"DSD26DGWCBG",

"DSD26DHWABG",

"DSD26DHWB",

"DSD26DHWCBG",

"DSE25JBLJCTS",

"DSE25JBLKCTS"

]

},

{

"part_name": "Light Switch WR23X10725",

"part_number": "PS8758429",

"manufacturer": "Kenmore",

"price": "8.56",

"description": "The interior light of your refrigerator is controlled by a switch that is activated when the door is opened and closed. If your refrigerator light will not turn on, there could be an issue with the switch. The switch is spring loaded and is a generally closed type of switch meaning there should be no continuity when the button is depressed, and continuity through the switch when the button is not depressed. This plastic, white, OEM switch is sourced directly from the manufacturer, is sold individually and is easy to replace. The repair usually takes less than 15 minutes and requires a flat blade screwdriver and needle nose pliers.",

"rating": "96",

"troubleshooting_tips": "This part fixes the following symptoms: Light not working | Fridge too warm This part works with the following products: Refrigerator, Freezer, Range. Part# WR23X10725 replaces these: AP5796096, RF-7100-067, RF-7100-16, RF-7100-43,

SWR23X0193, SWR23X193, WR23X0164, WR23X0180, WR23X0193, WR23X0212, WR23X0240, WR23X0241, WR23X0359, WR23X0404, WR23X0411, WR23X0434, WR23X0475, WR23X10130, WR23X10143, WR23X10162 ... Show more , WR23X10320, WR23X10435, WR23X10445, WR23X164, WR23X180, WR23X193, WR23X212, WR23X240, WR23X241, WR23X27351, WR23X359, WR23X404, WR23X411, WR23X434, WR23X475, WR23X5141, WR23X5142, WR23X5155, WR23X5160, WR23X5166 Show less
Back to Top",

"review_count": "61",

"appliance": "refrigerator",

"compatible_models": [

"140060A",

"31861-1",

"31880",

"36211XBMBRWW",

"36211XBMDRWW",

"36211XBMERWW",

"36211XBMFRWW",

"36211XBRERWW",

"36211XBRFRWW",

"36337400790",

"36337400791",

"36337400792",

"36337401790",

"36337401791",

"36337401792",

"36337408790",

"36337408791",

"36337408792",

"36337409790",
"36337409791",
"36337409792",
"36337450791",
"36337450792",
"36337450890",
"36337451791",
"36337451792",
"36337451890",
"36337458791",
"36337458792",
"36337458890"

]

},

{

"part_name": "Refrigerator Air Damper Control Assembly WPW10594329",

"part_number": "PS11756641",

"manufacturer": "Kenmore",

"price": "130.03",

"description": "This air damper control assembly is for refrigerators.\r\n\r\nThe air damper control assembly controls the cold airflow from the freezer compartment into the refrigerator compartment.\r\n\r\nUnplug the refrigerator before installing this part.",

"rating": "99",

"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Clicking sound | Fridge too warm | Fridge too cold This part works with the following products: Refrigerator. Part# WPW10594329 replaces these: AP6023299, W10127431, W10207517, W10594329
Back to Top",

```
"review_count": "22",  
"appliance": "refrigerator",  
"compatible_models": [  
  "10672002010",  
  "10672002011",  
  "10672002013",  
  "10672002015",  
  "10672003010",  
  "10672003011",  
  "10672003012",  
  "10672003013",  
  "10672003014",  
  "10672003016",  
  "10672003017",  
  "10672003018",  
  "10672009010",  
  "10672009011",  
  "10672009013",  
  "10672009015",  
  "10672012010",  
  "10672013010",  
  "10672013017",  
  "10672019010",  
  "59672002010",  
  "59672002011",  
  "59672002013",
```

"59672002015",

"59672003010",

"59672003011",

"59672003012",

"59672003013",

"59672003014",

"59672003016"

]

},

{

"part_name": "Defrost Thermostat 5303918202",

"part_number": "PS469510",

"manufacturer": "Kenmore",

"price": "32.86",

"description": "This defrost thermostat is also known as a refrigerator defrost bi-metal thermostat kit. The function of the defrost bi-metal thermostat is to prevent overheating during the defrost cycle in your refrigerator by protecting the evaporator. The most common sign that there is a problem with your refrigerator defrost thermostat kit is if your freezer is cold but your refrigerator is warm. If your evaporator coils are icy then your defrost bi-metal thermostat kit could be defective. To do this installation the tools you will need include a 1/4 inch nut driver, a pair of wire strippers and crimpers, and a heat gun.",

"rating": "87",

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Freezer not defrosting | Freezer section too warm | Frost buildup This part works with the following products: Refrigerator. Part# 5303918202 replaces these: AP2150133, 833603, 241619705, 5303918202 Back to Top",

"review_count": "18",

"appliance": "refrigerator",

"compatible_models": [

"25331113300",
"25331113302",
"25331113304",
"25331113308",
"2533111330A",
"2533111330B",
"2533111330C",
"2533111330D",
"2533111330E",
"2533111330F",
"2533111330G",
"2533111330H",
"2533111330J",
"2533111330K",
"2533111330L",
"25331115300",
"25331115302",
"25331115304",
"25331115308",
"2533111530A",
"2533111530B",
"2533111530C",
"2533111530D",
"2533111530E",
"2533111530F",
"2533111530G",


```
"2533111530H",  
"2533111530J",  
"2533111530K",  
"2533111530L"  
]  
,  
{  
  "part_name": "Damper Control Assembly 242303001",  
  "part_number": "PS8746718",  
  "manufacturer": null,  
  "price": "166.50",  
  "description": "This authentic OEM damper control assembly is designed to be  
compatible with refrigerators. The assembly regulates the airflow between the freezer and  
refrigerator compartments. When the refrigerator needs to cool down, the damper receives  
signals from the thermostat or control board to open and allows more cold air from the  
freezer to enter the refrigerator compartment. When the desired temperature is reached,  
the damper closes to restrict airflow. If the damper assembly is faulty or damaged, your  
fridge will be unable to maintain the desired temperature levels. It may be either too warm  
leading to food spoilage or too cold leading to frost buildup.",  
  "rating": "93",  
  "troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Fridge  
too cold This part works with the following products: Refrigerator. Part# 242303001  
replaces these: AP5788340 Back to Top",  
  "review_count": "11",  
  "appliance": "refrigerator",  
  "compatible_models": [  
    "CRSE263TB0",  
    "CRSE263TD0",  
    "CRSE263TS0",
```

"CRSE263TW0",
"CRSH232PB3",
"CRSH232PB5",
"CRSH232PB6",
"CRSH232PB7A",
"CRSH232PB8A",
"CRSH232PB9A",
"CRSH232PBBA",
"CRSH232PBEA",
"CRSH232PBFA",
"CRSH232PBHA",
"CRSH232PS3",
"CRSH232PS4",
"CRSH232PS5A",
"CRSH232PS6A",
"CRSH232PS7A",
"CRSH232PS9A",
"CRSH232PSCA",
"CRSH232PW3",
"CRSH232PW5",
"CRSH232PW6",
"CRSH232PW7A",
"CRSH232PW8A",
"CRSH232PW9A",
"CRSH232PWAA",
"CRSH232PWBA",

```
"CRSH232PWCA"
]
},
{
  "part_name": "Cold Control Thermostat 241537103",
  "part_number": "PS8769007",
  "manufacturer": "Kenmore",
  "price": "104.94",
  "description": "This cold control thermostat cycles on and off regularly to keep your refrigerator cold.",
  "rating": "98",
  "troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Will Not Start | Freezer section too warm | Fridge too cold This part works with the following products: Refrigerator. Part# 241537103 replaces these: AP5803894, 241537101, 5304421256, 5304445058, 5304458021, G450226-08 Back to Top",
  "review_count": "7",
  "appliance": "refrigerator",
  "compatible_models": [
    "25331113300",
    "25331113302",
    "25331113304",
    "25331113308",
    "2533111330A",
    "2533111330B",
    "2533111330C",
    "2533111330D",
    "2533111330E",
```

```
"2533111330F",  
"2533111330G",  
"2533111330H",  
"2533111330J",  
"2533111330K",  
"2533111330L",  
"25331115300",  
"25331115302",  
"25331115304",  
"25331115308",  
"2533111530A",  
"2533111530B",  
"2533111530C",  
"2533111530D",  
"2533111530E",  
"2533111530F",  
"2533111530G",  
"2533111530H",  
"2533111530J",  
"2533111530K",  
"2533111530L"  
]  
},  
{  
  "part_name": "Defrost Thermostat WR50X10068",  
  "part_number": "PS1017716",
```

"manufacturer": "Kenmore",

"price": "29.24",

"description": "This defrost termination thermostat (Defrost Limiter Thermostat, High Limit Thermostat, Refrigerator Defrost Bi-Metal Thermostat) acts as a safety device to stop the evaporator coil from overheating, by turning off the defrost heater at the end of the defrost cycle. This part attaches to the tubing of the evaporator coil in the freezer. A faulty defrost termination thermostat may result in the defrost heater never heating and a solid frost buildup on the evaporator coil, which results in too warm temperatures. The thermostat contacts are normally closed and have continuity until it reaches 140 degrees. If this high limit thermostat is open at room temperature or colder, it is defective. This limit thermostat has an attached mounting clip and comes with pink and amber wire leads. The thermostat is 1 inch in diameter and 1/2 inch thick, the 2 wire leads are 10 inches long.",

"rating": "90",

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Freezer section too warm | Freezer not defrosting | Frost buildup This part works with the following products: Refrigerator. Part# WR50X10068 replaces these: AP3884317, 1170024, WR50X10068, WR50X10015, WR50X10017, WR50X10018, WR50X10028, WR50X10051, WR50X10052, WR50X10053, WR50X10054, WR50X10074, WR50X10075, WR50X10079
Back to Top",

"review_count": "18",

"appliance": "refrigerator",

"compatible_models": [

"A4425GDTABB",

"A4425GDTAWW",

"A4425GDTW",

"BSS25GFPACC",

"BSS25GFPAWW",

"BSS25GFPCCC",

"BSS25GFPCWW",

"BSS25GFPDCC",

```
"BSS25GFPDWW",
"BSS25GFPECC",
"BSS25GFPEWW",
"BSS25GFPHCC",
"BSS25GFPHWW",
"BSS25JFRFWW",
"BSS25JFRJWW",
"BSS25JFTAWW",
"BSS25JSRFSS",
"BSS25JSRJSS",
"BSS25JSTASS",
"BSY25GFMCCC",
"BSY25GFMCWW",
"BSY25GFMDCC",
"BSY25GFMDWW",
"DSF25KGTBBG",
"DSF25MGSBBB",
"DSF25MGSBWW",
"DSS25JFPACC",
"DSS25JFPAWW",
"DSS25JFPCCC",
"DSS25JFPCWW"
]
},
{
  "part_name": "Thermostat Assembly WP2198202",
```

"part_number": "PS11739232",

"manufacturer": "Kenmore",

"price": "85.01",

"description": "This thermostat assembly is used in refrigerator units and freezers as a sensor. The thermostat senses the temperature increase in the evaporator during the cycle of defrosting and turns off when ice is melted. If you have any of the following symptoms, replacing your thermostat could solve the problem: fridge does not start, is too warm, too cold, runs too long, or will not start. The tools needed for this repair project is a putty knife, Phillips and flat blade screw driver, 1/4 inch nut driver, and needle nose pliers. Remember to unplug refrigerator from power source as a safety precaution. Refer to the manual provided by the manufacturer for further installation instructions.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Will Not Start | Fridge too warm | Freezer section too warm | Fridge and Freezer are too warm This part works with the following products: Refrigerator. Part# WP2198202 replaces these: AP6006166, 1110552, 1115242, 1115243, 1115244, 1115245, 1129437, 2161283, 2161284, 2169112, 2169113, 2198201, 2198202, 99989726, WP2198202VP Back to Top",

"review_count": "53",

"appliance": "refrigerator",

"compatible_models": [

"10640212010",

"10640212011",

"10641012100",

"10641012101",

"10641012104",

"10641014100",

"10641014101",

"10641014104",

"10641212100",

```
"10641212101",
"10641214100",
"10641214101",
"10641512100",
"10641512101",
"10641514100",
"10641514101",
"10641519100",
"10641519101",
"10644252400",
"10644253400",
"10644254400",
"10644552400",
"10644559400",
"10647021790",
"10647021791",
"10647022790",
"10647022791",
"10647028790",
"10647028791",
"10648062890"
]
},
{
  "part_name": "Defrost Thermostat 297216600",
  "part_number": "PS2350702",
```


"manufacturer": "Kenmore",

"price": "23.12",

"description": "This refrigerator defrost thermostat is a genuine OEM part and is sourced directly from the manufacturer. Located on the back wall of the freezer section in the refrigerator, the defrost thermostat is used to regulate the appliances temperature to keep the refrigerator cold and constant. The part is made of plastic, and has a 4 inch terminal on the white lead and a 6 inch terminal on the red lead. A refrigerator defrost thermostat may need to be replaced if the appliance is experiencing temperature related issues such as: too cold, too warm, frost buildup, not running, or running too long.",

"rating": "95",

"troubleshooting_tips": "This part fixes the following symptoms: Too warm | Fridge too warm | Frost buildup | Doesn't stop running This part works with the following products: Refrigerator, Freezer. Part# 297216600 replaces these: AP4374171, 1483781, 216731000, 216872200, 218673001, 218673008, 218969901, 218969902, 5304404743, 5404404743, 7216872200 Back to Top",

"review_count": "33",

"appliance": "refrigerator",

"compatible_models": [

"25314772100",

"25314772101",

"25314772102",

"25314772103",

"25316562100",

"25316562101",

"25316572100",

"25316572101",

"25321021100",

"25321021101",

"25321021102",

```
"25321021103",
"25321021104",
"25321021105",
"25321041100",
"25321041101",
"25321041102",
"25321041103",
"25321041104",
"25321041105",
"25321041107",
"25321041108",
"25321082100",
"25321082101",
"25321082102",
"25321082103",
"25321082104",
"25321082106",
"25321082107",
"25321101100"
]
},
{
  "part_name": "Defrost Thermostat Kit 5303918214",
  "part_number": "PS469522",
  "manufacturer": "Kenmore",
  "price": "20.60",
```

"description": "If you find that there is excessive frost in your freezer, or the freezer will not defrost, you may need to replace the defrost thermostat. The defrost thermostat kit comes with the clip, leads, and heat shrink. To access the defrost thermostat for this repair, you will need to remove your freezer shelves, as well as the back panel of your freezer. To complete this repair, you will need a 1/4-inch nut driver, a set of wire strippers and crimpers, and a heat gun or blow dryer. Before you begin this repair, be sure to disconnect the power source from the appliance.",

"rating": "86",

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too cold | Fridge too warm | Freezer section too warm | Freezer not defrosting This part works with the following products: Refrigerator. Part# 5303918214 replaces these: AP2150145, 892545, 5303918214, 5303918214, 75303918214 Back to Top",

"review_count": "25",

"appliance": "refrigerator",

"compatible_models": [

"25344302400",

"25344302401",

"25344303400",

"25344303401",

"25344303402",

"25344303403",

"25344304400",

"25344304401",

"25344309400",

"25344309401",

"25344333600",

"25344333601",

"25344333602",

"25344333603",

"25344333604",
"25344333605",
"25344333606",
"25344333607",
"25344333608",
"25344333609",
"2534433360A",
"25344352400",
"25344352401",
"25344352403",
"25344352404",
"25344352405",
"25344352406",
"25344352407",
"25344352408",
"25344352409"

]

},

{

"part_name": "Refrigerator Condenser Fan Motor Kit 5303918774",

"part_number": "PS11766772",

"manufacturer": "Kenmore",

"price": "132.58",

"description": "This is a replacement condenser fan motor kit for your refrigerator. This six-piece kit contains foam tape, 2 screws, the fan blade, the new motor mounting bracket, and the condenser fan motor. The condenser fan motor is found in the back of the refrigerator, and it moves air across the compressor and the condenser to keep them cool."

If the motor has failed, the condenser and the compressor will run hot, and this can cause the refrigerator not to cool. This is an OEM part from the manufacturer.",

"rating": "85",

"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Fridge too warm | Fridge and Freezer are too warm | Freezer section too warm This part works with the following products: Refrigerator, Freezer. Part# 5303918774 replaces these: AP6034262, 240334001, 240334003, 240334004, 240397101, 240453600, 240453601, 240525401, 240525402, 241681101, 241712101, 241879301, 241879302, 241885813, 241935601, 241935602, 5303918635, 5303918745, 5304479002, 5304491362 ... Show more , 5304493894 Show less Back to Top",

"review_count": "13",

"appliance": "refrigerator",

"compatible_models": [

"25331113300",

"25331113302",

"25331113304",

"25331113308",

"2533111330A",

"2533111330B",

"2533111330C",

"2533111330D",

"2533111330E",

"2533111330F",

"2533111330G",

"2533111330H",

"2533111330J",

"2533111330K",

"2533111330L",

"25331115300",
"25331115302",
"25331115304",
"25331115308",
"2533111530A",
"2533111530B",
"2533111530C",
"2533111530D",
"2533111530E",
"2533111530F",
"2533111530G",
"2533111530H",
"2533111530J",
"2533111530K",
"2533111530L"

]

},

{

"part_name": "Evaporator Fan Motor WR60X10185",

"part_number": "PS1019114",

"manufacturer": "Kenmore",

"price": "130.69",

"description": "This evaporator fan motor circulates air to the fresh food compartments for efficient cooling. It powers the evaporator fan that draws air from the refrigerator and circulates it over the evaporator coils. Your fan motor has a long life cycle, but can burn out quickly if there is an obstruction preventing the fan from rotating. If the fan does not operate, the freezer will not cool properly. This will affect the performance of the

compressor. This evaporator fan motor is located in the back of the freezer section of your refrigerator, behind the auger motor assembly. It is attached to the back wall. If you notice problems with your freezer then check to see if there is anything blocking a fan blade. If there is no obstruction, test the evaporator fan motor using a multimeter. Test the 2 wires that travel from the coil on the motor for resistance. If these tests indicate that the evaporator fan motor is at fault, it must be replaced. This part features 1 evaporator fan motor, which is metal and plastic, and comes in white/silver",

"rating": "89",

"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Fridge too warm | Freezer section too warm | Will Not Start This part works with the following products: Refrigerator, Freezer. Part# WR60X10185 replaces these: AP3875639, 1170107, WR60X10185, 197D2039P008, WR23X10346, WR23X10350, WR23X10353, WR23X10355, WR23X10364, WR23X10404, WR23X10405, WR23X10406, WR60X10043, WR60X10059, WR60X10068, WR60X10083, WR60X10084, WR60X10099, WR60X10149, WR60X10152 ... Show more , WR60X10154, WR60X10157 Show less Back to Top",

"review_count": "20",

"appliance": "refrigerator",

"compatible_models": [

"A4425GDTABB",

"A4425GDTAWW",

"A4425GDTBBB",

"A4425GDTBWW",

"A4425GDTW",

"BSS25GFPDCC",

"BSS25GFPDWW",

"BSS25GFPECC",

"BSS25GFPEWW",

"BSS25GFPHCC",

"BSS25GFPHWW",

"BSS25JFRFWW",

```
"BSS25JFRJWW",
"BSS25JFTAWW",
"BSS25JFTBWW",
"BSS25JFTCWW",
"BSS25JFTDWW",
"BSS25JFTEWW",
"BSS25JFTGWW",
"BSS25JFTHWW",
"BSS25JFTIWW",
"BSS25JFTJWW",
"BSS25JFTNWW",
"BSS25JFTPWW",
"BSS25JSRFSS",
"BSS25JSRJSS",
"BSS25JSTASS",
"BSS25JSTBSS",
"BSS25JSTCSS",
"BSS25JSTDSS"
]
},
{
  "part_name": "Condenser Fan Motor WR60X10168",
  "part_number": "PS967022",
  "manufacturer": "Kenmore",
  "price": "57.50",
```


"description": "This fan motor circulates the air through the refrigerator grille and cools the compressor and condenser coils. It also helps to evaporate extra water in the drain pan.",

"rating": "99",

"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Fridge too warm | Will Not Start This part works with the following products: Refrigerator. Part# WR60X10168 replaces these: AP3855309, 1170105, WR60X10018, WR60X10021, WR60X10028, WR60X10061, WR60X10153 Back to Top",

"review_count": "22",

"appliance": "refrigerator",

"compatible_models": [

"31181-1",

"31191-1",

"3210-00LOS00-A",

"3210-00ROS00-A",

"36211XBMBRWW",

"36211XBMDRWW",

"36211XBMERWW",

"36211XBMFRWW",

"36211XBRERWW",

"36211XBRFRWW",

"36368162894",

"36368167894",

"36368592896",

"36368595896",

"36368597896",

"36368672895",

```
"36368677895",
"36368852899",
"36368857899",
"36369262991",
"36369265991",
"36369267991",
"36369462991",
"36369467991",
"36369662991",
"36369667991",
"36369962991",
"36369965991",
"36369967991",
"36378162894"
]
},
{
  "part_name": "Condenser Fan Motor Kit W10124096",
  "part_number": "PS1957416",
  "manufacturer": "Kenmore",
  "price": "127.42",
```

```
  "description": "This condenser fan motor kit includes a motor, fan blade, wire harness,
and screws. Used in a refrigerator, the condenser fan motor moves the condenser fan blade
to direct and move air across the condenser coil. Please note: The manufacturer has
changed the appearance of the product from the original. The kit still functions the same as
the original part. It is an OEM factory replacement. Make sure to unplug the refrigerator
from the power source and wear gloves to protect your hands. Also, a helpful tip is to store
food to prevent deterioration when the power is off.",
```

"rating": "98",

"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Fridge too warm | Freezer section too warm | Fridge and Freezer are too warm This part works with the following products: Refrigerator, Ice Maker, Freezer. Part# W10124096 replaces these: AP4318657, 1378525, W10124096, 2188538, 2188727, 2188728, 2188729, 2188732, 2188891, 2206005, 2315538, 2315558, W10124096, W10124096VP, W10130108, W10204250, W10509333, W10861645 Back to Top",

"review_count": "44",

"appliance": "refrigerator",

"compatible_models": [

"10640212010",

"10641522500",

"10641523500",

"10641524500",

"10641529500",

"10642102300",

"10642102301",

"10642104300",

"10642106300",

"10642106301",

"10644022600",

"10644022601",

"10644022602",

"10644022603",

"10644023600",

"10644023601",

"10644023602",

```
"10644023603",  
"10644024600",  
"10644029600",  
"10644029601",  
"10644029602",  
"10644029603",  
"10644032600",  
"10644032601",  
"10644032602",  
"10644032603",  
"10644033600",  
"10644033601",  
"10644033602"
```

```
]
```

```
},
```

```
{
```

```
"part_name": "Condenser Fan Motor WR60X10220",
```

```
"part_number": "PS1766247",
```

```
"manufacturer": null,
```

```
"price": "51.98",
```

```
"description": "This fan motor is most times used with frost-free refrigerators with a  
condenser coil. When the compressor runs, so does this fan, circulating air through the  
refrigerator grille, cooling the compressor and condenser coils. This fan motor also helps to  
evaporate excess water in the drain pan.",
```

```
"rating": "99",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Noisy | Fridge too warm  
| Freezer section too warm | Will Not Start This part works with the following products:
```

Refrigerator. Part# WR60X10220 replaces these: AP4298602, 1257132, WR60X10220, WR60X10133, WR60X10171, WR60X10192 [Back to Top](#),

"review_count": "44",

"appliance": "refrigerator",

"compatible_models": [

"A4425GDTABB",

"A4425GDTAWW",

"A4425GDTBBB",

"A4425GDTBWW",

"A4425GDTW",

"BSS25GFPCCC",

"BSS25GFPCWW",

"BSS25GFPDCC",

"BSS25GFPDWW",

"BSS25GFPECC",

"BSS25GFPEWW",

"BSS25GFPHCC",

"BSS25GFPHWW",

"BSS25JFRFWW",

"BSS25JFRJWW",

"BSS25JFTAWW",

"BSS25JFTBWW",

"BSS25JFTCWW",

"BSS25JFTDWW",

"BSS25JFTEWW",

"BSS25JFTGWW",

```
"BSS25JFTHWW",  
"BSS25JFTIWW",  
"BSS25JFTJWW",  
"BSS25JFTNWW",  
"BSS25JFTPWW",  
"BSS25JSRFSS",  
"BSS25JSRJSS",  
"BSS25JSTASS",  
"BSS25JSTBSS"
```

```
]
```

```
},
```

```
{
```

```
"part_name": "Evaporator Fan Motor Kit - 120V 60Hz 5303918549",
```

```
"part_number": "PS3419839",
```

```
"manufacturer": "Kenmore",
```

```
"price": "76.34",
```

```
"description": "The evaporator fan motor (Motor Evaporator Fan, Evaporator Fan Motor Kit, Evaporator Fan Motor, Refrigerator Evaporator Fan Motor) circulates air through the food compartment for efficient cooling in refrigerators. The evaporator fan motor can squeal as its bearing dries out. The motor bearings can totally seize, preventing any movement. The motor coil can also burn out, preventing any fan movement. If this motor fails, the refrigerator compartment will warm up and eventually the freezer will reduce cooling as well. Excessive frost can build up on the evaporator coil due to lack of air movement. The motor can make a squealing noise when it is beginning to fail or will not operate at all when powered, and this is a sign it should be replaced. The evaporator is located in the rear of the freezer compartment. This part measures 2-1/2 inches wide by 3 inches tall by 1 inch thick, at its widest point. It is constructed of plastic and metal, and comes in black/silver. This kit includes the evaporator fan motor and harness.",
```

```
"rating": "85",
```

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Noisy | Freezer section too warm | Fridge and Freezer are too warm This part works with the following products: Refrigerator. Part# 5303918549 replaces these: AP4700070, 1637660, 5303918549, 240315801, 240315802, 240315803, 240369701, 240369702, 241537301, 5304445861 Back to Top",

"review_count": "24",

"appliance": "refrigerator",

"compatible_models": [

"25331113300",

"25331113302",

"25331113304",

"25331113308",

"2533111330A",

"2533111330B",

"2533111330C",

"2533111330D",

"2533111330E",

"2533111330F",

"2533111330G",

"25331115300",

"25331115302",

"25331115304",

"25331115308",

"2533111530A",

"2533111530B",

"2533111530C",

"2533111530D",

```
"2533111530E",
"2533111530F",
"2533111530G",
"25331123300",
"25331123302",
"25331125300",
"25331125302",
"25331133300",
"25331133302",
"25331133303",
"25331133306"
]
},
{
  "part_name": "Condenser Fan Motor 242018301",
  "part_number": "PS3501052",
  "manufacturer": "Kenmore",
  "price": "111.63",
  "description": "",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Noisy  
This part works with the following products: Refrigerator, Freezer. Part# 242018301  
replaces these: AP5272397, 242018304, 297279502 Back to Top",
  "review_count": "2",
  "appliance": "refrigerator",
  "compatible_models": [
    "20462151B",
```


"25360002410",
"25360002412",
"25360002413",
"25360002414",
"25360002415",
"25360002610",
"25360022410",
"25360022412",
"25360022413",
"25360022610",
"25360022611",
"25360082416",
"25360082417",
"25360083416",
"25360083417",
"25360085614",
"25360087712",
"25360089416",
"25360089417",
"25360302410",
"25360302412",
"25360302413",
"25360302414",
"25360302415",
"25360302610",
"25360302611",

"25360303410",

"25360303412",

"25360303413"

]

},

{

"part_name": "Condenser Fan Motor Kit 833697",

"part_number": "PS395284",

"manufacturer": "Kenmore",

"price": "63.12",

"description": "This condenser fan motor kit is designed for use with refrigerators. This fan draws air through the condenser coils and over the compressor. It does this with the goal of cooling the warm refrigerant before it enters the evaporator. When your fan or fan motor is not working your refrigerator will not cool properly. This is a 2-Watt, 115 Volt motor that rotates the fan in a counter clockwise direction. This kit includes the hardware needed for installation, and a set of instructions. Before you begin any repair work make sure to unplug your appliance.",

"rating": "95",

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Freezer section too warm | Noisy | Fridge runs too long This part works with the following products: Refrigerator, Freezer. Part# 833697 replaces these: AP3120994, 2790, 833697, 0054175, 0055586, 0056804, 0311168, 0312499, 10448601, 10448602, 10448603, 10522101, 10522102, 10522104, 10884501, 10884502, 10884504, 10884506, 10884507, 1101025 ... Show more , 1101026, 1101073, 1101140, 1105656, 1105657, 1107713, 1107714, 1121292, 1129383, 12001314, 14210089, 14211095, 14251476, 14273186, 1531106, 1549266, 20009052, 205943, 205953, 21012-1, 2149963, 2154725, 2154735, 2154798, 2154998, 2162431, 2199155, 237129, 27515-1, 28056-1, 28056-12, 28056-13, 28056-14, 28056-15, 28056-16, 28056-2, 28056-3, 28056-4, 28056-5, 28056-6, 28056-7, 28056-8, 28056-9, 311168, 4343855, 4344273, 46000833697, 482737, 483019, 483079, 483213, 510634, 515272, 515273, 515396, 517322, 517385, 52186-9, 530423, 530760, 531106, 531585, 531594, 544058, 54503-2, 549047, 549048, 549266, 549299, 552919, 553235, 553236, 56804, 604292,

605292, 606289, 606339, 61001016, 61001018, 61001562, 61002038, 67560-1, 67560-10, 67560-2, 67560-3, 67560-4, 67560-5, 67560-7, 67560-8, 68445-1, 68445-3, 68445-6, 68445-7, 68481-1, 68481-2, 68481-3, 68481-4, 69289215, 799397, 80833697, 8118, 8170524, 8170704, 831350, 833518, 833697, 833697VP, 850015, 851445, 851476, 851578, 851618, 851619, 851629, 851630, 851735, 876443, 938077, 938078, 938164, 938271, 938375, 945466, 945566, 945583, 946538, 946539, 946679, 989532, 99989708, A0287801, B0532506, B0540006, B0544605, B0547205, B0551904, B0552001, B0552004, B0552604, B5603501, B5603504, B5646204, B5646301, C36617-1, C3661701, C36618-1, C3661801, C7584001, C87369-1, C8736901, C8766901, C8809801, C8891701, D0709217, D75840-1, D7584001, D7584002, R0150001, R0150002, R0950046, R0950211, R1500-1, UEM1021, WP61002038, Y0054175, Y0055586, Y0056804, Y0311168, Y0312499, Y61001016 Show less Back to Top",

"review_count": "34",

"appliance": "refrigerator",

"compatible_models": [

"106106-8130600",

"106106-8130610",

"106106-8130620",

"106106-8130630",

"106106-8130640",

"106106-8130650",

"106106-8130660",

"106106-8130680",

"106106-8130690",

"1061068130670",

"10650202990",

"10650202991",

"10650202992",

"10650202993",

"10650203990",
"10650203991",
"10650203993",
"10650204990",
"10650204991",
"10650209990",
"10650209991",
"10650257000",
"10650257001",
"10650259001",
"10650262990",
"10650262992",
"10650264990",
"10650264992",
"10650267990",
"10650267991"

]

},

{

"part_name": "Evaporator Fan Motor WP2315539",

"part_number": "PS11740359",

"manufacturer": "Kenmore",

"price": "66.41",

"description": "This evaporator fan motor is located in the back of the freezer, and circulates air over the refrigerator coils. These coils will convert the heat into cool air, which is then circulated.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Noisy | Fridge and Freezer are too warm | Freezer section too warm This part works with the following products: Refrigerator. Part# WP2315539 replaces these: AP6007247, 2219689, 2225625, 2315539, W10438708, WP2315539VP Back to Top",

"review_count": "48",

"appliance": "refrigerator",

"compatible_models": [

"10632249101",

"10632842010",

"10632853010",

"10632862010",

"10632862011",

"10632873010",

"10632889010",

"10632942101",

"10632943101",

"10660212410",

"10660213410",

"10660214410",

"10660219410",

"10660232900",

"10660232903",

"10660233904",

"10660234900",

"10660234903",

"10660239900",

"10660239904",

"10660932901",

"10660933901",

"10660934900",

"10660934901",

"10660939901",

"10661102111",

"10661103111",

"10661104111",

"10661109111",

"10662152111"

]

},

{

"part_name": "Refrigerator Fresh Food Evaporator Fan Motor (DC) WR60X26866",

"part_number": "PS12172983",

"manufacturer": null,

"price": "120.03",

"description": "This evaporator fan motor is for refrigerators.\r\n\r\nThe evaporator fan motor circulates air through the fresh food compartment for efficient cooling.\r\n\r\nSafely store any food that could deteriorate while the power is off and unplug the refrigerator before installing this part. Wear work gloves to protect your hands.",

"rating": "90",

"troubleshooting_tips": "This part fixes the following symptoms: Fridge too warm | Noisy
This part works with the following products: Refrigerator. Part# WR60X26866 replaces these: AP6278228, WR49X25197, WR60X10341, WR60X10356, WR60X24303, WR60X26030, WR60X26033 Back to Top",

"review_count": "30",

"appliance": "refrigerator",

"compatible_models": [

"CFE28TP2MBS1",

"CFE28TP2MCS1",

"CFE28TP2MGS1",

"CFE28TP2MHS1",

"CFE28TP3MBD1",

"CFE28TP3MBW2",

"CFE28TP3MCD1",

"CFE28TP3MHD1",

"CFE28TP4MBW2",

"CFE28TP4MCW2",

"CFE28TP4MHW2",

"CFE28TSHESS",

"CFE28TSHFSS",

"CFE28TSHGSS",

"CFE28TSHISS",

"CFE28TSHJSS",

"CFE28TSHKSS",

"CFE28TSHMSS",

"CFE28TSHNSS",

"CFE28TSHOSS",

"CFE28TSHPSS",

"CFE28TSHRSS",

"CFE28TSHSS",

"CFE28UELBDs",

"CFE28UELCDS",

```
"CFE28UELEDS",
"CFE28UP2MBS1",
"CFE28UP2MCS1",
"CFE28UP2MGS1",
"CFE28UP2MHS1"
]
},
{
  "part_name": "Cap, Water Filter (Black) WP2186494B",
  "part_number": "PS11739084",
  "manufacturer": "Kenmore",
  "price": "41.79",
  "description": "This black water filter cap is located near the bottom kickplate.",
  "rating": "93",
  "troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Refrigerator, Wine and Beverage Cooler. Part# WP2186494B replaces these: AP6006022, 2186494B, 2186494TG, 2186884B, 4392866, 4392870, W10281557 Back to Top",
  "review_count": "17",
  "appliance": "refrigerator",
  "compatible_models": [
    "10644102300",
    "10644103300",
    "10644109300",
    "10650202990",
    "10650202991",
    "10650202992",
```



```
"10650202993",  
"10650203990",  
"10650203991",  
"10650203992",  
"10650203993",  
"10650204990",  
"10650204991",  
"10650204992",  
"10650204993",  
"10650209990",  
"10650209991",  
"10650209992",  
"10650209993",  
"10650252000",  
"10650252001",  
"10650252002",  
"10650254000",  
"10650254001",  
"10650254002",  
"10650257000",  
"10650257001",  
"10650259000",  
"10650259001",  
"10650259002"  
]  
},
```

```
{
  "part_name": "Water Filter Cover WP12568001",
  "part_number": "PS11738541",
  "manufacturer": "Kenmore",
  "price": "60.79",
  "description": "This part is the replacement water filter cover for your refrigerator. It is made of white plastic and is approximately 13 inches long and 4 inches wide at the widest point. The water filter cover protects the water filter from damage while it is installed in the refrigerator. The main reason to replace the water filter cover is if it is cracked, damaged, or missing. This part is sold individually and is an OEM part sourced directly from the manufacturer.",
  "rating": "88",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WP12568001 replaces these: AP6005492, 12568001, 8171033 Back to Top",
  "review_count": "8",
  "appliance": "refrigerator",
  "compatible_models": [
    "10672002011",
    "10672002013",
    "10672002015",
    "10672003010",
    "10672003011",
    "10672003012",
    "10672003013",
    "10672003014",
    "10672003016",
    "10672003017",
    "10672003018",
```

```
"10672009010",
"10672009011",
"10672009013",
"10672009015",
"10672012010",
"10672013010",
"10672013017",
"10672019010",
"59650002100",
"59650003100",
"59650004100",
"59650009100",
"59650012100",
"59650013100",
"59650014100",
"59650019100",
"59651672100",
"59651673100",
"59651674100"
]
},
{
  "part_name": "Cap, Water Filter (White) WP2260518W",
  "part_number": "PS11739972",
  "manufacturer": "Kenmore",
  "price": "27.48",
```

"description": "This filter cap is white in color.",

"rating": "91",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WP2260518W replaces these: AP6006884, 2260502W, 2260518W, WP2260518WVP Back to Top",

"review_count": "26",

"appliance": "refrigerator",

"compatible_models": [

"10641522500",

"10641523500",

"10641524500",

"10641529500",

"10644022600",

"10644022601",

"10644022602",

"10644022603",

"10644023600",

"10644023601",

"10644023602",

"10644023603",

"10644024600",

"10644029600",

"10644029601",

"10644029602",

"10644029603",

"10644032600",

"10644032601",

```
"10644032602",  
"10644032603",  
"10644033600",  
"10644033601",  
"10644033602",  
"10644033603",  
"10644034600",  
"10644039600",  
"10644039601",  
"10644039602",  
"10644039603"
```

```
]
```

```
},
```

```
{
```

```
"part_name": "Water Filter Cover WP67006331",
```

```
"part_number": "PS11743682",
```

```
"manufacturer": "Kenmore",
```

```
"price": "71.88",
```

```
"description": "This part is the replacement water filter cover for your refrigerator. The cover protects the water filter to prevent damage. If the water filter cover is cracked or missing, you should replace it. It is made of white plastic and is approximately 12 inches long, 5 inches wide at one end, and 4 inches wide at the other. To replace the water filter cover, simply depress the locking tabs and remove the old cover, then snap the new cover into place. This part is sold individually.",
```

```
"rating": "99",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# WP67006331 replaces these: AP6010501, 12960301, 12960301N, 67006331 Back to Top",
```

```
"review_count": "12",  
"appliance": "refrigerator",  
"compatible_models": [  
  "596379243017",  
  "59677532600",  
  "59677532601",  
  "59677532602",  
  "59677532603",  
  "59677532700",  
  "59677532702",  
  "59677533600",  
  "59677533601",  
  "59677533602",  
  "59677533603",  
  "59677533700",  
  "59677533702",  
  "59677539600",  
  "59677539601",  
  "59677539602",  
  "59677539603",  
  "59677539700",  
  "59677539702",  
  "59678332800",  
  "59678332801",  
  "59678332802",  
  "59678333800",
```

"59678333801",

"59678333802",

"59678333803",

"59678339800",

"59678339801",

"59678339802",

"59678339803"

]

},

{

"part_name": "Drawer Slide Rail End Cap Set W11197396",

"part_number": "PS12578233",

"manufacturer": "Kenmore",

"price": "35.19",

"description": "This drawer slide rail cover is for refrigerators.\r\n\r\nDrawer slide rail cover is a decorative trim that covers the slide rail.\r\n\r\nWear work gloves to protect your hands when installing this part.",

"rating": "96",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# W11197396 replaces these: AP6333648, 13047701, 13047801, W10165883, W10166677, WPW10166677
Back to Top",

"review_count": "17",

"appliance": "refrigerator",

"compatible_models": [

"10672002011",

"10672002013",

"10672002015",
"10672003010",
"10672003011",
"10672003012",
"10672003013",
"10672003014",
"10672003016",
"10672003017",
"10672003018",
"10672009010",
"10672009011",
"10672009013",
"10672009015",
"596379243017",
"59672002013",
"59672002015",
"59672003012",
"59672003013",
"59672003014",
"59672003016",
"59672003017",
"59672003018",
"59672009013",
"59672009015",
"59678282800",
"59678282802",


```
"59678282803",  
"59678282900"  
]  
,  
{  
  "part_name": "COVER LED Assembly WR55X11132",  
  "part_number": "PS4704284",  
  "manufacturer": null,  
  "price": "34.24",  
  "description": "COVER LED Assembly FF",  
  "rating": "99",  
  "troubleshooting_tips": "This part fixes the following symptoms: Light not working This  
part works with the following products: Refrigerator, Range. Part# WR55X11132 replaces  
these: AP5646375 Back to Top",  
  "review_count": "11",  
  "appliance": "refrigerator",  
  "compatible_models": [  
    "CFE28TP2MBS1",  
    "CFE28TP2MCS1",  
    "CFE28TP2MDS1",  
    "CFE28TP2MES1",  
    "CFE28TP2MFS1",  
    "CFE28TP2MGS1",  
    "CFE28TP2MHS1",  
    "CFE28TP2MKS1",  
    "CFE28TP3MBD1",  
    "CFE28TP3MBW2",
```

"CFE28TP3MCD1",
"CFE28TP3MDD1",
"CFE28TP3MED1",
"CFE28TP3MFD1",
"CFE28TP3MHD1",
"CFE28TP3MJD1",
"CFE28TP3MKD1",
"CFE28TP4MBW2",
"CFE28TP4MCW2",
"CFE28TP4MDW2",
"CFE28TP4MEW2",
"CFE28TP4MFW2",
"CFE28TP4MHW2",
"CFE28TP4MJW2",
"CFE28TP4MKW2",
"CFE28TP4MLW2",
"CFE28TSHBSS",
"CFE28TSHCSS",
"CFE28TSHDSS",
"CFE28TSHESS"

]

},

{

"part_name": "Refrigerator Pantry Drawer Lid W10827914",
"part_number": "PS11723195",
"manufacturer": "Kenmore",

"price": "115.96",

"description": "This is an OEM front cover for the pantry door of various refrigerator models. This cover is designed as a door that can cover the pantry compartment within your refrigerator and provide a transparent view of what is inside it. If this door is cracked, moldy, or missing, it needs to be replaced. This pantry door is made of durable white plastic and features a transparent window in the middle. This measures approximately 26 inches wide and 6 inches deep, and can be replaced by simply dislodging its securing tabs on the left and right side, and then inserting the new one into those same tabs. This pantry drawer cover is sold individually.",

"rating": "96",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# W10827914 replaces these: AP5985815, 12656820, 12656823, W10165964 Back to Top",

"review_count": "68",

"appliance": "refrigerator",

"compatible_models": [

"10672002010",

"10672002011",

"10672002013",

"10672002015",

"10672003010",

"10672003011",

"10672003012",

"10672003013",

"10672003014",

"10672003016",

"10672003017",

"10672003018",

"10672009010",

"10672009011",
"10672009013",
"10672009015",
"596379243017",
"59672002010",
"59672002011",
"59672002013",
"59672002015",
"59672003010",
"59672003011",
"59672003012",
"59672003013",
"59672003014",
"59672003016",
"59672003017",
"59672003018",
"59672009010"

]

},

{

"part_name": "Refrigerator Crisper Drawer COVER 5304508067",

"part_number": "PS12071129",

"manufacturer": "Kenmore",

"price": "111.49",

"description": "This crisper drawer cover assembly is for refrigerators.\r\n\r\nThe crisper drawer cover assembly includes the crisper drawer cover frame and the insert that covers the drawer. The assembly may include multiple parts; refer to your parts diagram for a

complete list of parts included.\r\n\r\nWear work gloves to protect your hands when installing this part.\r\nDOES NOT COME WITH WHEEL, WHEEL ATTACHES TO SHELF. (ROLLER 5304508016)",

"rating": "96",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# 5304508067 replaces these: AP6230468, 5304508410, 5304519462 Back to Top",

"review_count": "14",

"appliance": "refrigerator",

"compatible_models": [

"2537034241E",

"2537034241F",

"2537034241H",

"2537034241J",

"2537034341F",

"2537034341G",

"2537034341H",

"2537034341J",

"25370347411",

"2537034941J",

"2537041341C",

"2537041341F",

"2537041341H",

"25370417412",

"2537041941C",

"2537041941D",

"CFD28SDQSA",

"CFD28WQBC",

"CFD28WQBF",

"CFD28WQSC",

"CFD28WQSE",

"CFD28WQWC",

"CFD28WQWE",

"CFD28WQWF",

"CFEH272ITD0",

"CFEH272ITD1",

"CFEH272ITS0",

"CFEH272ITS1",

"CFEH272ITW1",

"FFHB2750TD0"

]

},

{

"part_name": "Dual Water Valve WP67005154",

"part_number": "PS11743618",

"manufacturer": null,

"price": "103.27",

"description": "This part, when activated, releases water from the supply line into the ice mold. This water inlet valve is for refrigerators.\r\n\r\nWater inlet valve supplies water to the refrigerator ice maker and water dispenser.\r\n\r\nSafely store any food that could deteriorate while the power is off and unplug the refrigerator before installing this part. Wear work gloves to protect your hands.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Not dispensing water | Ice maker not making ice | Ice maker won't dispense ice This part works with the following products: Refrigerator. Part# WP67005154 replaces these: AP6010439, 67003818, 67005154, 8208153, 8208275, WP67005154VP Back to Top",

"review_count": "19",

"appliance": "refrigerator",

"compatible_models": [

"59655652500",

"59655653500",

"59655654500",

"59655659500",

"59655662500",

"59655663500",

"59655664500",

"59655669500",

"59657002600",

"59657003600",

"59657006600",

"59657009600",

"59675522400",

"59675523400",

"59675524400",

"59675529400",

"59675532400",

"59675533400",

"59675534400",

"59675539400",

```
"59676522500",
"59676523500",
"59676524500",
"59676529500",
"59676532500",
"59676533500",
"59676534500",
"59676539500",
"ABC2037DEB",
"ABC2037DEQ"
]
},
{
  "part_name": "Refrigerator Water Inlet Valve Assembly WPW10420083",
  "part_number": "PS11754529",
  "manufacturer": "Kenmore",
  "price": "138.12",
  "description": "This water inlet valve assembly is for refrigerators.\r\n\r\nWater inlet valve assembly supplies water to the ice maker and water dispenser in the refrigerator.\r\n\r\nSafely store any food that could deteriorate while the power is off and unplug the refrigerator before installing this part. Wear work gloves to protect your hands.",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making ice | Leaking | Not dispensing water This part works with the following products: Refrigerator. Part# WPW10420083 replaces these: AP6021208, W10420083 Back to Top",
  "review_count": "5",
  "appliance": "refrigerator",
```


"compatible_models": [

"10672002011",

"10672002013",

"10672002015",

"10672003012",

"10672003013",

"10672003014",

"10672003016",

"10672003017",

"10672003018",

"10672009011",

"10672009013",

"10672009015",

"10672013017",

"59672002011",

"59672002013",

"59672002015",

"59672003012",

"59672003013",

"59672003014",

"59672003016",

"59672003017",

"59672003018",

"59672009011",

"59672009013",

"59672009015",

```
"59672012012",
"59672012014",
"59672012016",
"59672013012",
"59672013013"
]
},
{
  "part_name": "Water Inlet Valve WPW10498976",
  "part_number": "PS11755667",
  "manufacturer": "Kenmore",
  "price": "109.51",
  "description": "",
  "rating": "94",
  "troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making ice | Leaking This part works with the following products: Refrigerator. Part# WPW10498976 replaces these: AP6022334, W10420082, W10498976 Back to Top",
  "review_count": "3",
  "appliance": "refrigerator",
  "compatible_models": [
    "596467934251",
    "596467934351",
    "596467934451",
    "596467934951",
    "59679222011",
    "59679222012",
    "59679222013",
```

"59679222014",
"59679223011",
"59679223012",
"59679223013",
"59679223014",
"59679223015",
"59679229011",
"59679229012",
"59679229013",
"59679229014",
"59679312510",
"59679312511",
"59679313510",
"59679313511",
"59679319510",
"59679342510",
"59679343510",
"59679344510",
"59679349510",
"59679422410",
"59679422411",
"59679423410",
"59679423411"

]

},

{

"part_name": "Water Inlet Valve Assembly AJU72992601",

"part_number": "PS3533117",

"manufacturer": "LG",

"price": "123.71",

"description": "This includes the primary and secondary valves along with the wire harness.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Not dispensing water | Ice maker not making ice This part works with the following products: Refrigerator, Freezer. Part# AJU72992601 replaces these: AP4671476, 5221JA2011J, 5221JA2011P, AJU72992606, EBD60664501 Back to Top",

"review_count": "15",

"appliance": "refrigerator",

"compatible_models": [

"1867",

"48231784412",

"70322",

"70323",

"70329",

"70332",

"70333",

"70339",

"70355",

"70357",

"71022",

"71024",

"71026",

```
"71029",  
"71032",  
"71033",  
"71036",  
"71039",  
"71052",  
"71053",  
"71054",  
"71056",  
"71059",  
"71062",  
"71063",  
"71069",  
"71072",  
"71073",  
"71079",  
"71082"
```

```
]
```

```
},
```

```
{
```

```
"part_name": "Refrigerator Single Water Inlet Valve WP2315576",
```

```
"part_number": "PS11740365",
```

```
"manufacturer": "Kenmore",
```

```
"price": "71.41",
```

```
"description": "The single water inlet valve, also known as a water solenoid valve, is used  
for refrigerators. This part is a solenoid-operated switch that releases water from the supply  
line to the water valve and into the icemaker mold when activated. If your icemaker is
```

making small cubes, does not dispense ice or water, or leaks, this replacement could solve the issue. The tools needed for this repair are a 1/4 inch nut driver and a utility knife. Refer to the diagram provided by the manufacturer for further instructions. As a safety precaution, remember to unplug your dryer from the power source.",

"rating": "92",

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making ice | Leaking | Ice maker won't dispense ice | Not dispensing water This part works with the following products: Refrigerator, Ice Maker. Part# WP2315576 replaces these: AP6007253, 12213901, 2001318, 2155063, 2171999, 2181702, 2181704, 2181915, 2181917, 2182104, 2188782, 2210436, 2210494, 2315508, 2315576, W10219716, W10498974, WP2315576VP, WPW10219716 Back to Top",

"review_count": "24",

"appliance": "refrigerator",

"compatible_models": [

"1062155184",

"10647021790",

"10647021791",

"10647022790",

"10647022791",

"10647028790",

"10647028791",

"10657021790",

"10657021791",

"10657022790",

"10657022791",

"10657028790",

"10657028791",

"10660162990",

"10660167990",
"10660172990",
"10660177990",
"10660182000",
"10660182001",
"10660184001",
"10660187000",
"10660192000",
"10660192001",
"10660194001",
"10660197000",
"10660262990",
"10660262991",
"10660264991",
"10660267990",
"10660272990"

]

},

{

"part_name": "Water Inlet Valve W10865826",

"part_number": "PS11738056",

"manufacturer": "Kenmore",

"price": "72.40",

"description": "This OEM, 120V, 60 HZ water inlet valve is specially designed for refrigerators. It is responsible for regulating the flow of water into the water dispenser and ice maker of the fridge. If your refrigerator is leaking or it is unable to dispense water, the water inlet valve may be damaged or experiencing electrical failure. It will need to be

replaced to restore the functionality of the appliance. You can find the valve at the back of the refrigerator where it is connected to the water supply line.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Not dispensing water This part works with the following products: Refrigerator. Part# W10865826 replaces these: AP6026312, W10394076, W10726788, W10833705, W10872966, WPW10394076
Back to Top",

"review_count": "13",

"appliance": "refrigerator",

"compatible_models": [

"59672382410",

"596723824102",

"59672382411",

"59672382413",

"59672383410",

"596723834102",

"59672383411",

"59672383412",

"59672383413",

"59672389410",

"59672389411",

"59672389412",

"59672389413",

"7MF2976AEM00",

"7MF2976AEM01",

"7MF2976AEM02",

"7MF2976AEM03",


```
"7WF736SDAM10",
"7WF736SDAM11",
"7WF736SDAM12",
"7WF736SDAM13",
"7WF736SDAM14",
"IX7DDEXDSM00",
"IX7DDEXDSM01",
"IX7DDEXDSM02",
"JFFCC72EFP00",
"JFFCC72EFS00",
"JFX2897DRM00",
"JFX2897DRM01",
"JFX2897DRM02"
]
},
{
  "part_name": "Water Inlet Valve - 4 Coil 242253002",
  "part_number": "PS7321353",
  "manufacturer": "Kenmore",
  "price": "153.46",
  "description": "The water inlet valve supplies water to the refrigerator ice maker and water dispenser.\r\n\r\nThis part works with the following brands: Frigidaire, White Westinghouse, Kelvinator, Gibson, Kenmore, Sears, Tappan, & Electrolux.\r\n\r\nPossible Repair Solution For:\r\nLeaking water, water will not dispense, ice maker does not make ice, ice maker does not dispense ice.\r\n\r\nThis is an authentic water inlet valve (4 coil), which works with refrigerators.",
  "rating": "92",
```

"troubleshooting_tips": "This part fixes the following symptoms: Not dispensing water | Ice maker not making ice | Leaking This part works with the following products: Refrigerator. Part# 242253002 replaces these: AP5669874, 242102201 Back to Top",

"review_count": "5",

"appliance": "refrigerator",

"compatible_models": [

"20462151B",

"25370312211",

"25370313210",

"25370313211",

"25370319211",

"2537034241E",

"2537034241F",

"2537034241H",

"2537034241J",

"2537034341F",

"2537034341G",

"2537034341H",

"2537034341J",

"25370347411",

"2537034941J",

"2537044341A",

"2537044341C",

"2537044341D",

"2537044341E",

"25370447411",

"90462157B",

"CFD26WIS0",
"CFD26WIS1",
"CFD26WIS3",
"CFD26WIS4",
"CFD26WIS5",
"CFD26WIS6",
"CFD27WIPB2",
"CFD27WIPB3",
"CFD27WIPS2"

]

},

{

"part_name": "Water Inlet Valve 242252603",

"part_number": "PS7784017",

"manufacturer": "Kenmore",

"price": "60.68",

"description": "If you notice that the ice maker in your refrigerator is leaking or is not making or dispensing ice, you may need to replace the water inlet valve. When energized, the water inlet valve releases water from the supply line into the ice mold. The water inlet valve is in the back of your refrigerator so you will need to pull the fridge out from the wall before completing this repair. To complete this job, you will need a 1/2 inch wrench, a 1/4 inch nut driver and a utility knife. If your old inlet valve has a screw-in fitting, you may need to simply cut the end of the hose to fit in the new part. Be sure to disconnect both the water and power supply from the refrigerator prior to beginning this repair.",

"rating": "88",

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker not making ice | Leaking | Ice maker won't dispense ice | Not dispensing water This part works with the following products: Refrigerator, Freezer. Part# 242252603 replaces these: AP5671756,

2705494, 242252603, 218475600, 218720400, 240380301, 240519601, 241803701,
241803703, 5303289068, 5303304971, 7240519601, 7241803701 [Back to Top](#)",

"review_count": "20",

"appliance": "refrigerator",

"compatible_models": [

"25326092100",

"25326092101",

"25326093100",

"25331133300",

"25331133303",

"25331133306",

"25331135300",

"25331135303",

"25331143300",

"25331143303",

"25331145300",

"25331440300",

"25331440301",

"25331440302",

"25331442300",

"25331442301",

"25331442302",

"25331444300",

"25331444301",

"25331444302",

"25331444303",

"25331447300",
"25331447301",
"25331447302",
"25331670105",
"25331670106",
"25331672100",
"25331672101",
"25331672102",
"25331672103"

]

},

{

"part_name": "Water Inlet Valve W10408179",

"part_number": "PS3497634",

"manufacturer": "Kenmore",

"price": "90.52",

"description": "The water inlet valve (Refrigerator Water Inlet Valve Kit) provides water for the ice maker and water dispenser. This part is located at the back of the refrigerator, and connects to the water supply. If your water inlet valve is malfunctioning, you could be getting a lack of water to the inside of your refrigerator. Your ice maker may not produce cubes or your water dispenser may not work. This breakage can occur from material fatigue or normal use, and is a sign the part should be replaced soon. The water inlet valve must be replaced if the solenoids no longer have continuity or the valve has internal blockage. The part measures approximately 6.5 inches long and 3 inches wide and is constructed of plastic and metal. It comes in blue/green/red.",

"rating": "95",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Ice maker not making ice | Not dispensing water | Ice maker won't dispense ice This part works with the following products: Refrigerator. Part# W10408179 replaces these: AP5263471, 1938614,

W10408179, 2186486, 2188622, 2188708, 2188746, 2205762, 2255457, 2304757,
2304833, 2315534, 4389177, W10408179VP Back to Top",

"review_count": "79",

"appliance": "refrigerator",

"compatible_models": [

"10650202990",

"10650202991",

"10650202992",

"10650202993",

"10650203990",

"10650203991",

"10650203992",

"10650203993",

"10650204990",

"10650204991",

"10650204992",

"10650204993",

"10650209990",

"10650209991",

"10650209992",

"10650209993",

"10650222010",

"10650223010",

"10650228010",

"10650229010",

"10650252000",

```
"10650252001",
"10650252002",
"10650254000",
"10650254001",
"10650254002",
"10650257000",
"10650257001",
"10650259000",
"10650259001"
]
},
{
  "part_name": "Ice Funnel WR17X11267",
  "part_number": "PS652226",
  "manufacturer": "Kenmore",
  "price": "41.00",
  "description": "This paddle, when your glass is pushed against it, activates the dispenser to release the ice through the funnel.",
  "rating": "96",
  "troubleshooting_tips": "This part fixes the following symptoms: Not dispensing water | Ice maker won't dispense ice This part works with the following products: Refrigerator. Part# WR17X11267 replaces these: AP3192458, 947252, WR17X11267, WR17X10743, WR17X11148, WR17X11277 Back to Top",
  "review_count": "25",
  "appliance": "refrigerator",
  "compatible_models": [
    "A4425GDTABB",
```

"A4425GDTBBB",
"BSS25JSRFSS",
"BSS25JSRJSS",
"BSS25JSTASS",
"BSS25JSTBSS",
"BSS25JSTCSS",
"BSS25JSTDSS",
"BSS25JSTECS",
"BSS25JSTGSS",
"BSS25JSTHSS",
"BSS25JSTISS",
"BSS25JSTJSS",
"BSS25JSTNSS",
"BSS25JSTPSS",
"BSS25JSTRSS",
"DSS25KGRABB",
"DSS25KGRBBB",
"DSS25KGRCBB",
"DSS25KSRASS",
"DSS25KSRBSS",
"DSS25KSRCSS",
"DSS25LGPABB",
"DSS25LSPABS",
"ESH25LGRABB",
"ESH22JFWABB",
"ESH22JFWBBB",

"ESH22JFWCBB",

"ESH22JFWDBB",

"ESH22JFWEBB"

]

},

{

"part_name": "Dispenser Drip Tray WR17X12910",

"part_number": "PS3487867",

"manufacturer": null,

"price": "11.62",

"description": "This is a recessed grille made for refrigerators. This grille is used to collect any pooled water or melted ice from your water and ice dispenser. If this grille is cracked, stained, or warped in any way, and no longer fit to serve its purpose, it needs to be replaced. This grille is made of gray plastic and is easy to replace; simply pull up on the old grille with your hand, and slide in the new one. This grille is an OEM part and is sold individually.",

"rating": "98",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WR17X12910 replaces these: AP4926309 Back to Top",

"review_count": "8",

"appliance": "refrigerator",

"compatible_models": [

"DSE25JGHKCBB",

"DSE25JMHKCES",

"DSE25JSHBCSS",

"DSE25JSHECSS",

"DSE25JSHKCSS",

"DSE26JSEBCSS",

"DSE26JSECCSS",
"DSE26JSEDCSS",
"DSHS6VGBBCSS",
"GSE25GSHBCSS",
"GSE25GSHECCSS",
"GSE25GSHHCSS",
"GSE25GSHJCSS",
"GSE25GSHKCSS",
"GSE25GSHMCSS",
"GSE25GSHNCSS",
"GSE25GSHRCSS",
"GSE25HSHBHSS",
"GSE25HSHEHSS",
"GSE25HSHJHSS",
"GSE25HSHKHSS",
"GSE26GSEBCSS",
"GSE26GSECCSS",
"GSE26GSEDCSS",
"GSE26HSEBHSS",
"GSE26HSECHSS",
"GSE26HSEDHSS",
"GSHS6HGDBCSS",
"GSHS6HGDCCSS",
"GSHS6HGDDCSS"

]

},

```
{
  "part_name": "Ice Dispenser Door Chute WP2180353",
  "part_number": "PS11739035",
  "manufacturer": "Kenmore",
  "price": "15.93",
  "description": "*Please note, this door chute is no longer being manufactured with a heater.",
  "rating": "98",
  "troubleshooting_tips": "This part fixes the following symptoms: Ice maker won't dispense ice | Leaking | Door Sweating | Frost buildup This part works with the following products: Refrigerator. Part# WP2180353 replaces these: AP6005973, 2157651, 2167269, 2177296, 2179993, 2180351, 2180352, 2180353, 2203886, 2252076, 2261464, WP2180353VP Back to Top",
  "review_count": "7",
  "appliance": "refrigerator",
  "compatible_models": [
    "10641522500",
    "10641523500",
    "10641524500",
    "10641529500",
    "10644022600",
    "10644022601",
    "10644022602",
    "10644022603",
    "10644023600",
    "10644023601",
    "10644023602",
```

```
"10644023603",
"10644024600",
"10644029600",
"10644029601",
"10644029602",
"10644029603",
"10644032600",
"10644032601",
"10644032602",
"10644032603",
"10644033600",
"10644033601",
"10644033602",
"10644033603",
"10644034600",
"10644039600",
"10644039601",
"10644039602",
"10644039603"
]
},
{
  "part_name": "Dispenser Funnel Guide 242270102",
  "part_number": "PS8746715",
  "manufacturer": "Kenmore",
  "price": "185.89",
```

"description": "This dispenser module is for refrigerators.\r\n\r\nDispenser module attaches in the dispenser housing on the freezer door and includes the cradle, ice chute and ice chute door.\r\n\r\nSafely store any food that could deteriorate while the power is off. Unplug the refrigerator before installing this part. Wear work gloves to protect your hands.",

"rating": "94",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 242270102 replaces these: AP5788338 Back to Top",

"review_count": "9",

"appliance": "refrigerator",

"compatible_models": [

"2537034241J",

"2537034341J",

"2537034941J",

"CFD27WIPB2",

"CFD27WIPB3",

"CFD27WIPS2",

"CFD27WIPS3",

"CFD27WIPW2",

"CFD27WIPW3",

"CFD28WIQB0",

"CFD28WIQB1",

"CFD28WIQB6",

"CFD28WIQB8",

"CFD28WIQB9",

"CFD28WIQBA",

"CFD28WIQS0",

"CFD28WIQS1",
"CFD28WIQS6",
"CFD28WIQS8",
"CFD28WIQS9",
"CFD28WIQSA",
"CFD28WIQW0",
"CFD28WIQW1",
"CFD28WIQW6",
"CFD28WIQW8",
"CFD28WIQW9",
"CFD28WIQWA",
"DGHF2360PF0",
"DGHF2360PF1",
"DGHF2360PF2A"

]

},

{

"part_name": "Water Dispenser Actuator 241685703",

"part_number": "PS1526418",

"manufacturer": "Kenmore",

"price": "112.38",

"description": "Once a glass is pressed against the actuator pad it will cause the dispenser to deliver ice or water when activated.",

"rating": "98",

"troubleshooting_tips": "This part fixes the following symptoms: Not dispensing water
This part works with the following products: Refrigerator. Part# 241685703 replaces these:
AP3963432, 1195920, 241685703, 5304433613 Back to Top",

```
"review_count": "18",  
"appliance": "refrigerator",  
"compatible_models": [  
  "25344309400",  
  "25344309401",  
  "25344382402",  
  "25344383402",  
  "25344384402",  
  "25344389400",  
  "25344389402",  
  "25344389403",  
  "25344389405",  
  "25344389406",  
  "25344389407",  
  "2534438940B",  
  "25344399400",  
  "25344399402",  
  "25344399403",  
  "25344399404",  
  "25344399405",  
  "25344399407",  
  "25354363400",  
  "25354363401",  
  "25354363402",  
  "25354363403",  
  "25354363404",
```

```
"25354363405",
"25354363409",
"2535436340A",
"2535436340B",
"2535436340N",
"2535436340P",
"25354369400"
]
},
{
  "part_name": "Refrigerator Dispenser Overflow Grille WP2206670B",
  "part_number": "PS11739623",
  "manufacturer": "Kenmore",
  "price": "42.79",
  "description": "This grille is located on the bottom of the ice/water dispenser to catch the overflow. (Black)",
  "rating": "99",
  "troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works with the following products: Refrigerator. Part# WP2206670B replaces these: AP6006547, 2206670B, W10171993, W10189532, W10323446, WP2206670BVP Back to Top",
  "review_count": "21",
  "appliance": "refrigerator",
  "compatible_models": [
    "10641522500",
    "10641523500",
    "10641524500",
    "10641529500",
```


"10644022602",
"10644023600",
"10644024600",
"10644029601",
"10644029602",
"10644029603",
"10644032602",
"10644033600",
"10644034600",
"10644039603",
"10644322400",
"10644323400",
"10644324400",
"10644329400",
"10644422600",
"10644422601",
"10644422602",
"10644423601",
"10644424600",
"10644424601",
"10644424602",
"10644429601",
"10644429603",
"10644432601",
"10644432602",
"10644433603"

```
]
},
{
  "part_name": "Water Dispenser Actuator 241682003",
  "part_number": "PS1526383",
  "manufacturer": "Kenmore",
  "price": "49.51",
  "description": "Once a glass is pressed against the actuator pad it will cause the dispenser to deliver ice or water when activated.",
  "rating": "97",
  "troubleshooting_tips": "This part fixes the following symptoms: Not dispensing water | Leaking This part works with the following products: Refrigerator. Part# 241682003 replaces these: AP3965193, 1196652, 241682003, 5304422026 Back to Top",
  "review_count": "17",
  "appliance": "refrigerator",
  "compatible_models": [
    "25354703400",
    "25354703401",
    "25354703402",
    "25354703403",
    "25354703404",
    "25354703405",
    "25354703406",
    "25354703407",
    "25354703408",
    "25354703409",
    "2535470340A",
```

```
"25354713500",  
"25354713502",  
"25356943600",  
"25356953600",  
"33346",  
"33346-1",  
"BFHS2611LM0",  
"BFHS2611LM1",  
"BFHS2611LM2",  
"CRSE234FB0",  
"CRSE234FB1",  
"CRSE234FB2",  
"CRSE234FB3",  
"CRSE234FB4",  
"CRSE234FSM0",  
"CRSE234FSM1",  
"CRSE234FSM2",  
"CRSE234FSM3",  
"CRSE234FSM4"  
]  
,  
{  
  "part_name": "Dispenser Door Assembly or Flapper WR17X11653",  
  "part_number": "PS964304",  
  "manufacturer": "Kenmore",  
  "price": "15.57",
```

"description": "This “Dispenser Door Assembly” (Door Recess Assembly, Ice Door Assembly, Dispenser Door, Refrigerator Dispenser Ice Chute Door Kit, Dispenser Door Flap, Ice Chute Door, Flapper) keeps the room air from infiltrating the freezer. Once the lever is pressed, the door flap opens and allows the ice to dispense into your container. If your door flapper is broken, it could allow outside air to enter the freezer and alter the inside temperature. You may notice frost buildup surrounding the dispenser area. The door flap can disconnect from the dispenser lever, or the tabs that hold it in place may break. Frequent use may distort the sealing face and cause air leaks and frost buildup. This part mounts in the ice dispenser, and measures approximately 3.25 inches in diameter. It is constructed of plastic and rubber, and comes in white/black. This part is sold individually.",

"rating": "94",

"troubleshooting_tips": "This part fixes the following symptoms: Door Sweating | Ice maker won't dispense ice | Frost buildup | Leaking This part works with the following products: Refrigerator. Part# WR17X11653 replaces these: AP3672582, 1032671, WR17X11653, WR17X3093, WR17X3492 Back to Top",

"review_count": "88",

"appliance": "refrigerator",

"compatible_models": [

"36350221000",

"36350222000",

"36350227000",

"36350232000",

"36350237000",

"36350242000",

"36350247000",

"36350622000",

"36350627000",

"36357552790",

"36357552791",

"36357557790",

```
"36357557791",  
"36358062890",  
"36358062891",  
"36358062892",  
"36358062893",  
"36358062894",  
"36358062896",  
"36358062897",  
"36358067890",  
"36358067891",  
"36358067892",  
"36358067893",  
"36358067894",  
"36358067897",  
"36358072891",  
"36358072892",  
"36358072893",  
"36358072894"  
]  
,  
{  
  "part_name": "Dispenser Door Solenoid Assembly WR62X10055",  
  "part_number": "PS1483583",  
  "manufacturer": "Kenmore",  
  "price": "64.68",
```

"description": "This part is a possible option when ice door won't open or shut properly or when water is not dispensing.",

"rating": "96",

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker won't dispense ice | Not dispensing water | Door won't open or close | Door Sweating This part works with the following products: Refrigerator. Part# WR62X10055 replaces these: AP3963333, 1194707, WR62X10055, 203C6017G001, WR62X10020 Back to Top",

"review_count": "33",

"appliance": "refrigerator",

"compatible_models": [

"39631UGTAWW",

"39631UGXAWW",

"39639USTAGV",

"39639USXAGV",

"A4425GDTABB",

"A4425GDTAWW",

"A4425GDTBBB",

"A4425GDTBWW",

"A4425GDTW",

"BSS25GFPACC",

"BSS25GFPAWW",

"BSS25GFPCCC",

"BSS25GFPCWW",

"BSS25GFPDCC",

"BSS25GFPDWW",

"BSS25GFPECC",

"BSS25GFPEWW",

```
"BSS25GFPHCC",
"BSS25GFPHWW",
"BSS25JFRFWW",
"BSS25JFRJWW",
"BSS25JFTAWW",
"BSS25JFTBWW",
"BSS25JFTCWW",
"BSS25JFTDWW",
"BSS25JFTEWW",
"BSS25JFTGWW",
"BSS25JFTHWW",
"BSS25JFTIWW",
"BSS25JFTJWW"
]
},
{
  "part_name": "Ice Guide WP2180224",
  "part_number": "PS11739026",
  "manufacturer": "Kenmore",
  "price": "19.45",
  "description": "This is a refrigerator ice guide that is made entirely of clear plastic. This ice guide is located in the freezer door. Turn your refrigerator ice dispenser off before replacing the part. This is a simple repair, and the only tool you will need is a small flat blade screwdriver to push on the pivot tab on the bottom of the ice guide. Do not worry about breaking the side or pivot tabs on your existing ice guide because it will be discarded anyway. This is a genuine manufacturer replacement part.",
  "rating": "95",
```

"troubleshooting_tips": "This part fixes the following symptoms: Ice maker won't dispense ice | Ice maker dispenses too much ice | Leaking | Door Sweating This part works with the following products: Refrigerator. Part# WP2180224 replaces these: AP6005964, 2180224, WP2180224VP Back to Top",

"review_count": "60",

"appliance": "refrigerator",

"compatible_models": [

"10641522500",

"10641523500",

"10641524500",

"10641529500",

"10644102300",

"10644103300",

"10644109300",

"10644322400",

"10644323400",

"10644324400",

"10644329400",

"10650022000",

"10650022004",

"10650027001",

"10650027002",

"10650027003",

"10650027004",

"10650032000",

"10650032003",

"10650032004",

"10650037000",

"10650037001",

"10650037004",

"10650202992",

"10650202993",

"10650203993",

"10650212010",

"10650222010",

"10650223010",

"10650228010"

]

},

{

"part_name": "Door Closure Cam Kit R0181181",

"part_number": "PS2168612",

"manufacturer": "Kenmore",

"price": "11.09",

"description": "This door closing cam kit is intended for use on the bottom of your refrigerator and freezer door hinges. The cam helps close the doors and to lifts them slightly when opened. If your door will not open or close, or will not stay closed, there could be an issue with the door close cam. Other common symptoms associated with the door close cam are: the door is sweating, the fridge is too warm, or a clicking sound can be heard coming from the door. If your refrigerator has an ice and water dispenser, you will need to disconnect the power and water to the unit before you begin the repair.",

"rating": "84",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close | Clicking sound | Door Sweating | Fridge too warm This part works with the following products: Refrigerator. Part# R0181181 replaces these: AP4247867, 1035, 0057151, 0057153, 0312511, 0312526, 0312527, 12113201, 12113202, 12113203, 12113204,

12113402, 12113501, 12113502, 12431301, 12431302, 4343794, 4343795, 4343938, 4343939 ... Show more , 4343940, 4343941, 8170336, 8170337, 8170673, 8170692, D7748301, D7748302, D7751401, D7751402, D7751403, D7751404, D7833202, R0181180, R0181181, R0950075, R0950149, Y0057151, Y0057153, Y0312511, Y0312526, Y0312527 Show less Back to Top",

"review_count": "17",

"appliance": "refrigerator",

"compatible_models": [

"1999A",

"1999A-P1193906WL",

"1999CIWA",

"1999CIWEA",

"1999CIWEL-P1171101WL",

"1999CIWEW",

"1999CIWEW-P1171101WW",

"1999CIWL-P1121502WL",

"1999CIWW",

"1999CIWW-P1121502WW",

"1999W",

"1999W-P1193906WW",

"2599A",

"2599A-P1190419WL",

"2599CIWA",

"2599CIWEA",

"2599CIWEA-P1170601WL",

"2599CIWEL-P1170601WL",

"2599CIWEW",

"2599CIWEW-P1170601WW",

"2599CIWL-P1121501WL",

"2599CIWW",

"2599CIWW-P1121501WW",

"2599W",

"2599W-P1190419WW",

"2699A",

"2699W",

"35271",

"35271-P1121805W",

"35271W-P1121805WW"

]

},

{

"part_name": "Door Shelf Retainer Bar End Cap WR2X9162",

"part_number": "PS299579",

"manufacturer": "Kenmore",

"price": "22.24",

"description": "This is a replacement shelf bar end cap. The end cap connects to the shelf bar on either side, and then snaps into position on the freezer door. This will allow you to store items in the freezer door. It is a little more than 2 inches long and is made of white plastic. To replace the end cap, you can simply depress the locking tab and remove the entire bar and end cap assembly. Then, use a flat blade screwdriver to depress the locking tab, and the endcap will detach. Finally, snap the new end cap locking tabs into place, and snap the bar assembly back onto the freezer door. This product is sold individually.",

"rating": "60",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WR2X9162 replaces these: AP2060713, 299265, WR02X7671, WR02X8413, WR02X9162, WR2X7671, WR2X8413 Back to Top",

"review_count": "5",

"appliance": "refrigerator",

"compatible_models": [

"31181-1",

"31341-1",

"31880",

"36011-1",

"36017-1",

"36018-1",

"36021-1",

"36130-1",

"36130-5",

"36211XBMBRWW",

"36211XBMDRWW",

"36211XBMERWW",

"36211XBMFRWW",

"36211XBRERWW",

"36211XBRFRWW",

"36221-1",

"36300-1",

"36310-1",

"36311-1",

"36370-1",

"36371-1",

"36380-1",

"36388-1",

"3639748514",

"3639748584",

"36411XBRERWW",

"36411XBRFRWW",

"36490-1",

"36530-1",

"36530-5"

]

},

{

"part_name": "Door Closing Cam WR2X4901",

"part_number": "PS297995",

"manufacturer": "Kenmore",

"price": "25.43",

"description": "This single door closure cam is mounted on the door, not the hinge.",

"rating": "93",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close | Door Sweating | Fridge too warm | Fridge runs too long This part works with the following products: Refrigerator. Part# WR2X4901 replaces these: AP2058495, 2310, WR2X4901, SWR02X4901, SWR2X4901, WR02X4901 Back to Top",

"review_count": "18",

"appliance": "refrigerator",

"compatible_models": [

"36348042890",

"36348042891",

"36348047890",
"36348047891",
"36348252890",
"36348252891",
"36348257890",
"36348257891",
"36358042890",
"36358042891",
"36358047890",
"36358047891",
"36358062890",
"36358062891",
"36358067890",
"36358067891",
"36358251890",
"36358251891",
"36358252890",
"36358252891",
"36358257890",
"36358257891",
"36358272890",
"36358272891",
"36358275890",
"36358275891",
"36358277890",
"36358277891",

```
"3638400410",
"3638400411"
]
},
{
  "part_name": "Refrigerator Vertical Mullion Rail - Black WP12722803B",
  "part_number": "PS11738596",
  "manufacturer": "Kenmore",
  "price": "166.63",
  "description": "Commonly referred to as the flapper assembly, the door mullion is an important part of a double, or triple door refrigerator.",
  "rating": "100",
  "troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# WP12722803B replaces these: AP6005547, 12722803B, 12722803BKV, 12722803BN, 12732501B, 67003264, 67004131, 8208250 Back to Top",
  "review_count": "18",
  "appliance": "refrigerator",
  "compatible_models": [
    "10672002010",
    "10672002011",
    "10672002013",
    "10672002015",
    "10672003010",
    "10672009010",
    "10672009011",
    "10672009013",
```

"10672009015",
"10672012010",
"10672013010",
"10672019010",
"10678586800",
"59672002010",
"59672002011",
"59672002013",
"59672002015",
"59672003010",
"59672009010",
"59672009011",
"59672009013",
"59672009015",
"59672012010",
"59672012011",
"59672012012",
"59672012014",
"59672012016",
"59672013010",
"59672013011",
"59672013012"

]

},

{

"part_name": "Dairy Door WR22X10068",

"part_number": "PS2354645",

"manufacturer": null,

"price": "32.37",

"description": "This is the replacement dairy door for your refrigerator. It is made of clear plastic and is approximately 11 inches wide and 5.5 inches long. The dairy door connects to the shelf and it can be raised and lowered to access the interior of the shelf. The main reason you would want to replace the dairy door is if your old door is cracked or missing. This part is sold individually and is an OEM part sourced directly from the manufacturer.",

"rating": "90",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WR22X10068 replaces these: AP4413136, WR22X0414, WR22X0415, WR22X0503, WR22X414, WR22X415, WR22X503 Back to Top",

"review_count": "15",

"appliance": "refrigerator",

"compatible_models": [

"36211XBMBRWW",

"36211XBMDRWW",

"36211XBMERWW",

"36211XBMFRWW",

"36211XBRERWW",

"36211XBRFRWW",

"36411XBRERWW",

"36411XBRFRWW",

"37511KBSARWW",

"37511KBSERWW",

"38341FBMERWW",

"38341FBMFRWW",

"38351HBMERWW",

```
"38351HBMFRWW",
"38351HBRERWW",
"38351HBRFRWW",
"38451HBRERWW",
"38451HBRFRWW",
"CTG16EAABRWH",
"CTG16EAACRWH",
"CTG16EABDRWH",
"CTG16EACBRWW",
"CTG16EACCRWW",
"CTG16GACBRWW",
"CTG16GACCRWW",
"CTH17RBT2RWW",
"CTH17RBTZRWW",
"CTS17RBSARWW",
"CTS17RBSBRWW",
"CTS17RBSDRWW"
]
},
{
  "part_name": "Dairy Door 240326203",
  "part_number": "PS429785",
  "manufacturer": "Kenmore",
  "price": "38.96",
  "description": "",
  "rating": "100",
```

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 240326203 replaces these: AP2115795, 890990, 240326206, 240326207, 240326208, 240326209, 240326210, 240326211, 240326212, 240326213, 240326214, 240326215
Back to Top",

"review_count": "3",

"appliance": "refrigerator",

"compatible_models": [

"25351622100",

"25351622101",

"25351622102",

"25351622103",

"25351622104",

"25351624100",

"25351624101",

"25351624102",

"25351624103",

"25351624104",

"25351692100",

"25351692101",

"25351692102",

"25351692103",

"25351692104",

"25351692105",

"25351693100",

"25351693101",

"25351693102",

"25351693103",

"25351693104",

"25351693105",

"25351693106",

"25351694100",

"25351694101",

"25351694102",

"25351694103",

"25351694104",

"25351694105",

"25351699100"

]

},

{

"part_name": "Complete Dairy Compartment Door - Clear WP2256101",

"part_number": "PS11739923",

"manufacturer": "Kenmore",

"price": "58.29",

"description": "This is a replacement dairy compartment door for your refrigerator. The dairy compartment door opens and closes to allow access to the dairy items stored in the refrigerator door. Because it is made of clear plastic, the door can occasionally become cracked and broken. When the door is cracked, it will need to be replaced. The door measures approximately 15 inches in length and 6 inches in width. To replace the door, carefully remove the old door and insert the new door, lipped edge down. This product is sold individually and is OEM part from the manufacturer.",

"rating": "85",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WP2256101 replaces these: AP6006837, 2156058, 2156065, 2162903, 2164027, 2169662, 2170757, 2170947, 2170967, 2173171, 2177105, 2182780, 2256101, 2308042, PETBT41DG Back to Top",

```
"review_count": "9",  
"appliance": "refrigerator",  
"compatible_models": [  
  "10640212010",  
  "10640212011",  
  "10640262010",  
  "10640263010",  
  "10640263011",  
  "10640269010",  
  "10640562010",  
  "10640563010",  
  "10640563011",  
  "10640569010",  
  "10640569011",  
  "10641012100",  
  "10641012101",  
  "10641012104",  
  "10641014100",  
  "10641014101",  
  "10641014104",  
  "10641122210",  
  "10641122211",  
  "10641122212",  
  "10641122213",  
  "10641123210",  
  "10641123211",
```

```
"10641123212",
"10641124210",
"10641129210",
"10641129211",
"10641129212",
"10641129213",
"10641132710"
]
},
{
  "part_name": "Retainer Bar End Cap - Left or Right Side WR2X9144",
  "part_number": "PS299562",
  "manufacturer": null,
  "price": "32.80",
  "description": "Sold individually.",
  "rating": "100",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#
WR2X9144 replaces these: AP2060697, 2392, WR2X9144, WR02X8776, WR02X9144,
WR2X8776 Back to Top",
  "review_count": "11",
  "appliance": "refrigerator",
  "compatible_models": [
    "1993LPO",
    "36211XBMBRWW",
    "36211XBMDRWW",
    "36211XBMERWW",
    "36211XBMFRWW",
```

"36211XBRERWW",
"36211XBRFRWW",
"36411XBRERWW",
"36411XBRFRWW",
"A3315ABRERWW",
"A3315ABRFRWW",
"A3315ABRW",
"A3317ABRERWW",
"A3317ABRFRWW",
"A3317ABRW",
"CTE14CYTBRWH",
"CTE14CYTDRWH",
"CTE14CYTJRWH",
"CTE16CYTBRWH",
"CTE16CYTDRWH",
"CTH14CYBELAA",
"CTH14CYBELWW",
"CTH14CYBERAA",
"CTH14CYBERWW",
"CTH14CYBLLAA",
"CTH14CYBLLWW",
"CTH14CYBLRAA",
"CTH14CYBLRWW",
"CTH14CYBRLAA",
"CTH14CYBRLWW"

]

```
},
```

```
{
```

```
"part_name": "Dairy Door - Clear 240337712",
```

```
"part_number": "PS1525960",
```

```
"manufacturer": "Kenmore",
```

```
"price": "68.34",
```

```
"description": "This is a dairy door for your refrigerator. This part covers the products in the dairy bin section. To access this section, simply lift the lid. This dairy door is made entirely of plastic and is transparent. It is almost 10 inches wide, and roughly 6 inches long. In order to make this repair you will not need any tools, as this part will easily clip in and out of place of the hinged holes.",
```

```
"rating": "98",
```

```
"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 240337712 replaces these: AP3959552, 1194855, 240337703, 240337704, 240337707, 240337708, 240337711, 240337713, 240337714, 240337715, 240337716, 240337717, 240337718, 240337719, 240337720 Back to Top",
```

```
"review_count": "7",
```

```
"appliance": "refrigerator",
```

```
"compatible_models": [
```

```
"25331113300",
```

```
"25331113302",
```

```
"25331113304",
```

```
"25331113308",
```

```
"2533111330A",
```

```
"2533111330B",
```

```
"2533111330C",
```

```
"2533111330D",
```

```
"2533111330E",
```



```
"2533111330F",
"2533111330G",
"2533111330H",
"2533111330J",
"2533111330K",
"2533111330L",
"25331115300",
"25331115302",
"25331115304",
"25331115308",
"2533111530A",
"2533111530B",
"2533111530C",
"2533111530D",
"2533111530E",
"2533111530F",
"2533111530G",
"2533111530H",
"2533111530J",
"2533111530K",
"2533111530L"
]
},
{
  "part_name": "Handle Mounting Block 218396700",
  "part_number": "PS427804",
```

"manufacturer": "Kenmore",
"price": "41.13",
"description": "Sold individually.",
"rating": "74",
"troubleshooting_tips": "This part works with the following products: Refrigerator, Freezer. Part# 218396700 replaces these: AP2114457, 450838, 218396701 Back to Top",
"review_count": "3",
"appliance": "refrigerator",
"compatible_models": [
"25323024100",
"25323024101",
"25323024102",
"25323024103",
"25323024104",
"25323114100",
"25323114101",
"25323114102",
"25323414100",
"25323414101",
"25323424100",
"25323424101",
"25323424102",
"25323424104",
"25323425100",
"25323429100",
"25323714100",

```
"25323714101",  
"25323724100",  
"25323724101",  
"25323725100",  
"25323725101",  
"25324042100",  
"25324042101",  
"25324042102",  
"25324042103",  
"25324042104",  
"25324082100",  
"25324082101",  
"25324082102"  
]
```

```
},
```

```
{
```

```
"part_name": "Freezer Door Handle WP67005140",
```

```
"part_number": "PS11743615",
```

```
"manufacturer": "Kenmore",
```

```
"price": "95.96",
```

```
"description": "This is a door handle for your refrigerator or freezer, which allows you to  
easily open and close the door. Take note that the screws are not included when you order  
this part; you will need to keep the screws from your old handle when making this repair.  
You are going to need a Phillips screwdriver and either a flat-blade screwdriver or a putty  
knife for this repair. This handle is white and is nine inches long by almost four inches  
wide.",
```

```
"rating": "95",
```

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# WP67005140 replaces these: AP6010436, 12285404, 12610801W, 12610802W, 12610803W, 12610803WN, 67001902, 67005140, 8170990 Back to Top",

"review_count": "21",

"appliance": "refrigerator",

"compatible_models": [

"59661142100",

"59661142101",

"59661144100",

"59661144101",

"59661152100",

"59661152101",

"59661154100",

"59661154101",

"59661162100",

"59661162101",

"59661164100",

"59661164101",

"59661272100",

"59661272101",

"59661273100",

"59661273101",

"59661274100",

"59661274101",

"59661279100",

"59661279101",

```
"59661282100",
"59661282101",
"59661284100",
"59661284101",
"59661289100",
"59661289101",
"59661292100",
"59661292101",
"59661294100",
"59661294101"
]
},
{
  "part_name": "WHITE HANDLE KIT 5303918823",
  "part_number": "PS12364435",
  "manufacturer": null,
  "price": "39.24",
  "description": "",
  "rating": "84",
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 5303918823 replaces these: AP6284358, 5304511147, A06837801 Back to Top",
  "review_count": "5",
  "appliance": "refrigerator",
  "compatible_models": [
    "CRTE151TW0",
    "CRTE151TW1",
```

"CRTE182TW0",
"CRTE182TW1",
"CRTE182TW2",
"CRTE182TW3",
"CRTE185TW0",
"CRTE206TW1",
"CRTEH182TW0",
"FFHI1832TP0",
"FFHI2032TP0",
"FFHI2032TP1",
"FFHT1514TW0",
"FFHT1514TW1",
"FFHT1514TW2",
"FFHT1514TW3",
"FFHT1514TW4",
"FFHT1614TW0",
"FFHT1621TW0",
"FFHT1621TW1",
"FFHT1621TW2",
"FFHT1814TW0",
"FFHT1814TW1",
"FFHT1820VB0",
"FFHT1820VS0",
"FFHT1820VW0",
"FFHT1821TW0",
"FFHT1821TW1",

```
"FFHT1832TP0",
"FFHT2021TW0"
]
},
{
  "part_name": "Smooth Door Handle Kit - Black WR12X22183",
  "part_number": "PS9494525",
  "manufacturer": null,
  "price": "84.86",
  "description": "This kit includes both refrigerator and freezer handles. It is used for replacing refrigerator doors handles",
  "rating": "94",
  "troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# WR12X22183 replaces these: AP5948588, WR12X11008, WR12X11009, WR12X20142 Back to Top",
  "review_count": "29",
  "appliance": "refrigerator",
  "compatible_models": [
    "GTH17GBEDRBB",
    "GTH17GBEFRBB",
    "GTH18GBD4RBB",
    "GTH18GBDCRBB",
    "GTH18GBDDRBB",
    "GTH18GBDERBB",
    "GTH18GBDGRBB",
    "GTH18GBDHRBB",
    "GTH18GCD4RBB",
```

"GTH18GCDCRBB",
"GTH18GCDDRBB",
"GTH18GCDERBB",
"GTH18GCDGRBB",
"GTH18GCDHRBB",
"GTH18LBD4RBB",
"GTH18LBDCRBB",
"GTH18LBDERBB",
"GTH18LCD4RBB",
"GTH18LCDCRBB",
"GTH18LCDERBB",
"GTJ18CBD4RSA",
"GTJ18GCDCRSA",
"GTJ18GCDDRSA",
"GTJ18GCDESA",
"GTJ18GCDGRSA",
"GTJ18GCDHRSA",
"GTJ18GCDJRSA",
"GTK17GBEDRBS",
"GTK17GBEFRBS",
"GTK17GCEDRBS"

]

},

{

"part_name": "Door Handle WR12X21070",

"part_number": "PS10056095",

"manufacturer": null,

"price": "102.29",

"description": "This is the replacement door handle for your refrigerator. It has a slightly curved shape, is chrome in color and is approximately 34 inches long and 2 inches wide. The door handle allows you to open and close your refrigerator door, and you will want to replace it if it is damaged or missing. This part is sold individually and is an OEM part sourced directly from the manufacturer.",

"rating": "98",

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# WR12X21070 replaces these: AP5951281, WR12X20441 Back to Top",

"review_count": "10",

"appliance": "refrigerator",

"compatible_models": [

"DSE25JGHKCBB",

"DSE25JMHBCES",

"DSE25JMHECES",

"DSE25JMHKCES",

"DSE25JSHBCSS",

"DSE25JSHECSS",

"DSE25JSHKCSS",

"DSE26JMEBCES",

"DSE26JMECCES",

"DSE26JMEDCES",

"DSE26JSEBCSS",

"DSE26JSECCSS",

"DSE26JSEDCSS",

"GSE22ESHBSS",

```
"GSE22ESHCSS",
"GSE22ESHDSS",
"GSE23GSECCSS",
"GSE23GSEFCSS",
"GSE23GSKECSS",
"GSE23GSKJCSS",
"GSE23GSKKCSS",
"GSE25ESHBSS",
"GSE25ESHCSS",
"GSE25ESHDSS",
"GSE25GSHBCSS",
"GSE25GSHECSS",
"GSE25GSHHCSS",
"GSE25GSHJCSS",
"GSE25GSHKCSS",
"GSE25HMHBHES"
]
},
{
  "part_name": "Door Handle 297311201",
  "part_number": "PS2368270",
  "manufacturer": null,
  "price": "58.31",
  "description": "The screws and trims are NOT included with this handle.",
  "rating": "90",
```

"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator, Freezer. Part# 297311201 replaces these: AP4454118, 1532442, 297311201, 218762701 Back to Top",

"review_count": "14",

"appliance": "refrigerator",

"compatible_models": [

"25357672790",

"25357672791",

"25357677791",

"25357682790",

"25357682791",

"CALR17LW0",

"CALR17LW1",

"CALR17LW2",

"CFUM14LW0",

"CFUM14LW1",

"CFUM17LW0",

"CFUM17LW1",

"CFUM21LS0",

"CFUM21LW0",

"CFUM21LW1",

"CFUM21LW2",

"CFUM21LW3",

"CFUM21PW1",

"CRSE230KW0",

"CRSH265LW0",

"CRSH265LW1",

```
"CRSH265LW2",
"CRSH265LW3",
"F45WJ26HW0",
"F45WJ26HW1",
"F45WJ26HW2",
"F45ZR24JW0",
"F45ZR24JW1",
"FFH1767GW0",
"FFH1767GW1"
]
},
{
  "part_name": "Refrigerator Freezer Door Handle Kit - White WR12X22148",
  "part_number": "PS9864030",
  "manufacturer": null,
  "price": "84.54",
  "description": "This door handle kit includes handles for both the refrigerator and freezer. It also includes a plug for the handle. These handles make it easy for you to open and close your appliance door. If they are cracked or damaged, it is a good idea to replace them. The refrigerator door handle is approximately 19 inches in length, and the freezer door handle is approximately 18 5/8 inches in length. These handles are white in color. You will need a screwdriver to successfully install the new handles on your appliance. This kit does not include the screws required for installation.",
  "rating": "90",
  "troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# WR12X22148 replaces these: AP5949272, WR12X11010, WR12X11011, WR12X20141 Back to Top",
  "review_count": "67",
```

"appliance": "refrigerator",

"compatible_models": [

"GTH17GBEDRWW",

"GTH17GBEFRWW",

"GTH18GBD4RWW",

"GTH18GBDCRWW",

"GTH18GBDDRWW",

"GTH18GBDERWW",

"GTH18GBDGRWW",

"GTH18GBDHRWW",

"GTH18GBDR4WW",

"GTH18GCDCRWW",

"GTH18GCDDRWW",

"GTH18GCDERWW",

"GTH18GCDGRWW",

"GTH18GCDHRWW",

"GTH18LBD4RWW",

"GTH18LBDCRWW",

"GTH18LBDERWW",

"GTH18LCD4RWW",

"GTH18LCDCRWW",

"GTH18LCDERWW",

"GTS18GBEJRWW",

"GTS18GBEMRWW",

"GTT18GBD4RCC",

"GTT18GBD4RWW",

```
"GTT18GBDCRWW",  
"GTT18GBDDRWW",  
"GTT18GBDERWW"  
]  
},  
{
```

```
"part_name": "Door Handle 218428101",  
"part_number": "PS427922",  
"manufacturer": null,  
"price": "47.51",  
"description": "This white handle can be used with both the freezer door and the fresh  
food door of many refrigerators. Note: As per the manufacturer, this handle includes the  
mounting block and screw for the top of the handle. If you need the screw for the bottom, it  
must be ordered separately. This is a simple repair that only requires a Phillips screwdriver.  
You will remove the 2 screws located on the top of the fridge door and slide the old handle  
out of place. Take your new handle and use your screwdriver to position back into place.",
```

```
"rating": "88",  
"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or  
close This part works with the following products: Refrigerator. Part# 218428101 replaces  
these: AP2114539, 372, 218428101, 241711801 Back to Top",
```

```
"review_count": "41",  
"appliance": "refrigerator",  
"compatible_models": [  
"25363812200",  
"25363812202",  
"25364702401",  
"25364702402",  
"BRT18HP7GW0",
```

"BRT18HP7JW0",
"BRT18HP7JW1",
"BRT18S6GW0",
"BRT18S6GW1",
"BRT217TGW0",
"CFHT1513LZ1",
"CFHT1513LZ2",
"CFHT1513LZ3",
"CFHT1513LZ4",
"CFHT1513LZ5",
"CFHT1513LZ8",
"CFHT1713LZ0",
"CFHT1713LZ1",
"CFHT1713LZ2",
"CFHT1713LZ3",
"CFHT1713LZ6",
"CFHT1713LZ9",
"CFHT1713LZZ",
"CRT151HLW2",
"CRT151HLW3",
"CRT151HLW4",
"CRT151HLW5",
"CRT151HLW7",
"CRT151HLW8",
"CRT151HLW9"

]

```
},
```

```
{
```

```
"part_name": "Refrigerator Door Handle Set (2 pieces) - Black 5304506471",
```

```
"part_number": "PS11770475",
```

```
"manufacturer": null,
```

```
"price": "64.87",
```

```
"description": "This is a door handle set for your refrigerator. This door handle set includes two 17-inch-long black handles that slide on and screw into your refrigerator door. If your current refrigerator door handles for your fridge or freezer compartments are missing, damaged, unsightly, or unable to pull the door, they will need replacing. To replace a door handle, unthread the screw securing its top and slide it down to release, then slide the new handle on and secure its top. This set includes two OEM door handles, but does not include their securing screws, which are instead sold separately.",
```

```
"rating": "90",
```

```
"troubleshooting_tips": "This part fixes the following symptoms: Door won't open or close This part works with the following products: Refrigerator. Part# 5304506471 replaces these: AP6036332, 242059503, 242059506, 5304504509, 5304504510, 5304510039, 5304510041, 53304486361 Back to Top",
```

```
"review_count": "57",
```

```
"appliance": "refrigerator",
```

```
"compatible_models": [
```

```
"CFTR1826LM0",
```

```
"CFTR1826LM1",
```

```
"CFTR1826LM2",
```

```
"CFTR1826LM3",
```

```
"CFTR1826LM4",
```

```
"CFTR1826LM5",
```

```
"CFTR1826LM6",
```

```
"CFTR1826LM7",
```


"CFTR1826LM8",
"CFTR1826LM9",
"CFTR1826LMA",
"CFTR1826LMB",
"CFTR1826LMC",
"CFTR1826LMD",
"CFTR1826LME",
"CFTR1826LMF",
"CFTR1826LMG",
"CFTR1826LMH",
"FFHI1817LB0",
"FFHI1817LB1",
"FFHI1817LB2",
"FFHI1817LB3",
"FFHI1817LB4",
"FFHI1817LB6",
"FFHI1817LB7",
"FFHI1817LB8",
"FFHI1817LB9",
"FFHI1817LBA",
"FFHI1817LBB",
"FFHI1817LBC"

]

},

{

"part_name": "Holder,Pipe MEG61879201",

```
"part_number": "PS3535430",
"manufacturer": "LG",
"price": "9.34",
"description": "",
"rating": null,
"troubleshooting_tips": "This part fixes the following symptoms: Leaking This part works
with the following products: Refrigerator, Freezer. Back to Top",
"review_count": null,
"appliance": "refrigerator",
"compatible_models": [
  "48231784207",
  "48231784214",
  "48231784221",
  "71012",
  "71013",
  "71014",
  "71016",
  "71019",
  "71043",
  "71049",
  "71052",
  "71053",
  "71054",
  "71059",
  "71079",
  "71602",
```

```
"71604",
"71606",
"71609",
"72033",
"72039",
"74012",
"74013",
"74015",
"74019",
"74102",
"74105",
"74109",
"74405"
]
},
{
  "part_name": "Refrigerator Dispenser Water Tube 218976438",
  "part_number": "PS8746683",
  "manufacturer": null,
  "price": "20.42",
  "description": "",
  "rating": null,
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part# 218976438 replaces these: AP5788311 Back to Top",
  "review_count": null,
  "appliance": "refrigerator",
```

"compatible_models": [

"CRSE233TB0",

"CRSE233TS0",

"CRSE233TW0",

"CRSH232PB9A",

"CRSH232PBBA",

"CRSH232PBEA",

"CRSH232PBHA",

"CRSH232PS7A",

"CRSH232PS9A",

"CRSH232PW9A",

"CRSH232PWAA",

"CRSH232PWBA",

"CRSH232PWCA",

"CRSH232PWDA",

"CRSH232PWEA",

"CRSS262QB3",

"CRSS262QB4",

"CRSS262QB5",

"CRSS262QS3",

"CRSS262QS4",

"CRSS262QS5",

"CRSS262QW3",

"CRSS262QW4",

"CRSS262QW5",

"DFHS2313MFCA",

"DFHS2313MFDA",

"DFHS2313MFEA",

"DFHS2313MFFA",

"DFHS2313MFHA",

"DFHS2313MFJA"

]

},

{

"part_name": "Grommet / Tube Assembly WR17X11168",

"part_number": "PS292253",

"manufacturer": "Kenmore",

"price": "25.02",

"description": "This is a replacement fill tube and grommet assembly for your refrigerator. This part acts your water line to your ice maker. If you're noticing water in the back of the refrigerator or any kind of leak, or if your ice bucket isn't filling up with as much ice, you may need to change out the fill tube and grommet assembly. When you purchase this part, you get the water line, as well as the fill tube and grommet. This is an OEM part sourced directly from the manufacturer.",

"rating": "100",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Ice maker not making ice This part works with the following products: Refrigerator. Part# WR17X11168 replaces these: AP3186471, 945251, WR02X10564, WR02X10826, WR02X10960, WR17X11082, WR17X11506, WR17X11543, WR2X10564, WR2X10826, WR2X10960 Back to Top",

"review_count": "5",

"appliance": "refrigerator",

"compatible_models": [

"A4425GDTABB",

"A4425GDTAWW",

"A4425GDTBBB",
"A4425GDTBWW",
"A4425GDTW",
"BSS25GFPACC",
"BSS25GFPAWW",
"BSS25GFPCCC",
"BSS25GFPCWW",
"BSS25GFPDCC",
"BSS25GFPDWW",
"BSS25GFPECC",
"BSS25GFPEWW",
"BSS25GFPHCC",
"BSS25GFPHWW",
"BSS25JFRFWW",
"BSS25JFRJWW",
"BSS25JFTAww",
"BSS25JFTBWW",
"BSS25JFTCWW",
"BSS25JFTDWW",
"BSS25JFTEWW",
"BSS25JFTGWW",
"BSS25JFTHWW",
"BSS25JFTIWW",
"BSS25JFTJWW",
"BSS25JFTNWW",
"BSS25JFTPWW",

```
"BSS25JSRFSS",  
"BSS25JSRJSS"  
]  
},  
{  
  "part_name": "Water Tube Kit W10823511",  
  "part_number": "PS11730901",  
  "manufacturer": "Kenmore",  
  "price": "36.02",
```

"description": "This is the replacement water tube kit for your refrigerator. This tubing is made of plastic, is 1/4 inch in diameter, and comes with 2 inserts. This tube may be longer than the original tube, and may need to be cut. This water tube transports water to the ice and water dispensers. If your refrigerator is leaking, or if the ice and water dispensers are not dispensing properly, you may need to replace this tube. This part is sold individually and is an OEM part sourced directly from the manufacturer.",

"rating": "75",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Ice maker not making ice | Not dispensing water This part works with the following products: Refrigerator, Ice Maker, Freezer. Part# W10823511 replaces these: AP5989588, 1105233, 1108197, 1108348, 1111250, 1112556, 1113158, 1113159, 1113371, 1113372, 1119096, 2001259, 2001321, 2001322, 2155294, 2172593, 2174662, 2181940, 2181941, 2181942 ... Show more , 2181943, 2181944, 2181945, 2181946, 2181947, 2181948, 2183156, 2202587, 2204332, 2205746, 2208933, 2210514, 2210517, 2223137, 2252393, 2304859, 2314045, 2314046, 2314047, 4339669, 4339975, 4340032, 4340070, 4341083, 4341084, 4342775, 4343701, 4344404, 4387492, 482003, 483202, 627665, 653200, 653415, 653499, 659811, 758037, 758581, 8170412, 8170934, 8208151, 831304, 836240, 836241, 839060, 839063, 840124, 840125, 840860, 842775, 844847, 845998, 849986, 849987, 867089, 867194, 867200, 937669, 937680, 937681, 939010, 939011, 940828, 944681, 977049, 977052, 983370, 987053, 988220, 992584, 992585, B5705311, B5705315, B5705323, W10175644, W10357068, W10357069, W10357076, W10437857, W10823511VP Show less Back to Top",

"review_count": "7",

"appliance": "refrigerator",

"compatible_models": [

"1064650043714",

"1064689482991",

"10647021790",

"10647021791",

"10647022790",

"10647022791",

"10647028790",

"10647028791",

"10650022000",

"10650022001",

"10650022002",

"10650022003",

"10650022004",

"10650027000",

"10650027001",

"10650027002",

"10650027003",

"10650027004",

"10650029213",

"10650032000",

"10650032001",

"10650032002",

"10650032003",

"10650032004",


```
"10650037000",
"10650037001",
"10650037002",
"10650037003",
"10650037004",
"10650042710"
]
},
{
  "part_name": "Filter Inlet Water Tube 8201597",
  "part_number": "PS886401",
  "manufacturer": "Kenmore",
  "price": "46.75",
  "description": "As per the manufacturer, this part starts out as 1/4\" tubing but ends up
at 5/16\".",
  "rating": "97",
  "troubleshooting_tips": "This part fixes the following symptoms: Leaking | Not dispensing
water This part works with the following products: Refrigerator, Wine and Beverage Cooler.
Part# 8201597 replaces these: AP3607291, 1018190, 8201597, 2186492, 2188744,
2200202, 2305536, 2305537, 2319867, 2319868, 8201597, 8201597VP, W10281558,
W10296822, W10296835, W10296836 Back to Top",
  "review_count": "17",
  "appliance": "refrigerator",
  "compatible_models": [
    "10641522500",
    "10641523500",
    "10641524500",
```

"10641529500",
"10644022600",
"10644022601",
"10644022602",
"10644022603",
"10644023600",
"10644023601",
"10644023602",
"10644023603",
"10644024600",
"10644029600",
"10644029601",
"10644029602",
"10644029603",
"10644032600",
"10644032601",
"10644032602",
"10644032603",
"10644033600",
"10644033601",
"10644033602",
"10644033603",
"10644034600",
"10644039600",
"10644039601",
"10644039602",

"10644039603"

]

},

{

"part_name": "Ice Maker Water Fill Tube Kit WP2196157",

"part_number": "PS11739222",

"manufacturer": "Kenmore",

"price": "10.13",

"description": "The icemaker water fill tube provides water to the icemaker so it can produce ice and dispense water. If you notice that your ice maker is not making or dispensing ice, or is leaking, you may need to replace the water fill tube. This water fill tube kit comes with a fill tube and a compression nut. This part is made of white plastic and is approximately 10 inches in length. The ice maker water fill tube is in the rear of the fridge. To complete this repair, you will need a 1/4 inch nut driver and a utility knife. Before beginning this repair, you may want to disconnect the water and power supply to the refrigerator.",

"rating": "92",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Ice maker not making ice | Not dispensing water | Ice maker won't dispense ice This part works with the following products: Refrigerator, Ice Maker, Freezer, Wine and Beverage Cooler. Part# WP2196157 replaces these: AP6006156, 1112845, 2154070, 2154080, 2154081, 2174759, 2174760, 2182015, 2196035, 2196157, 836489, 841907, 842896, 848725, 849908, 983655, 983990, W10281566 Back to Top",

"review_count": "25",

"appliance": "refrigerator",

"compatible_models": [

"106106-8130600",

"106106-8130610",

"106106-8130620",

"106106-8130630",

"106106-8130640",
"106106-8130650",
"106106-8130660",
"106106-8130680",
"106106-8130690",
"1061068130670",
"10631400200",
"10631402200",
"10631404200",
"10631409200",
"10631410200",
"10631412200",
"10631414200",
"10631419200",
"10639420990",
"10639422990",
"10639424990",
"10639427990",
"10639430990",
"10639432990",
"10639434990",
"10639437990",
"10647021790",
"10647021791",
"10647022790",
"10647022791"

]

},

{

"part_name": "TUBE-WATER W11415785",

"part_number": "PS12745424",

"manufacturer": null,

"price": "59.10",

"description": "This water fill tube is a genuine OEM part that is compatible with various models of refrigerator. It is a small plastic tube that supplies water to the ice maker tray. It is typically located at the back of the refrigerator, where it runs from the water inlet valve to the ice maker assembly. When the ice maker needs to produce ice, water flows through this tube and fills the ice maker tray, where it freezes into ice cubes. The fill tube is an essential component of the ice maker system, ensuring a steady supply of water for ice production. If the fill tube becomes clogged or damaged, it can water leaks inside the refrigerator and also lead to difficulties producing ice when needed.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Ice maker not making ice This part works with the following products: Refrigerator. Part# W11415785 replaces these: 12961401, 67006317, W11232485 Back to Top",

"review_count": "6",

"appliance": "refrigerator",

"compatible_models": [

"59677532600",

"59677532601",

"59677532602",

"59677532603",

"59677532700",

"59677532702",

"59677533600",

"59677533601",
"59677533602",
"59677533603",
"59677533700",
"59677533702",
"59677539600",
"59677539601",
"59677539602",
"59677539603",
"59677539700",
"59677539702",
"59678532800",
"59678533800",
"59678539800",
"59679542014",
"59679542015",
"59679543015",
"59679543016",
"59679549013",
"59679549015",
"5GI6FARAF000",
"5GI6FARAF001",
"5MFI267AA000"

]

},

{

"part_name": "Union Connector - 5/16 Inch to 5/16 Inch WR02X11330",

"part_number": "PS758446",

"manufacturer": "Kenmore",

"price": "9.02",

"description": "Quick connector for plastic water line - 5/16\" to 5/16\""

"rating": "80",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Not dispensing water | Ice maker not making ice This part works with the following products: Refrigerator, Water Filter System. Part# WR02X11330 replaces these: AP3414915, 963908, SWR02X7223, SWR2X7223, WR02X10067, WR02X10471, WR02X12349, WR02X4047, WR02X4048, WR02X7223, WR02X8455, WR02X8545, WR2X10067, WR2X10471, WR2X11330, WR2X4047, WR2X4048, WR2X7223, WR2X8455, WR2X8545 Back to Top",

"review_count": "10",

"appliance": "refrigerator",

"compatible_models": [

"36350221000",

"36350222000",

"36350227000",

"36350232000",

"36350237000",

"36350242000",

"36350247000",

"36350622000",

"36350627000",

"36357552790",

"36357552791",

"36357557790",

"36357557791",
"36358062890",
"36358062891",
"36358062892",
"36358062893",
"36358062894",
"36358062896",
"36358062897",
"36358067890",
"36358067891",
"36358067892",
"36358067893",
"36358067894",
"36358067897",
"36358072891",
"36358072892",
"36358072893",
"36358072894"

]

},

{

"part_name": "Plastic Tube - 5/16 Inch MJU62070602",
"part_number": "PS3536013",
"manufacturer": "LG",
"price": "16.90",

"description": "This water tube, or plastic tube, is used in refrigerators and freezers. The tube ensures water is directed to parts of the refrigerator that need it, such as the water dispenser and ice maker. If you find that your current one is leaking or broken in any way, replacing the tube can fix this problem. Make sure to unplug the appliance from the power source before you start this installation project. Refer to the diagram provided by the manufacturer for further instruction and accurate guidance.",

"rating": "99",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Not dispensing water This part works with the following products: Refrigerator, Freezer. Part# MJU62070602 replaces these: AP4681126, 5210JA3004A, 5210JA3004B, 5210JA3004L, 5210JA3004M, 5210JA3004R, 5210JA3004S, 5210JA3004U, 5210JA3029U, MJU62070601, MJU62070606, MJU62070611, MJU62070615, MJU63336703 Back to Top",

"review_count": "19",

"appliance": "refrigerator",

"compatible_models": [

"1867",

"48231784207",

"48231784214",

"48231784221",

"48231784412",

"71012",

"71013",

"71014",

"71016",

"71019",

"71022",

"71023",

"71024",

"71026",

```
"71029",  
"71032",  
"71052",  
"71053",  
"71054",  
"71056",  
"71059",  
"71062",  
"71063",  
"71069",  
"71072",  
"71073",  
"71079",  
"71082",  
"71083",  
"71089"  
]  
,  
{  
  "part_name": "P-Trap Drain Tube Kit W10619951",  
  "part_number": "PS8691807",  
  "manufacturer": "Kenmore",  
  "price": "39.39",
```

"description": "The p-trap drain tube kit may also be known as the duck bill, or the drain pipe, and it is compatible with your refrigerator. The function of the p-trap drain kit is to carry the water that has formed during the defrost cycle to the bottom of the refrigerator, where your drain pan is located. The tools you will need for this repair include a 1/4-inch

nut driver and a small flat-blade screwdriver. To do this repair you will need to pull the refrigerator forward in order to reach the lower access panel at the back. This kit includes the tube extension piece and spacer.",

"rating": "97",

"troubleshooting_tips": "This part fixes the following symptoms: Leaking | Freezer not defrosting | Frost buildup | Fridge too warm This part works with the following products: Refrigerator. Part# W10619951 replaces these: AP5780744, 2887289, W10210987, W10210988, W10309238, W10344401, W10344402, W10585186, W10588598, W10604169, W10622098, W10622099 Back to Top",

"review_count": "30",

"appliance": "refrigerator",

"compatible_models": [

"10669312310",

"10672002010",

"10672002011",

"10672002013",

"10672002015",

"10672003010",

"10672003011",

"10672003012",

"10672003013",

"10672003014",

"10672003016",

"10672003017",

"10672003018",

"10672009010",

"10672009011",

"10672009013",

"10672009015",

"10672012010",

"10672013010",

"10672013017",

"10672019010",

"596379243017",

"596467934251",

"596467934351",

"596467934451",

"596467934951",

"59665232404",

"59665232405",

"59665234404",

"59665234405"

]

},

{

"part_name": "SHELF MODULE FF WR71X38318",

"part_number": "PS16619590",

"manufacturer": null,

"price": "30.65",

"description": "This door bin is for refrigerators and attaches to the inside of the refrigerator door and typically holds jars and bottles. Follow the instructions in the owner's manual for installing this part.",

"rating": "96",

"troubleshooting_tips": "This part works with the following products: Refrigerator. Part# WR71X38318 replaces these: WR71X24428 Back to Top",

"review_count": "55",
"appliance": "refrigerator",
"compatible_models": [
"GSE23GGPBCBB",
"GSE23GGPBCWW",
"GSE23GGPECBB",
"GSE23GGPECWW",
"GSE23GYPBCFS",
"GSE23GYPECFS",
"GSE25GGPBCBB",
"GSE25GGPBCWW",
"GSE25GGPECBB",
"GSE25GGPECWW",
"GSE25GGPFCBB",
"GSE25GGPFCWW",
"GSE25GYPBCFS",
"GSE25GYPECFS",
"GSE25GYPFCFS",
"GSS23GGPBCBB",
"GSS23GGPBCCC",
"GSS23GGPBCWW",
"GSS23GGPECBB",
"GSS23GGPECCC",
"GSS23GGPECWW",
"GSS23GGPFCBB",
"GSS23GGPFCCC",

"GSS23GGPFCWW",

"GSS23GMPBCES",

"GSS23GMPECES",

"GSS23GMPFCES",

"GSS23GYPBCFS",

"GSS23GYPECFS",

"GSS23GYPFCFS"

]

},

{

"part_name": "Refrigerator Water Filter RPWFE",

"part_number": "PS10063209",

"manufacturer": null,

"price": "92.32",

"description": "This NSF-certified water filter helps to improve the taste, quality, and health of your water by removing a number of contaminants including mercury, lead, and trace pharmaceuticals. The filter should be replaced every six month or after 300 gallons of water have been filtered. If you are unsure if your filter is due for replacement, another indicator is if the water flow from the dispenser has slowed down considerably. Replacing this part is a simple task that does not require any tools or shutting off the water or power supply to your fridge. Once the new filter has been installed, be sure to run at least two gallons of water through before consuming.",

"rating": "91",

"troubleshooting_tips": "This part fixes the following symptoms: Not dispensing water | Ice maker not making ice This part works with the following products: Refrigerator. Part# RPWFE replaces these: AP5955761, RPWF, RPWF3PK, RPWFE2PK, RPWFE3PK Back to Top",

"review_count": "35",

"appliance": "refrigerator",

"compatible_models": [

"CFE28TP2MBS1",

"CFE28TP2MCS1",

"CFE28TP2MDS1",

"CFE28TP2MES1",

"CFE28TP2MFS1",

"CFE28TP2MGS1",

"CFE28TP2MHS1",

"CFE28TP2MIS1",

"CFE28TP2MJS1",

"CFE28TP2MKS1",

"CFE28TP3MBD1",

"CFE28TP3MBW2",

"CFE28TP3MCD1",

"CFE28TP3MDD1",

"CFE28TP3MED1",

"CFE28TP3MFD1",

"CFE28TP3MGD1",

"CFE28TP3MHD1",

"CFE28TP3MID1",

"CFE28TP3MJD1",

"CFE28TP3MKD1",

"CFE28TP4MBW2",

"CFE28TP4MCW2",

"CFE28TP4MDW2",

"CFE28TP4MEW2",

```
"CFE28TP4MFW2",
"CFE28TP4MGW2",
"CFE28TP4MHW2",
"CFE28TP4MIW2",
"CFE28TP4MJW2"
]
},
{
  "part_name": "Ice Dispenser Drum 241685101",
  "part_number": "PS1526412",
  "manufacturer": "Kenmore",
  "price": "43.17",
  "description": "This part helps push the ice through the front plate to be crushed.",
  "rating": "98",
  "troubleshooting_tips": "This part fixes the following symptoms: Ice maker won't dispense ice | Ice maker not making ice This part works with the following products: Refrigerator. Part# 241685101 replaces these: AP3959117, 1196676, 241685103, 5304404346, 7241685101 Back to Top",
  "review_count": "16",
  "appliance": "refrigerator",
  "compatible_models": [
    "25344302400",
    "25344302401",
    "25344303400",
    "25344303401",
    "25344303402",
    "25344303403",
```


"25344304400",
"25344304401",
"25344309400",
"25344309401",
"25344333600",
"25344333601",
"25344333602",
"25344333603",
"25344333604",
"25344333605",
"25344333606",
"25344333607",
"25344333608",
"25344333609",
"2534433360A",
"25344352400",
"25344352401",
"25344352403",
"25344352404",
"25344352405",
"25344352406",
"25344352407",
"25344352408",
"25344352409"

]

},

```
{  
  "part_name": "Door Rack - White 240535201",  
  "part_number": "PS734991",  
  "manufacturer": "Kenmore",  
  "price": "39.79",  
  "description": "The door rack shelf bar has the end caps to attach it to the door already  
attached to the end of the bar.",  
  "rating": "95",  
  "troubleshooting_tips": "This part works with the following products: Refrigerator. Part#  
240535201 replaces these: AP3214686, 948957, 240535201 Back to Top",  
  "review_count": "14",  
  "appliance": "refrigerator",  
  "compatible_models": [  
    "25331420104",  
    "25331422103",  
    "25331424102",  
    "25331428103",  
    "25331429102",  
    "25331429103",  
    "25331429104",  
    "25331430104",  
    "25331430105",  
    "25331430106",  
    "25331432103",  
    "25331432104",  
    "25331432105",  
    "25331432106",  
  ]  
}
```

"25331434103",

"25331434104",

"25331434105",

"25331434106",

"25331434107",

"25331437103",

"25331437104",

"25331437105",

"25331437106",

"25331438103",

"25331438104",

"25331438105",

"25331438106",

"25331439103",

"25331439104",

"25331439105"

]

}

]