

kX Remote

The kX Remote Controller window has no buttons at the moment, so better guide will be available as soon as the remote is fully supported.

Power	Displays Windows 'Shutdown' dialog
0..9	similar to the keyboard keys '0'.. '9'
Mute	Master Mute
'-'	Decreases Master volume
'+'	Increases Master volume
Stop/Eject	Stop playback (*)
Play/Pause	Play/Pause playback (*)
Slow	Switch task (similar to 'Alt-Esc')
Previous	Previous track (*)
Next	Next track (*)
Step	Similar to the 'Tab' key
Options	'Application' key (system menu, if available)
Display	'Alt' key (opens application menu)
Return	'Backspace' key
Start	Opens Windows 'Start' menu
Cancel	Similar to the 'Esc' key
Up / Down / Left / Right	Similar to corresponding keyboard keys
Select / OK	Enter
Rec	(unused)
EAX	(unused)

(*) For supported players only (WinAmp, Foobar2000, certain versions of Media Player, WinDVD).

You can perform practically any task in most Windows applications by using 'Start', 'Display', 'Select', 'Step' and the arrows.