

Oasys Primer

Column Blast Tool – Ver 3.0

User Manual

Issue 1 | April 6, 2021

This report takes into account the particular instructions and requirements of our client.

It is not intended for and should not be relied upon by any third party and no responsibility is undertaken to any third party.

Job number 076023-37

Arup North America Ltd
560 Mission Street
Suite 700
San Francisco 94105
United States of America
www.arup.com

ARUP

Contents

	Page
1 Introduction	1
2 Model Creation	2
2.1 Main GUI	3
2.2 General Column Details	4
2.3 Steel Sections	5
2.4 Concrete Sections	6
2.5 Material Properties	8
2.6 Charge Details	9
2.7 Control Parameters	10
3 Model Setup	11
3.1 Rebar	12
3.2 Boundary Conditions	13
3.3 Gravity and Column Top Load	14
3.4 Blast Loading	14
3.5 Materials and Element Type	15
3.6 Contact	16
3.7 Ground	16
4 Additional Files	17

1 Introduction

This Oasys Primer JavaScript allow the user to quickly setup a column blast analysis for a range of steel and reinforced concrete section types.

Column Blast Tool V3.0

Column Dimensions

Total Column Height (m) 0.0
Height of Detailed (Solid) Section (m) 0.0

Column Top Load

Column Top Load (kN) 0
Load X Offset (m) 0
Load Y Offset (m) 0

Column Top X Moment (kN.m) 0
Column Top Y Moment (kN.m) 0

Gravity ("Lody_Body_Z") is applied to the model
☐ Post Blast Load Ramp Factor

Column End Conditions

Column Bottom: ☐ Pinned, ☒ Fixed, ☐ Spring
Column Top: ☐ Pinned - Z Free, ☒ Fixed - Z Free, ☐ Pinned - Z Locked, ☐ Fixed - Z Locked, ☐ Spring

Section Dimensions

☒ I-Section
☐ HSS - Square
☐ HSS - Rectangle
☐ HSS - Round
☐ C-Section

Section Width (m) 0.0, Web Thickness (m) 0.0
Section Depth (m) 0.0, Flange Thickness (m) 0.0

Element Dimension
Elements Through Thickness 6

Concrete Encased I-Beam
☐ Add Concrete Encasement

HSS Concrete Filled

Steel Material Properties

Set Material Undefined

Charge Details

X Distance From Column Center (m) 0.0
Y Distance From Column Center (m) 0.0
Z Height From Column Base (m) 0.0

Charge Mass (kg TNT eq) 0.0

☒ Hemispherical (LBE Type 1)
☐ Spherical (LBE Type 2)
☐ Air Burst + Ground Reflection (LBE Type 3)
☐ Viper (CFD)

Max Angle of Incidence for Blast Load 125

Control Parameters

Blast Phase Duration (sec) 0.01
Max Timestep (LCTM) 1.9e-6
Mass Scaling Timestep (DT2MS) 0.5e-6
Timestep Scale Factor (TSSFAC) 0.7

Pre Blast Loading Controls

☒ Pre Blast Loading (Implicit)
☐ Pre Blast Loading (Dynamic Relax)

Post Blast Loading Controls

☐ Post Blast Loading Check (Implicit)
☐ Post Blast Loading Check (Explicit)

Analysis Timeline

	Start	Finish
Pre Blast Phase	0.0	1.0
Blast Phase	1.0	1.001
Post Blast Phase	1.001	1.001

Create Cancel

Column Blast Tool V3.0

Column Dimensions

Total Column Height (m) 0.0
Height of Detailed (Solid) Section (m) 0.0

Column Top Load

Column Top Load (kN) 0
Load X Offset (m) 0
Load Y Offset (m) 0

Column Top X Moment (kN.m) 0
Column Top Y Moment (kN.m) 0

Gravity ("Lody_Body_Z") is applied to the model
☐ Post Blast Load Ramp Factor

Column End Conditions

Column Bottom: ☐ Pinned, ☒ Fixed, ☐ Spring
Column Top: ☐ Pinned - Z Free, ☒ Fixed - Z Free, ☐ Pinned - Z Locked, ☐ Fixed - Z Locked, ☐ Spring

Section Dimensions

☒ Round ☐ Rectangle

Section Diameter (m) 1, Rebar Number 10
Cover Thickness (m) 0.0

Rebar Hoop Spacing (m) 0.0

Rebar Size
Vert Rebar Dia (m) 0.0127
Hoop Rebar Dia (m) 0.0127

Element Dimension
Elements Through Cover Thickness 2

Concrete Material Properties

Set Material Undefined

Rebar Material Properties

Set Material Undefined

Steel Jacket

☐ Add Steel Jacket

Charge Details

X Distance From Column Center (m) 0.0
Y Distance From Column Center (m) 0.0
Z Height From Column Base (m) 0.0

Charge Mass (kg TNT eq) 0.0

☒ Hemispherical (LBE Type 1)
☐ Spherical (LBE Type 2)
☐ Air Burst + Ground Reflection (LBE Type 3)
☐ Viper (CFD)

Max Angle of Incidence for Blast Load 125

Control Parameters

Blast Phase Duration (sec) 0.01
Max Timestep (LCTM) 1.9e-6
Mass Scaling Timestep (DT2MS) 0.5e-6
Timestep Scale Factor (TSSFAC) 0.7

Pre Blast Loading Controls

☒ Pre Blast Loading (Implicit)
☐ Pre Blast Loading (Dynamic Relax)

Post Blast Loading Controls

☐ Post Blast Loading Check (Implicit)
☐ Post Blast Loading Check (Explicit)

Analysis Timeline


	Start	Finish
Pre Blast Phase	0.0	1.0
Blast Phase	1.0	1.001
Post Blast Phase	1.001	1.001

Create Cancel


Along with the main JavaScript (Column_Blast_v3-0.js) several JS modules, macros data, and image files also required. These files are located in various folders. The full list of these additional files is given Section 4.

2 Model Creation

It is recommended when using this Oasys Primer JavaScript to set the memory to 1000 due to the number of elements being processed.



The user first selects whether they are creating a steel or reinforced concrete column.



From there the user is taken to either the Steel or Reinforced Concrete GUI.

2.1 Main GUI

The main GUIs feature a series of sections that need to be completed by the user.

The image displays two screenshots of the Column Blast Tool V3.0 GUI, showing the configuration options for an I-section and a round column.

Top Screenshot (I-Section):

- Column Dimensions:** Total Column Height (m) 0.0, Height of Detailed (Solid) Section (m) 0.0, Column Top Load (kN) 0, Load X Offset (m) 0, Load Y Offset (m) 0, Column Top X Moment (kN.m) 0, Column Top Y Moment (kN.m) 0, Gravity ("Locdy_Body_Z") is applied to the model, Post Blast Load Ramp Factor (checkbox).
- Section Dimensions:** I-Section (checked), HSS - Square, HSS - Rectangle, HSS - Round, C-Section, Section Width (m) 0.0, Web Thickness (m) 0.0, Section Depth (m) 0.0, Flange Thickness (m) 0.0, Element Dimension, Elements Through Thickness 2, Concrete Encased I-Beam, Add Concrete Encasement, HSS Concrete Filled.
- Column End Conditions:** Column Bottom: Pinned, Fixed (checked), Spring; Column Top: Pinned - Z Free, Fixed - Z Free (checked), Pinned - Z Locked, Fixed - Z Locked, Spring.
- Charge Details:** X Distance From Column Center (m) 0.0, Y Distance From Column Center (m) 0.0, Z Height From Column Base (m) 0.0, Charge Mass (kg TNT eq) 0.0, Charge Type: Hemispherical (LBE Type 1) (checked), Spherical (LBE Type 2), Air Burst + Ground Reflection (LBE Type 3), Viper (CFD), Max Angle of Incidence for Blast Load 125.
- Control Parameters:** Blast Phase Duration (sec) 0.01, Max Timestep (LCTM) 1.0e-6, Mass Scaling Timestep (DT2MS) 0.5e-6, Timestep Scale Factor (TSSFAC) 0.7, Pre Blast Loading Controls: Pre Blast Loading (Implicit) (checked), Pre Blast Loading (Dynamic Relax) (checkbox), Post Blast Loading Controls: Post Blast Loading Check (Implicit) (checkbox), Post Blast Loading Check (Explicit) (checkbox).
- Analysis Timeline:** Start, Finish, Pre Blast Phase 0.0, 1.0, Blast Phase 1.0, 1.001, Post Blast Phase 1.001, 1.001.

Bottom Screenshot (Round):

- Column Dimensions:** Total Column Height (m) 0.0, Height of Detailed (Solid) Section (m) 0.0, Column Top Load (kN) 0, Load X Offset (m) 0, Load Y Offset (m) 0, Column Top X Moment (kN.m) 0, Column Top Y Moment (kN.m) 0, Gravity ("Locdy_Body_Z") is applied to the model, Post Blast Load Ramp Factor (checkbox).
- Section Dimensions:** Round (checked), Rectangle, Section Diameter (m) 1, Rebar Number 10, Cover Thickness (m) 0.0, Rebar Hoop Spacing (m) 0.0, Rebar Size, Vert Rebar Dia (m) 0.0127, Hoop Rebar Dia (m) 0.0127, Element Dimension, Elements Through Cover Thickness 2.
- Concrete Material Properties:** Set Material, Undefined.
- Rebar Material Properties:** Set Material, Undefined.
- Steel Jacket:** Add Steel Jacket (checkbox).
- Charge Details:** X Distance From Column Center (m) 0.0, Y Distance From Column Center (m) 0.0, Z Height From Column Base (m) 0.0, Charge Mass (kg TNT eq) 0.0, Charge Type: Hemispherical (LBE Type 1) (checked), Spherical (LBE Type 2), Air Burst + Ground Reflection (LBE Type 3), Viper (CFD), Max Angle of Incidence for Blast Load 125.
- Control Parameters:** Blast Phase Duration (sec) 0.01, Max Timestep (LCTM) 1.0e-6, Mass Scaling Timestep (DT2MS) 0.5e-6, Timestep Scale Factor (TSSFAC) 0.7, Pre Blast Loading Controls: Pre Blast Loading (Implicit) (checked), Pre Blast Loading (Dynamic Relax) (checkbox), Post Blast Loading Controls: Post Blast Loading Check (Implicit) (checkbox), Post Blast Loading Check (Explicit) (checkbox).
- Analysis Timeline:** Start, Finish, Pre Blast Phase 0.0, 1.0, Blast Phase 1.0, 1.001, Post Blast Phase 1.001, 1.001.

- The red entries are required to be filled out.
- The white/blue entries have suggested values but these need to be reviewed by the user for applicability for their analysis.

These sections include;

- Column Dimensions
- Column Loading
- Section Properties
- Material Properties
- Charge Details
- Control Parameters

2.2 General Column Details

Column Dimensions

The user enters the total height of the column and the height of the section of the column to be modelled in solid elements.

Column Dimensions

Total Column Height (m) 0.0

Height of Detailed (Solid) Section (m) 0.0

Column Top Load

The user specifies the loads and moments to applied to the top of the column.

The top load will be applied in the negative z direction.

An offset can be applied to the top vertical load.

The user can also specify a ramp factor that will be applied to the loads and moments in the post blast phase.

Column Top Load

Column Top Load (kN) 0

Load X Offset (m) 0

Load Y Offset (m) 0

Column Top X Moment (kN.m) 0

Column Top Y Moment (kN.m) 0

Gravity (*Lody_Body_Z) is applied to the model

☐ Post Blast Load Ramp Factor

Column End Conditions

The user selects the end conditions (Pinned, Fixed, Spring) for the top and bottom of the column.

If the Spring option is selected then the user has to enter the six spring stiffness (3 translation, 3 rotational) by clicking on the 'Set Spring' button.

The spring stiffness can be pre-setup by editing the;

- *bottom_spring.csv*
- *top_spring.csv*

files in the *Spring_Properties* folder

Column End Conditions

Column Bottom	Column Top
<input type="checkbox"/> Pinned	<input type="checkbox"/> Pinned - Z Free
<input checked="" type="checkbox"/> Fixed	<input checked="" type="checkbox"/> Fixed - Z Free
<input type="checkbox"/> Spring	<input type="checkbox"/> Pinned - Z Locked
	<input type="checkbox"/> Fixed - Z Locked
	<input type="checkbox"/> Spring

Set Spring Proper

End Fixing Springs

TX	10000000
TY	10000000
TZ	10000000
RX	10000000
RY	10000000
RZ	10000000

Set Close

2.3 Steel Sections


Section Dimensions

The user selects the section type and enters the relevant dimensions.

- I-Section
- HSS – Square
- HSS – Rectangle
- HSS – Round
- C-Section

Section Dimensions

☒ I-Section
☐ HSS - Square
☐ HSS - Rectangle
☐ HSS - Round
☐ C-Section



Section Width (m)	0.0	Web Thickness (m)	0.0
Section Depth (m)	0.0	Flange Thickness (m)	0.0

Element Dimensions

The user selects the number of solid elements to be used through the thickness of the steel plates.

Element Dimension

Elements Through Thickness

Encased I-Section

There is the option for an I-Beam to be modeled encased in concrete.

Concrete Encased I-Beam

☒ Add Concrete Encasement

Concrete Width (m)	0.0	Concrete Depth (m)	0.0
--------------------	-----	--------------------	-----

Filled HSS Sections

There is the option for a HSS section to be modeled filled with concrete.

HSS Concrete Filled

☐ Add Concrete Fill

2.4 Concrete Sections

Section Dimensions

The user selects the section type and enters the relevant dimensions.

- Round
- Rectangle

For a rectangular section the user can use the **check boxes** on the cross-section diagram to select the location of the rebar stirrups.

The diagram showing the cross section will dynamically update as the user changes the number of rebar and selects which stirrups to include.


Section Dimensions

☒ Round ☐ Rectangle

Section Diameter (m) Rebar Number

Cover Thickness (m)

Rebar Hoop Spacing (m)



Section Dimensions


☐ Round ☒ Rectangle

Section Width (m) Width Rebar Number

Section Depth (m) Depth Rebar Number

Cover Thickness (m)

Rebar Hoop Spacing (m)



Rebar Setup

The user selects rebar diameter for the vertical, hoop and stirrups.

There is a drop-down menu from which the user can select standard US, Canadian, UK/EU and Australian rebar sizes.

Rebar Size

Vert Rebar Dia (m)

Hoop Rebar Dia (m)

Rebar Size			
US #2	CA 10M	UK/EU 6	AUS N10
US #3	CA 15M	UK/EU 8	AUS N12
US #4	CA 20M	UK/EU 10	AUS N16
US #5	CA 25M	UK/EU 12	AUS N20
US #6	CA 30M	UK/EU 14	AUS N24
US #7	CA 35M	UK/EU 16	AUS N28
US #8	CA 45M	UK/EU 20	AUS N32
US #9	CA 55M	UK/EU 25	AUS N36
US #10		UK/EU 28	AUS N40
US #11		UK/EU 32	
US #14		UK/EU 40	
US #18		UK/EU 50	

Element Dimension

Elements Through Cover Thickness

Element Dimensions

The user selects the number of solid elements to be used through the thickness of the cover concrete.

Steel Jacket

The user can select to add a steel jacket to the outside of the concrete column.

Steel Jacket

☒ Add Steel Jacket

Steel Thickness (m)

Jacket Height (m)

2.5 Material Properties

The user can set material properties by clicking on the ‘Set Material’ button.

This will bring up a window for the relevant material type (Steel, Concrete, Rebar).

The current LS-DYNA material models used are;

- Steel: Mat_123
- Concrete: Mat_72R3
- Rebar: Mat_24

There are three preset material that the user can select from or the user can edit the values to create their own material.



To use a stress strain curve (LCSS) for a steel material, the user needs to pre-create the load curve/load table and save as a keyword file. The user will be prompted to select this keyword file when they click the ‘Set’ button. The id number entered in the LCSS text box needs to match the id number in the keyword file.

There are example load curve and load table keyword files in the ‘Material_Properties’ folder.

The preset materials can be changed by editing the;

- *steel_material.csv*
- *concrete_material.csv*
- *rebar_material.csv*

files in the *Material_Properties* folder.



2.6 Charge Details

Charge Details

The user enters the x, y and z coordinates of the charge relative to the center of the column

The user enters the charge mass in kilogram TNT equivalent.

The user can select from three types of Load_Blast_Enhanced charge.

- Hemispherical
- Spherical
- Air burst charge.

The user can also select a Viper (CFD) charge. In this case a second model is created that can be imported into the Viper CFD analysis to setup the column geometry. The result from the CFD analysis will then need to be imported into the main model.

The user enters the max angle of incidence for which the blast load should be applied to the structure

Charge Details

X Distance From Column Center (m)

0.0

Y Distance From Column Center (m)

0.0

Z Height From Column Base (m)

0.0

Charge Mass (kg TNT eqv)

0.0

☒

Hemispherical (LBE:Type 1)

☐


Spherical (LBE:Type 2)

☐


Air Burst + Ground Reflection (LBE:Type 3)

☐

Viper (CFD)



The angle of incidence is calculated by comparing the angle between the element normal vector and the vector between the element center and the charge location.



A max angle of incidence greater than 90 deg may be required if the blast load needs to be applied to the sides faces as well as the front face of the section.

*Set_Segment id 200 (id 300 for I-section) will contain the segments used for the blast loading.

2.7 Control Parameters

The user can set various basic control parameters for the model.


Pre-blast loading

The user can select to include a pre-blast loading phase where the gravity and top loads will be applied to the model.

The user can select either an Implicit or Dynamic Relaxation (DR) analysis for this phase.


If DR is chosen, there is a pop-up window in which the DR properties can be set.

The pre-set DR properties can be edited in the *dr_prop.csv* file in the *Dynamic_Relaxation_Properties* folder.



Control Parameters


Blast Phase Duration (sec)	0.01
Max Timestep (LCTM)	1.0e-6
Mass Scaling Timestep (DT2MS)	0.5e-6
Timestep Scale Factor (TSSFAC)	0.7



Pre Blast Loading Controls

☒ Pre Blast Loading (Implicit)

☐ Pre Blast Loading (Dynamic Relax)



Set DR Properties

Dynamic Relaxation Properties

NRCYCK	250
DRTOL	0.001
DRFCTR	0.995
DRTERM	0.2

Set Close


Post-blast loading

The user can select to include a post-blast loading phase where the gravity and top loads will held constant or ramped up.

The user can select either an Implicit or Explicit analysis for this phase.

If Explicit is chosen, then the user has to set the duration for this phase and post blast damping properties.


The pre-set damping properties can be edited in the *damping_global.csv* file in the *Damp_Properties* folder.



Post Blast Loading Controls

☐ Post Blast Loading Check (Implicit)

☐ Post Blast Loading Check (Explicit)



Set Damp Properties


Post Blast Damping Global

Damping Start Time	0.01
Damping Finish Time	0.25
Main Damping Value	30
Residual Damping Value	0.5

Set Close

Analysis Timeline

An overall analysis timeline is also shown for reference.




Analysis Timeline

	Start	Finish
Pre Blast Phase	0.0	1.0
Blast Phase	1.0	1.001
Post Blast Phase	1.001	1.001

3 Model Setup

The column is modeled using solid elements for the lower section where the blast load is applied and beam elements for the upper section of the column.



- An initial pre-load phase can be included to apply gravity and top load (if any) to the column. This can be either an implicit (static) or dynamic relaxation phase.
- The analysis then switches to an explicit (dynamic) analysis for the blast loading.
- A final post-load phase can be included to determine if the post-blast column still has the capacity to carry the gravity and top load. This can be either an implicit (static) or explicit (with damping) phase. A factor can also be applied to the loads to ramp them up during this phase




3.1 Rebar

For a concrete column the rebar are modelled using beam elements. The connection between the rebar and the concrete is modelled by having the beam and solid elements meshed together (i.e. sharing nodes).

The interaction between the different rebar is modelled using a contact definition that accounts for the thickness of the beam elements.

The hook lengths for the stirrup rebars are taken from our standard US structural details which are based on the AISC code. These are shown in the following table.

STANDARD HOOK GEOMETRY FOR STIRRUPS, TIES, HOOPS

TYPE OF STANDARD HOOK	BAR SIZE	MINIMUM INSIDE BEND DIAMETER D, in.	STRAIGHT EXTENSION L, in.	TYPE OF STANDARD HOOK
90-DEGREE HOOK	No. 3 THROUGH No. 5	$4d_b$	GREATER OF $6d_b$ and 3 in.	
	No. 6 THROUGH No. 8	$6d_b$	$12d_b$	
135-DEGREE HOOK	No. 3 THROUGH No. 5	$4d_b$	GREATER OF $6d_b$ and 3 in.	
	No. 6 THROUGH No. 8	$6d_b$		
180-DEGREE HOOK	No. 3 THROUGH No. 5	$4d_b$	GREATER OF $4d_b$ and 2.5 in.	
	No. 6 THROUGH No. 8	$6d_b$		

3.2 Boundary Conditions

The user can select either pinned, fixed or spring boundary conditions for the top and bottom of the column.

Top Restraint

For the top restraint a *Boundary_SPC is used on the top node of the last beam element.

For pinned (Z free) the restraint at the top will be;

- X, Y translation
- Z rotation

For pinned (Z fixed) the restraint at the top will be;

- X, Y, Z translation
- Z rotation

For fixed (Z free) the restraint at the top will be;

- X, Y translation
- X, Y, Z rotation

For fixed (Z fixed) the restraint at the top will be;

- X, Y, Z translation
- X, Y, Z rotation

For spring the user defines the spring stiffness for each of the six degrees of freedom.

- X, Y, Z translation
- X, Y, Z rotation

Bottom Restraint

For the bottom restraint a *Constrained_Nodal_Rigid_Body with the SPC option is used for the solid element nodes at the bottom of the column.

For pinned the restraint at the bottom will be;

- X, Y, Z translation
- Z rotation

For fixed the restraint at the bottom will be;

- X, Y, Z translation
- X, Y, Z rotation

For spring the user defines the spring stiffness for each of the six degrees of freedom.

- X, Y, Z translation
- X, Y, Z rotation

3.3 Gravity and Column Top Load

Gravity is applied to the model using the *Load_Body_Z card, with $g = 9.81 \text{ N/m}^2$

Column load and moments are applied to the top node of the last beam element using a *Load_Node card based on the value entered by the user.

- The top load acts in the negative Z direction.
- If an offset is defined for the top load. The resulting moment are calculated and applied to the top node.

3.4 Blast Loading

The blast loading is applied using the *Load_Blast_Enhanced card and a *Set_Segment. The user selects;

- The charge location (x, y, z cords).
- The charge mass in kilogram TNT equivalent.
- Either a spherical, hemispherical, or airburst charge.


A Viper (CFD) loading option is also available. If the user selected this option a second model is created with the blast segment set and column outer surface solid elements. This model can be used for importing into Viper for setting up the model geometry and data output locations.

A shell element sphere/hemisphere is created at the location of the charge for visualization.

A series of five *Rigidwall cards are used to surround the model and prevent any eroded element nodes from flying off and causing error termination.

The JavaScript calculates which segments to apply the load to based on the charge location and the max angle of incidence entered by the user.

For I-Section and C-Section profiles the JavaScript includes a routine that calculates which segments are in the blast shadow of other surfaces and does not apply the blast load to these segments.



3.5 Materials and Element Type

3.5.1 Steel

For the solid elements.

- The *Mat_Modified_Piecewise_Linear_Plasticity (Mat_123) material is used.
- The strain rate effects are defined by the user. The Cowper Symonds rule (C and P parameters) is used to include the strain rate effects.
- The type 2 fully integrated S/R solid element formulation is used

For the beam elements.

- The *Mat_Plastic_Kinematic (Mat_003) material is used.
- There is no failure defined
- There are no strain rate effects.
- The type 1 Hughes-Liu beam element formulation is used

3.5.2 Concrete

For the solid elements.

- The *Mat_Concrete_Damage_REL3 (Mat_72R3) material is used.
- The type 1 solid element formulation is used

For the beam elements.

- The *Mat_Elastic (Mat_001) material is used.
- There are no strain rate effects.
- The type 1 Hughes-Liu beam element formulation is used

3.5.3 Rebar

For the rebar beam elements.

- The *Mat_Piecewise_Linear_Plasticity (Mat_24) material is used.
- The strain rate effects are defined by the user. The Cowper Symonds rule (C and P parameters) is used to include the strain rate effects.
- The type 1 Hughes-Liu beam element formulation is used

3.6 Contact

A *Contact_Eroding_Single_Surface is applied to the solid element part to prevent elements from passing through each other as the column deforms.

A *Contact_Automatic_General is applied to the beam elements representing the rebar to provide the necessary contact between the different bars.

3.7 Ground

A *Rigidwall is used to represent the ground along with a rigid shell part for visualization.

4 Additional Files

The following files are required in addition to the main JavaScript

JS Modules Folder

- blast_walls.js
- control_database.js
- element_centroid.js
- end_nodes.js
- facing_segments.js
- geometry.js
- GUI_concrete.js
- GUI_damp_selection.js
- GUI_dr_selection.js
- GUI_general_functions.js
- GUI_material_selection.js
- GUI_spring_selection.js
- GUI_steel.js
- log.txt
- material_read.js
- mesh_channel.js
- mesh_charge.js
- mesh_con_rectangle.js
- mesh_con_round.js
- mesh_hss_rectangle.js
- mesh_hss_round.js
- mesh_isec.js
- vector.js
- viper_segments.js

Damp Properties Folder

- damping_global.csv

Dynamic Relaxation Folder

- dr_prop.csv

Material Properties

- concrete_materials.csv
- rebar_materials.csv
- steel_materials.csv
- example_steel_curve_01.key
- example_steel_curve_01.key

Spring Properties

- bottom_spring.csv
- top_spring.csv

Macros Folder

- area_001.prm
- extrude_001.prm
- hemisphere_001.prm
- line_mesh_001.prm
- merge_001.prm
- merge_all_001.prm
- plate_001.prm
- reflect_part_001.prm
- rotate_node_001.prm
- rotate_part_001.prm
- segment_coat_001.prm
- shell_coat_001.prm
- sphere_001.prm
- translate_node_001.prm
- translate_part_001.prm

Images Folder

- hss_rec.png
- hss_ro.png
- hss_sq.png
- isec.png
- csec.png
- angle.png