



Weather driver setup in UK :

Instructions

The language in the localizations settings must be populated as describe in the driver info : en-GB

In the post-code string the last two characters have to be ignored

If the post-code is CM24 8GF you have to enter the following string CM24 8:GB

No spaces except within the post-code

Examples

- For CM17 4JU you would enter CM17 4:GB
- For HA3 9BS you have to enter HA3 9:GB

The screenshot shows the 'Weather' driver configuration window. The left sidebar contains a tree view with 'Driver Configuration' expanded, showing 'Driver Utilities...', 'Driver Properties', 'Driver Events', and 'Driver Info'. The main panel displays the configuration settings for the Weather driver.

Category	Setting	Value
System Settings	Processor	Default (Master)
	General Settings	
General Settings	Location	CM24 8:GB
	Unit Type	Hybrid UK
	Pressure in Millimeters of Mercury	<input checked="" type="checkbox"/>
	Use PWS data	<input type="checkbox"/>
	Use Satellite	<input checked="" type="checkbox"/>
	Update Rate	15
Localizations Settings	Language	en-GB
	Sunday	Sunday
	Monday	Monday
	Tuesday	Tuesday
	Wednesday	Wednesday
	Thursday	Thursday
	Friday	Friday
	Saturday	Saturday
	Today	Today
	North	N
	North Northeast	NNE
	Northeast	NE
	East Northeast	ENE
	East	E
	East Southeast	ESE
	Southeast	SE
	South Southeast	SSE
	South	S
	South Southwest	SSW
Southwest	SW	

Location
Enter initial location as 'zipcode', 'city, country' or 'latitude, longitude'