

IP Phone User Guide v1.0



Veronika B. Boyanova

Musala Soft

November 2015

Table of Contents

| | |
|--|---|
| Table of Contents | 1 |
| 1 Introduction..... | 3 |
| 2 Features and Functions | 4 |
| 2.1 Softkeys functions | 4 |
| 2.2 Check Missed Calls & Call History..... | 4 |
| 2.3 Keypad | 5 |
| 2.4 LCD Icons | 6 |

Version History

| Date | Version | Description | Author |
|-------------------------|---------|--------------------------------------|-------------------|
| 23 November 2015 | 1.0 | IP Phone Guide: Functions & Softkeys | Veronika Boyanova |

1 Introduction

The Enterprise IP Phone Grandstream GXp1450 is used within Musala Soft as a part of Ving terminals or as a phone only.

Following section represents most important phone features for Ving users at the current moment.

2 Features and Functions

2.1 Softkeys functions

Softkeys are the ones displayed right under the LCD screen of the telephone. They are context sensitive and change depending on the status of the phone.

- **Next Scr** (Next Screen) – toggles between default idle screen and location and weather information.
- **FwdAll** (Forward All) – unconditionally forwards the phone line to another phone
OR
Missed (Missed Calls)
- **Redial**

Softkeys related to calls

- Dial
- Answer Call
- Reject Call
- End Call
- Others

2.2 Check Missed Calls & Call History

When a missed call takes place, it directly appears on the LCD phone screen. Unchecked missed calls can be reached by the respective softkey under the screen. Once checked, missed calls disappear from the initial screen and can be found in the phone menu.

In order to reach already checked (old) missed calls, a user should navigate to phone menu by pressing the round menu button surrounded by the four arrows.





Same button is used to open a menu section and arrows are used for navigation. Left arrow is used for navigation to the previous sub-menu (section).

Menu > Call history > Missed calls












The IP phone call history provides information for all answered and dialed calls as well unless deleted.













Phonebook is supported as well.






2.3 Keypad

| GXP2120/GXP2110/GXP2100 | GXP1450 | Definition |
|-----------------------------|---|---|
| LINE KEYS | LINE KEYS | Open or switch line; resume the call on hold. |
| HOLD | HOLD | Place active call on hold, or resume the call on hold. |
| SEND |  | Send out the number, or redial. |
| TRANSFER | TRANSFER | Transfer an active call to another number. |
| CONF | CONF | Establish conference call with other parties. |
| MUTE |  | During an active call, press to mute or unmute. |
| HEADSET |  | Headset. |
| DND |  | When the phone is in idle, press to enable/disable DND feature. |
| NAVIGATION KEYS/MENU | | <ul style="list-style-type: none"> Press the 4 navigation keys to move up/down/left/right; Press the round button in the center for MENU/ENTER/OK |

2.4 LCD Icons

| | |
|---|--|
|  | DND Status. OFF - Do Not Disturb disabled ON - Do Not Disturb enabled |
|  | Call Forward All Status. OFF - Call Forward All feature disabled ON - Call Forward All feature enabled |
|  | Call Forward Busy Status. OFF - Call Forward Busy feature disabled ON - Call Forward Busy feature enabled |
|  | Call Forward No Answer Status. OFF - Call Forward No Answer feature disabled ON - Call Forward No Answer feature enabled |
|  | Call Forward All and Call Forward No Answer Status. OFF - Call Forward All and Call Forward No Answer feature disabled ON - Call Forward All and Call Forward No Answer feature enabled |
|  | Keypad Status. OFF - keypad is unlocked ON - keypad is locked |
|  | Enter Keypad Unlock Password. |
|  | Voicemail Status. OFF - No new voicemail ON - New voicemail |
|  | Instant Message. OFF - No new instant message ON - New instant message |
|  | Voice Mail and Instant Message. OFF - No new instant message or voicemail ON - New instant message and voicemail |
|  | Network Status. OFF - Network connection is up ON - Network connection is down |

| | |
|---|--|
|  | Missed Call Status. OFF - No missed call ON - New missed call |
|  | Save Call Record Status. OFF - No saving call record activity ON - The phone is writing the call records into the flash at the moment |
|  | Waiting For Response. Please wait for the phone to response before the keypad entry |
|  | Handset Status. OFF - handset on hook ON - handset off hook |
|  | Speaker Status. OFF - speaker off ON - speaker on |
|  | Headset Status. OFF - headset off ON - headset on |
|  | Calling Out. The phone is calling out |
|  | Calling In. Phone is ringing with incoming call |
|  | Incoming Call. The current call is an incoming call |
|  | Outgoing Call. The current call is an outgoing call |
|  | Call Failed Fail to establish call |
|  | SRTP Status. OFF - SRTP is not used ON - SRTP is used |

| | |
|---|--|
|  | MUTE Status. OFF - No muted ON - Muted |
|  | Call On Hold. |
|  | Call Active. |
|  | Conference Call. |
|  | Core Dump. Core dump file can be downloaded from phone's Web GUI->Status page. |