

BUtil Classic Integration Manual

Project BMW AUTOSAR 4 Core Rel. 3
 Author BMW AG
 Release Date 2017-12-14
 Version 5.1.1
 Status Release
 Hotline +49 89 382 - 32233
 Contact bac@bmw.de
<https://asc.bmw.com/jira/browse/BSUP> (extern)
<https://asc.bmwgroup.net/jira/browse/BSUP> (intern)

Revision History

Version	Date	Changed by	Description
5.1.1	2017-12-14	JC-42	Version Update
5.1.0	2017-09-14	JC-42	Version Update
5.0.1	2017-08-10	JC-42	Version Update.
5.0.0	2017-06-29	JC-42	Initial version for SP2021

Company

Bayerische
 Motoren Werke
 Aktiengesellschaft

Postal address

BMW AG
 80788 München

Office address

Forschungs- und
 Innovationszentrum
 (FIZ)
 Hufelandstr. 1
 80937 München

Telephone

Switchboard
 +49 89 382-0

Internet

www.bmwgroup.com

Table of Contents

1	Introduction	3
1.1	Functional overview	3
2	Related documentation	4

1 Introduction

This Integration Manual describes the basis functionality, API and the configuration of the BMW system function BUtil.

Functional overview

The BUtil library contains some general purpose functions commonly used by other modules like Dlog, Prog and Bm. It is used in Application, Bootloader and Bootmanager.

2 Related documentation

References