

## BUtil Classic User Manual

Project BMW AUTOSAR 4 Core Rel. 3  
Author BMW AG  
Release Date 2017-12-14  
Version 5.1.1  
Status Release  
Hotline +49 89 382 - 32233  
Contact bac@bmw.de  
<https://asc.bmw.com/jira/browse/BSUP> (extern)  
<https://asc.bmwgroup.net/jira/browse/BSUP> (intern)

## Revision History

Version	Date	Changed by	Description
5.1.1	2017-12-14	JC-42	Version Update
5.1.0	2017-09-14	JC-42	Version Update
5.0.1	2017-08-10	JC-42	Version Update.
5.0.0	2017-06-29	JC-42	Initial version for SP2021

**Company**

Bayerische  
Motoren Werke  
Aktiengesellschaft

**Postal address**

BMW AG  
80788 München

**Office address**

Forschungs- und  
Innovationszentrum  
(FIZ)  
Hufelandstr. 1  
80937 München

**Telephone**

Switchboard  
+49 89 382-0

**Internet**

[www.bmwgroup.com](http://www.bmwgroup.com)

## Table of Contents

<b>1 Overview</b>	<b>3</b>
1.1 Purpose_____	3
<b>2 Related documentation</b>	<b>4</b>

## 1 Overview

BUtil is an internal used library within the BMW Platform Software Modules (BAC and aBAC). External software shall not use the library directly. The interfaces or features may be removed from one to the next release.

### Purpose

The BUtil library contains some general purpose functions commonly used by other modules like Dlog, Prog and Bm. It is used in Application, Bootloader and Bootmanager.

The Goal of this library is not to provide a general propose solution for external software, but only for the BMW Platform Software (BAC and aBAC). You shall not directly use this library.

## **2 Related documentation**

### **References**