

You are here: [MIP API](#) > [Commands](#) > [Filter \(0x0D\)](#) > GNSS Multi-Antenna Offset Control (0x0D,0x54)

GNSS Multi-Antenna Offset Control (0x0D,0x54)

Description	Set the antenna lever arm.	
Notes	<p>This command works with devices that utilize multiple antennas.</p> <p>Offset Limit: 10 m magnitude (default)</p>	
Parameter Name	Data Type	Description
Field Length	u8	4
Descriptor	u8	0x54
Function Selector	u8	This command supports the following MIP function selectors: Write Read Save Load Default [WRS LD]
Receiver Id [WRS LD]	u8	Receiver: 1, 2, etc...
Antenna Offset [W]	Vector3f	Antenna lever arm offset vector in the vehicle frame (m)
Ack/Nack Reply	See standard MIP ack/nack reply format.	
Response Data	Data Type	Description
Response Length	u8	3
Response Descriptor	u8	0xD4
Receiver Id	u8	
Antenna Offset	Vector3f	