

You are here: [MIP API](#) > [Commands](#) > [Filter \(0x0D\)](#) > Reset Navigation Filter (0x0D,0x01)

Reset Navigation Filter (0x0D,0x01)

Description	Resets the filter to the initialization state.	
Notes	If the auto-initialization feature is disabled, the initial attitude or heading must be set in order to enter the run state after a reset.	
Parameter Name	Data Type	Description
<i>Field Length</i>	<i>u8</i>	<i>2</i>
<i>Descriptor</i>	<i>u8</i>	<i>0x01</i>
Ack/Nack Reply	See standard MIP ack/nack reply format.	